OMRON

USER'S MANUAL

OMNUC G5 SERIES

R88M-K (AC Servomotors) R88D-KT (AC Servo Drives)

AC SERVOMOTORS/SERVO DRIVES

Trademarks and Copyrights

• System names and product names that appear in this manual are the trademarks or registered trademarks of the relevant companies.

© OMRON, 2009

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

Introduction

Thank you for purchasing an OMNUC G5-series Servo Drive. This manual explains how to install and wire the Servo Drive, set parameters needed to operate the Servo Drive, and remedies to be taken and inspection methods to be used should problems occur.

Intended Readers

This manual is intended for the following individuals.

Those having electrical knowledge (certified electricians or individuals having equivalent knowledge) and also being qualified for one of the following:

- Introducing FA equipment
- Designing FA systems
- Managing FA sites

Notice

This manual contains information you need to know to correctly use the Servo Drive and peripheral equipment.

Before using the Servo Drive, read this manual and gain a full understanding of the information provided herein.

After you finished reading the manual, keep it in a convenient place so that it can be referenced at any time.

Make sure this manual is delivered to the end user.

Terms and Conditions Agreement

Warranty, Limitations of Liability

Warranties

Exclusive Warranty

Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

Limitations

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

Buyer Remedy

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Application Considerations

Suitability of Use

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products

Omron Companies shall not be responsible for the userÅfs programming of a programmable Product, or any consequence thereof.

Disclaimers

Performance Data

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OmronÅfs test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the OmronÅfs Warranty and Limitations of Liability.

Change in Specifications

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your OmronÅfs representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

Items Requiring Acknowledgment

1. Terms of Warranty

(1) Warranty period

The warranty period of this product is 1 year after its purchase or delivery to the specified location.

(2) Scope of warranty

If the product fails during the above warranty period due to design, material or workmanship, we will provide a replacement unit or repair the faulty product free of charge at the location where you purchased the product.

Take note, however, that the following failures are excluded from the scope of warranty.

- a) Failure due to use or handling of the product in any condition or environment not specified in the catalog, operation manual, etc.
- b) Failure not caused by this product
- c) Failure caused by any modification or repair not carried out by OMRON
- d) Failure caused by any use not intended for this product
- e) Failure that could not be predicted with the level of science and technology available when the product was shipped from OMRON
- f) Failure caused by a natural disaster or any other reason for which OMRON is not held responsible

Take note that this warranty applies to the product itself, and losses induced by a failure of the product are excluded from the scope of warranty.

2. Limited Liability

- (1) OMRON shall not assume any responsibility whatsoever for any special damage, indirect damage or passive damage arising from this product.
- (2) OMRON shall not assume any responsibility for programming done by individuals not belonging to OMRON, if the product is programmable, or outcomes of such programming.

3. Conditions for Intended Application

- (1) If this product is combined with other product, the customer must check the standards and regulations applicable to such combination. The customer must also check the compatibility of this product with any system, machinery or device used by the customer. If the above actions are not taken, OMRON shall not assume any responsibility regarding the compatibility of this product.
- (2) If the product is used in the following applications, consult your OMRON sales representative to check the necessary items according to the specification sheet, etc. Also make sure the product is used within the specified ratings and performance ranges with an ample margin and implement safety measures, such as designing a safety circuit, to minimize danger should the product fail.
 - a) Used in any outdoor application, application subject to potential chemical contamination or electrical interference, or in any condition or environment not specified in the catalog, operation manual, etc.
 - b) Nuclear power control equipment, incineration equipment, railway, aircraft and vehicle equipment, medical machinery, entertainment machinery, safety system or any other device controlled by an administrative agency or industry regulation
 - c) System, machinery or device that may threaten human life or property
 - d) Gas, water or electricity supply system, system operated continuously for 24 hours or any other equipment requiring high reliability
 - e) Any other application where a high level of safety corresponding to a) to d) above is required
- (3) If the customer wishes to use this product in any application that may threaten human life or property, be sure to confirm beforehand that the entire system is designed in

such a way to notify dangers or ensure the necessary level of safety via design redundancy, and that the product is wired and installed appropriately in the system according to the intended application.

- (4) Sample applications explained in the catalog, etc. are provided for reference purposes only. When adopting any of these samples, check the function and safety of each equipment or device.
- (5) Understand all prohibited items and notes on use provided herein, so that this product will be used correctly and that customers or third parties will not suffer unexpected losses.

4. Specification Change

The product specifications and accessories explained in the catalog, operation manual, etc. are subject to change, if necessary, for the reasons of improvement, etc. Contact your OMRON sales representative to check the actual specifications of this product.

5. Scope of Service

The price of this product excludes costs of service such as dispatching engineers. If you have any request regarding service, consult your OMRON sales representative.

6. Scope of Application

The above paragraphs are based on the assumption that this product is traded and used in Japan.

If you wish to trade or use this product outside Japan, consult your OMRON sales representative.

Safety Precautions


To ensure that the OMNUC G5-series Servomotor and Servo Drive as well as peripheral equipment are used safely and correctly, be sure to read this Safety Precautions section and the main text before using the product in order to learn items you should know regarding the equipment as well as required safety information and precautions.

■Make an arrangement so that this manual also gets to the end user of this product.

■After reading this manual, keep it in a convenient place so that it can be referenced at any time.

Explanation of Display

- The precautions explained in this section describe important information regarding safety and must be followed without fail.
- The display of precautions in this manual and their meanings are explained below.



Even those items denoted by the caution symbol may lead to a serious outcome depending on the situation. Accordingly, be sure to observe all safety precautions.

Precautions for Safe Use

Indicates precautions on what to do and what not to do to ensure using the product safely.

Precautions for Correct Use

Indicates precautions on what to do and what not to do to ensure proper operation and performance.

Reference

Indicates an item that helps deepen your understanding of the product or other useful tip.


Explanation of Symbols

Example of symbols	
	\bigwedge This symbol indicates danger and caution.
$\overline{\sqrt{4}}$	The specific instruction is described using an illustration or text inside or near \triangle . The symbol shown to the left indicates "beware of electric shock".
	\bigotimes This symbol indicates a prohibited item (item you must not do).
	The specific instruction is described using an illustration or text inside or near \otimes . The symbol shown to the left indicates "disassembly prohibited".
0	The filled circle symbol indicates operations that you must do. The specific operation is shown in the circle and explained in text. This example shows a general precaution for something that you must do.
	This symbol indicates a compulsory item (item that must be done).
9	The specific instruction is described using an illustration or text inside or near . The symbol shown to the left indicates "grounding required".

For Safe Use of This Product

Illustrations contained in this manual sometimes depict conditions without covers and safety shields for the purpose of showing the details. When using this product, be sure to install the covers and shields as specified and use the product according to this manual.

If the product has been stored for an extended period of time, contact your OMRON sales representative.



	A DANGER
\triangle	Do not place flammable materials near the Servomotor, Servo Drive, or Regeneration Resistor. Fire may result.
\triangle	Install the Servomotor, Servo Drive, and Regeneration Resistor on non-flammable materials such as metals. Fire may result.
\triangle	When you perform a system configuration using the safety function, be sure to fully understand the relevant safety standards and the information in the operation manual, and apply them to the system design. Injury or damage may result.
	Do not use the cable when it is laying in oil or water. Electric shock, injury, or fire may result.
	Never connect a commercial power supply directly to the Servomotor. Fire or failure may result.
	Do not perform wiring or any operation with wet hands. Electric shock, injury, or fire may result.
\triangle	Do not touch the key grooves with bare hands if a motor with shaft-end key grooves is being used. Injury may result.

Security Measures





Anti-virus protection

Install the latest commercial-quality antivirus software on the computer connected to the control system and maintain to keep the software up-to-date.

Security measures to prevent unauthorized access

- Take the following measures to prevent unauthorized access to our products.
- Install physical controls so that only authorized personnel can access control systems and equipment.
- Reduce connections to control systems and equipment via networks to prevent access from untrusted devices.
- Install firewalls to shut down unused communications ports and limit communications hosts and isolate control systems and equipment from the IT network.
- Use a virtual private network (VPN) for remote access to control systems and equipment.
- Adopt multifactor authentication to devices with remote access to control systems and equipment.
- Set strong passwords and change them frequently.
- Scan virus to ensure safety of USB drives or other external storages before connecting them to control systems and equipment.



Data input and output protection

- Validate backups and ranges to cope with unintentional modification of input/output data to control systems and equipment.
- Checking the scope of data
- Checking validity of backups and preparing data for restore in case of falsification and abnormalities
- Safety design, such as emergency shutdown and fail-soft operation in case of data tampering and abnormalities



Data recovery

Backup data and keep the data up-to-date periodically to prepare for data loss.

When using an intranet environment through a global address, connecting to an unauthorized terminal such as a SCADA, HMI or to an unauthorized server may result in network security issues such as spoofing and tampering. You must take sufficient measures such as restricting access to the terminal, using a terminal equipped with a secure function, and locking the installation area by yourself.

When constructing an intranet, communication failure may occur due to cable disconnection or the influence of unauthorized network equipment. Take adequate measures, such as restricting physical access to network devices, by means such as locking the installation area.

When using a device equipped with the SD Memory Card function, there is a security risk that a third party may acquire, alter, or replace the files and data in the removable media by removing the removable media or unmounting the removable media.

Please take sufficient measures, such as restricting physical access to the Controller or taking appropriate management measures for removable media, by means of locking the installation area, entrance management, etc., by yourself.





Use the Servomotor and Servo Drive in a specified combination. Fire or equipment damage may result.



Do not store or install the Servo Drive in the following locations: Location subject to direct sunlight Location where the ambient temperature exceeds the specified level Location where the relative humidity exceeds the specified level Location subject to condensation due to rapid temperature changes Location subject to corrosive or flammable gases Location subject to higher levels of dust, salt content, or iron dust Location subject to splashes of water, oil, chemicals, etc. Location where the Servo Drive may receive vibration or impact directly Installing or storing the Servo Drive in these locations may result in fire, electric shock, or equipment damage.



The Servo Drive radiator, Regeneration Resistor, Servomotor, etc. may become hot while the power is supplied or remain hot for a while even after the power supply is cut off. Never touch these components. A burn injury may result.

Storage and Transportation





When transporting the Servo Drive, do not hold it by the cables or Servomotor shaft. Injury or failure may result.



Do not overload the Servo Drive or Servomotor. (Follow the instruction on the product label.) Injury or failure may result.



Use the motor eye-bolts only when transporting the Servomotor. Do not use them to transport the machine. Injury or failure may result.



When lifting a 15 kW or higher Servo Drive during moving or installation, always have two people lift the product by grasping a metal part. Do not grasp a plastic part. Risk of injury or product damage.

Installation and Wiring

	▲ Caution
	Do not step on the Servo Drive or place heavy articles on it. Injury may result.
	Do not block the intake or exhaust openings. Do not allow foreign objects to enter the product. Fire may result.
$\underline{\mathbb{N}}$	Be sure to observe the mounting direction. Failure may result.
	Provide the specified clearance between the Servo Drive and the inner surface of the control panel or other equipment. Fire or failure may result.
$\underline{\mathbb{N}}$	Do not apply strong impact on the Servomotor shaft or Servo Drive. Failure may result.
$\underline{\mathbb{N}}$	Wire the cables correctly and securely. Runaway motor, injury, or failure may result.
$\underline{\mathbb{N}}$	Securely tighten the mounting screws, terminal block screws, and cable screws. Failure may result.
	Use crimp terminals for wiring. If simple twisted wires are connected directly to the protective ground terminal, fire may result.
$\underline{\mathbb{N}}$	Only use the power supply voltage specified in this manual. Burn damage may result.
$\underline{\mathbb{N}}$	In locations where the power supply infrastructure is poor, make sure the rated voltage can be supplied. Equipment damage may result.
	Provide safety measures, such as a breaker, to protect against short circuiting of external wiring. Fire may result.
Ŵ	If the Servo Drive is used in the following locations, provide sufficient shielding measures. Location subject to noise generates due to static electricity, etc. Location subject to a strong electric or magnetic field Location where exposure to radioactivity may occur Location near power supply lines Using the Servo Drive in these locations may result in equipment damage.
\triangle	Connect an immediate stop relay in series with the brake control relay. Injury or failure may result.
	When connecting the battery, make sure the polarity is correct. Battery damage or explosion may result.

Operation and Adjustment


	▲ Caution
\triangle	Conduct a test operation after confirming that the equipment is not affected. Equipment damage may result.
\triangle	Before operating the Servo Drive in an actual environment, check if it operates correctly based on the parameters you have set. Equipment damage may result.
$\underline{\land}$	Never adjust or set parameters to extreme values, as it will make the operation unstable. Injury may result.
$\underline{\land}$	Separate the motor from the mechanical system and check its operation before installing the motor to the machine. Injury may result.
$\underline{\land}$	If an alarm generated, remove the cause of the alarm and ensure safety, and then reset the alarm and restart the operation. Injury may result.
\triangle	Do not use the built-in brake of the motor for normal braking operation. Failure may result.
	Do not operate the Servomotor connected to an excessive load inertia. Failure may result.
	Install safety devices to prevent idle running or lock of the electromagnetic brake or the gear head, or leakage of grease from the gear head. Injury, damage, or taint damage may result.
	If the Servo Drive fails, cut off the power supply to the Servo Drive at the power supply. Fire may result.
	Do not turn ON and OFF the main Servo Drive power supply frequently. Failure may result.

Maintenance and Inspection

	Caution
$\underline{\mathbb{V}}$	After replacing the Servo Drive, transfer to the new Servo Drive all data needed to resume operation, before restarting the operation. Equipment damage may result.
	Never repair the Servo Drive by disassembling it. Electric shock or injury may result.
	Be sure to turn OFF the power supply when the Servo Drive is not going to be used for a prolonged period of time. Injury may result.

Location of Warning Label

The Servo Drive bears a warning label at the following location to provide handling warnings. When handling the Servo Drive, be sure to observe the instructions provided on this label.



(R88D-KTA5L)

Instructions on Warning Label



Disposal

- When disposing of the battery, insulate it using tape and dispose of it by following the applicable ordinance of your local government.
- Dispose of the Servo Drive as an industrial waste.

Items to Check after Unpacking

After unpacking, check the following items.

- Is this the model you ordered?
- Was there any damage sustained during shipment?

Accessories of This Product

Safety Precautions document × 1 copy


- Connectors, mounting screws, mounting brackets, and other accessories other than those in the table below are not supplied. They must be prepared by the customer.
- •The safety bypass connector is required when the safety function is not used. To use the safety function, provide a Safety I/O Signal Connector separately.
- If any item is missing or a problem is found such as Servo Drive damage, contact the OMRON dealer or sales office where you purchased your product.

Specifications		Connector for main circuit power supply terminals and control circuit power supply terminals	Connector for External Regeneration Resistor connection terminals and motor connection terminals	Safety bypass connector	Mounting Brackets
	50 W				
Single- phase	100 W				
100 VAC	200 W				
	400 W				
	100 W				
Cingle	200 W	Included			_
Single- phase/3-	400 W				
phase 200 VAC	750 W	-			
200 VAC	1 kW	-			
	1.5 kW	-			
	2 kW				
	3 kW			Included	Included
3-phase 200 VAC	5 kW	-			Included
	7.5 kW				
	15 kW				
	600 W				
	1 kW	Included			_
	1.5 kW				
3-phase	2 kW				
400 VAC	3 kW				Included
	5 kW				Included
	7.5 kW	1-			
	15 kW				_

Revision History

The manual revision symbol is an alphabet appended at the end of the manual number found in the bottom left-hand corner of the front or back cover.

Example



Revision code	Revision date	Revised content
01	September 2009	Original production
02	June 2010	Made corrections and added explanations.
03	January 2011	Added models and made corrections.
04	September 2011	Added DC input ratings for the R88D-KT75H/-KT150H and made corrections.
05	September 2015	Made corrections and added explanations.
06	January 2018	Made corrections and added explanations.
07	September 2022	Revisions for adding safety precautions regarding security.

Structure of This Document

This manual consists of the following chapters. Read the necessary chapter or chapters referring to the following table.

		Outline
Chapter 1	Features and System Configuration	This chapter explains the features of the Servo Drive, name of each part, and applicable EC Directives and UL standards.
Chapter 2	Standard Models and External Dimensions	This chapter explains the models of Servo Drives, Servomotors, and peripheral equipment, and provides the external dimensions and mounting dimensions.
Chapter 3	Specifications	This chapter provides the general specifications, characteristics, connector specifications, and I/O circuits of the Servo Drives as well as the general specifications, characteristics, encoder specifications of the Servomotors and other peripheral devices.
Chapter 4	System Design	This chapter explains the installation conditions for the Servo Drive and Servomotor, wiring methods including wiring conforming to EMC Directives and regenerative energy calculation methods as well as the performance of External Regeneration Resistors.
Chapter 5	Basic Control Modes	This chapter explains an outline of operations available in various control modes and explains the contents of setting.
Chapter 6	Applied Functions	This chapter gives outline of applied functions such as damping control, electronic gears, gain switching and disturbance observer, and explains the contents of setting.
Chapter 7	Safety Function	This function stops the Servomotor based on a signal from a safety controller or safety sensor. An outline of the function is given together with operation and connection examples.
Chapter 8	Parameters Details	This chapter explains the set value and contents of setting of each parameter.
Chapter 9	Operation	This chapter gives the operating procedures and explains how to operate in each mode.
Chapter 10	Adjustment Functions	This chapter explains the functions, setting methods, and items to note regarding various gain adjustments.
Chapter 11	Error and Maintenance	This chapter explains the items to check when problems occur, error diagnosis using the alarm LED display and measures, error diagnosis based on the operating condition and measures, and periodic maintenance.
Chapter 12	Appendix	This chapter provides connection examples using OMRON's PLC and Position Controller, as well as a list of parameters.

Table Of Contents

	Introd	duction1			
	Terms and Conditions Agreement				
		Requiring Acknowledgment			
		y Precautions6			
	Items	s to Check after Unpacking17			
	Revis	sion History18			
	Struc	ture of This Document19			
Cha	oter1	Features and System Configuration			
	1-1	Outline			
	1-2	System Configuration			
	1-3	Names and Functions			
	1-4	System Block Diagrams1-5			
	1-5	Applicable Standards1-15			
	1-6	Unit Versions			
Cha	oter2	Standard Models and External Dimensions			
	2-1	Servo System Configuration2-1			
	2-2	How to Read Model Numbers2-3			
	2-3	Standard Model Tables2-5			
	2-4	External and Mounting Dimensions			
	2-5	EMC Filter Dimensions			
	2-6	Dimensions of Mounting Brackets (L-Brackets for Rack Mounting) \dots 2-72			
Cha	oter3	Specifications			
	3-1	Servo Drive Specifications			
	3-2	Overload Characteristics (Electronic Thermal Function)			
	3-3	Servomotor Specifications			
	3-4	Cable and Connector Specifications			
	3-5	Servo Relay Units and Cable Specifications			
	3-6	External Regeneration Resistor Specifications			
	3-7	EMC Filter Specifications			
Cha	oter4	System Design			
	4-1	Installation Conditions4-1			
	4-2	Wiring			
	4-3	Wiring Conforming to EMC Directives			
	4-4	Regenerative Energy Absorption			
	4-5	Large Load Inertia Adjustment and Dynamic Brake			
	4-6	Using DC Power			
Cha	oter5	Basic Control Mode			
	5-1	Position Control5-1			

5-2	Speed Control	5-7
5-3	Torque Control	5-14
5-4	Internally Set Speed Control	5-19
5-5	Switching Control	5-23
5-6	Fully-closed Control	5-26
Chapter6	Applied Functions	
6-1	Damping Control	6-1
6-2	Adaptive Filter	6-5
6-3	Notch Filter	6-7
6-4	Electronic Gear Function	6-10
6-5	Encoder Dividing Function	6-14
6-6	Brake Interlock	6-19
6-7	Gain Switching Function	6-24
6-8	Torque Limit	6-32
6-9	Sequence I/O Signal	6-35
6-10	Forward and Reverse Drive Prohibition Functions	6-41
6-11	Disturbance Observer Function	
6-12	Gain Switching 3 Function	6-46
6-13	Friction Torque Compensation Function	
6-14	Inertia Ratio Switching Function	6-49
6-15	Hybrid Vibration Suppression Function	
6-16	Feed-forward Function	
6-17	Instantaneous Speed Observer Function	6-55
Chapter7	Safety Function	
7-1	Safe Torque OFF (STO) Function	7-1
7-2	Operation Example	7-4
7-3	Connection Example	7-6
Chapter8	Parameter Details	
8-1	Basic Parameters	8-1
8-2	Gain Parameters	8-9
8-3	Vibration Suppression Parameters	8-20
8-4	Analog Control Parameters	8-25
8-5	Interface Monitor Setting Parameters	8-37
8-6	Extended Parameters	8-47
8-7	Special Parameters	8-60
Chapter9	Operation	
9-1	Operational Procedure	9-1
9-2	Preparing for Operation	9-2
9-3	Using the Front Display	9-6
9-4	Setting the Mode	9-7
9-5	Trial Operation	9-33

Table Of Contents

Chapter1	0 Adjustment Functions	
10-1	Gain Adjustment	10-1
	Realtime Autotuning	
10-3	Manual Tuning	10-10
Chapter1	1 Troubleshooting and Maintenance	
11-1	Troubleshooting	11-1
11-2	Warning List	11-4
11-3	Alarm List	11-5
11-4	Troubleshooting	11-10
11-5	Periodic Maintenance	11-27
Chapter1	2 Appendix	
12-1	Connection Examples	12-1
12-2	Parameter List	12-11
Index		

1

Features and System Configuration

This chapter explains the features of the Servo Drive, name of each part, and applicable EC Directives and UL standards.

1-1	Outline	1-1
	Outline of the OMNUC G5 Series	1-1
	Features of OMNUC G5-series Servo Drives	1-1
1-2	System Configuration	1-2
1-3	Names and Functions	1-3
	Servo Drive Part Names	1-3
	Servo Drive Functions	
1-4	System Block Diagrams	1-5
	- ,	
1-5		
	Applicable Standards	1-15
		1-15 1-15
	Applicable Standards	1-15 1-15 1-15
	Applicable Standards EC Directives UL and cUL Standards	1-15 1-15 1-15 1-16
	Applicable Standards EC Directives UL and cUL Standards Korean Radio Regulations (KC) SEMI F47	1-15 1-15 1-15 1-16 1-17
1-5	Applicable Standards EC Directives UL and cUL Standards Korean Radio Regulations (KC) SEMI F47	1-15 1-15 1-15 1-16 1-17 1-18

1-1 Outline

Outline of the OMNUC G5 Series

With the OMNUC G5 Series, you can perform fully-closed control in addition to position control, speed control and torque control.

Various models are available supporting wide-ranging motor capacities from 50 W to 15 kW and input power supplies from 100 to 400 V. You will surely find a model that best suits your application. Motors with high-resolution 20-bit incremental encoders and 17-bit absolute/incremental encoders are available as standard models.

The OMNUC G5 Series features realtime autotuning function and adaptive filter function that automatically perform complicated gain adjustments. A notch filter can also be automatically set to suppress machine vibration by reducing machine resonance during operation.

The damping control function of the Servomotor and Servo Drive realizes stable stopping performance in a mechanism which vibrates because of the low rigidity of the load.

Features of OMNUC G5-series Servo Drives

OMNUC G5-series Servo Drives have the following features.

Switching between Seven Control Modes

You can switch between seven control modes: 1) Position Control Mode, 2) Speed Control Mode, 3) Torque Control Mode, 4) Position and Speed Control Mode, 5) Position and Torque Control Mode, 6) Speed and Torque Control Mode, and 7) Fully-closed Control Mode. Desired modes can be selected with the flexible drive according to your need. A single drive supports various applications.

Achievement of Accurate Positioning by Fully-closed Control

Feedbacks from the external encoder connected to the motor is used to accurately control positions. Accordingly, position control is not affected by deviation caused by ball screws or temperature.

Wide Range of Power Supplies to Meet Any Need

The OMNUC G5 Series now has models supporting 400 V for use with large equipment, at overseas facilities and in wide-ranging applications and environment. Since the utilization ratio of facility equipment also increases, the TCO (total cost of ownership) will come down.

Safe Torque OFF (STO) Function to Ensure Safety

You can cut off the motor current to stop the motor based on a signal from an emergency stop button or other safety equipment. This can be used for an emergency stop circuit that is compliant with safety standards without using an external contactor.


Suppressing Vibration of Low-rigidity Mechanisms during Acceleration/Deceleration

The damping control function suppresses vibration of low-rigidity mechanisms or devices whose tips tend to vibrate.

Two damping filters are provided to enable switching the damping frequency automatically according to the rotation direction and also via an external signal. In addition, the settings can be made easily by setting the damping frequency and filter values.

1


1-2 System Configuration



•The following units support a motor with absolute encoder: CJ1W-NC214/414 CJ1W-NC234/434 CS1W-MC221/421 (-V1)

1-3 Names and Functions

Servo Drive Part Names



Servo Drive Functions

Display

A 6-digit 7-segment LED display shows the drive status, alarm codes, parameters, and other information.

Operation Area

Monitors the parameter setting and drive condition.

Charge Lamp

Lights when the main circuit power supply is turned ON.

Control I/O Connector (CN1)

Used for command input signals and I/O signals.

Encoder Connector (CN2)

Connector for the encoder installed in the Servomotor.

Expansion Connector (CN3)

A spare connector for expansion. Do not connect anything.

External Encoder Connector (CN4)

Connector for an encoder signal used during fully-closed control.

Analog monitor Connector (CN5)

You can use a special cable to monitor values, such as the motor rotation speed, torque command value, etc.


USB Connector (CN7)

Communications connector for the computer.

Safety Connector (CN8)

Connector for safety devices. If no safety devices are used, keep the factory-set safety bypass connector installed. 1


System Block Diagrams 1-4



R88D-KTA5L/-KT01L/-KT02L/-KT01H/-KT02H/-KT04H

1







1

Features and System Configuration


R88D-KT20H





R88D-KT30H/-KT50H




R88D-KT75H








R88D-KT06F/-KT10F/-KT15F/-KT20F




R88D-KT30F/-KT50F




1-12

R88D-KT75F



R88D-KT150F



1-5 Applicable Standards

EC Directives

EC Directives	Product	Applicable standards
Low	AC Servo Drive	EN 61800-5-1
Voltage Directive	AC Servomotor	EN60034-1/-5
EMC	AC Servo Drive	EN 55011 class A group 1
Directives		IEC61800-3
		EN61000-6-2
Machinery Directive	AC Servo Drive	EN954-1 (Category 3) EN ISO13849-1: 2008 (Category 3) (PLc,d) ISO13849-1: 2006 (Category 3) (PLc,d) EN61508 (SIL2) EN62061 (SIL2) EV61800-5-2 (STO) IEC61326-3-1 (SIL2)

Note. To conform to EMC directives, the Servomotor and Servo Drive must be installed under the conditions described in "4-3 Wiring Conforming to EMC Directives" (P.4-33).

UL and cUL Standards

Standard	Product	Applicable standards	File number
UL standards	AC Servo Drive	UL508C	E179149 ^{*1}
Standards	AC Servomotor	UL1004-1	E331224
		UL1004-1, UL1004-6	E331224 ^{*2}
CSA	AC Servo Drive	CSA C22.2 No. 14	E179149
standards	AC Servomotor	CSA C22.2 No. 100	E331224

*1: The R88D-KT20 \square and lower capacity Servo Drives are UL-listed.

The R88D-KT30 \square and higher capacity Servo Drives are UL-recognized.

*2: Applies to 1,500-r/min Servomotors of 7.5 to 15 kW and 1,000-r/min Servomotors of 4.5 to 6 kW.

The Servo Drives and Servomotors comply with UL 508C (file No. E179149) as long as the following installation conditions 1 and 2 are met.

- Use the Servo Drive in a pollution degree 1 or 2 environment as defined in IEC 60664-1 (example: installation in an IP54 control panel).
- (2) Be sure to connect a circuit breaker or fuse, which is a UL-listed product with LISTED and (1) mark, between the power supply and noise filter.

Refer to the following table for the rated current of the circuit breaker or fuse. Use copper wiring with a temperature rating of 75° C or higher.

Drive model	Circuit breaker (rated current) (A)
R88D-KT01L	10
R88D-KT02L	10
R88D-KT04L	10
R88D-KT01H	10
R88D-KT02H	10
R88D-KT04H	10
R88D-KT08H	15
R88D-KT10H	15
R88D-KT15H	20
R88D-KT20H	30
R88D-KT30H	50
R88D-KT50H	50
R88D-KT75H	60
R88D-KT150H	100/125 * ¹
R88D-KT06F	15
R88D-KT10F	15
R88D-KT15F	15
R88D-KT20F	20
R88D-KT30F	30
R88D-KT50F	30
R88D-KT75F	30
R88D-KT150F	50/60 * ²

*1: 100 A when used in combination with the R88M-K11K015T-□. 125A when used in combination with the R88M-K15K015T-□.

*2: 50 A when used in combination with the R88M-K11K015C. 60 A when used in combination with the R88M-K15K015C.

Korean Radio Regulations (KC)

- •The G5-series Servo Drives comply with the Korean Radio Regulations (KC).
- •The G5-series Servomotors and Linear Motors are exempt from the Korean Radio Regulations (KC).

SEMI F47

- Some Servo Drives conform to the SEMI F47 standard for momentary power interruptions (voltage sag immunity) for no-load or light-load operation.
- This standard applies to semiconductor manufacturing equipment.
- Note 1. It does not apply to Servo Drivers with single-phase 100-V specifications or with 24-VDC specifications for the control power input.
- Note 2. Always perform evaluation testing for SEMI F47 compliance in the actual system.


1-6 Unit Versions

The G5-series Servo Drive uses unit versions.

Unit versions are used to manage differences in supported functions when product upgrades are made.

Confirmation Method

The unit version of a G5-series Servo Drive is given on the product's nameplate as shown below.







Unit Version Here, the unit version is 1.2.

Unit Versions

Unit version	Upgraded content	Supported CX-Drive versions
Not indicated	New release	Ver. 1.80 or higher
Ver.1.1	Alarm 27.2 detection conditions have been changed to support the increase of encoder resolution in the G series.	Ver. 1.80 or higher
Ver.1.2	European area compliance No changes to existing Ver. 1.1 functions	Ver. 1.80 or higher


2


Standard Models and External Dimensions

This chapter explains the models of Servo Drives, Servomotors, and peripheral equipment, and provides the external dimensions and mounting dimensions.

2-1	Servo System Configuration	2-1
2-2	How to Read Model Numbers	2-3
	Servo Drive	
	Servomotor	2-4
2-3	Standard Model Tables	2-5
	Servo Drive Model Table	2-5
	Servomotor Model Tables	
	Servo Drive and Servomotor Combination Tables	2-11
	Peripheral Equipment and Cable Model Tables	2-13
2-4	External and Mounting Dimensions	2-25
	Servo Drive Dimensions	
	Servomotor Dimensions	
	External Regeneration Resistor Dimensions	
2-5	EMC Filter Dimensions	2-71
2-6	Dimensions of Mounting Brackets	
	(L-Brackets for Rack Mounting)	2-72

2-1 Servo System Configuration





2-2 How to Read Model Numbers

Servo Drive

The Servo Drive model number tells the Servo Drive type, applicable Servomotor capacity, power supply voltage, etc.

	R88D-KT01F
OMNUC G5-series Servo Drive	
Drive Type	
T : Pulse/analog type	
Maximum Applicable Servomotor Capacity	
A5 : 50 W	
01 :100 W	
02 : 200 W	
04 :400 W	
06 : 600 W	
08 : 750 W	
10 : 1 kW	
15 : 1.5 kW	
20 : 2 kW	
30 : 3 kW	
50 : 5 kW	
75 : 7.5 kW	
150 : 15 kW	
Power Supply Voltage	
L : 100 VAC	

H : 200 VAC F : 400 VAC

Servomotor

	R88M-K1003	30H-BOS2
OMNUC G5-series Servomotor		
Servomotor Capacity 050 : 50 W 100 : 100 W 200 : 200 W 400 : 400 W 600 : 600 W 750 : 750 W 900 : 900 W 1K0 : 1 kW 1K5 : 1.5 kW 2K0 : 2 kW 3K0 : 3 kW 4K0 : 4 kW 4K5 : 4.5 kW 5K0 : 5 kW 6K0 : 6 kW 7K5 : 7.5 kW 11K0 : 11 kW 15K0 : 15 kW		
Rated Rotation Speed 10 : 1,000 r/min 15 : 1,500 r/min 20 : 2,000 r/min 30 : 3,000 r/min		
Applied Voltage F : 400 VAC (incremental encoder specifications) H : 200 VAC (incremental encoder specifications) L : 100 VAC (incremental encoder specifications) C : 400 VAC (absolute encoder specifications) T : 200 VAC (absolute encoder specifications) S : 100 VAC (absolute encoder specifications) Options		
- F		

Blank: Straight shaft, no key

- B : With brake
- O : With oil seal
- S2 : With key and tap

2-3 Standard Model Tables

Servo Drive Model Table

Standard Models and External Dimensions

Specifications		Model
Single-phase 100 VAC	50 W	R88D-KTA5L
	100 W	R88D-KT01L
	200 W	R88D-KT02L
	400 W	R88D-KT04L
Single-phase/3-phase 200 VAC	100 W	R88D-KT01H
	200 W	R88D-KT02H
	400 W	R88D-KT04H
	750 W	R88D-KT08H
	1 kW	R88D-KT10H
	1.5 kW	R88D-KT15H
-phase 200 VAC	2 kW	R88D-KT20H
	3 kW	R88D-KT30H
	5 kW	R88D-KT50H
	7.5 kW	R88D-KT75H
	15 kW	R88D-KT150H
-phase 400 VAC	600 W	R88D-KT06F
	1 kW	R88D-KT10F
	1.5 kW	R88D-KT15F
	2 kW	R88D-KT20F
	3 kW	R88D-KT30F
	5 kW	R88D-KT50F
	7.5 kW	R88D-KT75F
	15 kW	R88D-KT150F

Servomotor Model Tables

3,000-r/min Servomotors

				Μ	Model		
S	pecific	ations	With increm	nental encoder	With abso	lute encoder	
			Straight shaft without key	Straight shaft with key and tap	Straight shaft without key	Straight shaft with key and tap	
		50 W	R88M-K05030H	R88M-K05030H-S2	R88M-K05030T	R88M-K05030T-S2	
	100 V	100 W	R88M-K10030L	R88M-K10030L-S2	R88M-K10030S	R88M-K10030S-S2	
	100 V	200 W	R88M-K20030L	R88M-K20030L-S2	R88M-K20030S	R88M-K20030S-S2	
		400 W	R88M-K40030L	R88M-K40030L-S2	R88M-K40030S	R88M-K40030S-S2	
		50 W	R88M-K05030H	R88M-K05030H-S2	R88M-K05030T	R88M-K05030T-S2	
		100 W	R88M-K10030H	R88M-K10030H-S2	R88M-K10030T	R88M-K10030T-S2	
		200 W	R88M-K20030H	R88M-K20030H-S2	R88M-K20030T	R88M-K20030T-S2	
		400 W	R88M-K40030H	R88M-K40030H-S2	R88M-K40030T	R88M-K40030T-S2	
		750 W	R88M-K75030H	R88M-K75030H-S2	R88M-K75030T	R88M-K75030T-S2	
s	200 V	1 kW	R88M-K1K030H	R88M-K1K030H-S2	R88M-K1K030T	R88M-K1K030T-S2	
Without brakes		1.5 kW	R88M-K1K530H	R88M-K1K530H-S2	R88M-K1K530T	R88M-K1K530T-S2	
out b		2 kW	R88M-K2K030H	R88M-K2K030H-S2	R88M-K2K030T	R88M-K2K030T-S2	
Vitho		3 kW	R88M-K3K030H	R88M-K3K030H-S2	R88M-K3K030T	R88M-K3K030T-S2	
~		4 kW	R88M-K4K030H	R88M-K4K030H-S2	R88M-K4K030T	R88M-K4K030T-S2	
		5 kW	R88M-K5K030H	R88M-K5K030H-S2	R88M-K5K030T	R88M-K5K030T-S2	
		750 W	R88M-K75030F	R88M-K75030F-S2	R88M-K75030C	R88M-K75030C-S2	
		1 kW	R88M-K1K030F	R88M-K1K030F-S2	R88M-K1K030C	R88M-K1K030C-S2	
		1.5 kW	R88M-K1K530F	R88M-K1K530F-S2	R88M-K1K530C	R88M-K1K530C-S2	
	400 V	2 kW	R88M-K2K030F	R88M-K2K030F-S2	R88M-K2K030C	R88M-K2K030C-S2	
		3 kW	R88M-K3K030F	R88M-K3K030F-S2	R88M-K3K030C	R88M-K3K030C-S2	
		4 kW	R88M-K4K030F	R88M-K4K030F-S2	R88M-K4K030C	R88M-K4K030C-S2	
		5 kW	R88M-K5K030F	R88M-K5K030F-S2	R88M-K5K030C	R88M-K5K030C-S2	

Note. Models with oil seals are also available.

			Model				
s	Specifications		With incremental encoder		With abso	lute encoder	
			Straight shaft without key	Straight shaft with key and tap	Straight shaft without key	Straight shaft with key and tap	
		50 W	R88M-K05030H-B	R88M-K05030H-BS2	R88M-K05030T-B	R88M-K05030T-BS2	
	100 V	100 W	R88M-K10030L-B	R88M-K10030L-BS2	R88M-K10030S-B	R88M-K10030S-BS2	
	100 V	200 W	R88M-K20030L-B	R88M-K20030L-BS2	R88M-K20030S-B	R88M-K20030S-BS2	
		400 W	R88M-K40030L-B	R88M-K40030L-BS2	R88M-K40030S-B	R88M-K40030S-BS2	
		50 W	R88M-K05030H-B	R88M-K05030H-BS2	R88M-K05030T-B	R88M-K05030T-BS2	
		100 W	R88M-K10030H-B	R88M-K10030H-BS2	R88M-K10030T-B	R88M-K10030T-BS2	
		200 W	R88M-K20030H-B	R88M-K20030H-BS2	R88M-K20030T-B	R88M-K20030T-BS2	
		400 W	R88M-K40030H-B	R88M-K40030H-BS2	R88M-K40030T-B	R88M-K40030T-BS2	
		750 W	R88M-K75030H-B	R88M-K75030H-BS2	R88M-K75030T-B	R88M-K75030T-BS2	
	200 V	1 kW	R88M-K1K030H-B	R88M-K1K030H-BS2	R88M-K1K030T-B	R88M-K1K030T-BS2	
kes		1.5 kW	R88M-K1K530H-B	R88M-K1K530H-BS2	R88M-K1K530T-B	R88M-K1K530T-BS2	
With brakes		2 kW	R88M-K2K030H-B	R88M-K2K030H-BS2	R88M-K2K030T-B	R88M-K2K030T-BS2	
With		3 kW	R88M-K3K030H-B	R88M-K3K030H-BS2	R88M-K3K030T-B	R88M-K3K030T-BS2	
		4 kW	R88M-K4K030H-B	R88M-K4K030H-BS2	R88M-K4K030T-B	R88M-K4K030T-BS2	
		5 kW	R88M-K5K030H-B	R88M-K5K030H-BS2	R88M-K5K030T-B	R88M-K5K030T-BS2	
		750 W	R88M-K75030F-B	R88M-K75030F-BS2	R88M-K75030C-B	R88M-K75030C-BS2	
		1 kW	R88M-K1K030F-B	R88M-K1K030F-BS2	R88M-K1K030C-B	R88M-K1K030C-BS2	
		1.5 kW	R88M-K1K530F-B	R88M-K1K530F-BS2	R88M-K1K530C-B	R88M-K1K530C-BS2	
	400 V	2 kW	R88M-K2K030F-B	R88M-K2K030F-BS2	R88M-K2K030C-B	R88M-K2K030C-BS2	
		3 kW	R88M-K3K030F-B	R88M-K3K030F-BS2	R88M-K3K030C-B	R88M-K3K030C-BS2	
		4 kW	R88M-K4K030F-B	R88M-K4K030F-BS2	R88M-K4K030C-B	R88M-K4K030C-BS2	
		5 kW	R88M-K5K030F-B	R88M-K5K030F-BS2	R88M-K5K030C-B	R88M-K5K030C-BS2	

Note. Models with oil seals are also available.

		Model							
Specifications		With incre	mental encoder	With abs	olute encoder				
		Straight shaft without key	Straight shaft with key and tap	Straight shaft without key	Straight shaft with key and tap				
	1 kW	R88M-K1K020H	R88M-K1K020H-S2	R88M-K1K020T	R88M-K1K020T-S2				
	1.5 kW	R88M-K1K520H	R88M-K1K520H-S2	R88M-K1K520T	R88M-K1K520T-S2				
	2 kW	R88M-K2K020H	R88M-K2K020H-S2	R88M-K2K020T	R88M-K2K020T-S2				
	3 kW	R88M-K3K020H	R88M-K3K020H-S2	R88M-K3K020T	R88M-K3K020T-S2				
200 V	4 kW	R88M-K4K020H	R88M-K4K020H-S2	R88M-K4K020T	R88M-K4K020T-S2				
	5 kW	R88M-K5K020H	R88M-K5K020H-S2	R88M-K5K020T	R88M-K5K020T-S2				
	7.5 kW			R88M-K7K515T	R88M-K7K515T-S2				
	11 kW			R88M-K11K015T	R88M-K11K015T-S2				
S	15 kW			R88M-K15K015T	R88M-K15K015T-S2				
Without brakes	400 W	R88M-K40020F	R88M-K40020F-S2	R88M-K40020C	R88M-K40020C-BS2				
outt	600 W	R88M-K60020F	R88M-K60020F-S2	R88M-K60020C	R88M-K60020C-BS2				
Mith	1 kW	R88M-K1K020F	R88M-K1K020F-S2	R88M-K1K020C	R88M-K1K020C-S2				
	1.5 kW	R88M-K1K520F	R88M-K1K520F-S2	R88M-K1K520C	R88M-K1K520C-S2				
	2 kW	R88M-K2K020F	R88M-K2K020F-S2	R88M-K2K020C	R88M-K2K020C-S2				
400 V	3 kW	R88M-K3K020F	R88M-K3K020F-S2	R88M-K3K020C	R88M-K3K020C-S2				
	4 kW	R88M-K4K020F	R88M-K4K020F-S2	R88M-K4K020C	R88M-K4K020C-S2				
	5 kW	R88M-K5K020F	R88M-K5K020F-S2	R88M-K5K020C	R88M-K5K020C-S2				
	7.5 kW			R88M-K7K515C	R88M-K7K515C-S2				
	11 kW			R88M-K11K015C	R88M-K11K015C-S2				
	15 kW			R88M-K15K015C	R88M-K15K015C-S2				

1,500-r/min and 2,000-r/min Servomotors

Note 1. Models with oil seals are also available.

Note 2. The rated rotation speed of Servomotors of 7.5 to 15 kW is 1,500 r/min.

			Model				
S	Specifications		With incremental encoder		With absolute encoder		
			Straight shaft without key	Straight shaft with key and tap	Straight shaft without key	Straight shaft with key and tap	
		1 kW	R88M-K1K020H-B	R88M-K1K020H-BS2	R88M-K1K020T-B	R88M-K1K020T-BS2	
		1.5 kW	R88M-K1K520H-B	R88M-K1K520H-BS2	R88M-K1K520T-B	R88M-K1K520T-BS2	
		2 kW	R88M-K2K020H-B	R88M-K2K020H-BS2	R88M-K2K020T-B	R88M-K2K020T-BS2	
		3 kW	R88M-K3K020H-B	R88M-K3K020H-BS2	R88M-K3K020T-B	R88M-K3K020T-BS2	
	200 V	4 kW	R88M-K4K020H-B	R88M-K4K020H-BS2	R88M-K4K020T-B	R88M-K4K020T-BS2	
		5 kW	R88M-K5K020H-B	R88M-K5K020H-BS2	R88M-K5K020T-B	R88M-K5K020T-BS2	
		7.5 kW			R88M-K7K515T-B	R88M-K7K515T-BS2	
		11 kW			R88M-K11K015T-B	R88M-K11K015T-S2	
		15 kW			R88M-K15K015T-B	R88M-K15K015T-S2	
With brakes		400 W	R88M-K40020F-B	R88M-K40020F-BS2	R88M-K40020C-B	R88M-K40020C-BS2	
h bra		600 W	R88M-K60020F-B	R88M-K60020F-BS2	R88M-K60020C-B	R88M-K60020C-BS2	
Wit		1 kW	R88M-K1K020F-B	R88M-K1K020F-BS2	R88M-K1K020C-B	R88M-K1K020C-BS2	
		1.5 kW	R88M-K1K520F-B	R88M-K1K520F-BS2	R88M-K1K520C-B	R88M-K1K520C-BS2	
		2 kW	R88M-K2K020F-B	R88M-K2K020F-BS2	R88M-K2K020C-B	R88M-K2K020C-BS2	
	400 V	3 kW	R88M-K3K020F-B	R88M-K3K020F-BS2	R88M-K3K020C-B	R88M-K3K020C-BS2	
		4 kW	R88M-K4K020F-B	R88M-K4K020F-BS2	R88M-K4K020C-B	R88M-K4K020C-BS2	
		5 kW	R88M-K5K020F-B	R88M-K5K020F-BS2	R88M-K5K020C-B	R88M-K5K020C-BS2	
		7.5 kW			R88M-K7K515C-B	R88M-K7K515C-BS2	
		11 kW			R88M-K11K015C-B	R88M-K11K015C-BS2	
		15 kW			R88M-K15K015C-B	R88M-K15K015C-BS2	

Note 1. Models with oil seals are also available.

Note 2. The rated rotation speed of Servomotors of 7.5 to 15 kW is 1,500 r/min.

1,000-r/min Servomotors

			Model					
S	Specifications		With increm	nental encoder	With absolute encoder			
			Straight shaft without key			Straight shaft with key and tap		
		900 kW	R88M-K90010H	R88M-K90010H-S2	R88M-K90010T	R88M-K90010T-S2		
		2 kW	R88M-K2K010H	R88M-K2K010H-S2	R88M-K2K010T	R88M-K2K010T-S2		
	200 V	3 kW	R88M-K3K010H	R88M-K3K010H-S2	R88M-K3K010T	R88M-K3K010T-S2		
S		4.5 kW	R88M-K6K010T R88	R88M-K4K510T-S2				
Without brakes		6 kW			R88M-K6K010T	R88M-K6K010T-S2		
out b		900 kW	R88M-K90010F	R88M-K90010F-S2	R88M-K90010C	R88M-K90010C-S2		
Vitho		2 kW	R88M-K2K010F	R88M-K2K010F-S2	R88M-K2K010C	R88M-K2K010C-S2		
_	400 V	3 kW	R88M-K3K010F	R88M-K3K010F-S2	R88M-K3K010C	R88M-K3K010C-S2		
		4.5 kW			R88M-K4K510C	R88M-K4K510C-S2		
		6 kW			R88M-K6K010C	R88M-K6K010C-S2		
		900 kW	R88M-K90010H-B	R88M-K90010H-BS2	R88M-K90010T-B	R88M-K90010T-BS2		
		2 kW	R88M-K2K010H-B	R88M-K2K010H-BS2	R88M-K2K010T-B	R88M-K2K010T-BS2		
	200 V	3 kW	R88M-K3K010H-B	R88M-K3K010H-BS2	R88M-K3K010T-B	R88M-K3K010T-S2 R88M-K4K510T-S2 R88M-K4K510T-S2 R88M-K4K510T-S2 R88M-K90010C-S2 R88M-K2K010C-S2 R88M-K3K010C-S2 R88M-K4K510C-S2 R88M-K4K510C-S2 R88M-K4K510C-S2 R88M-K4K510C-S2 R88M-K4K510C-S2 R88M-K4K510C-S2 R88M-K4K510C-S2 R88M-K4K510C-S2 R88M-K6K010T-BS2 R88M-K4K510T-BS2 R88M-K4K510T-BS2 R88M-K6K010T-BS2 R88M-K6K010T-BS2 R88M-K6K010T-BS2 R88M-K6K010C-BS2 R88M-K2K010C-BS2 R88M-K3K010C-BS2 R88M-K3K010C-BS2		
6		4.5 kW			R88M-K4K510T-B	R88M-K4K510T-BS2		
With brakes		6 kW			R88M-K6K010T-B	R88M-K6K010T-BS2		
th br		900 kW	R88M-K90010F-B	R88M-K90010F-BS2	R88M-K90010C-B	R88M-K90010C-BS2		
Ň		2 kW	R88M-K2K010F-B	R88M-K2K010F-BS2	R88M-K2K010C-B	R88M-K2K010C-BS2		
	400 V	3 kW	R88M-K3K010F-B	R88M-K3K010F-BS2	R88M-K3K010C-B	R88M-K3K010C-BS2		
		4.5 kW			R88M-K4K510C-B	R88M-K4K510C-BS2		
		6 kW			R88M-K6K010C-B	R88M-K6K010C-BS2		

Note. Models with oil seals are also available.

Servo Drive and Servomotor Combination Tables

The tables in this section show the possible combinations of OMNUC G5-series Servo Drives and Servomotors. The Servomotors and Servo Drives can only be used in the listed combinations.

"- \Box " at the end of the motor model number is for options, such as the shaft type, brake, oil seal and key.

3,000-r/min Servomotors and Servo Drives

	Servomotor			
Voltage	Rated output	With incremental encoder	With absolute encoder	Servo Drive
Single-phase	50 W	R88M-K05030H-	R88M-K05030T-	R88D-KTA5L
100 V	100 W	R88M-K10030L-	R88M-K10030S-	R88D-KT01L
Single-phase/	200 W	R88M-K20030L-	R88M-K20030S-	R88D-KT02L
3-phase 100 V	400 W	R88M-K40030L-	R88M-K40030S-	R88D-KT04L
	50 W*	R88M-K05030H-	R88M-K05030T-	R88D-KT01H
	100 W	R88M-K10030H-	R88M-K10030T-	R88D-KT01H
	200 W	R88M-K20030H-	R88M-K20030T-	R88D-KT02H
Single-phase/ 3-phase 200 V	400 W	R88M-K40030H-	R88M-K40030T-	R88D-KT04H
	750 W	R88M-K75030H-	R88M-K75030T-	R88D-KT08H
	1 kW*	R88M-K1K030H-	R88M-K1K030T-	R88D-KT15H
	1.5 kW	R88M-K1K530H-	R88M-K1K530T-	R88D-KT15H
	2 kW	R88M-K2K030H-	R88M-K2K030T-	R88D-KT20H
3-phase 200 V	3 kW	R88M-K3K030H-	R88M-K3K030T-	R88D-KT30H
3-p11856 200 V	4 kW*	R88M-K4K030H-	R88M-K4K030T-	R88D-KT50H
	5 kW	R88M-K5K030H-	R88M-K5K030T-	R88D-KT50H
	750 W*	R88M-K75030F-	R88M-K75030C-	R88D-KT10F
	1 kW*	R88M-K1K030F-	R88M-K1K030C-	R88D-KT15F
	1.5 kW	R88M-K1K530F-	R88M-K1K530C-	R88D-KT15F
3-phase 400 V	2 kW	R88M-K2K030F-	R88M-K2K030C-	R88D-KT20F
	3 kW	R88M-K3K030F-	R88M-K3K030C-	R88D-KT30F
	4 kW*	R88M-K4K030F-	R88M-K4K030C-	R88D-KT50F
	5 kW	R88M-K5K030F-	R88M-K5K030C-	R88D-KT50F

* Use these combination with caution because the Servo Drive and Servomotor have different capacities.

Voltage	Rated output	With incremental encoder	With absolute encoder	Servo Drive
Single-phase/	1 kW	R88M-K1K020H-	R88M-K1K020T-	R88D-KT10H
3-phase 200 V	1.5 kW	R88M-K1K520H-	R88M-K1K520T-	R88D-KT15H
	2 kW	R88M-K2K020H-	R88M-K2K020T-	R88D-KT20H
	3 kW	R88M-K3K020H-	R88M-K3K020T-	R88D-KT30H
	4 kW*	R88M-K4K020H-	R88M-K4K020T-	R88D-KT50H
3-phase 200 V	5 kW	R88M-K5K020H-	R88M-K5K020T-	R88D-KT50H
	7.5 kW		R88M-K7K515T-	R88D-KT75H
	11 kW*		R88M-K11K015T-	R88D-KT150H
	15 kW		R88M-K15K015T-	R88D-KT150H
	400 W*	R88M-K40020F-	R88M-K40020C-	R88D-KT06F
	600 W	R88M-K60020F-	R88M-K60020C-	R88D-KT06F
	1 kW	R88M-K1K020F-	R88M-K1K020C-	R88D-KT10F
	1.5 kW	R88M-K1K520F-	R88M-K1K520C-	R88D-KT15F
	2 kW	R88M-K2K020F-	R88M-K2K020C-	R88D-KT20F
3-phase 400 V	3 kW	R88M-K3K020F-	R88M-K3K020C-	R88D-KT30F
	4 kW*	R88M-K4K020F-	R88M-K4K020C-	R88D-KT50F
	5 kW	R88M-K5K020F-	R88M-K5K020C-	R88D-KT50F
	7.5 kW		R88M-K7K515C-	R88D-KT75F
	11 kW*		R88M-K11K015C-	R88D-KT150F
	15 kW		R88M-K15K015C-	R88D-KT150F

1,500-r/min and 2,000-r/min Servomotors and Servo Drives

* Use these combination with caution because the Servo Drive and Servomotor have different capacities.

1,000-r/min Servomotors and Servo Drives

Voltage	Rated output	With incremental encoder	With absolute encoder	Servo Drive	
Single-phase/ 3-phase 200 V	900 W*	R88M-K90010H-□	R88M-K90010T-□	R88D-KT15H	
	2 kW*	R88M-K2K010H-	R88M-K2K010T-	R88D-KT30H	
3-phase 200 V	3 kW*	R88M-K3K010H-	R88M-K3K010T-	R88D-KT50H	
3-phase 200 V	4.5 kW*		R88M-K4K510T-	R88D-KT50H	
	6 kW*		R88M-K6K010T-	R88D-KT75H	
	900 W*	R88M-K90010F-	R88M-K90010C-	R88D-KT15F	
	2 kW*	R88M-K2K010F-	R88M-K2K010C-	R88D-KT30F	
3-phase 400 V	3 kW*	R88M-K3K010F-	R88M-K3K010C-	R88D-KT50F	
	4.5 kW*		R88M-K4K510C-	R88D-KT50F	
	6 kW*		R88M-K6K010C-	R88D-KT75F	

* Use these combination with caution because the Servo Drive and Servomotor have different capacities.

Peripheral Equipment and Cable Model Tables

Encoder Cables (European Flexible Cables)

Specifications		Model
[100 V and 200 V]	1.5 m	R88A-CRKA001-5CR-E
For 3,000-r/min Servomotors of 50 to 750 W (for both absolute encoders and incremental encoders)	3 m	R88A-CRKA003CR-E
	5 m	R88A-CRKA005CR-E
	10 m	R88A-CRKA010CR-E
	15 m	R88A-CRKA015CR-E
	20 m	R88A-CRKA020CR-E
[100 V and 200 V]	1.5 m	R88A-CRKC001-5NR-E
3,000-r/min Servomotors of 1.0 kW or more For 2,000-r/min Servomotors	3 m	R88A-CRKC003NR-E
For 1,000-r/min Servomotors	5 m	R88A-CRKC005NR-E
[400 V]	10 m	R88A-CRKC010NR-E
For 3,000-r/min Servomotors For 2,000-r/min Servomotors	15 m	R88A-CRKC015NR-E
For 1,000-r/min Servomotors	20 m	R88A-CRKC020NR-E

Creations	Specifications		lel
Specifications		For motor without brake	For motor with brake
[100 V and 200 V]	1.5 m	R88A-CAKA001-5SR-E	
For 3,000-r/min Servomotors of 50 to 750 W	3 m	R88A-CAKA003SR-E	
	5 m	R88A-CAKA005SR-E	(See note 1.)
	10 m	R88A-CAKA010SR-E	
	15 m	R88A-CAKA015SR-E	
	20 m	R88A-CAKA020SR-E	
[200 V]	1.5 m	R88A-CAGB001-5SR-E	R88A-CAGB001-5BR-E
For 3,000-r/min Servomotors of 1 to 2 kW	3 m	R88A-CAGB003SR-E	R88A-CAGB003BR-E
For 2,000-r/min Servomotors of 1 to	5 m	R88A-CAGB005SR-E	R88A-CAGB005BR-E
2 kW For 1,000-r/min Servomotors of 900 W	10 m	R88A-CAGB010SR-E	R88A-CAGB010BR-E
	15 m	R88A-CAGB015SR-E	R88A-CAGB015BR-E
	20 m	R88A-CAGB020SR-E	R88A-CAGB020BR-E
[400 V]	1.5 m	R88A-CAGB001-5SR-E	R88A-CAKF001-5BR-E
For 3,000-r/min Servomotors of 750 W to 2 kW	3 m	R88A-CAGB003SR-E	R88A-CAKF003BR-E
For 2,000-r/min Servomotors of 400 W	5 m	R88A-CAGB005SR-E	R88A-CAKF005BR-E
to 2 kW For 1,000-r/min Servomotors of 900 W	10 m	R88A-CAGB010SR-E	R88A-CAKF010BR-E
	15 m	R88A-CAGB015SR-E	R88A-CAKF015BR-E
	20 m	R88A-CAGB020SR-E	R88A-CAKF020BR-E
For 3,000-r/min Servomotors of 3 to	1.5 m	R88A-CAGD001-5SR-E	R88A-CAGD001-5BR-E
5 kW For 2,000-r/min Servomotors of 3 to	3 m	R88A-CAGD003SR-E	R88A-CAGD003BR-E
5 kW	5 m	R88A-CAGD005SR-E	R88A-CAGD005BR-E
For 1,000-r/min Servomotors of 2 to 4.5 kW	10 m	R88A-CAGD010SR-E	R88A-CAGD010BR-E
	15 m	R88A-CAGD015SR-E	R88A-CAGD015BR-E
	20 m	R88A-CAGD020SR-E	R88A-CAGD020BR-E

Motor Power Cables (European Flexible Cables)

Note 1.: Different connectors are used for the motor power and the brake on 100-V and 200-V, 3,000-r/ min Servomotors of 50 to 750 W and Servomotors of 6 to 15 kW. When using a Servomotor with a brake, two cables are required: a Power Cable without Brake and a Brake Cable.

Note 2.: For flexible power cables for Servomotors of 11 to 15 kW, refer to *4-2 Wiring* (P. 4-7) and make your own cable.

For flexible power cables for Servomotors of 6 to 7.5 kW, refer to *3-4 Cable and Connector Specifications* and make your own power cable.

Brake Cables (European Flexible Cables)

Specifications		Model
[100 V and 200 V]	1.5 m	R88A-CAKA001-5BR-E
For 3,000-r/min Servomotors of 50 to 750 W		R88A-CAKA003BR-E
	5 m	R88A-CAKA005BR-E
	10 m	R88A-CAKA010BR-E
	15 m	R88A-CAKA015BR-E
	20 m	R88A-CAKA020BR-E

Note: For flexible brake cables for Servomotors of 6 to 15 kW, refer to 3-4 Cable and Connector Specifications and make your own brake cable.

Encoder Cables (Global Non-Flexible Cables)

Specifications		Model
[100 V and 200 V]	3 m	R88A-CRKA003C
For 3,000-r/min Servomotors of 50 to 750 W (for both absolute encoders and incremental encoders)	5 m	R88A-CRKA005C
(10 m	R88A-CRKA010C
	15 m	R88A-CRKA015C
	20 m	R88A-CRKA020C
	30 m	R88A-CRKA030C
	40 m	R88A-CRKA040C
	50 m	R88A-CRKA050C
[100 V and 200 V]	3 m	R88A-CRKC003N
3,000-r/min Servomotors of 1.0 kW or more For 2,000-r/min Servomotors	5 m	R88A-CRKC005N
For 1,500-r/min Servomotors	10 m	R88A-CRKC010N
For 1,000-r/min Servomotors	15 m	R88A-CRKC015N
[400 V] For 2 000 r/min Son (emotors)	20 m	R88A-CRKC020N
For 3,000-r/min Servomotors For 2,000-r/min Servomotors	30 m	R88A-CRKC030N
For 1,500-r/min Servomotors For 1,000-r/min Servomotors	40 m	R88A-CRKC040N
	50 m	R88A-CRKC050N

		М	odel
Specifications		For motor without brake	For motor with brake
[100 V and 200 V]	3 m	R88A-CAKA003S	(See note 1.)
For 3,000-r/min Servomotors of 50 to 750 W	5 m	R88A-CAKA005S	1
	10 m	R88A-CAKA010S	
	15 m	R88A-CAKA015S	
	20 m	R88A-CAKA020S	
	30 m	R88A-CAKA030S	
	40 m	R88A-CAKA040S	
	50 m	R88A-CAKA050S	1
[200 V]	3 m	R88A-CAGB003S	R88A-CAGB003B
For 3,000-r/min Servomotors of 1 to 2 kW For 2,000-r/min Servomotors of 1 to 2 kW	5 m	R88A-CAGB005S	R88A-CAGB005B
For 1,000-r/min Servomotors of 900 W	10 m	R88A-CAGB010S	R88A-CAGB010B
	15 m	R88A-CAGB015S	R88A-CAGB015B
	20 m	R88A-CAGB020S	R88A-CAGB020B
	30 m	R88A-CAGB030S	R88A-CAGB030B
	40 m	R88A-CAGB040S	R88A-CAGB040B
	50 m	R88A-CAGB050S	R88A-CAGB050B
[400 V]	3 m	R88A-CAGB003S	R88A-CAKF003B
For 3,000-r/min Servomotors of 750 W to 2 kW	5 m	R88A-CAGB005S	R88A-CAKF005B
For 2,000-r/min Servomotors of 400 W to 2	10 m	R88A-CAGB010S	R88A-CAKF010B
kW For 1,000-r/min Servomotors of 900 W	15 m	R88A-CAGB015S	R88A-CAKF015B
	20 m	R88A-CAGB020S	R88A-CAKF020B
	30 m	R88A-CAGB030S	R88A-CAKF030B
	40 m	R88A-CAGB040S	R88A-CAKF040B
	50 m	R88A-CAGB050S	R88A-CAKF050B
For 3,000-r/min Servomotors of 3 to 5 kW	3 m	R88A-CAGD003S	R88A-CAGD003B
For 2,000-r/min Servomotors of 3 to 5 kW For 1,000-r/min Servomotors of 2 to 4.5	5 m	R88A-CAGD005S	R88A-CAGD005B
kW	10 m	R88A-CAGD010S	R88A-CAGD010B
	15 m	R88A-CAGD015S	R88A-CAGD015B
	20 m	R88A-CAGD020S	R88A-CAGD020B
	30 m	R88A-CAGD030S	R88A-CAGD030B
	40 m	R88A-CAGD040S	R88A-CAGD040B
	50 m	R88A-CAGD050S	R88A-CAGD050B

Motor Power Cables (Global Non-Flexible Cables)

	Мс	odel	
Specifications		For motor without brake	For motor with brake
For 2,000-r/min Servomotors of 7.5 kW	3 m	R88A-CAGE003S	-
For 1,000-r/min Servomotors of 6 kW	5 m	R88A-CAGE005S	-
	10 m	R88A-CAGE010S	-
15		R88A-CAGE015S	-
	20 m	R88A-CAGE020S	-
30 m		R88A-CAGE030S	-
	40 m	R88A-CAGE040S	-
	50 m	R88A-CAGE050S	-

Note 1.: Different connectors are used for the motor power and the brake on 100-V and 200-V, 3,000-r/ min Servomotors of 50 to 750 W and Servomotors of 6 to 15 kW. When using a Servomotor with a brake, two cables are required: a Power Cable without Brake and a Brake Cable.

Note 2.: For non-flexible power cables for Servomotors of 11 or 15 kW, refer to 4-2 Wiring (P. 4-7) and make your own cable.

Brake Cables (Global Non-Flexible Cables)

Specifications		Model
[100 V and 200 V]	3 m	R88A-CAKA003B
For 3,000-r/min Servomotors of 50 to 750 W	5 m	R88A-CAKA005B
	10 m	R88A-CAKA010B
	15 m	R88A-CAKA015B
	20 m	R88A-CAKA020B
	30 m	R88A-CAKA030B
	40 m	R88A-CAKA040B
	50 m	R88A-CAKA050B
For 1,500-r/min Servomotors of 7.5 to 15 kW	3 m	R88A-CAGE003B
For 1,000-r/min Servomotors of 6 kW	5 m	R88A-CAGE005B
	10 m	R88A-CAGE010B
	15 m	R88A-CAGE015B
	20 m	R88A-CAGE020B
	30 m	R88A-CAGE030B
	40 m	R88A-CAGE040B
	50 m	R88A-CAGE050B

Encoder Cables (Global Flexible Cables)

Specifications	Model	
[100 V and 200 V]	3 m	R88A-CRKA003CR
For 3,000-r/min Servomotors of 50 to 750 W (for both absolute encoders and incremental encoders)	5 m	R88A-CRKA005CR
()	10 m	R88A-CRKA010CR
	15 m	R88A-CRKA015CR
	20 m	R88A-CRKA020CR
	30 m	R88A-CRKA030CR
	40 m	R88A-CRKA040CR
	50 m	R88A-CRKA050CR
[100 V and 200 V]	3 m	R88A-CRKC003NR
3,000-r/min Servomotors of 1.0 kW or more For 2,000-r/min Servomotors	5 m	R88A-CRKC005NR
For 1,500-r/min Servomotors	10 m	R88A-CRKC010NR
For 1,000-r/min Servomotors	15 m	R88A-CRKC015NR
[400 V]	20 m	R88A-CRKC020NR
For 3,000-r/min Servomotors For 2,000-r/min Servomotors	30 m	R88A-CRKC030NR
For 1,500-r/min Servomotors	40 m	R88A-CRKC040NR
For 1,000-r/min Servomotors	50 m	R88A-CRKC050NR

Motor Power Cables (Global Flexible Cables)

Specifications		Model		
		For motor without brake	For motor with brake	
[100 V and 200 V]	3 m	R88A-CAKA003SR		
For 3,000-r/min Servomotors of 50 to 750 W	5 m	R88A-CAKA005SR		
	10 m	R88A-CAKA010SR		
	15 m	R88A-CAKA015SR	(See note 1.)	
	20 m	R88A-CAKA020SR		
	30 m	R88A-CAKA030SR		
	40 m	R88A-CAKA040SR		
	50 m	R88A-CAKA050SR		
[200 V]	3 m	R88A-CAGB003SR	R88A-CAGB003BR	
For 3,000-r/min Servomotors of 1 to 2 kW For 2,000-r/min Servomotors of 1 to 2 kW	5 m	R88A-CAGB005SR	R88A-CAGB005BR	
For 1,000-r/min Servomotors of 900 W	10 m	R88A-CAGB010SR	R88A-CAGB010BR	
	15 m	R88A-CAGB015SR	R88A-CAGB015BR	
	20 m	R88A-CAGB020SR	R88A-CAGB020BR	
	30 m	R88A-CAGB030SR	R88A-CAGB030BR	
	40 m	R88A-CAGB040SR	R88A-CAGB040BR	
	50 m	R88A-CAGB050SR	R88A-CAGB050BR	

Specifications		Model		
		For motor without brake	For motor with brake	
[400 V]	3 m	R88A-CAGB003SR	R88A-CAKF003BR	
For 3,000-r/min Servomotors of 750 W to 2 kW	5 m	R88A-CAGB005SR	R88A-CAKF005BR	
For 2,000-r/min Servomotors of 400 W to	10 m	R88A-CAGB010SR	R88A-CAKF010BR	
2 kW For 1,000-r/min Servomotors of 900 W	15 m	R88A-CAGB015SR	R88A-CAKF015BR	
	20 m	R88A-CAGB020SR	R88A-CAKF020BR	
	30 m	R88A-CAGB030SR	R88A-CAKF030BR	
	40 m	R88A-CAGB040SR	R88A-CAKF040BR	
	50 m	R88A-CAGB050SR	R88A-CAKF050BR	
For 3,000-r/min Servomotors of 3 to 5 kW	3 m	R88A-CAGD003SR	R88A-CAGD003BR	
For 2,000-r/min Servomotors of 3 to 5 kW For 1,000-r/min Servomotors of 2 to	5 m	R88A-CAGD005SR	R88A-CAGD005BR	
4.5 kW	10 m	R88A-CAGD010SR	R88A-CAGD010BR	
	15 m	R88A-CAGD015SR	R88A-CAGD015BR	
	20 m	R88A-CAGD020SR	R88A-CAGD020BR	
	30 m	R88A-CAGD030SR	R88A-CAGD030BR	
	40 m	R88A-CAGD040SR	R88A-CAGD040BR	
	50 m	R88A-CAGD050SR	R88A-CAGD050BR	

Note 1.: Different connectors are used for the motor power and the brake on 100-V and 200-V, 3,000-r/ min Servomotors of 50 to 750 W and Servomotors of 6 to 15 kW. When using a Servomotor with a brake, two cables are required: a Power Cable without Brake and a Brake Cable.

Note 2.: For flexible power cables for Servomotors of 11 to 15 kW, refer to 4-2 Wiring (P. 4-7) and make your own cable.

For flexible power cables for Servomotors of 6 to 7.5 kW, refer to *Motor Power Cable Specifications* on page 3-100 and make your own power cable.

Brake Cables (Global Flexible Cables)

Specifications		Model
[100 V and 200 V]	3 m	R88A-CAKA003BR
	5 m	R88A-CAKA005BR
	10 m	R88A-CAKA010BR
	15 m	R88A-CAKA015BR
	20 m	R88A-CAKA020BR
	30 m	R88A-CAKA030BR
	40 m	R88A-CAKA040BR
	50 m	R88A-CAKA050BR

Note: For flexible brake cables for Servomotors of 6 to 15 kW, refer to *3-4 Cable and Connector Specifications* and make your own brake cable.

Absolute Encoder Battery Cables

Specifications	Model	
Absolute Encoder Battery Cable (battery not supplied)	0.3 m	R88A-CRGD0R3C
Absolute Encoder Battery Cable (R88A-BAT01G battery \times 1 supplied)	0.3 m	R88A-CRGD0R3C-BS

Absolute Encoder Backup Battery

Specifications	Model
2,000 mA•h 3.6 V	R88A-BAT01G

Analog Monitor Cable

Specifications		Model
Analog monitor cable	1 m	R88A-CMK001S

Connectors

Specif	Model	
Motor connector for encoder cable	[100 V and 200 V] For 3,000-r/min of 50 to 750 W	R88A-CNK02R
	[100 V and 200 V] For 3,000-r/min of 1 to 5 kW For 2,000 r/min, 1,000 r/min [400 V] For 3,000 r/min, 2,000 r/min and 1,000 r/min	R88A-CNK04R
Control I/O connector (CN1)		R88A-CNU11C
Encoder connector (CN2)		R88A-CNW01R
External encoder connector (CN4)		R88A-CNK41L
Safety connector (CN8)		R88A-CNK81S
Power cable connector (for 750 W max.)		R88A-CNK11A
Brake cable connector (for 750 W max.)		R88A-CNK11B

Servo Relay Units (for CN1)

	Specifications	
Servo Relay Unit	For CS1W-NC113/-NC133 For CJ1W-NC113/-NC133 For C200HW-NC113	XW2B-20J6-1B
	For CS1W-NC213/-NC413/-NC233/-NC433 For CJ1W-NC213/-NC413/-NC233/-NC433 For C200HW-NC213/-NC413	XW2B-40J6-2B
	For CJ1M-CPU21/-CPU22/-CPU23	XW2B-20J6-8A XW2B-40J6-9A
	For CQM1-CPU43-V1 For CQM1H-PLB21	XW2B-20J6-3B

Servo Relay Unit Cables for Servo Drives

Specifications			Model
Servo Drive cables	For CS1W-NC113/-NC133, CJ1W-NC113/-	1 m	XW2Z-100J-B25
	NC133, C200HW-NC113 (XW2B-20J6-1B) For CS1W-NC213/-NC413/-NC233/-NC433, CJ1W-NC213/-NC413/-NC233/-NC433, C200HW-NC213/-NC413 (XW2B-40J6-2B) For CQM1-CPU43-V1 or CQM1H-PLB21 (XW2B-20J6-3B)	2 m	XW2Z-200J-B25
For CJ1M-CPU21/-CPU22/-CPU23 (XW2B-20J6-8A/XW2B-40J6-9A)	1 m	XW2Z-100J-B31	
	(XW2B-20J6-8A/XW2B-40J6-9A)	2 m	XW2Z-200J-B31

Note: Do not use a Servo Relay Unit Cable for line receiver inputs (+CWLD: CN1 pin 44, -CWLD: CN1 pin 45, +CCWLD: CN1 pin 46, -CCWLD: CN1 pin 47).

Use a General-purpose Control Cable (R88A-CPG \Box S) and prepare wiring suited for the controller to be connected.

Specifications			Model
	For CQM1H-PLB21 (XW2B-20J6-3B)	0.5 m	XW2Z-050J-A3
		1 m	XW2Z-100J-A3
	For CS1W-NC113, C200HW-NC113 (XW2B-	0.5 m	XW2Z-050J-A6
	20J6-1B)	1 m	XW2Z-100J-A6
	For CS1W-NC213/-NC413, C200HW-NC213/-	0.5 m	XW2Z-050J-A7
	NC413 (XW2B-20J6-2B)	1 m	XW2Z-100J-A7
	For CS1W-NC133 (XW2B-20J6-1B)	0.5 m	XW2Z-050J-A10
		1 m	XW2Z-100J-A10
Position Control Unit cablesFor CS1W-NC233/-NC433 (XW2B-20J6-2B)For CJ1W-NC113 (XW2B-20J6-1B)For CJ1W-NC213/-NC413 (XW2B-20J6-2B)For CJ1W-NC133 (XW2B-20J6-1B)For CJ1W-NC233/-NC433 (XW2B-20J6-2B)For CJ1W-NC233/-NC433 (XW2B-20J6-2B)For CJ1M-CPU21/-CPU22/-CPU23 (XW2B-20J6-8A/XW2B-40J6-9A)	For CS1W-NC233/-NC433 (XW2B-20J6-2B)	0.5 m	XW2Z-050J-A11
		1 m	XW2Z-100J-A11
	For CJ1W-NC113 (XW2B-20J6-1B)	0.5 m	XW2Z-050J-A14
		1 m	XW2Z-100J-A14
	For CJ1W-NC213/-NC413 (XW2B-20J6-2B)	0.5 m	XW2Z-050J-A15
		1 m	XW2Z-100J-A15
	For CJ1W-NC133 (XW2B-20J6-1B)	0.5 m	XW2Z-050J-A18
		1 m	XW2Z-100J-A18
	For CJ1W-NC233/-NC433 (XW2B-20J6-2B)	0.5 m	XW2Z-050J-A19
		1 m	XW2Z-100J-A19
		0.5 m	XW2Z-050J-A33
	1 m	XW2Z-100J-A33	

Servo Relay Unit Cables for Position Control Units

Control Cables

Specifications			Model
Specified cables for Position Control Unit (line-driver output for 1 axis) CJ1W-NC234/-NC434		1 m	XW2Z-100J-G9
		5 m	XW2Z-500J-G9
		10 m	XW2Z-10MJ-G9
Specified cables for Position Control Unit		1 m	XW2Z-100J-G13
(open collector output for 1 axis) CJ1W-NC214/-NC414		3 m	XW2Z-300J-G13
Specified cables for Position Control Unit		1 m	XW2Z-100J-G1
(line-driver output for 2 axes) CJ1W-NC234/-NC434		5 m	XW2Z-500J-G1
		10 m	XW2Z-10MJ-G1
Specified cables for Position Control Unit		1 m	XW2Z-100J-G5
(open collector output for 2 axes) CJ1W-NC214/-NC414		3 m	XW2Z-300J-G5
Specified cables for Motion Control Unit (for 1 axis)		1 m	R88A-CPG001M1
CS1W-MC221-V1/-MC421-V1		2 m	R88A-CPG002M1
		3 m	R88A-CPG003M1
		5 m	R88A-CPG005M1
Specified cables for Motion Control Unit (for 2 axes)		1 m	R88A-CPG001M2
CS1W-MC221-V1/-MC421-V1		2 m	R88A-CPG002M2
		3 m	R88A-CPG003M2
		5 m	R88A-CPG005M2
General control cables (with connector on one end)		1 m	R88A-CPG001S
		2 m	R88A-CPG002S
Connector-terminal block cables		1 m	XW2Z-100J-B24
		2 m	XW2Z-200J-B24
Connector-terminal block	M3 screw and for pin terminals		XW2B-50G4
	M3.5 screw and fo round terminals	r fork/	XW2B-50G5
	M3 screw and for fork/round terminals		XW2D-50G6

External Regeneration Resistors

Specifications	Model
Regeneration process capacity: 20 W, 50 Ω (with 150°C thermal sensor)	R88A-RR08050S
Regeneration process capacity: 20 W, 100 Ω (with 150°C thermal sensor)	R88A-RR080100S
Regeneration process capacity: 70 W, 47 Ω (with 150°C thermal sensor)	R88A-RR22047S1
Regeneration process capacity: 180 W, 20 Ω (with 200°C thermal sensor)	R88A-RR50020S

Mounting Brackets (L-Brackets for Rack Mounting)


Specifications	Model
R88D-KTA5L/-KT01L/-KT01H/-KT02H	R88A-TK01K
R88D-KT02L/-KT04H	R88A-TK02K
R88D-KT04L/-KT08H	R88A-TK03K
R88D-KT10H/-KT15H/-KT06F/-KT10F/-KT15F	R88A-TK04K


2-4 External and Mounting Dimensions

Servo Drive Dimensions

Single-phase 100 VAC: R88D-KTA5L/-KT01L (50 to 100 W) Single-phase/3-phase 200 VAC: R88D-KT01H/-KT02H (100 to 200 W)

Wall Mounting






Front Mounting (Using Front Mounting Brackets)


* Rectangular hole dimensions are reference values.

Single-phase/3-phase 100 VAC: R88D-KT02L (200 W) Single-phase/3-phase 200 VAC: R88D-KT04H (400 W)

Wall Mounting




Front Mounting (Using Front Mounting Brackets)




* Rectangular hole dimensions are reference values.

Single-phase/3-phase 100 VAC: R88D-KT04L (400 W) Single-phase/3-phase 200 VAC: R88D-KT08H (750 W)

Wall Mounting




Front Mounting (Using Front Mounting Brackets)




* Rectangular hole dimensions are reference values.

Single-phase/3-phase 200 VAC: R88D-KT10H/-KT15H (900 W to 1.5 kW)


Wall Mounting







Front Mounting (Using Front Mounting Brackets)





^{*} Rectangular hole dimensions are reference values.

3-phase 200 VAC: R88D-KT20H (2 kW)


Wall Mounting

External dimensions







Mounting dimensions




Front Mounting (Using Front Mounting Brackets)

External dimensions





Mounting dimensions





* Rectangular hole dimensions are reference values.

3-phase 200 VAC: R88D-KT30H/-KT50H (3 to 5 kW)


Wall Mounting

External dimensions





Mounting dimensions





2

OMNUC G5-SERIES AC SERVOMOTOR AND SERVO DRIVE USER'S MANUAL


External dimensions

Front Mounting (Using Front Mounting Brackets)





Mounting dimensions





* Rectangular hole dimensions are reference values.

3-phase 200 VAC: R88D-KT75H (7.5 kW)


Wall Mounting

External dimensions







Mounting dimensions




External dimensions

Front Mounting (Using Front Mounting Brackets)





Mounting dimensions



* Rectangular hole dimensions are reference values.


. 4

270


3-phase 200 VAC: R88D-KT150H (15 kW)

Wall Mounting

External dimensions




Mounting dimensions




3-phase 400 VAC: R88D-KT06F/-KT10F/-KT15F (600 W to 1.5 kW)

Wall Mounting




Front Mounting (Using Front Mounting Brackets)



* Rectangular hole dimensions are reference values.

3-phase 400 VAC: R88D-KT20F (2 kW)


Wall Mounting



Front Mounting (Using Front Mounting Brackets)

External dimensions


Mounting dimensions



^{*} Rectangular hole dimensions are reference values.

3-phase 400 VAC: R88D-KT30F/-KT50F (3 to 5 kW)


Wall Mounting



Front Mounting (Using Front Mounting Brackets)

External dimensions

Mounting dimensions





* Rectangular hole dimensions are reference values.

3-phase 400 VAC: R88D-KT75F (7.5 kW)


Wall Mounting

External dimensions






Mounting dimensions



Front Mounting (Using Front Mounting Brackets)

External dimensions



(235)* * Rectangular hole dimensions are reference values.

2

334


2.5

2.5


3-phase 400 VAC: R88D-KT150F (15 kW)

Wall Mounting

External dimensions



Mounting dimensions






3,000-r/min Servomotors (100 V and 200 V)

50 W/100 W (without Brake)

 R88M-K05030H (-S2)/-K10030L (-S2)
 INC


 R88M-K05030T (-S2)/-K10030S (-S2)
 ABS



Model	Dimensions (mm)				
model	LL	LM	LN		
R88M-K05030	72	48	23		
R88M-K10030	92	68	43		


Note. The standard models have a straight shaft. Models with a key and tap are indicated with S2 at the end of the model number.

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.



Model	Dimensions (mm)					
Model	LL	LM	LN			
R88M-K05030□-Bx	102	78	23			
R88M-K10030□-Bx	122	98	43			


Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.




Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.

200 W/400 W (with Brake)

R88M-K20030□-B (S2)/-K40030□-B (S2) INC R88M-K20030□-B (S2)/-K40030□-B (S2) ABS




(Shaft end specifications with key and tap)




Model	Dimensions (mm)					
model	LL	LM	S			
R88M-K20030□-B□	116	93	11			
R88M-K40030□-B□	135.5	112.5	14			

Note. The standard models have a straight shaft. Models with a key and tap are indicated with S2 at the end of the model number.

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.



Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.




Note. The standard models have a straight shaft. Models with a key and tap are indicated with S2 at the end of the model number.

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.

1 kW/1.5 kW/2 kW (without Brake)

R88M-K1K030H (-S2)/-K1K530H (-S2)/-K2K030H (-S2) INC R88M-K1K030T (-S2)/-K1K530T (-S2)/-K2K030T (-S2) ABS 1 kW/1.5 kW/2 kW (with Brake)


R88M-K1K030H-B (S2)/-K1K530H-B (S2)/-K2K030H-B (S2) INC R88M-K1K030T-B (S2)/-K1K530T-B (S2)/-K2K030T-B (S2) ABS



Model		Dimensions (mm)					
Model	LL	LM	KB1	KB2			
R88M-K1K030	141	97	66	119			
R88M-K1K530	159.5	115.5	84.5	137.5			
R88M-K2K030	178.5	134.5	103.5	156.5			
R88M-K1K030□-B□	168	124	66	146			
R88M-K1K530□-B□	186.5	142.5	84.5	164.5			
R88M-K2K030□-B□	205.5	161.5	103.5	183.5			

Note. The standard models have a straight shaft. Models with a key and tap are indicated with S2 at the end of the model number.


Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.



Model	Dimensions (mm)					
Model	LL	LM	KB2			
R88M-K3K030	190	146	168			
R88M-K3K030□-B□	215	171	193			

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.





Model		Dimensions (mm)					
Model	LL	LM	KB1	KB2			
R88M-K4K030	208	164	127	186			
R88M-K5K030	243	199	162	221			
R88M-K4K030□-B□	236	192	127	214			
R88M-K5K030□-B□	271	227	162	249			

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.

3,000-r/min Servomotors (400 V)


750 W/1 kW/1.5 kW/2 kW (without Brake)

R88M-K75030F (-S2)/-K1K030F (-S2)/-K1K530F (-S2)/-K2K030F (-S2) INC R88M-K75030C (-S2)/-K1K030C (-S2)/-K1K530C (-S2)/-K2K030C (-S2) ABS

750 W/1 kW/1.5 kW/2 kW (with Brake)

R88M-K75030F-B (S2)/-K1K030F-B (S2)/-K1K530F-B (S2)/-K2K030F-B (S2) R88M-K75030C-B (S2)/-K1K030C-B (S2)/-K1K530C-B (S2)/-K2K030C-B (S2)






Model	Dimensions (mm)						
model	LL	LM	KB1	KB2			
R88M-K75030	131.5	87.5	56.5	109.5			
R88M-K1K030	141	97	66	119			
R88M-K1K530	159.5	115.5	84.5	137.5			
R88M-K2K030	178.5	134.5	103.5	156.5			
R88M-K75030□-B□	158.5	114.5	53.5	136.5			
R88M-K1K030□-B□	168	124	63	146			
R88M-K1K530□-B□	186.5	142.5	81.5	164.5			
R88M-K2K030□-B□	205.5	161.5	100.5	183.5			

Note. The standard models have a straight shaft. Models with a key and tap are indicated with S2 at the end of the model number.

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.



Model	Dimensions (mm)					
Woder	LL	LM	KB2			
R88M-K3K030	190	146	168			
R88M-K3K030□-B□	215	171	193			

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.

4 kW/5 kW (without Brake)


 R88M-K4K030F (-S2)/-K5K030F (-S2)
 INC

 R88M-K4K030C (-S2)/-K5K030C (-S2)
 ABS

4 kW/5 kW (with Brake)

 R88M-K4K030F-B (S2)/-K5K030F-B (S2)
 INC

 R88M-K4K030C-B (S2)/-K5K030C-B (S2)
 ABS



Model		Dimensions (mm)						
inodol	LL	LM	KB1	KB2				
R88M-K4K030	208	164	127	186				
R88M-K5K030	243	199	162	221				
R88M-K4K030□-B□	236	192	127	214				
R88M-K5K030□-B□	271	227	162	249				

Note. The standard models have a straight shaft. Models with a key and tap are indicated with S2 at the end of the model number.

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.

1,500-r/min and 2,000-r/min Servomotors (200 V)


1 kW/1.5 kW/2 kW/3 kW (without Brake)

R88M-K1K020H (-S2)/-K1K520H (-S2)/-K2K020H (-S2)/-K3K020H (-S2) R88M-K1K020T (-S2)/-K1K520T (-S2)/-K2K020T (-S2)/-K3K020T (-S2)



1 kW/1.5 kW/2 kW/3 kW (with Brake)

R88M-K1K020H-B (S2)/-K1K520H-B (S2)/-K2K020H-B (S2)/-K3K020H-B (S2) R88M-K1K020T-B (S2)/-K1K520T-B (S2)/-K2K020T-B (S2)/-K3K020T-B (S2) ABS



Model	Dimensions (mm)					
Model	LL	LR	LM	S	KB1	KB2
R88M-K1K020	138	55	94	22	60	116
R88M-K1K520	155.5	55	111.5	22	77.5	133.5
R88M-K2K020	173	55	129	22	95	151
R88M-K3K020	208	65	164	24	127	186
R88M-K1K020□-B□	166	55	122	22	60	144
R88M-K1K520□-B□	183.5	55	139.5	22	77.5	161.5
R88M-K2K020□-B□	201	55	157	22	95	179
R88M-K3K020□-B□	236	65	192	24	127	214

Note. The standard models have a straight shaft. Models with a key and tap are indicated with S2 at the end of the model number.

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.

4 kW/5 kW (without Brake)


 R88M-K4K020H (-S2)/-K5K020H (-S2)
 INC

 R88M-K4K020T (-S2)/-K5K020T (-S2)
 ABS

4 kW/5 kW (with Brake)

 R88M-K4K020H-B (S2)/-K5K020H-B (S2)
 INC


 R88M-K4K020T-B (S2)/-K5K020T-B (S2)
 ABS



Model		Dimensions (mm)					
Woder	LL	LM	KB1	KB2			
R88M-K4K020	177	133	96	155			
R88M-K5K020	196	152	115	174			
R88M-K4K020□-B□	206	162	96	184			
R88M-K5K020□-B□	225	181	115	203			


Note. The standard models have a straight shaft. Models with a key and tap are indicated with S2 at the end of the model number.

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.



Model	Dimensions (mm)								
Model	LL	LR	LM	S	KB1	KB2	L1	L2	L3
R88M-K7K515T	312	113	268	42	219	290	117.5	117.5	149
R88M-K7K515T-B	337	113	293	42	253	315	117.5	152.5	183

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.




Model	Dimensions (mm)								
induci	LL	LR	LM	S	KB1	KB2	L1	L2	L3
R88M-K11K015T	316	116	272	55	232	294	124.5	124.5	162
R88M-K15K015T	384	116	340	55	300	362	158.5	158.5	230
R88M-K11K015T-B	364	116	320	55	266	342	124.5	159.5	196
R88M-K15K015T-B	432	116	388	55	334	410	158.5	193.5	264


Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.


1,500-r/min and 2,000-r/min Servomotors (400 V)

400 W/600 W (without Brake)



400 W/600 W (with Brake)





Model		Dimensions (mm)							
Woder	LL	LM	KB1	KB2					
R88M-K40020	131.5	87.5	56.5	109.5					
R88M-K60020	141	97	66	119					
R88M-K40020□-B□	158.5	114.5	53.5	136.5					
R88M-K60020□-B□	168	124	63	146					

Note. The standard models have a straight shaft. Models with a key and tap are indicated with S2 at the end of the model number.


Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.

1 kW/1.5 kW/2 kW/3 kW (without Brake)

R88M-K1K020F (-S2)/-K1K520F (-S2)/-K2K020F (-S2)/-K3K020F (-S2) R88M-K1K020C (-S2)/-K1K520C (-S2)/-K2K020C (-S2)/-K3K020C (-S2) ABS

1 kW/1.5 kW/2 kW/3 kW (with Brake)

R88M-K1K020F-B (S2)/-K1K520F-B (S2)/-K2K020F-B (S2)/-K3K020F-B (S2) R88M-K1K020C-B (S2)/-K1K520C-B (S2)/-K2K020C-B (S2)/-K3K020C-B (S2)



Model	Dimensions (mm)								
Woder	LL	LR	LM	S	KB1	KB2			
R88M-K1K020	138	55	94	22	60	116			
R88M-K1K520	155.5	55	111.5	22	77.5	133.5			
R88M-K2K020	173	55	129	22	95	151			
R88M-K3K020	208	65	164	24	127	186			
R88M-K1K020□-B□	166	55	122	22	57	144			
R88M-K1K520□-B□	183.5	55	139.5	22	74.5	161.5			
R88M-K2K020□-B□	201	55	157	22	92	179			
R88M-K3K020□-B□	236	65	192	24	127	214			

Note. The standard models have a straight shaft. Models with a key and tap are indicated with S2 at the end of the model number.

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.

4 kW/5 kW (without Brake)


 R88M-K4K020F (-S2)/-K5K020F (-S2)
 INC

 R88M-K4K020C (-S2)/-K5K020C (-S2)
 ABS

4 kW/5 kW (with Brake)

 R88M-K4K020F-B (S2)/-K5K020F-B (S2)
 INC


 R88M-K4K020C-B (S2)/-K5K020C-B (S2)
 ABS



Model	Dimensions (mm)							
Woder	LL	LM	KB1	KB2				
R88M-K4K020	177	133	96	155				
R88M-K5K020	196	152	115	174				
R88M-K4K020□-B□	206	162	96	184				
R88M-K5K020□-B□	225	181	115	203				


Note. The standard models have a straight shaft. Models with a key and tap are indicated with S2 at the end of the model number.

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.




Model		Dimensions (mm)							
Woder	LL	LR	LM	S	KB1	KB2	L1	L2	L3
R88M-K7K515C	312	113	268	42	219	290	117.5	117.5	149
R88M-K7K515C-B	337	113	293	42	253	315	117.5	152.5	183

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.




Model				Dimensions (mm)					
model	LL	LR	LM	S	KB1	KB2	L1	L2	L3
R88M-K11K015C	316	116	272	55	232	294	124.5	124.5	162
R88M-K15K015C	384	116	340	55	300	362	158.5	158.5	230
R88M-K11K015C-B	364	116	320	55	266	342	124.5	159.5	196
R88M-K15K015C-B	432	116	388	55	334	410	158.5	193.5	264

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.



Model	Dimensions (mm)					
Woder	LL	LM	KB2			
R88M-K90010	155.5	111.5	133.5			
R88M-K90010□-B□	183.5	139.5	161.5			

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.




R88M-K2K010T (-S2)/-K3K010T (-S2) ABS

2 kW/3 kW (with Brake)

R88M-K2K010H-B (S2)/-K3K010H-B (S2) INC R88M/-K2K010T-B (S2)/-K3K010T-B (S2) ABS


Motor and brake



Model	Dimensions (mm)							
Model	LL	LM	KB1	KB2				
R88M-K2K010	163.5	119.5	82.5	141.5				
R88M-K3K010	209.5	165.5	128.5	187.5				
R88M-K2K010□-B□	192.5	148.5	82.5	170.5				
R88M-K3K010□-B□	238.5	194.5	128.5	216.5				


Note. The standard models have a straight shaft. Models with a key and tap are indicated with S2 at the end of the model number.

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.




Model	Dimensions (mm)								
	LL	LR	LM	S	KB1	KB2	L1	L2	
R88M-K4K510T	266	113	222	42	185	244	98	98	
R88M-K4K510T-B	291	113	247	42	185	269	98	133	

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.



Model	Dimensions (mm)								
Model	LL	LR	LM	S	KB1	KB2	L1	L2	L3
R88M-K6K010T	312	113	268	42	219	290	117.5	117.5	149
R88M-K6K010T-B	337	113	293	42	253	315	117.5	152.5	183

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.



Model	Dimensions (mm)						
Model	LL	LM	KB1	KB2			
R88M-K90010	155.5	111.5	77.5	133.5			
R88M-K90010□-B□	183.5	139.5	74.5	161.5			

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.

2 kW/3 kW (without Brake)


 R88M-K2K010F (-S2)/-K3K010F (-S2)
 INC

 R88M-K2K010C (-S2)/-K3K010C (-S2)
 ABS

2 kW/3 kW (with Brake)

 R88M-K2K010F-B (S2)/-K3K010F-B (S2)
 INC


 R88M-K2K010C-B (S2)/-K3K010C-B (S2)
 ABS



Model	Dimensions (mm)							
Woder	LL	LM	KB1	KB2				
R88M-K2K010	163.5	119.5	82.5	141.5				
R88M-K3K010	209.5	165.5	128.5	187.5				
R88M-K2K010□-B□	192.5	148.5	82.5	170.5				
R88M-K3K010□-B□	238.5	194.5	128.5	216.5				

Note. The standard models have a straight shaft. Models with a key and tap are indicated with S2 at the end of the model number.

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.




Model	Dimensions (mm)								
Woder	LL	LR	LM	S	KB1	KB2	L1	L2	
R88M-K4K510C	266	113	222	42	185	244	98	98	
R88M-K4K510C-B	291	113	247	42	185	269	98	133	

Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.

2

OMNUC G5-SERIES AC SERVOMOTOR AND SERVO DRIVE USER'S MANUAL




Model	Dimensions (mm)								
	LL	LR	LM	S	KB1	KB2	L1	L2	L3
R88M-K6K010C	312	113	268	42	219	290	117.5	117.5	149
R88M-K6K010C-B	337	113	293	42	253	315	117.5	152.5	183


Models with an oil seal are indicated with O at the end of the model number. The motor dimensions do not change.

External Regeneration Resistor Dimensions


R88A-RR08050S/-RR080100S




R88A-RR22047S1








2-5 EMC Filter Dimensions




Filter model	Ext	ernal dimensi	ons	Mount dimensions		
r mer moder	Н	W	D	M1	M2	
R88A-FIK102-RE	190	42	44	180	20	
R88A-FIK104-RE	190	57	30	180	30	
R88A-FIK107-RE	190	64	35	180	40	
R88A-FIK114-RE	190	86	35	180	60	
R88A-FIK304-RE	190	86	40	180	60	
R88A-FIK306-RE	245	94	40	235	60	
R88A-FIK312-RE	290	130	45	280	100	


2-6 Dimensions of Mounting Brackets (L-Brackets for Rack Mounting)

R88A-TK01K







R88A-TK02K




Bottom Dimensions



R88A-TK03K



R88A-TK04K



3

Specifications

This chapter provides the general specifications, characteristics, connector specifications, and I/O circuits of the Servo Drives as well as the general specifications, characteristics, encoder specifications of the Servomotors and other peripheral devices.

3-1	Servo Drive Specifications	3-1
	General Specifications	
	Characteristics	
	Main Circuit and Motor Connections	
	Control I/O Connector Specifications (CN1)	3-18
	Control Input Circuits	3-28
	Control Input Details	3-32
	Control Output Circuits	
	Control Output Details	
	Encoder Connector Specifications (CN2)	
	External Encoder Connector Specifications (CN4)	
	Analog Monitor Connector Specifications (CN5)	
	USB Connector Specifications (CN7)	
	Safety Connector Specifications (CN8)	
3-2	Overload Characteristics (Electronic Thermal Function	
	Overload Characteristics Graphs	3-58
3-3	Servomotor Specifications	3-59
	General Specifications	3-59
	Characteristics	3-60
	Encoder Specifications	3-96
3-4	Cable and Connector Specifications	3-97
	Encoder Cable Specifications	3-97
	Motor Power Cable Specifications	
	Connector Specifications	3-107
	Analog Monitor Cable Specifications	3-111
	Control Cable Specifications	3-112
3-5	Servo Relay Units and Cable Specifications	3-127
	Servo Relay Units Specifications	3-127
	Position Control Unit-Servo Relay Unit Cable Specifications	
3-6	External Regeneration Resistor Specifications	
	External Regeneration Resistor Specifications	
3-7	EMC Filter Specifications	3-148

Select a Servo Drive that matches the Servomotor to be used. Refer to "Servo Drive and Servomotor Combination Tables" (P.2-11).

The same OMNUC G5-Series AC Servo Drive can be used for either a pulse train input or analog input. You can change the control mode according to the controller. (The default setting is for position control with pulse train commands.)

General Specifications

	Ite	m	Specifications				
terr	bient operat perature an nidity	ing	0 to +55°C, 20 to 85% max. (with no condensation)				
	rage ambier d humidity	nt temperature	-20 to +65°C, 20 to 85% max. (with no condensation) Maximum allowable temperature: 80°C for 72 hours maximum (with no condensation)				
	erating and s nosphere	storage	No corrosive gases				
Vib	ration resist	ance	10 to 60 Hz and at an acceleration of 5.88 m/s ² or less (Not to be run continuously at the resonance point)				
Ins	ulation resis	tance	Between power supply terminals/power terminals and FG terminal: 0.5 $M\Omega$ min. (at 500 VDC)				
Die	Dielectric strength		Between power supply terminals/power line terminals and FG terminal: 1,500 VAC for 1 min at 50/60 Hz				
Pro	tective struc	ture	Built into panel				
	EC Directives	EMC Directive	EN 55011, EN 61000-6-2, IEC 61800-3				
Idard		Low Voltage Directive	EN 61800-5-1				
nternational standard		Machinery Directive	EN954-1 (Category 3), EN ISO 13849-1: 2008 (Category 3) (PLc,d), ISO 13849-1: 2006 (Category 3) (PLc,d), EN61508 (SIL2), EN62061 (SIL2), EN61800-5-2 (STO), IEC61326-3-1 (SIL2)				
ernat	UL standar	ds	UL 508C				
Inte	CSA stand	ards	CSA C22.2 No. 14				
	Korean Ra Regulation		Compliant				

Note 1. The above items reflect individual evaluation testing. The results may differ under compound conditions.

Note 2. Disconnect all connections to the Servo Drive before attempting a megameter test (insulation resistance measurement) on a Servo Drive. Failure to follow this guideline may result in damaging the Servo Drive. Never perform a dielectric strength test on the Servo Drive. Failure to follow this guideline may result in damaging the internal elements.

Note 3. Some Servo Drive parts will require maintenance. For details, refer to "11-5 Periodic Maintenance" (P.11-27).

Characteristics

100-VAC Input Models

	Item		R88D-KTA5L	R88D-KT01L	R88D-KT02L	R88D-KT04L		
Continuous ou	utput current	(rms)	1.2 A	1.7 A	2.5 A	4.6 A		
Input power supply	Main circuit	Power supply capacity	0.4 KVA	0.4 KVA	0.5 KVA	0.9 KVA		
		Power supply voltage	Single-phase 100	to 120 VAC (85 to 1	32 V) 50/60 Hz			
		Rated current	1.7 A	2.6 A	4.3 A	7.6 A		
		Heat value ^{*1}	11 W	16.6 W	21 W	25 W		
	Control circuit	Power supply voltage	Single-phase 100 to 120 VAC (85 to 132 V) 50/60 Hz					
		Heat value ^{*1}	4 W	4 W	4 W	4 W		
Weight			Approx. 0.8 kg	Approx. 0.8 kg	Approx. 1.0 kg	Approx. 1.6 kg		
Maximum app	licable moto	or capacity	50 W	100 W	200 W	400 W		
Applicable Servomotor	3,000 r/ min INC		K05030H	K10030L	K20030L	K40030L		
(R88M-)		ABS	K05030T	K10030S	K20030S	K40030S		
	2,000-r/ min	ABS	_	_	_	_		
	1,000-r/ min	ABS	_	_	_	-		
Performance	Speed con	trol range	1:5000	•	•			
	Speed vari characteris	iation (load stic)	0.01% max. from (0% to 100% (percer	tage of rated speed	d)		
	Speed var (voltage characteris		0% at rated voltage $\pm 10\%$ (percentage of rated speed)					
	Temperatu (temperatu characteris		$\pm 0.01\%$ max. (percentage of rated speed) from 0 to 50°C					
	Torque con repeatabili		±1%					

*1: The heat value is given for rated operation.

3

Specifications

200-VAC Input Models

	Item		R88D- KT01H	R88D- KT02H	R88D- KT04H	R88D- KT08H	R88D- KT10H	R88D- KT15H	
Continuous o	utput currer	nt (rms)	1.2 A	1.6 A	2.6 A	4.1 A	5.9 A	9.4 A	
Input power supply	Main circuit	Power supply capacity	0.5 KVA	0.5 KVA	0.9 KVA	1.3 KVA	1.8 KVA	2.3KVA	
		Power supply voltage	Single-phase or 3-phase 200 to 240 VAC (170 to 264 V) 50/60 Hz						
		Rated current	1.6/0.9 A * ¹	2.4/1.3 A * ¹	4.1/2.4 A * ¹	6.6/3.6 A * ¹	9.1/5.2 A * ¹	14.2/8.1 A *1	
		Heat value ^{*2}	14.3/13.7 W * ¹	23/19 W * ¹	33/24 W * ¹	30/35.5 W *1	57/49 W * ¹	104/93 W *1	
	Control circuit	Power supply voltage	Single-phas	e 200 to 240	VAC (170 to :	264 V) 50/60	Hz	L	
		Heat value ^{*2}	4 W	4 W	4 W	4 W	7 W	7 W	
Weight	I		Approx. 0.8 kg	Approx. 0.8 kg	Approx. 1.0 kg	Approx. 1.6 kg	Approx. 1.8 kg	Approx. 1.8 kg	
Maximum applicable motor capacity			100 W	200 W	400 W	750 W	1 kW	1.5 kW	
Applicable Servomotor	3,000-r/ min		K05030H K10030H	K20030H	K40030H	K75030H	_	K1K030H K1K530H	
(R88M-)		ABS	K05030T K10030T	K20030T	K40030T	K75030T	_	K1K030T K1K530T	
	2,000-r/ min	INC	_	-	-	_	K1K020H	K1K520H	
		ABS	_	-	-	-	K1K020T	K1K520T	
	1,000-r/ min	INC	-	-	-	-	-	K90010H	
		ABS	-	-	-	-	-	K90010T	
Performance	Speed cor	ntrol range	1:5000						
	Speed var characteris	iation (load stic)	0.01% max.	from 0% to 1	00% (percen	tage of rated	speed)		
	Speed var (voltage ch	iation naracteristic)	0% at rated	voltage ±10%	6 (percentage	of rated spe	ed)		
	Temperatu (temperatu characteris		±0.01% max	k. (percentage	e of rated spe	ed) from 0 to	50°C		
	Torque co repeatabili		±1%						

*1. The first value is for single-phase input power and the second value is for 3-phase input power.

*2. The heat value is given for rated operation.

	Item		R88D- KT20H	R88D- KT30H	R88D- KT50H	R88D- KT75H	R88D- KT150H		
Continuous ou	utput curren	t (rms)	13.4 A	18.7 A	33.0 A	44.0 A	66.1 A		
Input power supply	Main circuit	Power supply capacity	3.3 KVA	4.5 KVA	7.5 KVA	11.0 KVA	22.0 KVA		
		Power supply voltage	3-phase 200 to 230 VAC (170 to 253 V) 50/60 Hz ^{*2}						
		Rated current	11.8 A	15.1 A	21.6 A	32.0 A	58.0 A		
		Heat value*1	139 W	108 W	328 W	381 W	720 W		
	Control circuit	Power supply voltage	Single-phase 200 to 230 VAC (170 to 253 V) 50/60 Hz ^{*2}						
		Heat value ^{*1}	10 W	13 W	13 W	15 W	17 W		
Weight	Weight			Approx. 4.8 kg	Approx. 4.8 kg	Approx. 13.5 kg	Approx. 21.0 kg		
Maximum app	Maximum applicable motor capacity			3 kW	5 kW	7.5 kW	15 kW		
Applicable Servomotor (B88M-)	3,000-r/ min	INC	K2K030H	K3K030H	K4K030H K5K030H				
(R88M-)		ABS	K2K030T	K3K030T	K4K030T K5K030T				
	2000-r/ min,	INC	K2K020H	K3K020H	K4K020H K5K020H				
	1500-r/ min	ABS	K2K020T	K3K020T	K4K020T K5K020T	K7K515T	K11K015T K15K015T		
	1,000-r/ min	INC	-	K2K010H	K3K010H				
		ABS	-	K2K010T	K3K010T K4K510T	K6K010T			
Performance	Speed cor	ntrol range	1:5000	•	•	•	•		
	Speed var characteri	iation (load stic)	0.01% max. from 0% to 100% (percentage of rated speed)						
	Speed var characteri	iation (voltage stic)	0% at rated voltage $\pm 10\%$ (percentage of rated speed)						
		ure variation ure characteristic)	$\pm 0.01\%$ max. (percentage of rated speed) from 0 to 50°C						
	Torque co	ntrol repeatability	±2%						

*1. The heat value is given for rated operation.

*2. You can use either an AC power supply or DC power supply with the R88D-KT75H and R88D-KT150H. The DC power supply must be 280 to 325 VDC (238 to 357 VDC).

400-VAC Input Models

Item			R88D-KT06F	R88D-KT10F	R88D-KT15F	R88D-KT20F	
Continuous output current (rms)			1.5 A	2.9 A	4.7 A	6.7 A	
	Main circuit Power supply capacity		1.2 KVA	1.8 KVA	2.3 KVA	3.8 KVA	
		Power supply voltage	3-phase 380 to 4	480 VAC (323 to 5	528 V) 50/60 Hz		
Input power		Rated current	2.1 A	2.8 A	3.9 A	5.9 A	
supply		Heat value*1	32.2 W	48 W	49 W	65 W	
	Control circuit	Power supply voltage	24 VDC (20.4 to	27.6 V)			
		Heat value ^{*1}	7 W	7 W	7 W	10 W	
Weight	1		Approx. 1.9 kg	Approx. 1.9 kg	Approx. 1.9 kg	Approx. 2.7 kg	
Maximum applicable motor capacity		600 W	1 kW	1.5 kW	2 kW		
Applicable Servomotor	3,000-r/min	INC	-	K75030F	K1K030F K1K530F	K2K030F	
(R88M-)		ABS	-	K75030C	K1K030C K1K530C	K2K030C	
	2000-r/min	INC	K40020F K60020F	K1K020F	K1K520F	K2K020F	
		ABS	K40020C K60020C	K1K020C	K1K520C	K2K020C	
	1,000-r/min	INC	_	_	K90010F	_	
		ABS	-	-	K90010C	-	
Performance	Speed control	range	1:5000				
	Speed variation (load characteristic)		0.01% max. from 0% to 100% (percentage of rated speed)				
		Speed variation (voltage characteristic)		0% at rated voltage \pm 10% (percentage of rated speed)			
	Temperature (temperature of		$\pm 0.01\%$ max. (percentage of rated speed) from 0 to 50°C				
	Torque contro	l repeatability	±1%			±2%	

*1. The heat value is given for rated operation.

Item		R88D-KT30F	R88D-KT50F	R88D-KT75F	R88D-KT150F		
Continuous o	utput current (I	rms)	9.4 A	16.5 A	22.0 A	33.4 A	
	Main circuit	Power supply capacity	4.5 KVA	6.0 KVA	11.0 KVA	22.0 KVA	
		Power supply voltage	3-phase 380 to	480 VAC (323 to 5	528 V) 50/60 Hz		
Input power		Rated current	7.6 A	12.1 A	16.0 A	29.0 A	
supply		Heat value*1	108 W	200 W	300 W	590 W	
	Control circuit	Power supply voltage	24 VDC (20.4 to	27.6 V)			
		Heat value*1	13 W	13 W	15 W	22 W	
Weight			Approx. 4.7 kg	Approx. 4.7 kg	Approx. 13.5 kg	Approx. 21.0 kg	
Maximum app	olicable motor	capacity	3 kW	5 kW	7.5 kW	15 kW	
Applicable Servomotor	3,000-r/min	INC	K3K030F	K4K030F K5K030F			
(R88M-)		ABS	K3K030C	K4K030C K5K030C			
	2000-r/min, 1500-r/min	INC	K3K020F	K4K020F K5K020F			
		ABS	K3K020C	K4K020C K5K020C	K7K515C	K11K015C K15K015C	
	1,000-r/min	INC	K2K010F	K3K010F			
		ABS	K2K010C	K3K010C K4K510C	K6K010C		
Performance	Speed control	range	1:5000				
	Speed variation (load characteristic)		0.01% max. from 0% to 100% (percentage of rated speed)				
	Speed variation characteristic)	Speed variation (voltage characteristic)		0% at rated voltage \pm 10% (percentage of rated speed)			
	Temperature (temperature d		$\pm 0.01\%$ max. (percentage of rated speed) from 0 to 50°C				
	Torque contro	l repeatability	±2%	±2%			

*1. The heat value is given for rated operation.

Protective Functions

Error detected	Description
Control power supply undervoltage	The DC voltage of the control power supply fell below the specified value.
Overvoltage	The DC voltage of the main circuit exceeded the specified value.
Main power supply undervoltage	The DC voltage of the main circuit is low.
Overcurrent	Overcurrent flowed to the IGBT. Motor power line ground fault or short circuit.
Servo Drive overheat	The temperature of the drive radiator exceeded the specified value.
Overload	Operation was performed with torque significantly exceeding the rating for several seconds to several tens of seconds.
Regeneration overload	The regenerative energy exceeded the regeneration absorption capacity of the Regeneration Resistor.
Encoder communications error	The encoder wiring is disconnected.
Encoder communications data error	Communications cannot be performed between the encoder and the drive.
Error counter overflow	The number of accumulated pulses in the error counter exceeded the set value for the Error Counter Overflow Level (Pn014).
Excessive hybrid error	During fully-closed control, difference between position of load from external encoder and position of motor due to encoder was larger than the number of pulses set by Internal/External Feedback Pulse Error Counter Overflow Level (Pn328).
Overspeed	The motor rotation speed exceeded the maximum number of rotations.
Electronic gear setting error	The set value for the Electronic Gear Ratio (Pn009 to Pn010, Pn500 to Pn503) is not appropriate.
Error counter overflow	Error counter value based on the encoder pulse reference exceeded 2 ²⁹ (536870912).
Interface I/O setting error	An error was detected in the interface I/O signal.
Overrun limit error	The motor exceeded the allowable operating range set in the Overrun Limit Setting (Pn514) with respect to the position command input.
Parameter error	Data in the Parameter Save area was corrupted when the power supply was turned ON and data was read from the EEPROM.
Parameters destruction	The checksum for the data read from the EEPROM when the power supply was turned ON does not match.
Drive prohibition input error	The forward drive prohibition and reverse drive prohibition inputs are both turned OFF.
Excessive analog input	A current exceeding the Excessive Analog Input (Pn424, Pn427 or Pn430) was applied to the analog command input (pin 14).
Absolute encoder system down error ABS	The voltage supplied to the absolute encoder is lower than the specified value.
Absolute encoder counter overflow error ABS	The multi-rotation counter of the absolute encoder exceeds the specified value.
Absolute encoder overspeed error ABS	The motor rotation speed exceeds the specified value when only the battery power supply of the absolute encoder is used.
Absolute encoder 1-rotation counter	A 1-turn counter error was detected.
error ABS	
Absolute encoder multi-rotation counter	A multi-rotation counter error or phase-AB signal error was detected.
error ABS	

Error detected	Description
Absolute encoder status error ABS	The rotation of the absolute encoder is higher than the specified value.
Encoder phase-Z error	A phase Z pulse was not detected regularly.
Encoder CS signal error	A logic error was detected in the CS signal.
External encoder communications error	An error was detected in external encoder connection and communications data.
External encoder status error	An external encoder alarm code was detected.
Phases-A, B and Z connection error	An error was generated for connection of phases A, B, and Z of external encoder.
Motor non-conformity	The combination of the Servomotor and Servo Drive is not appropriate.

Main Circuit and Motor Connections

When wiring the main circuit, use proper wire sizes, grounding systems, and noise resistance.

R88D-KTA5L/-KT01L/-KT02L/-KT04L R88D-KT01H/KT02H/-KT04H/-KT08H/-KT10H/-KT15H

Main Circuit Connector Specifications (CNA)

Symbol	Name	Function
L1	Main circuit power	R88D-KT□L
L2	supply input	(50 to 400 W) : Single-phase 100 to 120 VAC (85 to 132 V) 50/60 Hz R88D-KT□H
		(100 W to 1.5 kW) : Single-phase: 200 to 240 VAC (170 to 264 V) 50/ 60 Hz
L3		(100 W to 1.5 kW) : 3-phase: 200 to 240 VAC (170 to 264 V) 50/60 Hz
		Note. Single-phase should connect to L1 and L3.
L1C	Control circuit power	R88D-KT L : Single-phase 100 to 120 VAC (85 to 132 V) 50/60 Hz
L2C	supply input	R88D-KT H : Single-phase 200 to 240 VAC (170 to 264 V) 50/60 Hz

Motor Connector Specifications (CNB)

Symbol	Name		Function	
B1			5L/-KT01L/-KT02L/-KT01H/-KT02H/-KT04H:	
B3		Normally, do not short B1 and B2. Doing so may cause malfunctions. If there is high regenerative energy, connect an External		
B2	External Regeneration Resistor connection terminals	Regeneration Resistor between B1 and B2. R88D-KT04L/-KT08H/-KT10H/-KT15H: Normally B2 and B3 are shorted. Do not short B1 and B2. Doing so may cause malfunctions. If there is high regenerative energy, remove the short-circuit bar between B2 and B3 and connect an External Regeneration Resistor between B1 and B2.		
U	Motor connection	Phase U	These are the output terminals to the Servomotor.	
V	terminals	Phase V	Be sure to wire them correctly.	
W		Phase W		

Precautions for Correct Use

• Tighten the ground screws to the torque of 0.7 to 0.8 N•m (M4) or 1.4 to 1.6 N•m (M5).

R88D-KT20H

Main Circuit Connector Specifications (CNA)

Symbol	Name	Function
L1	Main circuit power	R88D-KT⊡H (2 kW) :
L2	supply input	3-phase: 200 to 230 VAC (170 to 253 V) 50/60 Hz
L3		
L1C	Control circuit power	R88D-KT H : Single-phase 200 to 230 VAC (170 to 253 V) 50/60
L2C	supply input	Hz

Motor Connector Specifications (CNB)

Symbol	Name		Function
U	Motor connection	Phase U	These are the output terminals to the Servomotor.
V	terminals	Phase V	Be sure to wire them correctly.
W		Phase W	

External Regeneration Resistor Connector Specifications (CNC)

Symbol	Name	Function		
B1	External Regeneration Resistor connection	Normally B2 and B3 are shorted. Do not short B1 and B2. Doing so may cause malfunctions.		
B3	terminals	If there is high regenerative energy, remove the short-circuit bar between B2 and B3 and connect an External Regeneration Resistor between B1 and B2.		
B2				
NC	Do not connect.			

Precautions for Correct Use

• Tighten the ground screws to the torque of 0.7 to 0.8 N•m (M4) or 1.4 to 1.6 N•m (M5).

• Never connect an External Regeneration Resistor between the B1 and NC terminals.

R88D-KT30H/R88D-KT50H

Main Circuit Terminal Block Specifications

Symbol	Name		Function		
L1	Main circuit power		R88D-KT⊡H (3 to 5 kW):		
L2	supply input	3-phase 200 to 230 VAC (170 to 253 V) 50/60 Hz	00 to 230 VAC (170 to 253 V) 50/60 Hz		
L3					
L1C	Control circuit power		H : Single-phase 200 to 230 VAC (170 to 253 V) 50/60		
L2C	supply input	Hz			
B1	External Regeneration	Normally B2 and B3 are connected. Do not short B1 and B2. Doing			
B3	Resistor connection	so may cause malfunctions. If there is high regenerative energy, remove the short-circuit bar between B2 and B3 and connect an			
B2	terminals	External R	egeneration Resistor between B1 and B2.		
NC	Do not connect.				
U	Motor connection	Phase U	These are the output terminals to the Servomotor.		
V	terminals	Phase V	Be sure to wire them correctly.		
W		Phase W			

- Tighten the terminal block screws to the torque of 0.75 N•m (M4) or 1.5 N•m (M5).
- If the torque for terminal block screws exceeds 1.2 N•m (M4) or 2.0 N•m (M5), the terminal block may be damaged.
- Tighten the fixing screw of the terminal block cover to the torque of 0.2 N•m (M3).
- \bullet Tighten the ground screws to the torque of 0.7 to 0.8 N•m (M4) or 1.4 to 1.6 N•m (M5).
- Never connect an External Regeneration Resistor between the B1 and NC terminals.

R88D-KT75H

Terminal Block Specifications, Left Terminal Block (TB1)

Symbol	Name	Function
L1		R88D-KT□H (7.5 kW): 3-phase 200 to 230 VAC (170 to 253 V) 50/
L2	Main circuit power supply input	60 Hz
L3		280 to 325 VDC (238 to 357 VDC)
B1	External Regeneration	Connect an External Regeneration Resistor between B1 and B2.
B2	Resistor connection terminals	
N (NC)	terminals	
U		These are the output terminals to the Servomotor.
V	Motor connection terminals	Be sure to wire them correctly.
W		
÷		

Terminal Block Specifications, Right Terminal Block (TB2)

Symbol	Name	Function
L1C	Control circuit power	R88D-KT H: Single-phase 200 to 230 VAC (170 to 253 V) 50/60
L2C	supply input	Hz 280 to 325 VDC (238 to 357 VDC)
DB1	Dynamic brake	These terminals are used to control the MC for externally connected
DB2	resistance control terminals	dynamic brake resistance. The output contact specifications are 1 A max. at 300 VAC/100 VDC max. Connect them if required.
DB3		Normally DB3 and DB4 are connected. When using an externally
DB4		connected Dynamic Brake Resistor, remove the short bar from between DB3 and DB4.
Ē	Frame ground	This is the ground terminal. Ground to 100 Ω or less.



- Tighten the terminal block screws to the torque of 1.5 N•m (M5).
- If the torque for terminal block screws exceeds 2.0 N•m (M5), the terminal block may be damaged.
- Tighten the fixing screw of the terminal block cover to the torque of 0.2 N•m (M3).
- Tighten the ground screws to the torque of 1.4 to 1.6 N•m (M5).
- Never connect an External Regeneration Resistor between the B1 and N (NC) terminals

R88D-KT150H

Terminal Block Specifications, Top Terminal Block (TB1)

Symbol	Name	Function
L1C	Control circuit power	R88D-KT□H: Single-phase 200 to 230 VAC (170 to 253 V) 50/60
L2C	supply input	Hz 280 to 325 VDC (238 to 357 VDC)
DB1	Dynamic brake	These terminals are used to control the MC for externally connected
DB2	resistance control terminals	dynamic brake resistance. The output contact specifications are 1 A max. at 300 VAC/100 VDC max. Connect them if required.

Terminal Block Specifications, Bottom Terminal Block (TB2)

Symbol	Name	Function
L1		R88D-KT□H (15 kW): 3-phase 200 to 230 VAC (170 to 253 V) 50/ 60 Hz
L2	Main circuit power supply input	
L3		280 to 325 VDC (238 to 357 VDC)
B1	External Regeneration	Connect an External Regeneration Resistor between B1 and B2.
B2	Resistor connection terminals	
N (NC)		
U		These are the output terminals to the Servomotor.
V	Motor connection	Be sure to wire them correctly.
W	terminals	
(±		
÷	Frame ground	This is the ground terminal. Ground to 100 Ω or less.

- Tighten the terminal block screws to the torque of 1.5 N•m (M5) or 2.5 N•m (M6).
- If the torque for terminal block screws exceeds 2.0 N•m (M5) or 3.0 N•m (M6), the terminal block may be damaged.
- Tighten the fixing screw of the terminal block cover to the torque of 0.4 N•m (M5).
- Tighten the ground screws to the torque of 2.4 to 2.6 N•m (M6).
- Never connect an External Regeneration Resistor between the B1 and N (NC) terminals

R88D-KT06F/R88D-KT10F/R88D-KT15F/R88D-KT20F

Main Circuit Connector Specifications (CNA)

Symbol	Name	Function
L1	Main circuit power	
L2	supply input	(600 W to 2 kW) : 3-phase: 380 to 480 VAC (323 to 528 V) 50/60 Hz
L3		

Motor Connector Specifications (CNB)

Symbol	Name	Function		
U	Motor connection	Phase U	These are the output terminals to the Servomotor.	
V	terminals	Phase V	Be sure to wire them correctly.	
W		Phase W		

Control Circuit Connector Specifications (CNC)

Symbol	Name	Function	
24 V	Control circuit power	24 VDC ± 15%	
0 V	supply input		

External Regeneration Resistor Connector Specifications (CND)

Symbol	Name	Function
B1	External Regeneration Resistor connection	Normally B2 and B3 are connected. Do not short B1 and B2. Doing so may cause malfunctions.
B3	terminals	If there is high regenerative energy, remove the short-circuit bar
B2		between B2 and B3 and connect an External Regeneration Resistor between B1 and B2.
NC	Do not connect.	·

Precautions for Correct Use

- Tighten the ground screws to the torque of 0.7 to 0.8 N•m (M4) or 1.4 to 1.6 N•m (M5).
- Never connect an External Regeneration Resistor between the B1 and NC terminals.


R88D-KT30F/R88D-KT50F

Main Circuit Terminal Block Specifications (TB1)

Symbol	Name	Function		
24 V	Control circuit power	24 VDC ± 15%		
0 V	supply input			

Main Circuit Terminal Block Specifications (TB2)

Symbol	Name	Function		
L1	Main circuit power supply	R88D-KT⊡F (3 to 5 kW): 3-phase 380 to 480 VAC (323 to 528 V) 50/60 Hz		
L2	input			
L3				
B1	External Regeneration	Normally B2 and B3 are connected. Do not short B1 and B2. Doing so may cause malfunctions. If there is high regenerative energy, remove the short-circuit bar between B2 and B3 and connect an External Regeneration Resistor between B1 and B2.		
B3	Resistor connection			
B2	terminals			
NC	Do not connect.			
U	Motor connection	Phase U	These are the output terminals to the Servomotor.	
V	terminals	Phase V	Be sure to wire them correctly.	
W]	Phase W		



- Tighten the terminal block screws to the torque of 0.75 N•m (M4) or 1.5 N•m (M5).
- If the torque for terminal block screws exceeds 1.2 N•m (M4) or 2.0 N•m (M5), the terminal block may be damaged.
- Tighten the fixing screw of the terminal block cover to the torque of 0.2 N•m (M3).
- \bullet Tighten the ground screws to the torque of 0.7 to 0.8 N•m (M4) or 1.4 to 1.6 N•m (M5).
- Never connect an External Regeneration Resistor between the B1 and NC terminals.

R88D-KT75F

Terminal Block Specifications, Left Terminal Block (TB1)

Symbol	Name	Function		
L1		R88D-KT□F (7.5 kW): 3-phase 380 to 480 VAC (323 to 528 V) 50/ 60 Hz		
L2	Main circuit power supply input			
L3				
B1	External Regeneration Resistor connection	Connect an External Regeneration Resistor between B1 and B2.		
B2	terminals			
NC	Do not connect.	·		
U		Red	These are the output terminals to the Servomotor.	
V	Motor connection	White	Be sure to wire them correctly.	
W	terminals	Blue		
		Green/ Yellow		

Terminal Block Specifications, Right Terminal Block (TB2)

Symbol	Name	Function
24 V	Control circuit power	24 VDC±15%
0 V	supply input	
DB1	Dynamic brake resistance control terminals	These terminals are used to control the MC for externally connected dynamic brake resistance. The output contact specifications are 1 A max. at 300 VAC/100 VDC max. Connect them if required.
DB2	control terminals	
DB3		Normally DB3 and DB4 are connected. When using an externally
DB4		connected Dynamic Brake Resistor, remove the short bar from between DB3 and DB4.
(=)	Frame ground	This is the ground terminal. Ground to 10 Ω or less.



- Tighten the terminal block screws to the torque of 1.5 N•m (M5).
- If the torque for terminal block screws exceeds 2.0 N•m (M5), the terminal block may be damaged.
- Tighten the fixing screw of the terminal block cover to the torque of 0.2 N•m (M3).
- Tighten the ground screws to the torque of 1.4 to 1.6 N•m (M5).
- Never connect an External Regeneration Resistor between the B1 and NC terminals

R88D-KT150F


Terminal Block Specifications, Top Terminal Block (TB1)

Symbol	Name	Function
24 V	Control circuit power	24 VDC±15%
0 V	supply input	
DB1		These terminals are used to control the MC for externally
DB2	Dynamic brake resistance control terminals	connected dynamic brake resistance. The output contact specifications are 1 A max. at 300 VAC/100 VDC max. Connect them if required.

Terminal Block Specifications, Bottom Terminal Block (TB2)

Symbol	Name	Function		
L1				
L2	Main circuit power supply input	н88D-к 60 Hz	R88D-KT□F (15 kW): 3-phase 380 to 480 VAC (323 to 528 V) 50/ 60 Hz	
L3				
B1	External Regeneration	Connect	Connect an External Regeneration Resistor between B1 and B2.	
B2	Resistor connection terminals			
NC	Do not connect.			
U		Red	These are the output terminals to the Servomotor.	
V	Motor connection	White	Be sure to wire them correctly.	
W	terminals	Blue		
÷		Green/ Yellow		
	Frame ground	This is the ground terminal. Ground to 10 Ω or less.		

- Tighten the terminal block screws to the torque of 1.5 N•m (M5) or 2.5 N•m (M6).
- If the torque for terminal block screws exceeds 2.0 N•m (M5) or 3.0 N•m (M6), the terminal block may be damaged.
- Tighten the fixing screw of the terminal block cover to the torque of 0.4 N•m (M5).
- Tighten the ground screws to the torque of 2.4 to 2.6 N•m (M6).
- Never connect an External Regeneration Resistor between the B1 and NC terminals




Control I/O Signal Connections and External Signal Processing for Position Control

Control I/O Connector Specifications (CN1)

*1. A cable equipped with a battery is not required if a backup battery is connected.

- Note 1. The inputs of pins 8, 9 and 26 to 33, and outputs of pins 10, 11, 34, 35, 38 and 39, can be changed via parameter settings.
- Note 2. Pins 13, 20, 42 and 43 represent signals which are applicable when an absolute encoder is used.
- Note 3. If pins 21, 22, 49, 48, 23, and 24 are used for the encoder output, use pin 25 (ZGND) to wire the ground.
- Note 4. It is not necessary to wire input pins that are not being used.




Control I/O Signal Connections and External Signal Processing for Speed Control

*1. A cable equipped with a battery is not required if a backup battery is connected.

- Note 1. The inputs of pins 8, 9 and 26 to 33, and outputs of pins 10, 11, 34, 35, 38 and 39, can be changed via parameter settings.
- Note 2. Pins 13, 20, 42 and 43 represent signals which are applicable when an absolute encoder is used.
- Note 3. If pins 21, 22, 49, 48, 23, and 24 are used for the encoder output, use pin 25 (ZGND) to wire the ground.
- Note 4. It is not necessary to wire input pins that are not being used.

Specifications



Control I/O Signal Connections and External Signal Processing for Torque Control

*1. A cable equipped with a battery is not required if a backup battery is connected.

Note 1. The inputs of pins 8, 9 and 26 to 33, and outputs of pins 10, 11, 34, 35, 38 and 39, can be changed via parameter settings.

Note 2. Pins 13, 20, 42 and 43 represent signals which are applicable when an absolute encoder is used.

Note 3. If pins 21, 22, 49, 48, 23, and 24 are used for the encoder output, use pin 25 (ZGND) to wire the ground.

Note 4. It is not necessary to wire input pins that are not being used.

3

Specifications

Control I/O Signal List

CN1 Control Inputs

D'a				Control mode				
Pin number	Symbol	Name	Function and interface	Position	Speed	Torque	Fully- closed	
1	+24VCW	24-V open-collector input for command	Input terminals for position command					
2	+24VCCW	Reverse pulse, feed pulse, or 90° phase difference signal (phase A)	pulses for both line driver and open collector.					
3	+CW/ +PULS/+FA		Changes to enable (set value: 0 <default setting>) according to the setting of Command Pulse Input Selection</default 					
4	-CW/-PULS/ -FA		(Pn005).	\checkmark			\checkmark	
5	+CCW/ +SIGN/+FB	Forward pulse, direction signal, or 90°						
6	-CCW/-SIGN/ -FB	phase difference signal (phase B)						
44	+CWLD	Reverse pulse (input for	Input terminals for position command	\checkmark				
45	-CWLD	line driver only)	pulses dedicated to the line-driver output.					
46	+CCWLD	Forward pulse (input for line driver only)	Changes to enable (set value: 1) according to the setting of Command				v	
47	-CCWLD		Pulse Input Selection (Pn005).					
20	SEN	Sensor ON Input	This performs serial transmission of multi-rotation data of the absolute encoder and also outputs 1-rotation data as the initial incremental pulses. This input is enabled by setting the Operation Switch when Using Absolute Encoder (Pn015) to 0 or 2.	V	V	V		
13	SENGND	Signal ground	This is a sensor ON signal ground.					
42	BAT	Backup battery input ABS	These are the backup battery connection terminals used when the absolute encoder power is interrupted. (Connection to this terminal is not necessary if you use the absolute encoder battery cable for backup.)	V	V	V	V	
	REF	Speed command input	This is an analog input terminal for speed command. Use the Speed Command Scale (Pn302) to change the rotation speed scale for the command input.					
14	TREF1	Torque command input 1	Provides a torque command input (set value: 0 or 2) according to the setting of Torque Command/Speed Limit Selection (Pn317). Use the Torque Command Scale (Pn319) to change the rotation speed scale for the command input.			V		

Pin		Name	Function and interface	Control mode				
number	Symbol			Position	Speed	Torque	Fully- closed	
14	VLIM	Speed limit input	Provides a speed limit input (set value: 1) according to the setting of Torque Command/Speed Limit Selection (Pn317). Use the Speed Command Scale (Pn302) to change the limit speed scale for the analog input.			1		
15	AGND1	Analog ground 1	This is an analog signal ground.					
	PCL	Forward torque limit input	Provides a forward torque limit input (set value: 0 or 4) or forward/reverse torque limit input (set value: 5) according to the setting of Torque Limit Selection (Pn521).					
16	TREF2	Torque command input 2	Provides a torque command input (set value: 1) according to the setting of Torque Command/Speed Limit Selection (Pn317). Use the Torque Command Scale (Pn319) to change the rotation speed scale for the command input.			1		
17	AGND1	Analog ground 1	This is an analog signal ground.					
18	NCL	Reverse torque limit input	Provides a reverse torque limit input (set value: 0 or 4) according to the setting of Torque Limit Selection (Pn521).	\checkmark	\checkmark			
7	+24VIN	12 to 24-VDC power supply input	The positive input terminal of the external power supply (12 to 24 VDC) for sequence inputs	\checkmark	\checkmark	\checkmark		
	SI1 to SI10	Sequence input signal	These allocate the following function and settings of Input Signal Selection 1 to 10				ie	
	NOT [8]	Reverse drive prohibition input	This performs the drive prohibition input in the reverse direction. Changes to enable (set value: 0 or 2) according to the setting of Drive Prohibition Input Selection (Pn504).			\checkmark	\checkmark	
	POT [9]	Forward drive prohibition input	This performs the drive prohibition input in the forward direction. Changes to enable (set value: 0 or 2) according to the setting of Drive Prohibition Input Selection (Pn504).	\checkmark	\checkmark	V	\checkmark	
8, 9, 26 to 33	DFSEL1 [26]	Damping filter switching 1	Changes to enable (set value: 1 or 2) according to the setting of Damping Filter Selection (Pn213). If the set value of Damping Filter Selection (Pn213) is 2, switching between 4 settings is possible by combining this with the damping filter switching input 2 (DFSEL2).	\checkmark			\checkmark	

Dia		Name	Function and interface	Control mode				
Pin number	Symbol			Position	Speed	Torque	Fully- closed	
	GSEL [27]	Gain switching	This changes to enable (set value: 2) according to the setting of the Gain Switching Mode (Pn115 for position control, Pn120 for speed control, or Pn124 for torque control). When the signal is OFF and ON, gain 1 and gain 2 change to enable, respectively.	\checkmark	\checkmark	\checkmark	~	
	GESEL1 [28]	Electronic gear switching 1	Switches the numerator for electronic gear ratio. You can switch maximum 4 electronic gear ratio numerators by combining with electronic gear switching input 2 (GESEL2).	V			V	
	RUN [29]	Operation command input	This turns ON the servo (motor power supply starts).	\checkmark	\checkmark	\checkmark	\checkmark	
	ECRST [30]	Error counter reset input	Resets the position error counter. An edge (set value: 0) or level (set value: 1) can be selected according to the setting of Error Counter Reset Condition Selection (Pn517).	V				
	RESET [31]	Alarm reset input	Release the alarm status. The error counter is reset when the alarm is reset. Some alarms cannot be reset with this input.					
	TVSEL [32]	Control mode switching input	This signal switches the control mode for Servo Drive. Changes to enable (set value: 3 to 5) according to the setting of Control Mode Selection (Pn001).	V	V	V		
	IPG [33]	Pulse prohibition input	Prohibits the position command pulse. Changes to enable (set value: 0) according to the setting of Command Pulse Prohibition Input Setting (Pn518).	\checkmark				
	VSEL1 [33]	Internally set speed selection 1	Use this input to select a desired Speed Setting (Pn304 to 311) during the					
	VSEL2 [30]	Internally set speed selection 2	internally set speed operation.		\checkmark			
	VSEL3 [28]	Internally set speed selection 3						
	TLSEL	Torque limit switching	Switches the torque limit value via ON/ OFF. Changes to enable (set value: 3 or 6) according to the setting of Torque Limit Selection (Pn521). The torque limit value and operating direction vary according to the set value.				1	
8, 9, 26 to 33	DFSEL2	Damping filter switching 2	Changes to enable (set value: 2) according to the setting of Damping Filter Selection (Pn213). Switching between 4 settings is possible by combining this with the damping filter switching input 1 (DFSEL1).	\checkmark			1	

Pin		Name	Function and interface	Control mode				
number	Symbol			Position	Speed	Torque	Fully- closed	
	GESEL2	Electronic gear switching 2	You can switch maximum 4 electronic gear ratio numerators by combining with electronic gear switching input 1 (GESEL1).					
	VZERO	Zero speed designation input	This signal forcibly sets the speed command to 0. Changes to enable (set value: 1 to 3) according to the setting of Zero Speed Designation Selection (Pn315).			\checkmark		
	VSIGN	Speed command sign input	Designates the motor rotation direction for speed commands. Changes to enable (set value: 1) according to the setting of Speed Command Direction Selection (Pn301).					
	TSIGN	Torque command sign input	This signal designates the motor rotation direction for torque commands. Changes to enable (set value: 1) according to the setting of Torque Command Direction Selection (Pn318).			\checkmark	\checkmark	
8, 9, 26 to 33	STOP	Emergency stop input	This is an emergency stop input. When input, this becomes an emergency stop input error and thereby stop the motor.		\checkmark	\checkmark		
	JSEL	Inertia ratio switching input	This signal switches between inertia ratio 1 and inertia ratio 2.	\checkmark	\checkmark		\checkmark	

• Be cautious that allocatable pin numbers are fixed for the following functions. Error counter reset input (ECRST): Pin 30 only Command pulse input prohibition input (IPG): Pin 33 only

• The number in brackets indicates the pin number (allocation) at default setting. (The allocations vary according to the control mode.)

CN1 Control Outputs

Pin					Contro	l mode	•
number	Symbol	Name	Function and interface	Position	Speed	Torque	Fully- closed
21	+A	Encoder phase A +output	Encoder signals (or external encoder signals during fully-closed control) are output according to the setting of Encoder Dividing Numerator (Pn011). This is the line-driver output (equivalent to RS-422). The maximum output frequency is 4 Mpps. Phase Z is output for encoder signals (or external encoder signals during fully- closed control). This is the line-driver output (equivalent to RS-422).				
22	-A	Encoder phase A - output					
49	+B	Encoder phase B +output		\checkmark	\checkmark	V	N
48	-В	Encoder phase B - output					,
23	+Z	Encoder phase Z +output					
24	-Z	Encoder phase Z - output					

Pin		Name	Function and interface	Control mode				
number	Symbol			Position	Speed	Torque	Fully- closed	
19 25	Z ZGND	Encoder phase-Z output Encoder phase-Z output common	Phase Z is output for encoder signals (or external encoder signals during fully- closed control). Open-collector output	\checkmark	\checkmark	\checkmark	\checkmark	
	SO1 to SO4	Sequence output signal	These signals allocate the following funct settings of Output Signal Selections 1 to					
	BKIR [11] BKIRCOM [10]	Brake interlock output	Outputs the timing signal for operating the electromagnetic brake on a motor.					
	READY [35] READYCO M [34]	Servo ready completed	This output signal indicates the Drive is ready to be energized. It is turned ON when the control and main power supply is established and not in alarm status.	\checkmark	\checkmark	\checkmark	\checkmark	
	/ALM [37] ALMCOM [36]	Servo alarm	The output is OFF when an alarm is generated for the Servo Drive.	V	V	V		
	INP1 [39]	Positioning completion output 1	If the position error is equal to	V				
	INP1COM [38]		Positioning Completion Range 1 (Pn431) or less, this output turns ON according to the setting condition of Positioning Completion Condition Selection (Pn432).				\checkmark	
	TGON [39] TGONCOM [38]	Motor rotation speed detection output	This output turns ON when the motor rotation speed reaches the speed set in Rotation Speed for Motor Rotation Detection (Pn436).		V	V		
	TLIMT TLIMTCOM	Torque limit output	This output turns ON while the torque is limited.	\checkmark				
	ZSP ZSPCOM	Zero speed detection signal	This output turns ON when the motor rotation speed is equal to Zero Speed Detection (Pn434) or less.		V	V		
	VCMP VCMPCOM	Speed conformity output	This output turns ON when the command speed corresponds to the motor rotation speed. This output turns ON when the difference between the command speed and motor rotation speed is inside the setting range of Speed Conformity Detection Width (Pn435).		√	1		
	INP2	Positioning completion	If the position error is equal to					
10, 11, 34 to 39	INP2COM	output 2	Positioning Completion Range 2 (Pn442) or less, this output turns ON according to the setting condition of Positioning Completion Condition Selection (Pn432).	\checkmark			\checkmark	
	WARN1 WARN1COM	Warning output 1	This output turns ON according to the setting condition of Warning Output Selection 1 (Pn440).	\checkmark	\checkmark	\checkmark	\checkmark	

Pin				Control mode			
number	Symbol	Name	Function and interface	Position	Speed	Torque	Fully- closed
	WARN2	Warning output 2	This output turns ON according to the				
	WARN2COM		setting condition of Warning Output Selection 1 (Pn440).			V	N
	P-CMD	Position command	This output turns ON when a positioning				
	P-	status output	command is input.				\checkmark
	CMDCOM						
	V-LIMIT	Speed limiting output	This turns ON during torque control or				
	V-		speed limit status.				
	LIMITCOM						
	ALM-ATB	Alarm clear attribute	This output turns ON when an alarm				
39	ALM- ATBCOM	output	occurs or the alarm can be cleared.	\checkmark	\checkmark	\checkmark	\checkmark
34 to 39		0					
, so	V-CMD	Speed command status output	This output turns ON during speed control or when a speed command is		1		
10, 11,	V-		input.		V		
10	CMDCOM						

• You cannot change the allocation for servo alarm output (/ALM). (The allocation is fixed.)

• The number in brackets indicates the pin number (allocation) at default setting. (The allocations vary according to the control mode.)

CN1 Pin Arrangement

					24-V	1					1
		24-V open-collector	1	PCOM	open-collector input for command pulse	07	SI4	General-purpose	26	SI3 ^{*2}	General-purpose input 3 ¹²
2	PCOM	input for command pulse	3	+CW/ +PULS/+FA	Reverse pulses, feed pulses, or 90°	27	(GSEL)	input 4 (gain switching)	28	SI5 ^{°2}	General-purpose
4	–CW/ –PULS/–FA	Reverse pulses, feed pulses, or 90° phase difference		+PULS/+PA	phase difference signal (phase A) Forward pulse.	29	SI6	General-purpose input 6 (operation			input 5*2
		signal (phase A) Forward pulse,	5	+CCW/ +SIGN/+FB	direction signal, or 90°phase difference		(RUN)	command) General-purpose	30	SI7 ^{*2}	General-purpose input 7*2
6	-CCW/ -SIGN/-FB	direction signal, or 90 ^a phase difference signal (phase B)		+24VIN	signal (phase B) 12 to 24-VDC	31	SI8 (RESET)	input 8 (alarm reset input)		SI9	General-purpose
8	SI1	General-purpose input 1 (reverse drive	7	+24 V IIN	power supply input	33	SI10 ¹²	General-purpose	32	(TVSEL)	input 9 (control mode switching)
	(NOT)	prohibition input)	9	SI2 (POT)	General-purpose input 2 (forward drive			input10 ⁺²	34	SO2COM	General-purpose output 2
10	SO1COM	General-purpose output 1		(-)	prohibition input) General-purpose	35	SO2 (READY)	General-purpose output 2 (servo ready completed output)			common Alarm output
		common	11	SO1 (BKIR)	input 1 (brake interlock output)		(READT)	Alarm output	36	ALMCOM [SO3COM]	common [general-purpose output 3 common]
12		*1	13	SENGND	Signal ground	37	[SO3]	[general-purpose output 3]	38	SO4COM	General-purpose output 4
14	REF/TREF1/ VLIM	Speed command input, torque command input 1.		DENGIND		39	SO4 ^{*2}	General-purpose output 4 ^{*2}			common
		speed limit input Forward torque limit input,	15	AGND1	Analog ground 1				40		"
16	PCL/TREF2	torque command input 2	17	AGND2	Analog	41		"1	42	BAT	Absolute encoder backup
18	NCL	Reverse torque limit input			ground 2	43	BATGND	Absolute encoder backup			battery input Reverse pulse
		Sensor ON	19	z	Phase-Z output (open collector)			battery input Reverse pulse	44	+CWLD	(input for line driver only)
20	SEN	undefined	21	+ A	Encoder	45	-CWLD	(input for line driver only)	46	+CCWLD	Forward pulse (input for line
22	-A	Encoder phase A-output		+A	phase A+output	47	-CCWLD	Forward pulse (input for line	-0	TOOMED	driver only)
			23	+Z	Encoder phase Z+output			driver only)	48	-В	Encoder phase B-output
24	-Z	Encoder phase Z-output	25	ZGND	Phase-Z (open collector)	49	+B	Encoder phase B+output	50		*1
				Laite	common						

Note.Do not connect anything to unused pins (*1).

For general-purpose inputs 1 to 10 (SI1 to 10) and general-purpose outputs (SO1, SO2 and SO4), use user parameters Pn400 to Pn409 (Input Signal Selections 1 to 10) and Pn410 to Pn413 (Output Signal Selections 1 to 4) to set the function allocations.

The alarm output (/ALM) is fixed to general-purpose output 3. This is indicated with square brackets in the above figure.

The function that is allocated by default is given in parentheses. "*2" indicates terminals that have different default functions depending on the control mode.

Refer to "6-9 Sequence I/O Signal" (P.6-35) for details on allocations.


To use an absolute encoder, connect a battery to either Pin 42 which is the backup battery input, or 43 which is the battery holder for absolute encoder cable. (Never connect to both.)

Connectors for CN1 (Pin 50)

Name	Model	Manufacturer	OMRON model number	
Cable plug	10150-3000PE	Sumitomo 3M	R88A-CNU11C	
Cable case (shell kit)	10350-52A0-008			


Control Input Circuits

Speed Command Input, Torque Command Input, Speed Limit Input and Torque Limit Input



Position Command Pulse (Line Receiver Input)


When connecting with a line driver and a line receiver, up to 4 Mpps will be available. (+CWLD: 44, -CWLD: 45, +CCWLD: 46, -CCWLD: 47)



• The shielded twisted-pair cable should not exceed 10 m in length.

Position Command Pulse (Photocoupler Input)


When connecting with a line driver and a photocoupler, the maximum speed will be 500 kpps. (+CW: 3, -CW: 4, +CCW: 5, -CCW: 6)




• The shielded twisted-pair cable should not exceed 10 m in length.

Open Collector Input

• External 24-V power supply without a Current Limit Resistor (200 kpps maximum) (+24 VCW: 1, -CW: 4, +24 VCCW: 2, -CCW: 6)



• External control power supply (200 kpps maximum) (+CW: 3, -CW: 4, +CCW: 5, -CCW: 6)




Select a Current Limit Resistor (R) appropriate for Vcc.


rh.

Precautions for Correct Use

• The open collector wiring should not exceed 3 m in length.



Sensor Input



- A PNP transistor is recommended.
- The signal level is as follows.
 - H level: 2.0 V or more, L level: 0.8 V or less

Control Input Details

Details on the input pins for the CN1 connector are described here.

High-speed Photocoupler Input

Pin 3: +Reverse pulse (+CW), +feed pulse (+PULS), or +phase A (+FA) Pin 4: -Reverse pulse (-CW), -feed pulse (-PULS), or -phase A (-FA) Pin 5: +Forward pulse (+CCW), +direction signal (+SIGN), or +phase B (+FB) Pin 6: -Forward pulse (-CCW), -direction signal (-SIGN), or -phase B (-FB)


Function

• The functions of these signals depend on the settings of the Command Pulse Rotation Direction Switching Selection (Pn006) and the Command Pulse Mode Selection (Pn007).

Pn005 Set value	Pn006 Set value	Pn007 Set value	Command pulse mode	Input pins	Motor forward command	Motor reverse command
		0/2	90° phase difference signals (quadruple multiplier)	3: +FA 4: -FA 5: +FB 6: -FB		
0	0	1	Reverse pulse/forward pulse	3: +CW 4: -CW 5: +CCW 6: -CCW		
		3	Feed pulse/ direction signal	3: +PULS 4: -PULS 5: +SIGN 6: -SIGN		

Note 1. If the Command Pulse Rotation Direction Switching Selection (Pn006) is set to 1, the rotation direction will be reversed.

Note 2. If the photocoupler LED is turned ON, each signal will go high as shown above.



Command Pulse Timing for Photocoupler Inputs



Line Receiver Input


```
Pin 44: +Reverse pulse (+CW), +feed pulse (+PULS), or +phase A (+FA)
Pin 45: -Reverse pulse (-CW), -feed pulse (-PULS), or -phase A (-FA)
Pin 46: +Forward pulse (+CCW), +direction signal (+SIGN), or +phase B (+FB)
Pin 47: -Forward pulse (-CCW), -direction signal (-SIGN), or -phase B (-FB)
```

Function

• The functions of these signals depend on the settings of the Command Pulse Rotation Direction Switching Selection (Pn006) and the Command Pulse Mode Selection (Pn007).

Pn005 Set value	Pn006 Set value	Pn007 Set value	Command pulse mode	Input pins	Motor forward command	Motor reverse command
		0/2	90° phase difference signals (quadruple multiplier)	44: +FA 45: -FA 46: +FB 47: -FB		
1	0	1	Reverse pulse/ forward pulse	44: +CW 45: -CW 46: +CCW 47: -CCW		
		3	Feed pulse/ direction signal	44: +PULS 45: -PULS 46: +SIGN 47: -SIGN		

Note 1. If the Command Pulse Rotation Direction Switching Selection (Pn006) is set to 1, the rotation direction will be reversed.



Command Pulse Timing for Line Receiver Inputs

Sensor ON Input (SEN)

Pin 20: Sensor ON input (SEN) Pin 13: Signal ground (SENGND)

Function

This input changes to enable (set value: 1) according to the setting of Absolute Interface Function Selection (Pn616).

When the SEN signal turns ON, this performs serial transmission of multi-rotation data of the absolute encoder and also outputs 1-rotation data as the initial incremental pulses.

If the SEN signal is OFF, motor power supply is not possible even when the RUN signal (Operation command) is input. The RUN signal changes to enable after the SEN signal turns ON and the normal operation of encoder becomes ready.

If the power is turned ON with the encoder disconnected, the SEN signal is ignored.

Backup Battery Input (BAT)

Pin 42: Backup battery +input (BAT) Pin 43: Backup battery –input (BATGND)

Function

- These are the backup battery connection terminals used when the absolute encoder power is interrupted.
- Normally, the battery is connected to the battery holder for the absolute encoder battery cable. Do
 not connect anything to these terminals.

Precautions for Correct Use

Be sure not to connect to both of the absolute encoder battery cable and the backup battery inputs at the same time. Such connection may result in malfunction.

Speed Command Input (REF), Torque Command Input (TREF1) and Speed Limit Input (VLIM)

Pin 14: Speed command input (REF), torque command Input (TREF1) and speed limit input (VLIM)

Pin 15: Analog input ground (AGND1)

Function

During speed control

Speed command is input. Use the Speed Command Scale (Pn302) to change the rotation speed scale for the command input.

During torque control

This signal provides either a torque command input (set value: 0 or 2) or speed limit input (set value: 1) according to the setting of Torque Command/Speed Limit Selection (Pn317).

In the case of torque command input 1 (TREF1), you can use Torque Command Scale (Pn319) to change the rotation speed scale relative to the command input.

In the case of speed limit input (VLIM), you can use the Speed Command Scale (Pn302) to change the limit speed scale relative to the analog input.

Torque Command Input 2 (TREF2) and Forward Torque Limit Input (PCL)

Pin 16: Torque command input 2 (TREF2) and forward torque limit input (PCL) Pin 17: Analog input ground 2 (AGND2)

Function

During position control, speed control or fully-closed control

This signal provides a forward torque limit input (set value: 0 or 4) or forward/reverse torque limit input (set value: 5) according to the setting of Torque Limit Selection (Pn521).

You can use Analog Torque Limit Scale (Pn527) to change the torque limit scale relative to the analog input.

During torque control

This signal provides a torque command input (set value: 1) according to the setting of Torque Command/Speed Limit Selection (Pn317).

In the case of torque command input 2 (TREF2), you can use Torque Command Scale (Pn319) to change the rotation speed scale relative to the command input.

Reverse Torque Limit Input (NCL)

Pin 18: Reverse torque limit input (NCL)

Pin 17: Analog input ground 2 (AGND2)

Function

During position control, speed control or fully-closed control

This signal provides a reverse torque limit input (set value: 0 or 4) according to the setting of Torque Limit Selection (Pn521).

You can use Analog Torque Limit Scale (Pn527) to change the torque limit scale relative to the analog input.

Operation command (RUN)

Pin 29: Operation command (RUN)

This is the allocation at default setting. You can change the logics and allocations for input terminals (CN1 to 8, 9 and 26 to 33) according to the settings of Input Signal Selection 1 to 10 (Pn400 to 409).

You must always allocate the operation command (RUN). If it is not allocated, the servo will not turn ON.

Function


This input turns ON the power drive circuit for the main circuit of the Servo Drive. If this signal is not input (servo OFF), the motor cannot drive.

Forward Drive Prohibition Input (POT) and Reverse Drive Prohibition Input (NOT)

Pin 9: Forward drive prohibition input (POT) Pin 8: Reverse drive prohibition input (NOT)

These two signals are the inputs to prohibit forward and reverse rotation (overtravel inputs). If Drive Prohibition Input Selection (Pn504) is 1, you can use the setting of Stop Selection (Pn505) to select the operation to be taken upon input of each prohibit signal.

If Drive Prohibition Input Selection (Pn504) is 2, drive prohibition input protection (E380) actuates upon input of a drive prohibition.



Both signals are disabled (in a state in which drive prohibition will not operate) in the default settings. If prohibiting the drive input is required, set the Drive Prohibit Input Selection (Pn504) to either 0 or 2. The setting on the Input Signal Selection 1 to 10 (Pn400 to Pn409) can change the logic and allocation for the respective Input terminals (CN1 to 8, 9 and 26 to 33).

Alarm Reset Input (RESET)

Pin 31: Alarm reset input (RESET)

This is the allocation at default setting. You can change the logics and allocations for input terminals (CN1 to 8, 9 and 26 to 33) according to the settings of Input Signal Selection 1 to 10 (Pn400 to 409).

The input logic for the alarm reset input (RESET) is always NO. (You cannot set NC logic.)

Function

It is the external reset input for servo alarm. (A reset occurs at the rising edge of this input.) Inputting for 120 ms or more releases an alarm condition.

An alarm reset also resets the content of the error counter, upon which the position loop becomes no longer effective.

Eliminate the cause of the alarm before resuming operation. To prevent danger, turn OFF the Operation command (RUN) first, then input the alarm reset signal.

Some alarms cannot be reset with this input.

Error Counter Reset Input (ECRST)

Pin 30: Error counter reset input (ECRST)

This is the allocation at default setting. You can change the functions for input terminals (CN1 to 8, 9 and 26 to 33) according to the settings of Input Signal Selection 1 to 10 (Pn400 to 409). You can only allocate the error counter reset input (ECRST) to pin 30 (SI7). Allocating to any other terminal generates an error counter reset signal allocation error (A332).

The input logic for the error counter reset input (ECRST) is always NO. (You cannot set NC logic.)

Function

Inputting the error counter reset resets the content of the error counter, upon which the position loop becomes no longer effective.

You can use Error Counter Reset Condition Selection (Pn517) to set the status (level) signal (ON) or differential (rising edge) signal (from OFF to ON).

Input the differential signal for at least 100 μ s, or status signal for at least 1 ms. A reset may not occur if the time is shorter.

Control Mode Switching (TVSEL)

Pin 32: Control mode switching (TVSEL)

This is the allocation at default setting. You can change the logics and allocations for input terminals (CN1 to 8, 9 and 26 to 33) according to the settings of Input Signal Selection 1 to 10 (Pn400 to 409).

If the Control mode Selection (Pn001) is set to 3 to 5, the Control mode can be switched as given in the following table.

Pn001 set value	OFF (first control mode)	ON (second control mode)
3	Position control	Speed control
4	Position control	Torque control
5	Speed control	Torque control

Gain Switching (GSEL)

Pin 27: Gain switching (GSEL)

This is the allocation at default setting. You can change the logics and allocations for input terminals (CN1 to 8, 9 and 26 to 33) according to the settings of Input Signal Selection 1 to 10 (Pn400 to 409).

Function

This signal changes to enable (set value: 2) according to the setting of the Gain Switching Mode (Pn115 for position control, Pn120 for speed control, or Pn124 for torque control). When the signal is OFF and ON, gain 1 and gain 2 change to enable, respectively.

Damping Filter Switching 1 (DFSEL1) and Damping Filter Switching 2 (DFSEL2)

Pin 26: Damping filter switching 1 (DFSEL1)

No allocation: Damping filter switching 2 (DFSEL2)

This is the allocation at default setting. You can change the logics and allocations for input terminals (CN1 to 8, 9 and 26 to 33) according to the settings of Input Signal Selection 1 to 10 (Pn400 to 409).

Function

Use the sequence signal to switch among the 4 filters for use in damping control when the setting of Damping Filter Selection (Pn213) is enable (set value: 1 or 2).

Pn213 set value	DFSEL1	DFSEL2	Damping filter 1	Damping filter 2	Damping filter 3	Damping filter 4
1	OFF	-	Enabled		Enabled	
	ON	-		Enabled		Enabled
	OFF	OFF	Enabled			
2	ON	OFF		Enabled		
	OFF	ON			Enabled	
	ON	ON				Enabled

Electronic Gear Switching 1 (GESEL1) and Electronic Gear Switching 2 (GESEL2)

Pin 28: Electronic gear switching 1 (GESEL1) No allocation: Electronic gear switching 2 (GESEL2) This is the allocation at default setting. You can change the logics and allocations for input terminals (CN1 to 8, 9 and 26 to 33) according to the settings of Input Signal Selection 1 to 10 (Pn400 to 409).

Use these 2 signals to switch among up to 4 electronic gear ratio numerators.

GESEL1	GESEL2	Electronic Gear 1	Electronic Gear 2	Electronic Gear 3	Electronic Gear 4
OFF	OFF	Pn009 valid			
ON	OFF		Pn500 valid		
OFF	ON			Pn501 valid	
ON	ON				Pn502 valid

• Electronic Gear Ratio Denominator (Pn010) is a common setting.

Pulse Prohibition Input (IPG)

Pin 33: Pulse prohibition input (IPG)

This is the allocation at default setting. However, Command Pulse Prohibition Input (Pn518) is set to disable (set value: 1). To use this, change Pn518 to enable (set value: 0). You can change the functions for input terminals (CN1 to 8, 9 and 26 to 33) according to the settings of Input Signal Selection 1 to 10 (Pn400 to 409).

You can only allocate the pulse prohibition input (ECRST) to pin 33 (SI10). Allocating this input to any other terminal generates a pulse prohibition input allocation error (A337).

Function

You can use this input to forcibly stop the command pulse input.

When this input is ON, the drive ignores the command pulse input and does not count pulses.

Internally Set Speed Selection 1, 2 and 3 (VSEL1, 2 and 3)

Pin 33: Internally set speed selection 1 (VSEL1) Pin 30: Internally set speed selection 2 (VSEL2)

Pin 28: Internally set speed selection 3 (VSEL3)

This is the allocation at default setting. However, Command Speed Selection (Pn300) is set to disable (set value: 0). To use this, change Command Speed Selection (Pn300) to enable (set value: 1 to 3). You can change the logics and allocations for input terminals (CN1 to 8, 9 and 26 to 33) according to the settings of Input Signal Selection 1 to 10 (Pn400 to 409).

Perform speed control according to the internal speed set value in the parameter. You can select from up to 8 internal speed set values.

Pn300 set value	VSEL1	VSEL2	VSEL3	Speed command selection
	OFF	OFF	-	No. 1 Internally Set Speed (Pn304)
1	ON	OFF	-	No. 2 Internally Set Speed (Pn305)
1	OFF	ON	-	No. 3 Internally Set Speed (Pn306)
	ON	ON	-	No. 4 Internally Set Speed (Pn307)
	OFF	OFF	-	No. 1 Internally Set Speed (Pn304)
2	ON	OFF	-	No. 2 Internally Set Speed (Pn305)
2	OFF	ON	-	No. 3 Internally Set Speed (Pn306)
	ON	ON	-	Analog speed command input (REF)
	OFF	OFF	OFF	No. 1 Internally Set Speed (Pn304)
	ON	OFF	OFF	No. 2 Internally Set Speed (Pn305)
	OFF	ON	OFF	No. 3 Internally Set Speed (Pn306)
3	ON	ON	OFF	No. 4 Internally Set Speed (Pn307)
5	OFF	OFF	ON	No. 5 Internally Set Speed (Pn308)
	ON	OFF	ON	No. 6 Internally Set Speed (Pn309)
	OFF	ON	ON	No. 7 Internally Set Speed (Pn310)
	ON	ON	ON	No. 8 Internally Set Speed (Pn311)

To use the internally set speeds, use NC contacts for the zero speed designation input (VZERO). (If this is OFF, the speed command becomes 0.)The zero speed designation input (VZERO) is set to disable (set value: 0) by default. To use this, change Zero Speed Designation Selection (Pn315) to enable (set value: 1 to 2).

(If the zero speed designation input is not used, the motor turns at No. 1 Internally Set Speed (Pn304) when the servo turns ON.)

Zero Speed Designation (VZERO)

No allocation: Zero speed designation (VZERO)

There is no allocation at default setting. Also, Zero Speed Designation Selection (Pn315) is set to disable (set value: 1). You can change the logics and allocations for input terminals (CN1 to 8, 9 and 26 to 33) according to the settings of Input Signal Selection 1 to 10 (Pn400 to 409).

Function

You can use this input to forcibly change the speed command to 0.

This signal changes to enable (set value: 1 to 3) according to the setting of Zero Speed Designation Selection (Pn315).

Pn315 set value	Operation when ON
0	Zero speed designation is disabled.
1	The speed command becomes 0.
2	The speed command becomes 0, and the servo lock is applied when an actual speed is equal to or less than Position Lock Level Setting (Pn316).
3	The servo lock is applied when a command speed is equal to or less than the Position Lock Level Setting (Pn316) minus 10 r/min.

Speed Command Sign Input (VSIGN)

No allocation: Speed command sign designation (VSIGN) There is no allocation at default setting. Also, Speed Command Direction Selection (Pn301) is set to disable (set value: 0). You can change the logics and allocations for input terminals (CN1 to 8, 9 and 26 to 33) according to the settings of Input Signal Selection 1 to 10 (Pn400 to 409).

Function

You can use this input to designate the rotation direction relative to the speed command. If Speed Command Direction Selection (Pn301) is enable (set value: 1), the polarity of analog command input and rotation direction at internal command speed become disabled.

Pn303 set value	VSIGN	Analog speed command (REF)	Speed command direction ^{*1}	
0		+ Voltage (0 to 10 V)	Forward direction	
Ū	Not	- Voltage (-10 to 0 V)	Reverse direction	
1	affected	+ Voltage (0 to 10 V)	Reverse direction	
		- Voltage (-10 to 0 V)	Forward direction	
	OFF	+ Voltage (0 to 10 V)	Forward direction	
Not offected		- Voltage (-10 to 0 V)	Forward direction	
Not affected		+ Voltage (0 to 10 V)	Boyoroo direction	
	UN	- Voltage (-10 to 0 V)	Reverse direction	
		value VSIGN 0 Not affected 1 OFF	value VSIGN (REF) 0 + Voltage (0 to 10 V) + Voltage (0 to 10 V) 1 - Voltage (-10 to 0 V) + Voltage (0 to 10 V) 1 - Voltage (-10 to 0 V) + Voltage (0 to 10 V) 1 - Voltage (-10 to 0 V) + Voltage (0 to 10 V) Not affected OFF + Voltage (0 to 10 V) - Voltage (-10 to 0 V) + Voltage (0 to 10 V) + Voltage (0 to 10 V) ON - Voltage (0 to 10 V) + Voltage (0 to 10 V)	

Pn301 set value	VSIGN	Internal command speed	Speed command direction ^{*1}
		+ (1 to 20,000 r/min)	Forward direction
0	Not affected	– (–20,000 to –1 r/min)	Reverse direction
0		+ (1 to 20,000 r/min)	Forward direction
		– (–20,000 to –1 r/min)	Reverse direction
1	OFF	Not affected	Forward direction
I	ON	Not alleoted	Reverse direction

*1.The motor rotation direction (CW, CCW) specified by the command direction is determined by the setting of Pn000.

Torque Limit Switching (TLSEL)

No allocation: Torque Limit Switching (TLSEL)

There is no allocation at default setting. You can change the logics and allocations for input terminals (CN1 to 8, 9 and 26 to 33) according to the settings of Input Signal Selection 1 to 10 (Pn400 to 409).

Function

This input is used for switching the torque limit value.

This signal changes to enable (set value: 3 or 6) according to the setting of Torque Limit Selection (Pn521).

Pn521 set value TLSEL Forward direction		Reverse direction	
3	OFF	Pn013 (No. 1 Torque Limit)	Pn013 (No. 1 Torque Limit)
	ON	Pn522 (No. 2 Torque Limit)	Pn522 (No. 2 Torque Limit)
6	OFF	Pn013 (No. 1 Torque Limit)	Pn522 (No. 2 Torque Limit)
	ON	Pn525 (Forward External Torque Limit)	Pn526 (Reverse External Torque Limit)

Torque Command Sign Input (TSIGN)

No allocation: Torque command sign input (TSIGN)

There is no allocation at default setting. Also, Torque Command Direction Selection (Pn318) is set to disable (set value: 0). You can change the logics and allocations for input terminals (CN1 to 8, 9 and 26 to 33) according to the settings of Input Signal Selection 1 to 10 (Pn400 to 409).

Function

You can use this input to designate the rotation direction relative to the torque command. If Torque Command Direction Selection (Pn301) is enable (set value: 1), the polarity of torque command input is disabled.

Pn318 set value	Pn320 set value	TSIGN	Torque command input (TREF)	Torque command direction ^{*1}
	0	Not affected	+ Voltage (0 to 10 V)	Forward direction
0			- Voltage (-10 to 0 V)	Reverse direction
	1		+ Voltage (0 to 10 V)	Reverse direction
			- Voltage (-10 to 0 V)	Forward direction
1	Not affected	OFF	Not affected	Forward direction
		ON		Reverse direction

*1. The motor rotation direction (CW, CCW) specified by the command direction is determined by the setting of Pn000.

Emergency Stop Input (STOP)

No allocation: Emergency stop input (STOP)

There is no allocation at default setting. You can change the logics and allocations for input terminals (CN1 to 8, 9 and 26 to 33) according to the settings of Input Signal Selection 1 to 10 (Pn400 to 409).

Function

This is an external alarm stop input.

Upon input of an emergency stop, the system stops according to the set value of Stop Selection for Alarm Detection (Pn510).

Inertia Ratio Switching Input (JSEL)

No allocation: Inertia ratio switching input (JSEL)


This is the allocation at default setting. You can change the logics and allocations for input terminals (CN1 to 8, 9 and 26 to 33) according to the settings of Input Signal Selection 1 to 10 (Pn400 to 409).

Function


You can switch the inertia ratio between Inertia Ratio 1 (Pn004) and Inertia Ratio 2 (Pn613). When this signal is OFF, Inertia Ratio 1 (Pn004) becomes valid. If ON, Inertia Ratio 2 (Pn613) becomes valid.

Control Output Circuits

Position Feedback Output



Phase-Z Output (Open Collector Output)



Sequence Output

- General-purpose output
 SO1: 11, SO2: 35, /ALM: 37, SO4: 39
- General-purpose output common SO1COM : 10, SO2COM : 34, ALMCOM : 36, SO4COM : 38




Di: Surge voltage prevention diode (When driving a relay directly with an output signal, always insert a diode as shown in the above figure.)

External power supply 12 to 24 VDC Maximum service voltage: 30 VDC or less Maximum output current: 50mA max.

Control Output Details

Control Output Sequence



- *1. In this section, the hardware inputs the servo ON signal, but the signal is not accepted.
- *2. The servo ready completed output turns ON the moment the conditions of MPU initialization completed and main circuit power supply establishment are both satisfied.
- *3. Once the internal control power is established, the protective function starts working about 1.5 s after the MPU starts initializing itself. Make sure all I/O signals which connect to the amplifier (especially forward/reverse direction, drive prohibition input and external encoder input) are established before operation of the protective function starts. Also, you can increase this time with Pn618 "Power Supply ON Initialization Time."

Encoder Outputs (Phases A, B and Z)

Pin 21: +A, 22: -A, 48: -B, 49: +B, 23: +Z, 24: -Z

Function

- It outputs the phase A, phase B, and phase Z encoder signals for the Servomotor.
- The encoder outputs conform to the RS-422 communication method.
- You can use External Feedback Pulse Dividing Numerator Setting (Pn324) and External Feedback Pulse Dividing Denominator Setting (Pn325) to set the dividing ratio.
- The logical relation of phase B to the phase A pulse and whether to set the output source to an encoder or external encoder can be selected with Encoder Output Direction Switching Selection (Pn012).
- The ground for the output circuit line driver is connected to the signal ground (ZGND). It is not isolated.
- The maximum output frequency is 4 Mpps (after quadruple multiplier).
- The output frequency = the motor encoder resolution × (Pn324/Pn325) × 4 × motor rotation speed (r/min)/60
- The output phases are as shown below. (They are the same for both incremental and absolute encoders.)

Phase A	Phase A
Phase B	Phase B
Phase Z	Phase Z
Synchronous	Asynchronous
 If the motor encoder resolution × Pn324/Pn325 is a multiple of 4, phases Z and A are synchronized. 	 In cases except for the one on the left, phases A and Z are not synchronized.

Brake Interlock Output (BKIR)

Pin 11: Brake interlock output (BKIR)

Pin 10: Brake interlock output common (BKIRCOM)

This is the allocation at default setting. You can change the allocations of output terminals (CN1 to 10, 11, 34, 35, 38 and 39) according to the settings of Output Signal Selections 1 to 4 (Pn410 to 413).

Function

This outputs an external brake timing signal according to the settings of the Brake Timing when Stopped (Pn437) and Brake Timing During Operation (Pn438).

Servo Ready Completed Output (READY)

Pin 35: Servo ready completed output (READY) Pin 34: Servo ready completed output common (READYCOM) This is the allocation at default setting. You can change the allocations of output terminals (CN1 to 10, 11, 34, 35, 38 and 39) according to the settings of Output Signal Selections 1 to 4 (Pn410 to 413).

Function

This output signal indicates the Servo Drive is ready to supply power to the Servomotor. It is turned ON when the control and main power supply is established and not in alarm status.

Alarm Output (/ALM)

Pin 37: Alarm Output (/ALM) Pin 36: Alarm output common (ALMCOM) The alarm output terminal is fixed to pin 36 or 37.

Function

The output is turned OFF when the drive detects an error. This output is OFF when the power supply is turned ON, but turns ON when the drive's initial processing has been completed.

Positioning Completion Output 1 (INP1) and Positioning Completion Output 2 (INP2)

Pin 39: Positioning completion output 1 (INP1)

Pin 38: Positioning completion output common (INP1COM)

No allocation: Positioning completion output 2 (INP2)

No allocation: Positioning completion output 2 common (INP2COM)

This is the allocation at default setting. You can change the allocations of output terminals (CN1 to 10, 11, 34, 35, 38 and 39) according to the settings of Output Signal Selections 1 to 4 (Pn410 to 413).

Function

The INP1 turns ON when the error counter accumulated pulse is less than or equal to the Positioning Completion Range 1 (Pn431) set value.

The INP2 turns ON when the error counter accumulated pulse is less than or equal to the Positioning Completion Range 2 (Pn442) set value.

The output turns ON according to Positioning Completion Condition Selection (Pn432).

Motor Rotation Speed Detection Output (TGON)

Pin 39: Motor rotation speed detection output (TGON) Pin 38: Motor rotation speed detection output common (TGONCOM) This is the allocation at default setting. You can change the allocations of output terminals (CN1 to 10, 11, 34, 35, 38 and 39) according to the settings of Output Signal Selections 1 to 4 (Pn410 to 413).

Function

It turns ON when the speed of the Servomotor exceeds the set value of the Rotation Speed for Motor Rotation Detection (Pn436).

Torque Limiting Signal (TLIMT)

No allocation: Torque limiting signal (TLIMT) No allocation: Torque limiting signal common (TLIMTCOM) This is the allocation at default setting. You can change the allocations of output terminals (CN1 to 10, 11, 34, 35, 38 and 39) according to the settings of Output Signal Selections 1 to 4 (Pn410 to 413).

Function

This output turns ON while the torque is limited.

Zero Speed Detection Signal (ZSP)

No allocation: Zero speed detection signal (ZSP) No allocation: Zero speed detection signal common (ZSPCOM) This is the allocation at default setting. You can change the allocations of output terminals (CN1 to 10, 11, 34, 35, 38 and 39) according to the settings of Output Signal Selections 1 to 4 (Pn410 to 413).

Function

This output turns ON when the motor rotation speed is equal to Zero Speed Detection (Pn434) or less.

Speed Conformity Output Signal (VCMP)

No allocation: Speed conformity output signal (VCMP) No allocation: Speed conformity output signal common (VCMPCOM) This is the allocation at default setting. You can change the allocations of output terminals (CN1 to 10, 11, 34, 35, 38 and 39) according to the settings of Output Signal Selections 1 to 4 (Pn410 to 413).

Function

This output turns ON when the command speed corresponds to the motor rotation speed. This output turns ON when the difference between the command speed and motor speed is equal to the Speed Conformity Detection Width (Pn435) or less.

Warning Output 1 (WARN1) and Warning Output 2 (WARN2)

No allocation: Warning output 1 (WARN1) and warning output 2 (WARN2)

No allocation: Warning output 1 common (WARN1COM) and warning output 2 common (WARN2COM)

This is the allocation at default setting. You can change the allocations of output terminals (CN1 to 10, 11, 34, 35, 38 and 39) according to the settings of Output Signal Selections 1 to 4 (Pn410 to 413).

Function

The output turns ON according to the setting conditions of Warning Output Selection 1 (Pn440) and Warning Output Selection 2 (Pn441).

Position Command Status Output (P-CMD)

No allocation: Position command status output (P-CMD) No allocation: Position command status output common (P-CMDCOM) This is the allocation at default setting. You can change the allocations of output terminals (CN1 to 10, 11, 34, 35, 38 and 39) according to the settings of Output Signal Selections 1 to 4 (Pn410 to 413).

Function

This output turns ON when a positioning command is input.

Speed Limiting Output (V-LIMIT)

No allocation: Speed limiting output (V-LIMIT) No allocation: Speed limiting output common (V-LIMITCOM) This is the allocation at default setting. You can change the allocations of output terminals (CN1 to 10, 11, 34, 35, 38 and 39) according to the settings of Output Signal Selections 1 to 4 (Pn410 to 413).

Function

This turns ON during torque control or speed limit status.

Alarm Clear Attribute Output (ALM-ATB)

No allocation: Alarm clear attribute output (ALM-ATB) No allocation: Alarm clear attribute output common (ALM-ATB COM) This is the allocation at default setting. You can change the allocations of output terminals (CN1 to 10, 11, 34, 35, 38 and 39) according to the settings of Output Signal Selections 1 to 4 (Pn410 to 413).

Function

This output turns ON when an alarm occurs or the alarm can be cleared.

Speed Command Status Output (V-CMD)

No allocation: Speed command status output (V-CMD) No allocation: Speed command status output common (V-CMDCOM) This is the allocation at default setting. You can change the allocations of output terminals (CN1 to 10, 11, 34, 35, 38 and 39) according to the settings of Output Signal Selections 1 to 4 (Pn410 to 413).

Function

This output turns ON during speed control or when a speed command is input.

Encoder Connector Specifications (CN2)

Pin number	Symbol	Name	Function and interface
1	E5V	Encoder power supply +5 V	Power supply output for the encoder
2	E0V	Encoder power supply GND	
3	BAT+	Battery +	Backup power supply output for the absolute encoder
4	BAT–	Battery –	
5	PS+	Encoder + phase S input	Encoder signal I/O (serial signal)
6	PS-	Encoder – phase S input	
Shell	FG	Frame ground	Frame ground

Connectors for CN2 (6 Pins)

Name	Model	Manufacturer	OMRON model number
Drive connector	53460-0629	Molex Japan	-
Cable connector	55100-0670		R88A-CNW01R

External Encoder Connector Specifications (CN4)

These are the specifications of the connector that connects to the external encoder.

Pin number	Symbol	Name	Function and interface
1	E5V	External encoder power supply	Use at 5.2 V \pm 5% and at or below 250 mA.
2	E0V	output	This is connected to the control circuit ground connected to connector CN1.
3	+EXS	External encoder signal I/O	Performs serial signal input and output.
4	-EXS	(Serial signal)	
5	+EXA		Performs input and output of phase A, B, and Z signals.
6	–EXA		
7	+EXB	External encoder signal input	
8	–EXB	(Phase A, B, and Z signals)	
9	+EXZ		
10	–EXZ		
Shell	FG	Frame ground	Frame ground

Connectors for CN4 (10 Pins)

	Name	Model	Manufacturer	OMRON model number
-	Connector	MUF-PK10K-X	JST Mfg. Co., Ltd.	R88A-CNK41L

External Encoder Input Signals Table


External Encoder I/O (CN4)

Pin number	Symbol	Name	Function and interface
1	E5V	External encoder power	External encoder power supply: $5.2 \text{ VDC} \pm 5\%$, 250 mA max
2	E0V	supply output	If the above capacity is exceeded, provide a separate power supply.
3	+EXS	External encoder signal	This is an external encoder serial bi-directional
4	-EXS	serial interface	signal.*(Conforming to EIA485) Maximum response frequency: 400 Mpps
5	+EXA	External encoder signal 90° phase difference input	This is an external encoder 90° phase input signal.* Maximum response frequency: 4 Mpps (quadruple
6	-EXA	(Phases A, B and Z)	multiplier)
7	+EXB		
8	–EXB		
9	+EXZ		t1 t1 t1>0.25 μs
10	-EXZ		t2 t2>1.0 μs


* Connect external encoder signals to the serial interface (+EXS/–EXS) or 90° phase difference inputs according to the encoder type.

Example of Connection with External Encoder

■ 90° Phase Difference Output Type (Pn323 = 0)



■ Serial Communications Type, Incremental Encoder Specifications (Pn323 = 1)



Analog Monitor Connector Specifications (CN5)

Monitor Output Signal Table


Pin Number	Symbol	Name	Function and interface
1	AM1	Analog monitor output 1	Outputs the analog signal for the monitor. Default setting: Motor rotation speed 1 V/(500 r/min) You can use Pn416 and Pn417 to change the item and unit. You can use Pn421 to change the output method.
2	AM2	Analog monitor output 2	Outputs the analog signal for the monitor. Default setting: Torque command, 1 V/(33%) You can use Pn418 and Pn419 to change the item and unit. You can use Pn421 to change the output method.
3	GND	Analog monitor ground	Ground for analog monitors 1, 2
4	-	Not used	Do not connect.
5	-	Not used	Do not connect.
6	-	Not used	Do not connect.

Monitor output (CN5)

Connectors for CN5 (6 Pins)

Name	Model	Manufacturer
Connector housing	51004-0600	Molex Japan
Connector terminal	50011-8000	Molex Japan

Monitor Output Circuit



USB Connector Specifications (CN7)

Through the USB connection with computer, operations such as parameter setting and changing, monitoring of control status, checking alarm status and alarm history, and parameter saving and loading can be performed.


Pin number	Symbol	Name	Function and interface
1	VBUS		Use this function for computer communication.
2	D-	USB signal terminal	
3	D+		
4	-	Reserved for manufacturer use	Do not connect.
5	GND	Signal ground	Signal ground

Precautions for Correct Use

• Use a commercially available USB cable that is shielded, equipped with a ferrite core for noise immunity, and supports USB2.0. The Mini B type USB cable can be used.

Safety Connector Specifications (CN8)

Connection of Safety I/O Signals and Processing of External Signals



Safety I/O Signal Table

Safety I/O (CN8)


Pin Number	Symbol	Name	Function and interface
1	_	Reserved	Do not connect.
2	_		
3	SF1-	Safety input 1	Inputs 1 and 2 for operating the STO function, which are
4	SF1+		2 independent circuits. This input turns OFF the power transistor drive signals in the Servo Drive to cut off the
5	SF2-	Safety input 2	current output to the motor.
6	SF2+		
7	EDM-	EDM output	A monitor signal is output to detect a safety function
8	EDM+		failure.
Shell	FG	Frame ground	Connected to the ground terminal inside the Servo Drive.

Connector for CN8 (8 Pins)

Name	Model	Manufacturer	OMRON model number
Industrial Mini I/O Connector (D-SHAPE1)	2013595-1	Tyco Electronics AMP KK	R88A-CNK81S

Note. The recommended cable is a 6-conductor (AWG30 to AWG26) shielded cable with a finished outer diameter of 6.7 mm max.

Safety Input Circuit



Di: Surge voltage prevention diode (Use a high-speed diode.)

3-2 Overload Characteristics (Electronic Thermal Function)


An overload protection function (electronic thermal) is built into the Servo Drive to protect the Servo Drive and motor from overloading.

If an overload does occur, first eliminate the cause of the overload and then wait at least 1 minute for the motor temperature to drop before turning ON the power again.

If the alarm reset is repeated at short intervals, the motor windings may burn out.

Overload Characteristics Graphs

The following graphs show the characteristics of the load ratio and electronic thermal function's operation time.



3-3 Servomotor Specifications

The following OMNUC G5-Series AC Servomotors are available.

- 3,000-r/min Servomotors
- + 2,000-r/min Servomotors
- 1,500-r/min Servomotors
- 1,000-r/min Servomotors

There are various options available, such as models with brakes, or different shaft types. Select a Servomotor based on the mechanical system's load conditions and the installation environment.

General Specifications

Item		1	3,000-r/min \$	1,000-r/min Servomotors 1,500-r/min Servomotors 2,000-r/min Servomotors			
			50 to 750 W	1 to 5 kW	900 W to 15 kW		
Ambient operating temperature and operating humidity			0 to +40°C, 20% to 85% (with	n no condensation)			
Storage ambient temperature and humidity			-20 to +65°C, 20% to 85% (with no condensation) Maximum allowable temperature: 80°C for 72 hours maximum (standard humidity)				
Operating and storage atmosphere			No corrosive gases				
Vibration resistance *1			Acceleration of 49 m/s ^{2 *2} 24.5 m/s ^{2} max. in X, Y, and Z directions when the motor is stopped				
Impact resistance			Acceleration of 98 m/s ² max. 3 times each in X, Y, and Z directions				
Insulation resistance			Between power terminal and FG terminal: 20 M Ω min. (at 500 VDC)				
Dielectric strength		gth	1,500 VAC between power terminal and FG terminal for 1 min (voltage 100 V, 200 V) 1,800 VAC between power terminal and FG terminal for 1 min (voltage 400 V) 1,000 VAC between brake terminal and FG terminal for 1 min				
Insulation class			Туре В	Туре F			
Protective structure		cture	IP67 (except for through-shaft parts and motor and encoder connector pins)				
International standard	EC Directive	Low Voltage Directive	EN60034-1/-5				
	UL standa	irds	UL1004-1		UL1004-1, UL1004-6 *3		
	CSA stand	dards	CSA C22.2 No. 100		,		

*1. The amplitude may be amplified by machine resonance. Do not exceed 80% of the specified value for extended periods of time.

*2. 24.5m/s² is specified for 1,500-r/min Servomotors of 7.5 to 15 kW and 1,000-r/min Servomotors of 4.5 to 6 kW.

*3. UL 1004-6 applies only to 1,500-r/min Servomotors of 7.5 to 15 kW and 1,000-r/min Servomotors of 4.5 to 6 kW. Note 1. Do not use the cable when it is laying in oil or water.

Note 2. Do not expose the cable outlet or connections to stress due to bending or the weight of the cable itself.

Note 3. Disconnect all connections to the Servomotor before attempting a megameter test (insulation resistance measurement) on a Servomotor. Failure to follow this guideline may result in damaging the Servomotor. Never perform a dielectric strength test on the Servomotor. Failure to follow this guideline may result in damaging the internal elements.

Characteristics

3,000-r/min Servomotors

			100 VAC					
Model (R88M-)		K05030H K10030L		K20030L	K40030L			
Item		Unit	K05030T	K10030S	K20030S	K40030S		
Rated ou	ıtput * ¹	W	50	100	200	400		
Rated torque *1		N • m	0.16	0.32	0.64	1.3		
Rated rotation speed r/min		r/min	3,000					
Maximun	n rotation speed	r/min	6,000					
Momentary maximum torque *1		N • m	0.48	0.95	1.91	3.8		
Rated cu	ırrent * ¹	A (rms)	1.1	1.6	2.5	4.6		
Momenta current *	ary maximum 1	А (0-р)	4.7	6.9	10.6	19.5		
Rotor	Without brake	kg • m ²	0.025×10 ⁻⁴	0.051×10 ⁻⁴	0.14×10 ⁻⁴	0.26×10 ⁻⁴		
inertia	With brake	kg • m ²	0.027×10 ⁻⁴	0.054×10 ⁻⁴	0.16×10 ⁻⁴	0.28×10 ⁻⁴		
Applicab	le load inertia	-	30 times the rotor inertia max. *2					
Torque c	onstant * ¹	N • m/A	0.11±10%	0.14±10%	0.20±10%	0.21±10%		
Power ra	te Without brake	kW/s	10.1	19.8	28.9	62.3		
*1	With brake	kW/s	9.4	18.7	25.3	57.8		
Mechanica		ms	1.43	1.03	0.61	0.48		
time consta	^{ant} With brake	ms	1.54	1.09	0.70	0.52		
Electrica	l time constant	ms	0.82	0.91	3.0	3.4		
Allowable radial load *3		Ν	68	68	245	245		
Allowable	e thrust load * ³	Ν	58	58	98	98		
Weight \	Without brake	kg	Approx. 0.31	Approx. 0.45	Approx. 0.78	Approx. 1.2		
١	With brake	kg	Approx. 0.51	Approx. 0.65	Approx. 1.2	Approx. 1.6		
Radiator	plate dimensions	(material)	100 × 80 × t10 (Al)		130 × 120 × t12 (AI)			
Applicab	le Servo Drives (F		KTA5L	KT01L	KT02L	KT04L		
Brake	e inertia	kg • m ²	2×10 ⁻⁷	2×10 ⁻⁷	1.8×10 ⁻⁶	1.8×10 ⁻⁶		
Excit	Excitation voltage *4 V		24 VDC ± 5%					
Powe (at 20	er consumption D°C)	W	7	7	9	9		
Curre (at 20	ent consumption D°C)	А	0.3	0.3	0.36	0.36		
Statio	c friction torque	N • m	0.29 min.	0.29 min.	1.27 min.	1.27 min.		
Se Attra	ction time * ⁵	ms	35 max.	35 max.	50 max.	50 max.		
Relea	ase time * ⁵	ms	20 max.	20 max.	15 max.	15 max.		
Backlash		±1°						
Brake specifications Relea Back Back Back Allow Allow Allow	vable work per ng	J	39.2	39.2	137	137		
	able total work	J	4.9×10 ³	4.9×10 ³	44.1×10 ³	44.1×10 ³		

3-3 Servomotor Specifications

			100 VAC			
	Model (R88M-)		K05030H	K10030L	K20030L	K40030L
Ite	Item Unit		K05030T	K10030S	K20030S	K40030S
specifications	Allowable angular acceleration	rad/s ²	30,000 max. (Speed of 2,800 r/min or more must not be changed in less than 10 ms.)			
	Brake limit	-	10 million times min.			
peci	Rating	-	Continuous			
Brake sp	Insulation class	_	Туре F			

			200 VAC				
Model (R88M-)			K05030H	K10030H	K20030H	K40030H	
Item		Unit	K05030T	K10030T	K20030T	K40030T	
Rated outp	ut * ¹	W	50	100	200	400	
Rated torqu	ue * ¹	N • m	0.16	0.32	0.64	1.3	
Rated rotat	ion speed	r/min	3,000	l		1	
Maximum r	otation speed	r/min	6,000				
Momentary torque * ¹	maximum	N • m	0.48	0.95	1.91	3.8	
Rated curre	ent * ¹	A (rms)	1.1	1.1	1.5	2.4	
Momentary maximum current * ¹		A (0-p)	4.7	4.7	6.5	10.2	
Rotor	Without brake	kg • m ²	0.025×10 ⁻⁴	0.051×10 ⁻⁴	0.14×10 ⁻⁴	0.26×10 ⁻⁴	
inertia	With brake	kg∙m²	0.027×10 ⁻⁴	0.054 ×10 ⁻⁴	0.16×10 ⁻⁴	0.28×10 ⁻⁴	
Applicable	load inertia	-	30 times the rotor inertia max.* ²				
Torque cor	stant *1	N • m/A	0.11±10%	0.21±10%	0.32±10%	0.40±10%	
	Without brake	kW/s	10.1	19.8	28.9	62.3	
*1	With brake	kW/s	9.4	18.7	25.3	57.8	
	Without brake	ms	1.43	1.07	0.58	0.43	
time constant	With brake	ms	1.54	1.13	0.66	0.46	
Electrical ti	me constant	ms	0.82	0.90	3.2	3.4	
Allowable r	adial load * ³	Ν	68	68	245	245	
Allowable t	hrust load *3	Ν	58	58	98	98	
Weight Wi	thout brake	kg	Approx. 0.31	Approx. 0.46	Approx. 0.79	Approx. 1.2	
Wi	th brake	kg	Approx. 0.51	Approx. 0.66	Approx. 1.2	Approx. 1.6	
Radiator pl	ate dimensions	(material)	$100 \times 80 \times t10$ (AI)		130 × 120 × t12 (Al)		
Applicable	Servo Drives (F	R88D-)	KT01H	KT01H	KT02H	KT04H	

			20	0 VAC			
Model (R88M-))	K05030H	K10030H	K20030H	K40030H K40030T		
tem	Unit	K05030T	K10030T	K20030T			
Brake inertia	kg • m ²	2×10 ⁻⁷	2×10 ⁻⁷	1.8×10 ⁻⁶	1.8×10 ⁻⁶		
Excitation voltage *4	V	24 VDC ± 5%			-		
Power consumption (at 20°C)	w	7	7	9	9		
Current consumption (at 20°C)	А	0.3	0.3	0.36	0.36		
Static friction torque	N • m	0.29 min.	0.29 min.	1.27 min.	1.27 min.		
Attraction time *5	ms	35 max.	35 max.	50 max.	50 max.		
Release time *5	ms	20 max.	20 max.	15 max.	15 max.		
Backlash		±1°		I			
Allowable work per braking	J	39.2	39.2	137	137		
Allowable total work	J	4.9×10 ³	4.9×10 ³	44.1×10 ³	44.1×10 ³		
Allowable total work Allowable angular acceleration Brake limit Rating Insulation class	rad/s ²	30,000 max. (Speed of 2,800 r/min or more must not be changed in less than 10 ms.)					
Brake limit	-	10 million times min.					
Rating	-	Continuous					
Insulation class	_	Туре F					

				200 VAC		
Model (R88M-)			K75030H	K1K030H	K1K530H	
Item		Unit	K75030T	K1K030T	K1K530T	
Rated outp	out * ¹	W	750	1000	1500	
Rated torq	ue * ¹	N • m	2.4	3.18	4.77	
Rated rota	tion speed	r/min	3,000	I		
Maximum	rotation speed	r/min	6,000	5,000		
Momentar torque * ¹	y maximum	N ∙ m	7.1	9.55	14.3	
Rated curr	ent *1	A (rms)	4.1	6.6	8.2	
Momentar current *1	y maximum	A (0-p)		28	35	
Rotor	Without brake	kg ∙ m²	0.87×10 ⁻⁴	2.03×10 ⁻⁴	2.84×10 ⁻⁴	
inertia	With brake	kg • m ²	0.97×10 ⁻⁴	2.35×10 ⁻⁴	3.17×10 ⁻⁴	
Applicable	load inertia	_	20 times the rotor inertia max. * ²	15 times the rotor inertia max. *2		
Torque co	nstant *1	N • m/A	0.45±10%	0.37 0.45		
	Without brake	kW/s	65.4	49.8	80.1	
*1	With brake	kW/s	58.7	43.0	71.8	
Mechanica	Without brake	ms	0.37	0.61	0.49	
time constant	With brake	ms	0.42	0.71	0.55	
Electrical t	ime constant	ms	5.3	5.8	6.3	
Allowable	radial load * ³	Ν	392	490	490	
Allowable thrust load *3		N	147	196	196	
Weight W	ithout brake	kg	Approx. 2.3	Approx. 3.5	Approx. 4.4	
W	ith brake	kg	Approx. 3.1	Approx. 4.5	Approx. 5.4	
Radiator p	late dimensions	(material)	$170 \times 160 \times t12$ (AI)	$320 \times 300 \times t20$ (AI)		
Applicable	Servo Drives (F	R88D-)	KT08H	KT15H	KT15H	

			200 VAC	
Model (R88M-))	K75030H	K1K030H	K1K530H
em	Unit	K75030T	K1K030T	K1K530T
Brake inertia	kg • m ²	0.75×10 ⁻⁵	0.33×10 ⁻⁴	0.33×10 ⁻⁴
Excitation voltage *4	V	24 VDC ± 5%	24 VDC ± 10%	
Power consumption (at 20°C)	w	10	19	19
Current consumption (at 20°C)	А	0.42	0.81±10%	0.81±10%
Static friction torque	N • m	2.45 min.	7.8 min.	7.8 min.
Attraction time *5	ms	70 max.	50 max.	50 max.
Release time *5	ms	20 max.	15 max. * ⁶	15 max. * ⁶
Backlash		±1°		
Allowable work per braking	J	196	392	392
Allowable total work	J	1.47×10 ⁵	4.9×10 ⁵	4.9×10 ⁵
Allowable total work Allowable angular acceleration Brake limit Rating Insulation class	rad/s ²	30,000	10,000	
Brake limit	-	10 million times min.	1	
Rating	-	Continuous		
Insulation class	-	Type F		

	Model (R88M-)			20	0 VAC			
			K2K030H	K3K030H	K4K030H	K5K030H		
	Item	Unit	K2K030T	K3K030T	K4K030T	K5K030T		
Rated out	put * ¹	W	2000	3000	4000	5000		
Rated torc	ue * ¹	N • m	6.37	9.55	12.7	15.9		
Rated rota	ation speed	r/min	3,000	·	·	·		
Maximum	rotation speed	r/min	5,000		4,500	4,500		
Momentar torque * ¹	y maximum	N • m	19.1	28.6	38.2	47.7		
Rated curi	rent * ¹	A (rms)	11.3	18.1	19.6	24.0		
Momentar current * ¹	y maximum	А (0-р)	48	77	83	102		
Rotor	Without brake	kg • m ²	3.68×10 ⁻⁴	6.50×10 ⁻⁴	12.9×10 ⁻⁴	17.4×10 ⁻⁴		
inertia	With brake	kg • m ²	4.01×10 ⁻⁴	6.85×10 ⁻⁴	14.2×10 ⁻⁴	18.6×10 ⁻⁴		
Applicable	load inertia	-	15 times the rotor inertia max. *2					
Torque co	nstant * ¹	N • m/A	0.44	0.41	0.49	0.49		
Power rate	Without brake	kW/s	110	140	126	146		
	With brake	kW/s	101	116	114	136		
Mechanica I time	a Without brake	ms	0.44	0.41	0.51	0.50		
constant	With brake	ms	0.48	0.49	0.56	0.54		
Electrical 1	time constant	ms	6.7	11	12	13		
Allowable	radial load * ³	N	490	490	784	784		
Allowable thrust load *3		N	196	196	343	343		
Weig W	ithout brake	kg	Approx. 5.3	Approx. 8.3	Approx. 11.0	Approx. 14.0		
ht W	ith brake	kg	Approx. 6.3	Approx. 9.4	Approx. 12.6	Approx. 16.0		
Radiator p	late dimensions	(material)	$380 \times 350 \times t30$	(AI)				
Applicable	e drives (R88D-)		KT20H	KT30H	KT50H	KT50H		

				200 VAC					
	Model (R88M-)		K2K030H	K3K030H	K4K030H	K5K030H			
	Item	Unit	K2K030T	K3K030T	K4K030T	K5K030T			
	Brake inertia	kg • m ²	0.33×10 ⁻⁴	0.33×10 ⁻⁴	1.35×10 ⁻⁴	1.35×10 ⁻⁴			
	Excitation voltage *4	V	24 VDC ± 10%						
	Power consumption (at 20°C)	w	19	19	22	22			
	Current consumption (at 20°C)	А	0.81±10%	0.81±10%	0.90±10%	0.90±10%			
	Static friction torque	N • m	7.8 min.	11.8 min.	16.1 min.	16.1 min.			
	Attraction time *5	ms	50 max.	80 max.	110 max.	110 max.			
	Release time *5	ms	15 max. * ⁶	15 max. * ⁶	50 max. * ⁷	50 max. * ⁷			
	Backlash		±1°	-	•				
	Allowable work per braking	J	392	392	1,470	1,470			
S	Allowable total work	J	4.9×10 ⁵	4.9×10 ⁵	2.2×10 ⁶	2.2×10 ⁶			
Brake specifications	Allowable angular acceleration	rad/s ²	10,000						
peci	Brake limit	-	10 million times m	nin.					
kes	Rating	-	Continuous						
БТА	Insulation class	-	Type F						

			400 VAC				
Model (R88M-)		K75030F	K1K030F	K1K530F	K2K030F		
Item		Unit	K75030C	K1K030C	K1K530C	K2K030C	
Rated ou	tput * ¹	W	750	1000	1500	2000	
Rated tor	rque * ¹	N • m	2.39	3.18	4.77	6.37	
Rated rot	tation speed	r/min	3,000	1		- I	
Maximum	n rotation speed	r/min	5,000				
Momenta torque * ¹	ary maximum	N • m	7.16	9.55	14.3	19.1	
Rated cu	rrent *1	A (rms)	2.4	3.3	4.2	5.7	
Momentary maximum current * ¹		A (0-p)	10	14	18	24	
Rotor	Without brake	kg ∙ m²	1.61×10 ⁻⁴	2.03×10 ⁻⁴	2.84×10 ⁻⁴	3.68×10 ⁻⁴	
inertia	With brake	kg∙m²	1.93×10 ⁻⁴	2.35×10 ⁻⁴	3.17×10 ⁻⁴	4.01×10 ⁻⁴	
Applicabl	le load inertia	_	20 times the rotor inertia max. * ²	15 times the rotor inertia max. *2			
Torque c	onstant *1	N • m/A	0.78	0.75	0.89	0.87	
	te Without brake	kW/s	35.5	49.8	80.1	110	
*1	With brake	kW/s	29.6	43	71.8	101	
	al Without brake	ms	0.67	0.60	0.49	0.45	
time constant	With brake	ms	0.8	0.70	0.55	0.49	
Electrical	time constant	ms	5.9	5.8	6.5	6.6	
Allowable radial load *3		Ν	490	490	490	490	
Allowable	e thrust load * ³	Ν	196	196	196	196	
Weight V	Without brake	kg	Approx. 3.1	Approx. 3.5	Approx. 4.4	Approx. 5.3	
٧	With brake	kg	Approx. 4.1	Approx. 4.5	Approx. 5.4	Approx. 6.3	
Radiator	plate dimensions	(material)	$320 \times 300 \times t20$ (A	l)			
Applicabl	le Servo Drives (F	R88D-)	KT10F	KT15F	KT15F	KT20F	


			40	0 VAC		
Model (R88M-)		K75030F	K1K030F	K1K530F	K2K030F	
tem	Unit	K75030C	K1K030C	K1K530C	K2K030C	
Brake inertia	kg • m ²	0.33×10 ⁻⁴	0.33×10 ⁻⁴	0.33×10 ⁻⁴	0.33×10 ⁻⁴	
Excitation voltage *4	V	24 VDC ± 10%			-	
Power consumption (at 20°C)	w	17	19	19	19	
Current consumption (at 20°C)	А	0.70±10%	0.81±10%	0.81±10%	0.81±10%	
Static friction torque	N • m	2.5 min.	7.8 min.	7.8 min.	7.8 min.	
Attraction time *5	ms	50 max.	50 max.	50 max.	50 max.	
Release time *5	ms	15 max. * ⁶				
Backlash		±1°			I	
Allowable work per braking	J	392	392	392	392	
Allowable total work	J	4.9×10 ⁵	4.9×10 ⁵	4.9×10 ⁵	4.9×10 ⁵	
Allowable angular acceleration	rad/s ²	10,000				
Brake limit	-	10 million times min.				
Allowable total work Allowable angular acceleration Brake limit Rating Insulation class	-	Continuous				
Insulation class	-	Type F				

				400 VAC			
Model (R88M-)		K3K030F	K4K030F	K5K030F			
Item		Unit	K3K030C	K4K030C	K5K030C		
Rated out	put * ¹	W	3000	4000	5000		
Rated tor	que * ¹	N • m	9.55	12.7	15.9		
Rated rot	ation speed	r/min	3,000	1			
Maximum	rotation speed	r/min	5,000	4,500			
Momenta torque * ¹	ry maximum	N • m	28.6	38.2	47.7		
Rated cu	rent *1	A (rms)	9.2	9.9	12.0		
Momenta current * ¹	ry maximum	A (0-p)	39	42	51		
Rotor	Without brake	kg∙m²	6.50×10 ⁻⁴	12.9×10 ⁻⁴	17.4×10 ⁻⁴		
inertia	With brake	kg ∙ m²	7.85×10 ⁻⁴	14.2×10 ⁻⁴	18.6×10 ⁻⁴		
Applicabl	e load inertia	_	15 times the rotor inertia max. *2				
Torque co	onstant *1	N • m/A	0.81	0.98	0.98		
Power rat	e Without brake	kW/s	140	126	146		
*1	With brake	kW/s	116	114	136		
	al Without brake	ms	0.40	0.51	0.50		
time constant	With brake	ms	0.49	0.56	0.54		
Electrical	time constant	ms	12	13	13		
Allowable	radial load *3	Ν	490	784	784		
Allowable thrust load *3		N	196	343	343		
Weight V	/ithout brake	kg	Approx. 8.3	Approx. 11.0	Approx. 14.0		
۷	/ith brake	kg	Approx. 9.4	Approx. 12.6	Approx. 16.0		
Radiator	plate dimensions	(material)	$380 \times 350 \times t30$ (AI)				
Applicabl	e Servo Drives (F	R88D-)	KT30F	KT50F	KT50F		

			400 VAC				
Model (R88M-))	K3K030F	K4K030F	K5K030F			
em	Unit	K3K030C	K4K030C	K5K030C			
Brake inertia	kg • m ²	0.33×10 ⁻⁴	1.35×10 ⁻⁴	1.35×10 ⁻⁴			
Excitation voltage *4	V	24 VDC ± 10%		1			
Power consumption (at 20°C)	w	19	22	22			
Current consumption (at 20°C)	А	0.81±10%	0.90±10%	0.90±10%			
Static friction torque	N • m	11.8 min.	16.1 min.	16.1 min.			
Attraction time *5	ms	80 max.	110 max.	110 max.			
Release time *5	ms	15 max. * ⁶	50 max. * ⁷	50 max. * ⁷			
Backlash		±1°					
Allowable work per braking	J	392	1470	1470			
Allowable total work	J	4.9×10 ⁵	2.2×10 ⁶	2.2×10 ⁶			
Allowable angular acceleration	rad/s ²	10,000	10,000				
Brake limit	-	10 million times min.					
Allowable total work Allowable angular acceleration Brake limit Rating Insulation class	-	Continuous					
Insulation class	-	Type F	Type F				

- *1. These are the values when the Servomotor is combined with a drive at normal temperature (20°C, 65%). The momentary maximum torque indicates the standard value.
- *2. Applicable load inertia.
 - The operable load inertia ratio (load inertia/rotor inertia) depends on the mechanical configuration and its rigidity. For a machine with high rigidity, operation is possible even with high load inertia. Select an appropriate motor and confirm that operation is possible.
 - The dynamic brake is rated for short-term operation. Use it only for emergency stopping. Design the system to stop for at least ten minutes after the dynamic brake operates. Otherwise, the dynamic brake circuits may fail or the dynamic brake resistor may burn.
- *3. The allowable radial and thrust loads are the values determined for a limit of 20,000 hours at normal operating temperatures.

The allowable radial loads are applied as shown in the following diagram.




- *4. This is a non-excitation brake. (It is released when excitation voltage is applied.)
- *5. The operation time is the value (reference value) measured with a surge suppressor (CR50500 by Okaya Electric Industries Co., Ltd.).
- *6. Direct current switching with a varistor (Z15D151 by Ishizuka Electronics Co.).
- *7. Direct current switching with a varistor (TNR9G820K by Nippon Chemi-Con Corporation).


Torque-Rotation Speed Characteristics for 3,000-r/min Servomotors

- 3,000-r/min Servomotor (100 VAC)
 - The following graphs show the characteristics with a 3-m standard cable and a 100-VAC input.


• R88M-K05030H/T (50 W)

- R88M-K10030L/S (100 W)
- R88M-K20030L/S (200 W)






- Note 1: The continuous operation range is the range in which continuous operation is possible. Continuous operation at the maximum speed is also possible. However, doing so will reduce the output torque.
- Note 2: If the motor power cable exceeds 20 m, the voltage drop will increase and the momentary operation range will become narrower.




- Note 1: The continuous operation range is the range in which continuous operation is possible. Continuous operation at the maximum speed is also possible. However, doing so will reduce the output torque.
- Note 2: If the motor power cable exceeds 20 m, the voltage drop will increase and the momentary operation range will become narrower.


Specifications




- R88M-K75030F/C (750 W)
- R88M-K1K030F/C (1 kW)








- Note 1: The continuous operation range is the range in which continuous operation is possible. Continuous operation at the maximum speed is also possible. However, doing so will reduce the output torque.
- Note 2: If the motor power cable exceeds 20 m, the voltage drop will increase and the momentary operation range will become narrower.



Use the following Servomotors in the ranges shown in the graphs below. Using outside of these ranges may cause the motor to generate heat, which could result in encoder malfunction.



1,500-r/min and 2,000-r/min Servomotors

			200 VAC				
Model (R88M-)			K1K020H	K1K520H	K2K020H		
Item	ltem Unit		K1K020T	K1K520T	K2K020T		
Rated outp	ut * ¹	W	1,000	1,500	2,000		
Rated torq	ue * ¹	N • m	4.77	7.16	9.55		
Rated rotat	tion speed	r/min	2,000				
Maximum ı	rotation speed	r/min	3,000				
Momentary torque * ¹	r maximum	N • m	14.3	21.5	28.6		
Rated curre	ent * ¹	A (rms)	5.7	9.4	11.5		
Momentary current * ¹	r maximum	А (0-р)	24	40	49		
Rotor	Without brake	kg∙m²	4.60×10 ⁻⁴	6.70×10 ⁻⁴	8.72×10 ⁻⁴		
inertia	With brake	kg ∙ m²	5.90×10 ⁻⁴	7.99×10 ⁻⁴	10.0×10 ⁻⁴		
Applicable	load inertia	_	10 times the rotor inertia	max. * ²			
Torque cor	nstant *1	N • m/A	0.63	0.58	0.64		
	Without brake	kW/s	49.5	76.5	105		
*1	With brake	kW/s	38.6	64.2	91.2		
	Without brake	ms	0.80	0.66	0.66		
time constant	With brake	ms	1.02	0.80	0.76		
Electrical ti	me constant	ms	9.4	10	10		
Allowable r	adial load * ³	Ν	490	490	490		
Allowable t	hrust load * ³	N	196	196	196		
Weight Wi	thout brake	kg	Approx. 5.2	Approx. 6.7	Approx. 8.0		
Wi	th brake	kg	Approx. 6.7	Approx. 8.2	Approx. 9.5		
Radiator pl (material)	ate dimensions		275 × 260 × t15 (AI)				
Applicable	Servo Drives (F		KT10H	KT15H	КТ20Н		
Brake i	nertia	kg∙m²	1.35×10 ⁻⁴	1.35×10 ⁻⁴	1.35×10 ⁻⁴		
Excitati	on voltage *4	V	24 VDC ± 10%				
Power (at 20°0	consumption C)	W	14	19	19		
Current (at 20°0	t consumption C)	А	0.59±10%	0.79±10%	0.79±10%		
Static f	riction torque	N • m	4.9 min.	13.7 min.	13.7 min.		
Attracti	on time * ⁵	ms	80 max.	100 max.	100 max.		
Releas	e time * ⁵	ms	70 max. * ⁶	50 max. * ⁶	50 max. * ⁶		
Backlas	sh		±1°	·	· ·		
Attracti Attracti Releas Backlas Allowat braking	ole work per	J	588	1,176	1,176		

			200 VAC				
	Model (R88M-)	1	K1K020H	K1K520H	K2K020H		
Ite	ltem Unit		K1K020T	K1K520T	K2K020T		
ns	Allowable total work	J	7.8×10 ⁵	1.5×10 ⁶	1.5×10 ⁶		
specifications	Allowable angular acceleration	rad/s ²	10,000				
spec	Brake limit	-	10 million times min.				
Brake :	Rating	-	Continuous				
Bra	Insulation class	-	Туре F				

				200 VAC		
	Model (R88M-)		K3K020H	K4K020H	K5K020H	
Item		Unit	K3K020T	K4K020T	K5K020T	
Rated out	out * ¹	W	3,000	4,000	5,000	
Rated tore	lue *1	N • m	14.3	19.1	23.9	
Rated rota	tion speed	r/min	2,000			
Maximum	rotation speed	r/min	3,000			
Momentar torque * ¹	y maximum	N • m	43.0	57.3	71.6	
Rated cur	rent *1	A (rms)	17.4	21.0	25.9	
Momentar current *1	y maximum	А (0-р)	74	89	110	
Rotor	Without brake	kg • m²	12.9×10 ⁻⁴	37.6×10 ⁻⁴	48.0×10 ⁻⁴	
inertia	With brake	kg • m ²	14.2×10 ⁻⁴	38.6×10 ⁻⁴	48.8×10 ⁻⁴	
Applicable	load inertia	-	10 times the rotor inerti	a max. * ²		
Torque co	nstant * ¹	N • m/A	0.59	0.70	0.70	
	Without brake	kW/s	159	97.1	119	
*1	With brake	kW/s	144	94.5	117	
	I Without brake	ms	0.57	0.65	0.63	
time constant	With brake	ms	0.63	0.66	0.64	
Electrical	time constant	ms	12	20	19	
Allowable	radial load * ³	Ν	784	784	784	
Allowable	thrust load *3	N	343	343	343	
Weight W	ithout brake	kg	Approx. 11.0	Approx. 15.5	Approx. 18.6	
V	ith brake	kg	Approx. 12.6	Approx. 18.7	Approx. 21.8	
Radiator p (material)	late dimensions		$380 \times 350 \times t30$ (AI)	$470 \times 440 \times t30$ (AI)		
Applicable	Servo Drives (F	R88D-)	КТ30Н	KT50H	KT50H	

			200 VAC	
Model (R88M-)		K3K020H	K4K020H	K5K020H
tem	Unit	K3K020T	K4K020T	K5K020T
Brake inertia	kg • m ²	1.35×10 ⁻⁴	4.7×10 ⁻⁴	4.7×10 ⁻⁴
Excitation voltage *4	V	24 VDC ± 10%		
Power consumption (at 20°C)	w	22	31	31
Current consumption (at 20°C)	А	0.90±10%	1.3±10%	1.3±10%
Static friction torque	N • m	16.2 min.	24.5 min.	24.5 min.
Attraction time *5	ms	110 max.	80 max.	80 max.
Release time *5	ms	50 max. * ⁶	25 max. * ⁷	25 max. * ⁷
Backlash		±1°		
Allowable work per braking	J	1470	1372	1372
Allowable total work	J	2.2×10 ⁶	2.9×10 ⁶	2.9×10 ⁶
Allowable total work Allowable angular acceleration Brake limit Rating Insulation class	rad/s ²	10,000		
Brake limit	-	10 million times min.		
Rating	-	Continuous		
Insulation class	-	Type F		

			200 VAC				
N	Nodel (R88M-)						
Item		Unit	K7K515T	K11K015T	K15K015T		
Rated outpu	ut * ¹	W	7,500	11,000	15,000		
Rated torqu	ie * ¹	N • m	47.8	70.0	95.0		
Rated rotati	on speed	r/min	1,500	1			
Maximum re	otation speed	r/min	3,000	2,000			
Momentary torque * ¹	maximum	N•m	119.0	175.0	224.0		
Rated curre	ent * ¹	A (rms)	44.0	54.2	66.1		
Momentary current *1	maximum	A (0-p)	165	203	236		
Rotor	Without brake	kg ∙ m²	101×10 ⁻⁴	212×10 ⁻⁴	302×10 ⁻⁴		
inertia	With brake	kg∙m²	107×10 ⁻⁴	220×10 ⁻⁴	311×10 ⁻⁴		
Applicable I	oad inertia	_	10 times the rotor inertia max. *2				
Torque con	stant * ¹	N • m/A	0.77	0.92	1.05		
	Without brake	kW/s	226	231	302		
*1	With brake	kW/s	213	223	293		
	Without brake	ms	0.58	0.80	0.71		
time constant	With brake	ms	0.61	0.83	0.74		
Electrical tir	ne constant	ms	21	31	32		
Allowable ra	adial load * ³	Ν	1,176	2,254	2,254		
Allowable th	nrust load * ³	N	490	686	686		
Weight Wit	hout brake	kg	Approx. 36.4	Approx. 52.7	Approx. 70.2		
Wit	h brake	kg	Approx. 40.4	Approx. 58.9	Approx. 76.3		
Radiator pla (material)	ate dimensions		$550 \times 520 \times t30$ (AI)	$670 \times 630 \times t35$ (AI)			
Applicable \$	Servo Drives (F	R88D-)	КТ75Н	KT150H	KT150H		

			200 VAC	
Model (R88M-))			
em Unit		K7K515T	K11K015T	K15K015T
Brake inertia	kg • m ²	4.7×10 ⁻⁴	7.1×10 ⁻⁴	7.1×10 ⁻⁴
Excitation voltage *4	V	24 VDC ± 10%	·	·
Power consumption (at 20°C)	w	34	26	26
Current consumption (at 20°C)	А	1.4±10%	1.08±10%	1.08±10%
Static friction torque	N • m	58.8 min.	100 min.	100 min.
Attraction time *5	ms	150 max.	300 max.	300 max.
Release time *5	ms	50 max.	140 max.	140 max.
Backlash		±1°		
Allowable work per braking	J	1,372	2,000	2,000
Allowable total work	J	2.9×10 ⁶	4.0×10 ⁶	4.0×10 ⁶
Allowable angular acceleration	rad/s ²	5,000	3,000	
Brake limit	-	10 million times min.		
Rating	-	Continuous		
Allowable total work Allowable angular acceleration Brake limit Rating Insulation class	-	Type F		

				40	0 VAC	
	Model (R88M-)		K40020F	K60020F	K1K020F	K1K520F
Item		Unit	K40020C	K60020C	K1K020C	K1K520C
Rated out	out * ¹	W	400	600	1,000	1,500
Rated torc	ue * ¹	N • m	1.91	2.86	4.77	7.16
Rated rota	tion speed	r/min	2,000			
Maximum	rotation speed	r/min	3,000			
Momentar torque * ¹	y maximum	N • m	5.73	8.59	14.3	21.5
Rated cur	rent *1	A (rms)	1.2	1.5	2.8	4.7
Momentar current * ¹	y maximum	A (0-p)	4.9	6.5	12	20
Rotor	Without brake	kg • m ²	1.61×10 ⁻⁴	2.03×10 ⁻⁴	4.60×10 ⁻⁴	6.70×10 ⁻⁴
inertia	With brake	kg • m ²	1.90×10 ⁻⁴	2.35×10 ⁻⁴	5.90×10 ⁻⁴	7.99×10 ⁻⁴
Applicable	load inertia	-	10 times the roto	or inertia max. * ²		
Torque co	nstant * ¹	N • m/A	1.27	1.38	1.27	1.16
	Without brake	kW/s	22.7	40.3	49.5	76.5
*1	With brake	kW/s	19.2	34.8	38.6	64.2
	I Without brake	ms	0.70	0.62	0.79	0.66
time constant	With brake	ms	0.83	0.72	1.01	0.79
Electrical	ime constant	ms	5.7	5.9	10	10
Allowable	radial load * ³	Ν	490	490	490	490
Allowable	thrust load * ³	Ν	196	196	196	196
Weight W	ithout brake	kg	Approx. 3.1	Approx. 3.5	Approx. 5.2	Approx. 6.7
V	ith brake	kg	Approx. 4.1	Approx. 4.5	Approx. 6.7	Approx. 8.2
Radiator p (material)	late dimensions		$320 \times 300 \times t20$	(AI)	$275 \times 260 \times t15$	(AI)
Applicable	Servo Drives (F	R88D-)	KT06F	KT06F	KT10F	KT15F

			40	0 VAC		
Model (R88M-)		K40020F	K60020F	K1K020F	K1K520F	
Item	Unit	K40020C	K60020C	K1K020C	K1K520C	
Brake inertia	kg • m ²	1.35×10 ⁻⁴	1.35×10 ⁻⁴	1.35×10 ⁻⁴	1.35×10 ⁻⁴	
Excitation voltage *4	V	24 VDC ± 10%				
Power consumption (at 20°C)	w	17	17	14	19	
Current consumption (at 20°C)	А	0.70±10%	0.70±10%	0.59±10%	0.79±10%	
Static friction torque	N • m	2.5 min.	2.5 min.	4.9 min.	13.7 min.	
Attraction time *5	ms	50 max.	50 max.	80 max.	100 max.	
Release time *5	ms	15 max. * ⁷	15 max. * ⁷	70 max. * ⁶	50 max. * ⁶	
Backlash		±1°				
Allowable work per braking	J	392	392	588	1176	
Allowable total work	J	4.9×10 ⁵	4.9×10 ⁵	7.8×10 ⁵	1.5×10 ⁶	
Allowable total work Allowable angular acceleration Brake limit Rating	rad/s ²	10,000				
Brake limit	-	10 million times	min.			
Rating	-	Continuous				
Insulation class	-	Type F				

				400	VAC			
	Model (R88M-)		K2K020F	K3K020F	K4K020F	K5K020F		
Item		Unit	K2K020C	K3K020C	K4K020C	K5K020C		
Rated outp	out * ¹	W	2,000	3,000	4,000	5,000		
Rated torq	ue * ¹	N • m	9.55	14.3	19.1	23.9		
Rated rota	tion speed	r/min	2,000			1		
Maximum	rotation speed	r/min	3,000					
Momentar torque * ¹	y maximum	N • m	28.7	43.0	57.3	71.6		
Rated curr	ent *1	A (rms)	5.9	8.7	10.6	13.0		
Momentar current *1	y maximum	А (0-р)	25	37	45	55		
Rotor	Without brake	kg∙m²	8.72×10 ⁻⁴	12.9×10 ⁻⁴	37.6×10 ⁻⁴	48.0×10 ⁻⁴		
inertia	With brake	kg • m ²	10.0×10 ⁻⁴	14.2×10 ⁻⁴	38.6×10 ⁻⁴	48.8×10 ⁻⁴		
Applicable	load inertia	-	10 times the rotor inertia max. *2					
Torque co	nstant * ¹	N • m/A	1.27	1.18	1.40	1.46		
	Without brake	kW/s	105	159	97.1	119		
*1	With brake	kW/s	91.2	144	94.5	117		
	Without brake	ms	0.68	0.56	0.60	0.60		
time constant	With brake	ms	0.78	0.61	0.61	0.61		
Electrical t	ime constant	ms	10	12	21	19		
Allowable	radial load * ³	Ν	490	784	784	784		
Allowable	thrust load * ³	Ν	196	343	343	343		
Weight W	ithout brake	kg	Approx. 8.0	Approx. 11.0	Approx. 15.5	Approx. 18.6		
W	ith brake	kg	Approx. 9.5	Approx. 12.6	Approx. 18.7	Approx. 21.8		
Radiator p (material)	late dimensions		$\begin{array}{c} 275 \times 260 \times t15 \\ (\text{AI}) \end{array}$	$\begin{array}{c} 380 \times 350 \times t30 \\ (\text{AI}) \end{array}$	$470 \times 440 \times t30$	(AI)		
Applicable	Servo Drives (F	R88D-)	KT20F	KT30F	KT50F	KT50F		

			40	0 VAC		
Model (R88M-))	K2K020F	K3K020F	K4K020F	K5K020F	
Item	Unit	K2K020C	K3K020C	K4K020C	K5K020C	
Brake inertia	kg • m ²	1.35×10 ⁻⁴	1.35×10 ⁻⁴	4.7×10 ⁻⁴	4.7×10 ⁻⁴	
Excitation voltage *4	V	24 VDC ± 10%				
Power consumption (at 20°C)	w	19	22	31	31	
Current consumption (at 20°C)	А	0.79±10%	0.90±10%	1.3±10%	1.3±10%	
Static friction torque	N • m	13.7 min.	16.2 min.	24.5 min.	24.5 min.	
Attraction time *5	ms	100 max.	110 max.	80 max.	80 max.	
Release time *5	ms	50 max. * ⁶	50 max. * ⁶	25 max. * ⁷	25 max. * ⁷	
Backlash		±1°				
Allowable work per braking	J	1176	1470	1372	1372	
Allowable total work	J	1.5×10 ⁶	2.2×10 ⁶	2.9×10 ⁶	2.9×10 ⁶	
Allowable total work Allowable angular acceleration Brake limit Rating	rad/s ²	10,000				
Brake limit	-	10 million times	min.			
Rating	-	Continuous				
Insulation class	-	Type F				

				400 VAC		
	Model (R88M-)					
Item		Unit	K7K515C	K11K015C	K15K015C	
Rated ou	tput * ¹	W	7,500	11,000	15,000	
Rated tor	que * ¹	N • m	47.8	70.0	95.9	
Rated rot	ation speed	r/min	1,500	-1		
Maximun	n rotation speed	r/min	3,000	2,000		
Momenta torque *1	ry maximum	N • m	119.0	175.0	224.0	
Rated cu	rrent *1	A (rms)	22.0	27.1	33.1	
Momenta current *1	ry maximum	А (0-р)	83	101	118	
Rotor	Without brake	kg • m ²	101×10 ⁻⁴	212×10 ⁻⁴	302×10 ⁻⁴	
inertia	With brake	kg • m ²	107×10 ⁻⁴	220×10 ⁻⁴	311×10 ⁻⁴	
Applicabl	e load inertia	-	10 times the rotor inertia max. *2			
Torque c	onstant * ¹	N • m/A	1.54	1.84	2.10	
Powerrat	e Without brake	kW/s	226	231	302	
*1	With brake	kW/s	213	223	293	
	al Without brake	ms	0.58	0.80	0.71	
time constant	With brake	ms	0.61	0.83	0.74	
Electrical	time constant	ms	21	31	32	
Allowable	e radial load * ³	Ν	1,176	2,254	2,254	
Allowable	e thrust load * ³	Ν	490	686	686	
Weight V	Vithout brake	kg	Approx. 36.4	Approx. 52.7	Approx. 70.2	
١	With brake k		Approx. 40.4	Approx. 58.9	Approx. 76.3	
Radiator (material)	plate dimensions		$\begin{array}{c} 550\times520\timest30\\ (\text{AI}) \end{array}$	670 × 630 × t35	(AI)	
Applicabl	e Servo Drives (F	R88D-)	KT75F	KT150F	KT150F	

Specifications


				400 VAC	
	Model (R88M-)	1			
lte	m	Unit	K7K515C	K11K015C	K15K015C
	Brake inertia	kg ∙ m²	4.7×10 ⁻⁴	7.1×10 ⁻⁴	7.1×10 ⁻⁴
	Excitation voltage *4	V	24 VDC ± 10%		
	Power consumption (at 20°C)	w	34	26	26
	Current consumption (at 20°C)	А	1.4±10%	1.08±10%	1.08±10%
	Static friction torque	N • m	58.8 min.	100 min.	100 min.
	Attraction time *5	ms	150 max.	300 max.	300 max.
	Release time *5	ms	50 max.	140 max.	140 max.
	Backlash		±1°	•	
	Allowable work per braking	J	1,372	2,000	2,000
ns	Allowable total work	J	2.9×10 ⁶	4.0×10 ⁶	4.0×10 ⁶
Brake specifications	Allowable angular acceleration	rad/s ²	5,000	3,000	•
spec	Brake limit	-	10 million times m	in.	
ake (Rating	-	Continuous		
Bri	Insulation class	-	Type F		

*1. These are the values when the Servomotor is combined with a drive at normal temperature (20°C, 65%). The momentary maximum torque indicates the standard value.


*2. Applicable load inertia.

- The operable load inertia ratio (load inertia/rotor inertia) depends on the mechanical configuration and its rigidity. For a machine with high rigidity, operation is possible even with high load inertia. Select an appropriate motor and confirm that operation is possible.
- The dynamic brake is rated for short-term operation. Use it only for emergency stopping. Design the system to stop for at least ten minutes after the dynamic brake operates. Otherwise, the dynamic brake circuits may fail or the dynamic brake resistor may burn.
- *3. The allowable radial and thrust loads are the values determined for a limit of 20,000 hours at normal operating temperatures.

The allowable radial loads are applied as shown in the following diagram.



- *4. This is a non-excitation brake. (It is released when excitation voltage is applied.)
- *5. The operation time is the value (reference value) measured with a surge suppressor (CR50500 by Okaya Electric Industries Co., Ltd.).
- *6. Direct current switching with a varistor (TNR9G820K by Nippon Chemi-Con Corporation).
- *7. Direct current switching with a varistor (Z15D151 by Ishizuka Electronics Co.).





Note 1: The continuous operation range is the range in which continuous operation is possible. Continuous operation at the maximum speed is also possible. However, doing so will reduce the output torque.


Note 2: If the motor power cable exceeds 20 m, the voltage drop will increase and the momentary operation range will become narrower.

3

Specifications







1,000-r/min Servomotors

					200 VAC		
I	Model (R88M-)		K90010H	K2K010H	K3K010H		
Item		Unit	K90010T	K2K010T	K3K010T	K4K510T	K6K010T
Rated outp	ut * ¹	W	900	2,000	3,000	4,500	6,000
Rated torq	ue * ¹	N • m	8.59	19.1	28.7	43.0	57.0
Rated rotat	tion speed	r/min	1,000				
Maximum I	rotation speed	r/min	2,000				
Momentary torque * ¹	r maximum	N • m	19.3	47.7	71.7	107.0	143.0
Rated curre	ent * ¹	A (rms)	7.6	17.0	22.6	29.7	38.8
Momentary current * ¹	r maximum	А (0-р)	24	60	80	110	149
Rotor	Without brake	kg • m²	6.70×10 ⁻⁴	30.3×10 ⁻⁴	48.4×10 ⁻⁴	79.1×10 ⁻⁴	101×10 ⁻⁴
inertia	With brake	kg • m ²	7.99×10 ⁻⁴	31.4×10 ⁻⁴	49.2×10 ⁻⁴	84.4×10 ⁻⁴	107×10 ⁻⁴
Applicable	load inertia	-	10 times the r	otor inertia max.	*2		
Torque cor	nstant *1	N • m/A	0.86	0.88	0.96	1.02	1.04
	Without brake	kW/s	110	120	170	233	325
*1	With brake	kW/s	92.4	116	167	219	307
	Without brake	ms	0.66	0.75	0.63	0.55	0.54
time constant	With brake	ms	0.78	0.78	0.64	0.63	0.57
Electrical ti	me constant	ms	11	18	21	20	23
Allowable r	adial load *3	N	686	1176	1470	1470	1764
Allowable t	hrust load * ³	N	196	490	490	490	588
Weight Wi	thout brake	kg	Approx. 6.7	Approx. 14.0	Approx. 20.0	Approx. 29.4	Approx. 36.4
Wi	th brake	kg	Approx. 8.2	Approx. 17.5	Approx. 23.5	Approx. 33.3	Approx. 40.4
Radiator pl (material)	ate dimensions		$270 \times 260 \times t^{-1}$	15 (AI)		470 × 440 × t30 (AI)	$\begin{array}{c} 550\times520\times\\ t30 \text{ (AI)} \end{array}$
Applicable	Servo Drives (F	R88D-)	KT15H	КТ30Н	KT50H	KT75H	KT75H
Brake i	nertia	kg ∙ m²	1.35×10 ⁻⁴	4.7×10 ⁻⁴	4.7×10 ⁻⁴	4.7×10 ⁻⁴	4.7×10 ⁻⁴
Excitat	on voltage *4	V	24 VDC ± 109	%			
Power (at 20°	consumption C)	w	19	31	34	34	34
Curren (at 20°	t consumption C)	А	0.79±10%	1.3±10%	1.4±10%	1.4±10%	1.4±10%
Static f	riction torque	N • m	13.7 min.	24.5 min.	58.8 min.	58.8 min.	58.8 min.
Attracti	on time * ⁵	ms	100 max.	80 max.	150 max.	150 max.	150 max.
(at 20° Static f Attracti Backlas	e time * ⁵	ms	50 max. * ⁶	25 max. * ⁷	50 max. * ⁷	50 max.	50 max.
ਰ ਯੂ ਸ਼ੁਸ਼ੂ Backlas	sh		±1°	_	4	<u>I</u>	ļ


			200 VAC					
	Model (R88M-)		K90010H	K2K010H	K3K010H			
Ite	m	Unit	K90010T	K2K010T	K3K010T	K4K510T	K6K010T	
	Allowable work per braking	J	1176	1372	1372	1372	1372	
SL	Allowable total work	J	1.5×10 ⁶	2.9×10 ⁶	2.9×10 ⁶	2.9×10 ⁶	2.9×10 ⁶	
specifications	Allowable angular acceleration	rad/s ²	10,000			5,000		
spec	Brake limit	-	10 million time	s min.				
			Continuous					
Brake	Insulation class	Туре F						

		400 VAC						
Model (R88M-)		K90010F	K2K010F	K3K010F				
ltem		Unit	K90010C	K2K010C	K3K010C	K4K510C	K6K010C	
Rated output *1		W	900	2,000	3,000	4,500	6,000	
Rated tor	que * ¹	N • m	8.59	19.1	28.7	43.0	57.3	
Rated rot	ation speed	r/min	1,000					
Maximum	rotation speed	r/min	2,000					
Momentary maximum torque *1		N • m	19.3	47.7	71.7	107.0	143.0	
Rated current *1		A (rms)	3.8	8.5	11.3	14.8	19.4	
Momentary maximum current * ¹		А (0-р)	12	30	40	55	74	
Rotor	Without brake	kg • m ²	6.70×10 ⁻⁴	30.3×10 ⁻⁴	48.4×10 ⁻⁴	79.1×10 ⁻⁴	101×10 ⁻⁴	
inertia	With brake	kg∙m²	7.99×10 ⁻⁴	31.4×10 ⁻⁴	49.2×10 ⁻⁴	84.4×10 ⁻⁴	107×10 ⁻⁴	
Applicable load inertia		_	10 times the rotor inertia max. *2					
Torque co	onstant * ¹	N • m/A	1.72	1.76	1.92	2.05	2.08	
Power rat	e Without brake	kW/s	110	120	170	233	325	
*1	With brake	kW/s	92.4	116	167	219	307	
Mechanical time constant	al Without brake	ms	0.66	0.76	0.61	0.55	0.54	
	With brake	ms	0.79	0.78	0.62	0.63	0.57	
Electrical	time constant	ms	11	18	22	20	23	
Allowable radial load *3		Ν	686	1176	1470	1470	1764	
Allowable thrust load *3		Ν	196	490	490	490	588	
	/ithout brake	kg	Approx. 6.7	Approx. 14.0	Approx. 20.0	Approx. 29.4	Approx. 36.4	
	/ith brake	kg	Approx. 8.2	Approx. 17.5	Approx. 23.5	Approx. 33.3	Approx. 40.4	
Radiator plate dimensions (material)			270 × 260 × t15 (AI)	470 × 440 × t30 (AI)		470 × 440 × t30 (AI)	550 × 520 × t30 (Al)	
Applicable Servo Drives (R88D-)		R88D-)	KT15F	KT30F	KT50F	KT50F	KT75F	

	400 VAC						
Model (R88M-)	K90010F	K2K010F	K3K010F				
ltem Unit		K90010C	K2K010C	K3K010C	K4K510C	K6K010C	
Brake inertia	kg • m ²	1.35×10 ⁻⁴	4.7×10 ⁻⁴	4.7×10 ⁻⁴	4.7×10 ⁻⁴	4.7×10 ⁻⁴	
Excitation voltage *4	V	24 VDC ± 109	24 VDC ± 10%				
Power consumption (at 20°C)	w	19	31	34	34	34	
Current consumption (at 20°C)	А	0.79±10%	1.3±10%	1.4±10%	1.4±10%	1.4±10%	
Static friction torque	N • m	13.7 min.	24.5 min.	58.8 min.	58.8 min.	58.8 min.	
Attraction time *5	ms	100 max.	80 max.	150 max.	150 max.	150 max.	
Release time *5	ms	50 max. * ⁶	25 max. * ⁷	50 max. * ⁷	50 max.	50 max.	
Backlash		±1°					
Allowable work per braking	J	1176	1372	1372	1372	1372	
Allowable total work	J	1.5×10 ⁶	2.9×10 ⁶	2.9×10 ⁶	2.9×10 ⁶	2.9×10 ⁶	
Allowable total work Allowable angular acceleration Brake limit Rating Insulation class	rad/s ²	10,000			5,000		
Brake limit	-	10 million times min.					
Rating	-	Continuous					
Insulation class	-	Type F					

- *1. These are the values when the Servomotor is combined with a drive at normal temperature (20°C, 65%). The momentary maximum torque indicates the standard value.
- *2. Applicable load inertia.
 - The operable load inertia ratio (load inertia/rotor inertia) depends on the mechanical configuration and its rigidity. For a machine with high rigidity, operation is possible even with high load inertia. Select an appropriate motor and confirm that operation is possible.
 - The dynamic brake is rated for short-term operation. Use it only for emergency stopping. Design the system to stop for at least ten minutes after the dynamic brake operates. Otherwise, the dynamic brake circuits may fail or the dynamic brake resistor may burn.
- *3. The allowable radial and thrust loads are the values determined for a limit of 20,000 hours at normal operating temperatures.


The allowable radial loads are applied as shown in the following diagram.



- *4. This is a non-excitation brake. (It is released when excitation voltage is applied.)
- *5. The operation time is the value (reference value) measured with a surge suppressor (CR50500 by Okaya Electric Industries Co., Ltd.).
- *6. Direct current switching with a varistor (TNR9G820K by Nippon Chemi-Con Corporation).
- *7. Direct current switching with a varistor (Z15D151 by Ishizuka Electronics Co.).

Torque-Rotation Speed Characteristics for 1,000-r/min Servomotors

- + 1,000-r/min Servomotor (200/400 VAC)
 - The following graphs show the characteristics with a 3-m standard cable and a 200-VAC input.



- Note 1: The continuous operation range is the range in which continuous operation is possible. Continuous operation at the maximum speed is also possible. However, doing so will reduce the output torque.
- Note 2: If the motor power cable exceeds 20 m, the voltage drop will increase and the momentary operation range will become narrower.

Temperature Characteristics of the Motor and Mechanical System

- OMNUC G5-Series AC Servomotors use rare earth magnets (neodymium-iron magnets). The temperature coefficient for these magnets is approx. -0.13%/°C.
 As the temperature drops, the motor's momentary maximum torque increases, and as the temperature rises, the motor's momentary maximum torque decreases.
- The momentary maximum torque rises by 4% at a normal temperature of 20°C compared to a temperature of -10°C. Conversely, the momentary maximum torque decreases about 8% when the magnet warms up to 80°C from the normal temperature.
- Generally, when the temperature drops in a mechanical system, the friction torque and the load torque increase. For that reason, overloading may occur at low temperatures.
 In particular, in systems that use a Decelerator, the load torque at low temperatures may be nearly twice as much as the load torque at normal temperatures.
 Check whether overloading may occur during starting at low temperature.
 Also check to see whether abnormal motor overheating or alarms occur at high temperatures.
- An increase in load friction torque seemingly increases load inertia. Therefore, even if the drive gains are adjusted at a normal temperature, the motor may not operate properly at low temperatures. Check to see whether optimal operation can be obtained even at low temperatures.

Encoder Specifications

Incremental Encoder Specifications

Item	Specifications
Encoder system	Optical encoder
	20 bits
Number of output pulses	Phases A and B: 262,144 pulses/rotationPhase Z:1 pulse/rotation
Power supply voltage	5 VDC ± 5%
Power supply current	180 mA (max.)
Output signals	+S, –S
Output interface	RS-485 compliant

Absolute Encoder Specifications

Item	Specifications
Encoder system	Optical encoder
	17 bits
Number of output pulses	Phases A and B: 32,768 pulses/rotationPhase Z:1 pulse/rotation
Maximum rotations	-32,768 to +32,767 rotations
Power supply voltage	5 VDC ± 5%
Power supply current	110 mA (max.)
Applicable battery voltage	3.6 VDC
Current consumption of battery	265 μA (for a maximum of 5 s right after power interruption) 100 μA (for operation during power interruption) 3.6 μA (when power is supplied to the Servo Drive)
Output signals	+S, –S
Output interface	RS-485 compliant

Note: Multi-rotation Data Backup

- The multi-rotation data will be lost if the battery cable connector is disconnected at the motor when connecting the battery cable for the absolute encoder and battery.
- If you do not use an absolute encoder battery cable and connect the battery to CN1, the multi-rotation data will be lost if CN2 is disconnected.

Cable and Connector Specifications 3-4

Encoder Cable Specifications

These cables are used to connect the encoder between the Servo Drive and the Servomotor. Select the cable matching the Servomotor. The cables listed are flexible, shielded and have IP67 protection.

Encoder Cables (European Flexible Cables)


R88A-CRKA CR-E

Cable types

(For both absolute encoders and incremental encoders: [100 V and 200 V] For 3,000-r/min Servomotors of 50 to 750 W)

Model	Length (L)	Outer diameter of sheath		
R88A-CRKA001-5CR-E	1.5 m			
R88A-CRKA003CR-E	3 m			
R88A-CRKA005CR-E	5 m	6.9 dia.		
R88A-CRKA010CR-E	10 m	0.9 01a.		
R88A-CRKA015CR-E	15 m			
R88A-CRKA020CR-E	20 m			

Connection configuration and external dimensions



Wiring

Servo Drive side			Servomotor side	
Symbol	Number		Number	Symbol
E5V	1	Red	6	E5V
E0V	2	Black	3	E0V
BAT+	3	Orange	5	BAT+
BAT-	4	Orange/White XX	2	BAT-
S+	5	Blue	7	S+
S–	6	Blue/White XX	4	S–
FG	Shell	•	1	FG

[Servo Drive side connector] Connector model 55100-0670 (Molex Japan)

Cable $0.34~mm^2\times 2C + 0.22~mm^2\times 2P$ or $AWG22 \times 2C + AWG24 \times 2P$

Angle clamp model JN6FR07SM1 (Japan Aviation Electronics) Connector pin model

LY10-C1-A1-1000 (Japan Aviation Electronics)

[Servomotor side connector]


R88A-CRKC NR

Cable types

(For both absolute encoders and incremental encoders: [100 V and 200 V] For 3,000-r/min Servomotors of 1 kW or more, [400 V] 3,000-r/min Servomotors, 2,000-r/min Servomotors and 1,000-r/min Servomotors)

Model	Length (L)	Outer diameter of sheath
R88A-CRKC001-5NR-E	1.5 m	
R88A-CRKC003NR-E	3 m	
R88A-CRKC005NR-E	5 m	7.6 dia.
R88A-CRKC010NR-E	10 m	7.0 dia.
R88A-CRKC015NR-E	15 m	
R88A-CRKC020NR-E	20 m	

Connection configuration and external dimensions



Wiring

Servo Drive	e side		Servomo	otor side
Symbol	Number	D. d.	Number	Symbol
E5V	1	Red	4	E5V
E0V	2	Black	1	E0V
BAT+	3	Orange	6	BAT+
BAT-	4	Orange/White XX	5	BAT-
S+	5	Blue	3	S+
S–	6	Blue/White XX	7	S–
FG	Shell	¶	9	FG
		Cable		

[Servo Drive side connector] Connector model 55100-0670 (Molex Japan) $1 \text{ mm}^2 \times 2\text{C} + 0.22 \text{ mm}^2 \times 2\text{P}$

or AWG17 \times 2C + AWG24 \times 2P

[Servomotor side connector] Straight plug model JN2DS10SL2-R (Japan Aviation Electronics) Contact model JN1-22-22S-10000 (Japan Aviation Electronics)


Absolute Encoder Battery Cable Specifications

Use the following Cable when using an absolute encoder.


Cable Model

Model	Length (L)	Battery	Weight
R88A-CRGD0R3C	0.3 m	Not included	Approx. 0.1 kg
R88A-CRGD0R3C-BS	0.3 m	R88A-BAT01G 1 included	Approx. 0.1 kg

Connection Configuration and External Dimensions



Wiring



Motor Power Cable Specifications

These cables connect the Servo Drive and the Servomotor. Select the cable matching the Servomotor.

The cables listed are flexible, shielded and have IP67 protection.

Power Cables without Brakes (European Flexible Cables)


R88A-CAKA SR-E

Cable types

[100 V and 200 V] (For 3,000-r/min Servomotors of 50 to 750 W)

Model	Length (L)	Outer diameter of sheath
R88A-CAKA001-5SR-E	1.5 m	
R88A-CAKA003SR-E	3 m	
R88A-CAKA005SR-E	5 m	6.7 dia.
R88A-CAKA010SR-E	10 m	0.7 dia.
R88A-CAKA015SR-E	15 m	
R88A-CAKA020SR-E	20 m	

Connection configuration and external dimensions



Wiring

Servo Drive side	Servomotor side		
Ded	Number	Symbol	
	- 1	Phase U	
White	2	Phase V	
	- 3	Phase W	
Green/Yellow	- 4	FG	

M4 crimp terminal

Cable 0.5 mm² \times 4C or AWG20 \times 4C

[Servomotor side connector] Angle plug model

JN8FT04SJ1 (Japan Aviation Electronics)

Connector pin model

ST-TMH-S-C1B-3500-A534G (Japan Aviation Electronics)

Note: for servomotors with brake a separate cable R88A-CAKA BR-E is needed.

R88A-CAGB SR-E

Cable types

200 V:


(For 3,000-r/min Servomotors of 1 to 2 kW, 2,000-r/min Servomotors of 1 to 2 kW, 1,000-r/min Servomotors of 900 W)

400 V:

(For 3,000-r/min Servomotors of 750W to 2 kW, 2,000-r/min Servomotors of 400 W to 2 kW, 1,000-r/min Servomotors of 900 W)

Model	Length (L)	Outer diameter of sheath	
R88A-CAGB001-5SR-E	1.5 m		
R88A-CAGB003SR-E	3 m		
R88A-CAGB005SR-E	5 m	12.7 dia.	
R88A-CAGB010SR-E	10 m	12.7 ula.	
R88A-CAGB015SR-E	15 m		
R88A-CAGB020SR-E	20 m		

Connection configuration and external dimensions



Wiring

Servo Drive side

	Number	Symbol
Black-1	А	Phase U
Black-2	В	Phase V
Black-3	С	Phase W
Green/Yellow	D	FG

M4 crimp terminal

Cable

 $2.5 \text{ mm}^2 \times 4C \text{ or AWG14} \times 4C$

[Servomotor side connector] Right angle plug model N/MS3108B20-4S (Japan Aviation Electronics)

Cable clamp model

Servomotor side

N/MS3057-12A (Japan Aviation Electronics)


R88A-CAGD SR-E

Cable types

(For 3,000-r/min Servomotors of 3 to 5 kW, 2,000-r/min Servomotors of 3 to 5 kW, 1,000-r/min Servomotors of 2 to 4.5 kW)

Model	Length (L)	Outer diameter of sheath	
R88A-CAGD001-5SR-E	1.5 m		
R88A-CAGD003SR-E	3 m		
R88A-CAGD005SR-E	5 m	13.2 dia.	
R88A-CAGD010SR-E	10 m	10.2 014.	
R88A-CAGD015SR-E	15 m		
R88A-CAGD020SR-E	20 m		

Connection configuration and external dimensions



Wiring

Servo Drive side	Servomotor side	
	Number	Symbol
	A	Phase U
Black-2	B	Phase V
STD Black-3	- C	Phase W
Green/Yellow	- D	FG

M5 crimp terminal

 $\begin{array}{l} \mbox{Cable} \\ \mbox{4 mm}^2 \times 4 \mbox{C or AWG11} \times 4 \mbox{C} \end{array}$

[Servomotor side connector]

Right angle plug model

N/MS3108B22-22S (Japan Aviation Electronics)

Cable clamp model

N/MS3057-12A (Japan Aviation Electronics)

Power Cables with Brakes (European Flexible Cables)

R88A-CAGB BR-E

Cable types


200 V:

(For 3,000-r/min Servomotors of 1 to 2 kW, 2,000-r/min Servomotors of 1 to 2 kW, 1,000-r/min Servomotors of 900 W)

Model	Length (L)	Outer diameter of sheath
R88A-CAGB001-5BR-E	1.5 m	
R88A-CAGB003BR-E	3 m	
R88A-CAGB005BR-E	5 m	12.5 dia.
R88A-CAGB010BR-E	10 m	12.5 uld.
R88A-CAGB015BR-E	15 m	
R88A-CAGB020BR-E	20 m	

Connection configuration and external dimensions





Wiring

Servo Drive side		Servom	otor side	
		Number	Symbol	
Black-5	0.5	G	Brake	
Black-6	0.5	- н	Brake	
		Α	NC	
Black-1	2.5	- F	Phase U	
Black-2	2.5	- 1	Phase V	
Black-3	2.5	в	Phase W	
Green/Yello	W 2.5	E	FG	
M4 crimp terminal	•	D	FG	
Cab	i	С	NC	
2.5 or	$mm^2 \times 4C + 0.5 mm^2 \times 2C$ G14 × 4C + AWG20 × 2C	Right a N/MS Cable	clamp model	odel S (Japan Aviation Electronics)

R88A-CAKF BR-E


Cable types

400 V:

(For 3,000-r/min Servomotors of 750W to 2 kW, 2,000-r/min Servomotors of 400 W to 2 kW, 1,000-r/min Servomotors of 900 W)

Model	Length (L)	Outer diameter of sheath
R88A-CAKF001-5BR-E	1.5 m	
R88A-CAKF003BR-E	3 m	
R88A-CAKF005BR-E	5 m	12.5 dia.
R88A-CAKF010BR-E	10 m	12.0 014.
R88A-CAKF015BR-E	15 m	
R88A-CAKF020BR-E	20 m	

Connection configuration and external dimensions



Wiring

Servo Drive side		Servomo	otor side
Dia als E	0.5	Number	Symbol
Black-5	0.5	— A	Brake
Black-6	0.5	— В	Brake
			NC
Black-1	2.5	D	Phase U
Black-2	2.5		Phase V
Black-3	2.5	F	Phase W
Green/Yello	W 2.5	G	FG
M4 crimp terminal		— н	FG
	II		
		C	NC

 $\begin{array}{l} \text{Cable} \\ \text{2.5 } \text{mm}^2 \times 4\text{C} + 0.5 \ \text{mm}^2 \times 2\text{C} \\ \text{or} \\ \text{AWG14} \times 4\text{C} + \text{AWG20} \times 2\text{C} \end{array}$

[Servomotor side connector]

Right angle plug model

N/MS3108B24-11S (Japan Aviation Electronics) Cable clamp model

N/MS3057-16A (Japan Aviation Electronics)


R88A-CAGD BR-E

Cable types

(For 3,000-r/min Servomotors of 3 to 5 kW, 2,000-r/min Servomotors of 3 to 5 kW, 1,000-r/min Servomotors of 2 to 4.5 kW)

Model	Length (L)	Outer diameter of sheath
R88A-CAGD001-5BR-E	1.5 m	
R88A-CAGD003BR-E	3 m	
R88A-CAGD005BR-E	5 m	13.5 dia.
R88A-CAGD010BR-E	10 m	10.0 ula.
R88A-CAGD015BR-E	15 m	
R88A-CAGD020BR-E	20 m	

Connection configuration and external dimensions



Wiring

e	Servom	otor side	_
	Number	Symbol	
	— A	Brake	
6 0.5	В	Brake	
	I	NC	
	D	Phase U	
	— E	Phase V	
	— F	Phase W	
Yellow 4	G	FG	
	— н	FG	
Cabla	С	NC	
$4 \text{ mm}^2 \times 4C + 0.5 \text{ mm}^2 \times 2C$	Right ang N/MS31	le plug mode 08B24-11S (-
	$\begin{array}{c c} 2 & 4 \\ 3 & 4 \\ \hline \begin{array}{c} 4 \\ \hline \begin{array}{c} 4 \\ \hline \end{array} \\ \hline \\ \hline$	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	5 0.5 NumberSymbol6 0.5 ABrake14BBrake14DPhase U24EPhase U34FPhase W $(Yellow 4)$ GFG $(Yellow 4)$ GF $(Yellow 4)$ </td

Cable clamp model

N/MS3057-16A (Japan Aviation Electronics)


Brake Cables (European Flexible Cables)

R88A-CAKA BR-E

Cable types 100 and 200 V: (For 3,000-r/min Servomotors of 50 to 750 W)

Model	Length (L)	Outer diameter of sheath
R88A-CAKA001-5BR-E	1.5 m	
R88A-CAKA003BR-E	3 m	
R88A-CAKA005BR-E	5 m	6.0 dia.
R88A-CAKA010BR-E	10 m	0.0 012.
R88A-CAKA015BR-E	15 m	
R88A-CAKA020BR-E	20 m	

Connection configuration and external dimensions



Wiring

Servo Drive side Servomotor side Symbol Number Black-1 0.5 1 Brake Black-2 <u>0.</u>5 2 Brake Cable [Servomotor side connector] $0.5 \text{ mm}^2 \times 2C$ or Connector model $AWG20 \times 2C$ JN4FT02SJ1-R (Japan Aviation Electronics) Contact model


ST-TMH-S-C1B (Japan Aviation Electronics)

Connector Specifications

Control I/O Connector (R88A-CNU11C)

This is the connector to be connected to the Servo Drive's control I/O connector (CN1). Use this connector when preparing a control cable by yourself. For information on wiring method, refer to *Control Cable Specifications* (P.3-112). This connector is soldered.

Dimensions



Connector plug model 10150-3000PE (Sumitomo 3M) Connector case model 10350-52A0-008 (Sumitomo 3M)


Encoder Connectors

These connectors are used for encoder cables. Use them when preparing an encoder cable by yourself. For information on wiring method, refer to *Encoder Cable Specifications* (P.3-97).

Dimensions

R88A-CNW01R (Drive's CN2 side)

This connector is soldered.




Connector plug model 55100-0670 (Molex Japan) R88A-CNK02R (Servomotor side) This connector is pressure welded. For the tools that are required for production, contact the manufacturer directly. The cable direction from the angle plug can be reversed.

Adaptive motors

100-V, 3,000-r/min Servomotors of 50 to 400 $\rm W$

200-V, 3,000-r/min Servomotors of 50 to 750 $\rm W$



Angle clamp model JN6FR07SM1 (Japan Aviation Electronics) Connector pin model LY10-C1-A1-10000 (Japan Aviation Electronics)

R88A-CNK04R (Servomotor side)AThis connector is pressure welded.AFor the tools that are required for production,
contact the manufacturer directly.A

Adaptive motors

200-V, 3,000-r/min Servomotors of all capacities

200-V, 2,000-r/min Servomotors of all capacities

200-V, 1,500-r/min Servomotors of all capacities


200-V, 1,000-r/min Servomotors of all capacities

400-V, 3,000-r/min Servomotors of all capacities

400-V, 2,000-r/min Servomotors of all capacities

400-V, 1,000-r/min Servomotors of all capacities

400-V, 1,500-r/min Servomotors of all capacities



Straight plug model JN2DS10SL2-R (Japan Aviation Electronics) Contact model JN1-22-22S-PKG100 (Japan Aviation Electronics)

Power Cable Connector (R88A-CNK11A)

This connector is used for power cables. Use it when preparing a power cable by yourself. For information on wiring method, refer to *Motor Power Cable Specifications* (P.3-100).

This connector is pressure welded.

For the tools that are required for production, contact the manufacturer directly.


The cable direction from the angle plug can be reversed.

Note If you reverse the direction, you cannot attach the Connector to Servomotors of 50 W and 100 W.

Adaptive motors

100-V, 3,000-r/min Servomotors of 50 to 400 $\rm W$

200-V, 3,000-r/min Servomotors of 50 to 750 $\rm W$



Angle plug model JN8FT04SJ1 (Japan Aviation Electronics) Socket contact model ST-TMH-S-C1B-3500-(A534G) (Japan Aviation Electronics)

Brake Cable Connector (R88A-CNK11B)


This connector is used for brake cables. Use it when preparing a brake cable by yourself. For information on wiring method, refer to *Brake Cables (European Flexible Cables)* (P.3-106). This connector is pressure welded. For the tools that are required for production, contact the manufacturer directly.

The cable direction from the angle plug can be reversed.

Adaptive motors

100-V, 3,000-r/min Servomotors of 50 to 400 W

200-V, 3,000-r/min Servomotors of 50 to 750 $\rm W$




Angle plug model JN4FT02SJ1-R (Japan Aviation Electronics) Socket contact model ST-TMH-S-C1B-3500-(A534G) (Japan Aviation Electronics)


0.8 MAX

External Encoder Connector (R88A-CNK41L)


Use this connector to connect to an external encoder in fully-closed control. This connector is soldered.


(10.5)






Pin Arrangement





View from Soldered Housing Surface

(42.5)




- Note 1: The recommended cable is a AWG28 to AWG24 shielded cable with a finished outer diameter of 6.8 max.
- Note 2: For information on wiring method, refer to *External Encoder Connector Specifications* (CN4) (P.3-51).

The cable length must be 20 m or less.

Safety I/O Signal Connector (R88A-CNK81S)

Use this connector to connect to a safety device. This connector is soldered.



- Note 1: The recommended cable is a 6-conductor (AWG30 to AWG26) shielded cable with a finished outer diameter of 6.7 mm max.
- Note 2: For information on wiring, refer to Safety Connector Specifications (CN8) (P. 3-55).


Analog Monitor Cable Specifications

Analog Monitor Cable (R88A-CMK001S)

Connection configuration and external dimensions

Symbol	No.	Bed
AM1	1	White
AM2	2	Black
GND	3	
	4	
	5	
	6	Cable: AWG24 × 3C UL1007
Connector h	ouoina	51004 0600 (Moley Japan)

Connector housing: 51004-0600 (Molex Japan) Connector terminal: 50011-8000 (Molex Japan)



Control Cable Specifications

Specified Cables for Motion Control Unit (R88A-CPG M)

Use this cable to connect to the Motion Control Units for OMRON Programmable Controllers (SYSMAC). Cables are available for either 1 axis or 2 axes. The following Motion Control Units can be used. CS1W-MC221/421(-V1) CV500-MC221/-MC421 C200H-MC221

Cable types

· Cables for 1 axis


Model	Length (L)	Outer diameter of sheath	Weight
R88A-CPG001M1	1 m		Approx. 0.2 kg
R88A-CPG002M1	2 m	8.3 dia.	Approx. 0.3 kg
R88A-CPG003M1	3 m	0.0 012.	Approx. 0.4 kg
R88A-CPG005M1	5 m		Approx. 0.6 kg

· Cables for 2 axes

Model	Length (L)	Outer diameter of sheath	Weight
R88A-CPG001M2	1 m		Approx. 0.3 kg
R88A-CPG002M2	2 m	8.3 dia.	Approx. 0.5 kg
R88A-CPG003M2	3 m	0.0 012.	Approx. 0.7 kg
R88A-CPG005M2	5 m		Approx. 1.0 kg

Connection configuration and external dimensions

· Cables for 1 axis



Cables for 1 axis

Motion Cor Unit side	ntrol		Sania D	rive side	
Symbol	Number	AWG20 Red	Number]
+24V	1	AWG20 Black	Turnbor	Oymbol	
DCGND	2				
XALM	3	White/Black (1)	37	/ALM	
XRUN	4	Pink/Black (1)	29	RUN	
XALMRS	5	Yellow/Black (1)	31	RESET	
XSGND	8	Gray/Black (1)	13	SENGND	*
XSOUT	9	Gray/Red (1)	20	SEN	*
X–GND	10	Orange/Black (2)	25	ZGND	
X–A	11	White/Red (1)	21	+A	
X-Ā	12	White/Black (1)	22	-A	
X–B	13	Yellow/Red (1)	49	+B	
X–B	14	Yellow/Black (1) XX	48	-B	
X–Z	15	Pink/Black (1)	23	+Z	
X–Z	16	Orange/Red (1)	24	-Z	
XOUT	17	Orange/Black (1)			Connector plug model
XAGND	18		15	AGND	10150-3000PE
		Orange/Black (1)	Shell	FG	(Sumitomo 3M)
+F24V	19	Gray/Black (1)	7	+24VIN	Connector case model
FDC GND	-		36	ALMCOM	
YALM	21	Cable: AWG26 \times 5P + AWG26 \times 6C			(Sumitomo 3M)
YRUN	22				
YALMRS	23				
YSGND	26				
YSOUT	27				
Y-GND	28				
Y-A	29				
Y-Ā	30				
Y-B	31				
Y-B	32				
Y–Z	33	Connector plug model			
Y-Z	34	10136-3000PE (Sumitomo 3M)			
YOUT	35	Connector case model			
YAGND	36	10336-52A0-008 (Sumitomo 3M)			

• The symbols on the controller side are the DRVX and DRVY connector symbols. For the DRVZ and DRVU connectors, X and Y are indicated as Z and U, respectively.

• Terminals marked with asterisks are for absolute encoders.

 Connect 24 VDC to the 2 lines (red and black) extending from the connector on the controller side. (red: +24 V, black: -)

· Cables for 2 axes

Motion Cor	ntrol		_		
Unit side		AWG20 Red		rive side	
Symbol	Number	AWG20 Black	Number	Symbol	
+24V	1	AWG20 Black			
DCGND	2	White/Black (1)			
XALM	3		- 37	/ALM	
XRUN	4	Pink/Black (1)	- 29	RUN	
XALMRS	5	Yellow/Black (1)	- 31	RESET	
XSGND	8	Gray/Black (1)	- 13	SENGND	*
XSOUT	9	Gray/Red (1)	- 20	SEN	*
X–GND	10	Orange/Black (2)	- 25	ZGND	
X–A	11	White/Red (1)	- 21	+A	
X-Ā	12	White/Black (1)	- 22	-A	
X–B	13	Yellow/Red (1)	- 49	+B	
X-B	14	Yellow/Black (1)	- 48	-B	
X–Z	15	Pink/Red (1)	- 23	+Z	
X–Z	16	Pink/Black (1)	- 24	-Z	Connector plug model
XOUT	17	Orange/Red (1)	- 14	REF/TREF1/VLIM	
XAGND	18	Orange/Black (1)	- 15	AGND	(Sumitomo 3M)
		······································	Shell	FG	Connector case model
+F24V	19	Orange/Black (1)	- 7	+24VIN	10350-52A0-008
FDC GND	20	Gray/Black (1)	- 36	ALMCOM	(Sumitomo 3M)
		Cable			,
			~ ~		
		AWG26 × 5P + AWG26 ×	< 6C		
		AWG26 × 5P + AWG26 ×	< 6C	Symbol	
		AWG26 × 5P + AWG26 >		Symbol +24VIN	
			Number		
YALM	21	White/Black (1)	Number - 7	+24VIN ALMCOM	
YALM	21 22	White/Black (1) Pink/Black (1)	Number - 7 - 36	+24VIN	
	22	White/Black (1) Pink/Black (1) Yellow/Black (1)	Number - 7 - 36 - 37	+24VIN ALMCOM /ALM RUN	
YRUN	22 23	White/Black (1) Pink/Black (1) Yellow/Black (1) Gray/Black (1)	Number - 7 - 36 - 37 - 29	+24VIN ALMCOM /ALM	*
YRUN YALMRS	22	White/Black (1) Pink/Black (1) Yellow/Black (1) Gray/Black (1) Gray/Red (1)	Number - 7 - 36 - 37 - 29 - 31	+24VIN ALMCOM /ALM RUN RESET	*
YRUN YALMRS YSGND	22 23 26	White/Black (1) Pink/Black (1) Yellow/Black (1) Gray/Black (1) Gray/Red (1) Orange/Black (2)	Number 7 - 36 - 37 - 29 - 31 - 13	+24VIN ALMCOM /ALM RUN RESET SENGND	*
YRUN YALMRS YSGND YSOUT Y-GND	22 23 26 27 28	White/Black (1) Pink/Black (1) Yellow/Black (1) Gray/Black (1) Gray/Red (1) Orange/Black (2) White/Red (1)	Number 7 36 37 29 31 13 20 25	+24VIN ALMCOM /ALM RUN RESET SENGND SEN	*
YRUN YALMRS YSGND YSOUT Y-GND Y-A	22 23 26 27 28 29	White/Black (1) Pink/Black (1) Yellow/Black (1) Gray/Black (1) Orange/Black (2) White/Red (1) White/Black (1)	Number 7 36 37 29 31 13 20	+24VIN ALMCOM /ALM RUN RESET SENGND SEN ZGND	*
YRUN YALMRS YSGND YSOUT Y-GND Y-A Y-Ā	22 23 26 27 28 29 30	White/Black (1) Pink/Black (1) Yellow/Black (1) Gray/Red (1) Orange/Black (2) White/Red (1) White/Black (1) Yellow/Red (1)	Number 7 36 37 29 31 13 20 25 21	+24VIN ALMCOM /ALM RUN RESET SENGND SEN ZGND +A -A	*
YRUN YALMRS YSGND YSOUT Y-GND Y-A Y-Ā Y-B	22 23 26 27 28 29 30 31	White/Black (1) Pink/Black (1) Gray/Black (1) Gray/Red (1) Orange/Black (2) White/Black (1) Yellow/Red (1) Yellow/Black (1) Yellow/Black (1)	Number 7 36 37 29 31 13 20 25 21 22	+24VIN ALMCOM /ALM RUN RESET SENGND SEN ZGND +A	* * Connector plua model
YRUN YALMRS YSGND YSOUT Y-GND Y-A Y-A Y-A Y-B Y-B	22 23 26 27 28 29 30 31 32	White/Black (1) Pink/Black (1) Gray/Black (1) Gray/Red (1) Orange/Black (2) White/Black (1) Yellow/Red (1) Yellow/Black (1) Yellow/Black (1) Yellow/Red (1) Yellow/Red (1) Yellow/Black (1) Yellow/Red (1)	Number 7 36 37 29 31 13 20 25 21 22 21 22 49 48	+24VIN ALMCOM /ALM RUN RESET SENGND SEN ZGND +A -A +B -B	* * Connector plug model 10150-3000PE
YRUN YALMRS YSGND YSOUT Y-GND Y-A Y-Ā Y-B Y-B Y-B Y-Z	22 23 26 27 28 29 30 31 32 33	White/Black (1) Pink/Black (1) Gray/Black (1) Gray/Red (1) Orange/Black (2) White/Black (1) Yellow/Red (1) Yellow/Red (1) Yellow/Red (1) Yellow/Red (1) Yellow/Red (1) Yellow/Black (1) Yellow/Black (1) Yellow/Black (1) Yellow/Black (1)	Number 7 36 37 29 31 13 20 25 21 22 49 48 23	+24VIN ALMCOM /ALM RUN RESET SENGND SEN ZGND +A -A +B -B +Z	10150-3000PE
YRUN YALMRS YSGND Y-GND Y-GND Y-A Y-A Y-B Y-B Y-B Y-B Y-Z Y-Z	22 23 26 27 28 29 30 31 32 33 33 34	White/Black (1) Pink/Black (1) Gray/Black (1) Gray/Red (1) Orange/Black (2) White/Red (1) Yellow/Red (1)	Number 7 36 37 29 31 13 20 25 21 49 48 23 24	+24VIN ALMCOM /ALM RUN RESET SENGND SEN ZGND +A -A +B -B +Z -Z	10150-3000PE (Sumitomo 3M)
YRUN YALMRS YSGND Y-GND Y-GND Y-A Y-A Y-A Y-B Y-B Y-B Y-B Y-Z Y-Z YOUT	22 23 26 27 28 29 30 31 32 33 34 35	White/Black (1) Pink/Black (1) Gray/Black (1) Gray/Red (1) Orange/Black (2) White/Black (1) Yellow/Red (1) Yellow/Red (1) Yellow/Red (1) Yellow/Red (1) Yellow/Red (1) Yellow/Black (1) Yellow/Black (1) Yellow/Black (1) Yellow/Black (1)	Number 7 36 37 29 31 13 20 25 21 22 49 48 23 24 24 14	+24VIN ALMCOM /ALM RUN RESET SENGND SEN ZGND +A -A +B -B +Z -Z REF/TREF1//LIM	10150-3000PE (Sumitomo 3M) Connector case model
YRUN YALMRS YSGND YSOUT Y-GND Y-A Y-A Y-B Y-B Y-B Y-Z Y-Z YOUT YAGND	22 23 26 27 28 29 30 31 32 33 34 35 36	White/Black (1) Pink/Black (1) Gray/Black (1) Gray/Red (1) Orange/Black (2) White/Red (1) White/Black (1) Yellow/Red (1) Yellow/Black (1) Yellow/Red (1) Yellow/Black (1) Yellow/Black (1) Yellow/Black (1) Orange/Red (1) Orange/Red (1) Orange/Red (1)	Number 7 36 37 29 31 13 20 25 21 22 49 48 23 24 14 15	+24VIN ALMCOM /ALM RUN RESET SENGND SEN ZGND +A -A +B -B +Z -Z REF/TREF1/VLIM AGND	10150-3000PE (Sumitomo 3M) Connector case model 10350-52A0-008
YRUN YALMRS YSGND YSOUT Y-GND Y-A Y-A Y-A Y-B Y-B Y-Z YOUT YAGND Connector p	22 23 26 27 28 29 30 31 32 33 34 35 36 oblug mod	White/Black (1) Pink/Black (1) Gray/Black (1) Gray/Red (1) Orange/Black (2) White/Red (1) White/Black (1) Yellow/Red (1) Yellow/Red (1) Yellow/Red (1) Yellow/Red (1) Yellow/Black (1) Yellow/Black (1) Orange/Red (1) Orange/Red (1) Orange/Black (1) Orange/Black (1) Orange/Black (1)	Number 7 36 37 29 31 13 20 25 21 22 49 48 23 24 14 15 Shell	+24VIN ALMCOM /ALM RUN RESET SENGND SEN ZGND +A -A +B -B +Z -Z REF/TREF1//LIM	10150-3000PE (Sumitomo 3M) Connector case model
YRUN YALMRS YSGND YSOUT Y-GND Y-A Y-A Y-B Y-B Y-B Y-Z YOUT YAGND Connector p	22 23 26 27 28 29 30 31 32 33 34 35 36 olug mod 000PE (S	White/Black (1) Pink/Black (1) Gray/Black (1) Gray/Red (1) Orange/Black (2) White/Red (1) White/Black (1) Yellow/Red (1) Yellow/Black (1) Orange/Red (1) Orange/Red (1) Orange/Black (1) Orange/Black (1) Orange/Black (1) AWG26 × 5P + AWG26 × 60	Number 7 36 37 29 31 13 20 25 21 22 49 48 23 24 14 15 Shell	+24VIN ALMCOM /ALM RUN RESET SENGND SEN ZGND +A -A +B -B +Z -Z REF/TREF1/VLIM AGND	10150-3000PE (Sumitomo 3M) Connector case model 10350-52A0-008

3

10336-52A0-008 (Sumitomo 3M)

- The symbols on the controller side are the DRVX and DRVY connector symbols. For the DRVZ and DRVU connectors, X and Y are indicated as Z and U, respectively.
- Terminals marked with asterisks are for absolute encoders.
- Connect 24 VDC to the 2 lines (red and black) extending from the connector on the controller side. (red: +24 V, black: -)

Specified Cables for Position Control Unit (for CJ1W-NCD4 - High-speed Type)

This cable is for connecting Position Control Units (CJ1W-NC□□4) for OMRON Programmable Controller SYSMAC CJ Series. Cables are available for either 1 axis or 2 axes. The following types of Position Control Units are supported. CJ1W-NC214/-NC414/-NC434

Cable types

Cable for line-driver output for 1 axis

Model	Length
XW2Z-100J-G9	1 m
XW2Z-500J-G9	5 m
XW2Z-10MJ-G9	10 m

• Cable for open collector output for 1 axis

Model	Length
XW2Z-100J-G13	1 m
XW2Z-300J-G13	3 m

Cable for line-driver output for 2 axes


Model	Length
XW2Z-100J-G1	1 m
XW2Z-500J-G1	5 m
XW2Z-10MJ-G1	10 m

· Cable for open collector output for 2 axes

Model	Length
XW2Z-100J-G5	1 m
XW2Z-300J-G5	3 m

Connection configuration and external dimensions

· Cables for 1 axis



Cable for line-driver output for 1 axis

	sted p	air 1	m								
Red: 24 VDC Black: 24 VDC GND	\supset	_	A					AWG18 twisted pair 1 m			
PCU side								Black: BKIR			
XG4M-5030-T (OMRO	N)							Sonio			
24-V power supply for output		цĻ						Servo Drive side (for axis 1 or 3) 10150-3000PE (Sumitomo 3M)			
24-V GND for output	3							11	BKIR		
Input common	5	łŤ					_ L	- 10	BKIRCOM	Brake interlock output	
Forward direction pulse output (+)	17	H		יי			1	44	+CWLD	Reverse pulse (*1)	
Forward direction pulse output (+)	16	\square		i	\searrow	$\overline{}$	1	44		(input for line driver only)	
Reverse direction pulse output (+)	19	\square		-	_ `	、	1	45	+CCWLD	Forward pulse (*1)	
Reverse direction pulse output (-)	18	\square			\searrow			40		(input for line driver only)	
Encoder phase A+	21			Ī				21	-00WLD +A	Encoder phase A+output	
Encoder phase A-	20	Ш			_X	X	<u> </u>	22	 A	Encoder phase A+output	
Encoder phase B+	23	Ш					İ	49	+B	Encoder phase B+output	
Encoder phase B-	22	Ш			_X	X		48	B	Encoder phase B-output	
Encoder phase Z+	25	Ш					<u> </u>	23	+Z	Encoder phase Z+output	
Encoder phase Z-	24			_i_	_X	X	-	24	Z	Encoder phase Z-output	
		11			~ ~			7	+24VIN	+24-V power supply for controls	
Error counter reset output	15	1			_X	X		30	ECRST	Error counter reset input	
RUN output	11	\square		_			i –	29	RUN	Operation command input	
General-purpose output	10	\square		_			-	26	DFSEL	Damping filter switching	
Alarm reset output	12	\vdash		+			<u> </u>	31	RESET	Alarm reset	
Torque limit output	13	1		÷			<u> </u>	27	TLSEL	Torque limit switching	
Positioning completed input	7	$\downarrow \downarrow$	_	-	\neg		1	39	INP	Positioning completion	
] 🔶			_X	X	<u>-</u>	38	INPCOM	output 1	
General-purpose input	6	\vdash	_		\neg	/	i –	35	READY	Servo ready completed	
		I ∳	_	+	_^	X		34	REDYCOM	output	
Alarm input	9	\vdash	_	÷	\sim		<u>+</u>	37	/ALM		
		!	_	÷	_^	^		36	ALMCOM	Alarm output	
SEN output	26	\vdash	_	t	\sim		1	20	SEN	Sensor ON input	
Signal ground	27	\vdash				/	i	13	SENGND	-	
				L			•	Shell	FG	Frame ground	
24-V power supply for output 24-V GND for output Input common Forward direction pulse output (+)	2 4 50										
					*1	Since th	ne PC	U hand	les forward direc	tion commands as	
Forward direction pulse output (-)					*1					tion commands as s (selectable by the	
Forward direction pulse output (-) Reverse direction pulse output (+)	39 38				*1	CW-dir	ection	/phase-	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-)	39 38 37				*1	CW-dir	ection oulse	/phase- directio	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+	39 38 37				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A-	39 38 37 36				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+	39 38 37 36 35				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B-	39 38 37 36 35 34 33 32				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B- Encoder phase Z+	39 38 37 36 35 34 33 32 31				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B-	39 38 37 36 35 34 33 32				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B- Encoder phase Z+ Encoder phase Z- Error counter reset output	39 38 37 36 35 34 33 32 31 30				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B- Encoder phase Z+ Encoder phase Z- Error counter reset output RUN output	39 38 37 36 35 34 33 32 31 30 41 45				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B- Encoder phase Z+ Encoder phase Z- Error counter reset output RUN output General-purpose output	39 38 37 36 35 34 33 32 31 30 41 45 44				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase Z+ Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output	39 38 37 36 35 34 33 32 31 30 41 45 44 42				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase Z+ Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output	39 38 37 36 35 34 33 32 31 30 41 45 44 42 42				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase Z+ Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output	39 38 37 36 35 34 33 32 31 30 41 45 44 42 42				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B- Encoder phase Z+ Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output	39 38 37 36 35 34 33 32 31 30 41 45 44 42 43 49				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase B+ Encoder phase B- Encoder phase Z+ Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output Positioning completed input	39 38 37 36 35 34 33 32 31 30 41 45 44 42 43 49 48				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse		
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B- Encoder phase Z- Encoder phase Z- Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output Positioning completed input General-purpose input	39 38 37 36 35 34 33 32 31 30 41 45 44 42 43 49 48 47				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse	es (selectable by the	
Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B- Encoder phase Z+ Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output Positioning completed input	39 38 37 36 35 34 33 32 31 30 41 45 44 42 43 49 48				*1	CW-dir output	ection oulse	/phase- directio	A advance pulse	es (selectable by the	

Cable for open collector output for 1 axis

AWG18 twiste Red: 24 VDC Black: 24 VDC GND	ed pai	r 1 m]			AV	VG18 tv	wisted pair 1 m Blue: BKIRCC Black: BKIR	DM
PCU side XG4M-5030-T (OMRO 24-V power supply for output	N)						or 3) 3M)		
24-V GND for output	3	_ _	•				11	BKIR	
Input common	5		L _		· – –.		10	BKIRCOM	Brake interlock output
Forward direction pulse output (with 1.6 kΩ Resistor)	16			\times	_×ţ		- 3	+CW/+PULS/+FA -CW/-PULS/-FA	Reverse pulses, feed pulses, or phase A (*1)
Reverse direction pulse output (with 1.6 k Ω Resistor)	18		↓ 	\times			- 5	+CCW/+SIGN/+FB -CCW/-SIGN/-FB	Forward pulse, direction signal, or phase B (*1)
Encoder phase A+	21			~	, , , , , , , , , , , , , , , , , ,		21	+A	Encoder phase A+output
Encoder phase A-	20		L i	Х	_Xl		22		Encoder phase A-output
Encoder phase B+	23	_	l i	\	$\neg \downarrow$		49	+B	Encoder phase B+output
Encoder phase B-	22	_	++	Х	_X+		- 48	-B	Encoder phase B-output
Encoder phase Z+	25	_		~	$\neg \bot$		- 23	+Z	Encoder phase Z+output
Encoder phase Z-	24	_	L .	X	_~`+		- 24	-Z	Encoder phase Z-output
			♦ <u>↓</u>	~			- 7	+24VIN	+24-V power supply for controls
Error counter reset output	15	_	+	×	_^+		- 30	ECRST	Error counter reset input
RUN output	11	_	Ηİ				29	RUN	Operation command input
General-purpose output	10	_	+ i				26	DFSEL	Damping filter switching
Alarm reset output	12	_	++		<u> </u>		31	RESET	Alarm reset
Torque limit output	13	_	<u> </u>		<u> </u>		27	TLSEL	Torque limit switching
Positioning completed input	7	_	<u> </u>	~	$\neg \dot{+}$		- 39	INP	Positioning completion
		•		X	_^_i		- 38	INPCOM	output 1
General-purpose input	6	_	+	~	$\neg +$		- 35	READY	Servo ready completed
	Ť	• —	Hi	X	$_$ \land \bot		- 34	REDYCOM	output
Alarm input	9	_	+ i	~	-		- 37	/ALM	Alarm output
		•	1	X	_X¦		- 36	ALMCOM	Alaini output
SEN output	26	_	++	~	$-\sqrt{\frac{1}{1}}$		20	SEN	Sensor ON input
Signal ground	27	_	+ !	\wedge	_^¦-		- 13	SENGND	
			_				Shell	FG	Frame ground

*1 Since the PCU handles forward direction commands as CW-direction/phase-A advance pulses (selectable by the output pulse direction selection parameter), connect the wires as shown here.

24-V power supply for output

24-V GND for output

Forward direction pulse output (with 1.6 k Ω Resistor)

Reverse direction pulse output (with 1.6 $k\Omega$ Resistor)

Encoder phase A+ Encoder phase A-

Encoder phase B+

Encoder phase B-

Encoder phase Z+

Encoder phase Z-

RUN output

Alarm input

SEN output

Signal ground

Error counter reset output 41

Positioning completed input 49

General-purpose output

Alarm reset output

Torque limit output

General-purpose input

Input common

2

4

50

38

36 35

34

33

32

31

30

45

44

42

43

48

47

Cable for line-driver output for 2 axes

AWG18 twis	tod r	air 1 m	h						
Red: 24 VDC			AWG18 twisted pair 1 m						
Black: 24 VDC GND	_X	-						– – Blue: BKIF	RCOM
PCU side							_X_	_X Black: BKI	R
XG4M-5030-T (OMRO	N)						Servo	Drive side (for axi	s 1 or 3)
24-V power supply for output	1	H	+					-3000PE (Sumitor	
24-V GND for output	3	┠┥					11	BKIR	Droke interlect entruit
Input common	5	<u> </u>	-∳ r-		·		10	BKIRCOM	Brake interlock output
Forward direction pulse output (+)	17	┣┥──	+i	~	\neg		44	+CWLD	Reverse pulse (*1)
Forward direction pulse output (-)	16	┣-┥──	╇	<u> </u>			45	-CWLD	(input for line driver only)
Reverse direction pulse output (+)	19	┣┼──	<u> </u>	~/-			46	+CCWLD	Forward pulse (*1)
Reverse direction pulse output (-)	18	<u> </u>	┼┼	<u> </u>	^_i		47	-CCWLD	(input for line driver only)
Encoder phase A+	21	<u> </u>	┼┼	~/-	—		21	+ A	Encoder phase A+output
Encoder phase A-	20		┼┼	<u> </u>			22	-A	Encoder phase A-output
Encoder phase B+	23	\vdash	+i-	\sim	—		49	+B	Encoder phase B+output
Encoder phase B-	22	\vdash	┼᠇	<u> </u>	-		48	-B	Encoder phase B-output
Encoder phase Z+	25		++	\sim	$\neg \checkmark$		23	+Z	Encoder phase Z+output
Encoder phase Z-	24		+		—^_i		24	-Z	Encoder phase Z-output
-			•	\sim	$\neg \checkmark$		7	+24VIN	+24-V power supply for controls
Error counter reset output	15		Η÷		_/\4		30	ECRST	Error counter reset input
RUN output	11		††				29	RUN	Operation command input
General-purpose output	10		+ -				26	DFSEL	Damping filter switching
Alarm reset output	12		++				31	RESET	Alarm reset
Torque limit output	13		+!				27	TLSEL	Torque limit switching
Positioning completed input	7		+:	\sim			39	INP	Positioning completion
	_	! ● ──	++	_/ \	—⁄ ``		38	INPCOM	output 1
General-purpose input	6		Τ÷	\sim	$\neg \checkmark$		35	READY	Servo ready completed
Alaura in a st	_	│ 	††				34	REDYCOM	output
Alarm input	9		11	\sim	\neg		37	/ALM	Alarm output
SEN output	26	•	1!				36	ALMCOM	
SEN output	26 27			\sim			20	SEN	Sensor ON input
Signal ground	21						13	SENGND	
		1				•	Shell	FG	Frame ground
						AW		visted pair 1 m	
					4	AW		visted pair 1 m	RCOM
					4		G18 tw	visted pair 1 m Blue: BKIF Black: BKI	RCOM R
24-V nower supply for output	2				· — — –4		G18 tw Servo	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi	RCOM R s 2 or 4)
24-V power supply for output	2				4		G18 tw Servo 10150-	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi -3000PE (Sumitor	RCOM R s 2 or 4)
24-V GND for output	4		•		· 4		G18 tw Servo 10150- 11	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi 3000PE (Sumitor BKIR	RCOM R s 2 or 4)
24-V GND for output Input common	4 50		•		·		G18 tw Servo 10150- 11 10	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi -3000PE (Sumitor BKIR BKIRCOM	RCOM R s 2 or 4) no 3M) Brake interlock output
24-V GND for output	4		•	 			G18 tw Servo 10150 11 10 44	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi 3000PE (Sumitor BKIR BKIRCOM +CWLD	RCOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1)
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-)	4 50 39 38		•	 X			G18 tw Servo 10150- 11 10 44 45	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD	RCOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only)
24-V GND for output Input common Forward direction pulse output (+)	4 50 39 38 37		•	 X X			G18 tw Servo 10150- 11 10 44 45 46	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD +CWLD +CCWLD	RCOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1)
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (+)	4 50 39 38						G18 tw Servo 10150- 11 10 44 45	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD	RCOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only)
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (+) Reverse direction pulse output (-)	4 50 39 38 37 36						G18 tw Servo 10150- 11 10 44 45 46 47	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axis 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD -CCWLD	RCOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1)
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+	4 50 39 38 37 36 35						G18 tw Servo 10150- 11 10 44 45 46 47 21	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD -CCWLD +A	RCOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A-output
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A-	4 50 39 38 37 36 35 34						G18 tw Servo 10150- 11 10 44 45 46 47 21 22	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD +CCWLD +A -A	COM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B- Encoder phase Z+	4 50 39 38 37 36 35 34 33						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD +CCWLD +A -A +B	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A-output Encoder phase B+output Encoder phase B-output Encoder phase B-output
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B-	4 50 39 38 37 36 35 34 33 32		• · · · · · · · · · · · · · · · · · · ·				G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD +CCWLD +A -A +B -B	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A+output Encoder phase B+output Encoder phase B-output Encoder phase Z+output Encoder phase Z-output
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B- Encoder phase Z+ Encoder phase Z-	4 50 39 38 37 36 35 34 33 32 31						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48 23	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD +CCWLD +A -A +B -B +Z -Z +24VIN	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A+output Encoder phase B+output Encoder phase B-output Encoder phase Z+output Encoder phase Z-output +24-V power supply for controls
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B- Encoder phase Z+ Encoder phase Z- Error counter reset output	4 50 39 38 37 36 35 34 33 32 31 30 41						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48 23 24 7 30	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CWLD -CWLD +CWLD -CCWLD +A -A +B -B +Z -Z +24VIN ECRST	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A+output Encoder phase B+output Encoder phase B-output Encoder phase Z+output Encoder phase Z-output
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B- Encoder phase Z+ Encoder phase Z- Encoder phase Z- Enror counter reset output RUN output	4 50 39 38 37 36 35 34 33 32 31 30						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48 23 24 7 30 29	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD +CCWLD +A -A +B -B +Z -Z +24VIN ECRST RUN	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A-output Encoder phase B+output Encoder phase B-output Encoder phase Z+output Encoder phase Z-output Encoder phase Z-output +24-V power supply for controls Error counter reset input Operation command input
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B- Encoder phase B- Encoder phase Z+ Encoder phase Z- Error counter reset output RUN output General-purpose output	4 50 39 38 37 36 35 34 33 32 31 30 41 45 44						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48 23 24 7 30	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD +CCWLD +A -A +B -B +Z -Z +24VIN ECRST RUN DFSEL	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A+output Encoder phase B+output Encoder phase B-output Encoder phase Z+output Encoder phase Z-output +24-V power supply for controls Error counter reset input
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B- Encoder phase Z+ Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output	4 50 39 38 37 36 35 34 33 32 31 30 41 45						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48 23 24 7 30 29 26 31	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CWLD -CWLD +CWLD -CCWLD +A -A +B -B +Z -Z +24VIN ECRST RUN DFSEL RESET	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A+output Encoder phase B+output Encoder phase B-output Encoder phase Z+output Encoder phase Z-output +24-V power supply for controls Error counter reset input Operation command input Damping filter switching Alarm reset
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B- Encoder phase B- Encoder phase B- Encoder phase Z+ Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output	4 50 39 38 37 36 35 34 33 32 31 30 41 45 44 42 42 43						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48 23 24 7 30 29 26 31 27	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD -CWLD +CWLD -CCWLD +A -A +B -B +Z -Z +24VIN ECRST RUN DFSEL RESET TLSEL	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A+output Encoder phase B+output Encoder phase B-output Encoder phase Z+output Encoder phase Z-output +24-V power supply for controls Error counter reset input Operation command input Damping filter switching
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B- Encoder phase Z+ Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output	4 50 39 38 37 36 35 34 33 32 31 30 41 45 44 42						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48 23 24 7 30 29 26 31 27 39	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD -CWLD +CCWLD -CCWLD +A -A +B -B +Z -Z +24VIN ECRST RUN DFSEL RESET TLSEL INP	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A+output Encoder phase B+output Encoder phase B-output Encoder phase Z+output Encoder phase Z-output +24-V power supply for controls Error counter reset input Operation command input Damping filter switching Alarm reset
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B- Encoder phase B- Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output Positioning completed input	4 50 39 38 37 36 35 34 33 32 31 30 41 45 44 42 42 43 49						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48 23 24 7 30 29 26 31 27 39 38	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CWLD -CWLD +CWLD -CCWLD +A -A +B -B +Z -Z +24VIN ECRST RUN DFSEL RESET TLSEL INP INPCOM	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A+output Encoder phase B+output Encoder phase B-output Encoder phase Z+output Encoder phase Z-output +24-V power supply for controls Error counter reset input Operation command input Damping filter switching Alarm reset Torque limit switching Positioning completion output 1
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (+) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B- Encoder phase B- Encoder phase B- Encoder phase Z+ Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output	4 50 39 38 37 36 35 34 33 32 31 30 41 45 44 42 42 43						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48 23 24 7 30 29 26 31 27 39 38 35	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD -CWLD +CCWLD -CCWLD +A -A +B -B +Z -Z +24VIN ECRST RUN DFSEL RESET TLSEL INP INPCOM READY	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A+output Encoder phase B+output Encoder phase B+output Encoder phase Z+output Encoder phase Z-output +24-V power supply for controls Error counter reset input Operation command input Damping filter switching Alarm reset Torque limit switching Positioning completion output 1 Servo ready completed
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (-) Encoder phase dutput (-) Encoder phase A+ Encoder phase A- Encoder phase B- Encoder phase B- Encoder phase Z+ Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output Positioning completed input	4 50 39 38 37 36 35 34 33 32 31 30 41 45 44 42 43 49 48						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48 23 24 7 30 29 26 31 27 39 38 35 34	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD -CWLD +CCWLD -CCWLD +A -A +B -B +Z -Z +24VIN ECRST RUN DFSEL RESET TLSEL INP INPCOM READY REDYCOM	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A+output Encoder phase B+output Encoder phase B-output Encoder phase Z+output Encoder phase Z-output +24-V power supply for controls Error counter reset input Operation command input Damping filter switching Alarm reset Torque limit switching Positioning completion output 1
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B+ Encoder phase B- Encoder phase B- Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output Positioning completed input	4 50 39 38 37 36 35 34 33 32 31 30 41 45 44 42 42 43 49						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48 23 24 7 30 29 26 31 27 39 38 35 34 37	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD -CWLD +A -A +B -B +Z -Z +24VIN ECRST RUN DFSEL RESET TLSEL INP INPCOM READY REDYCOM /ALM	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A+output Encoder phase B+output Encoder phase B-output Encoder phase Z+output Encoder phase Z-output +24-V power supply for controls Error counter reset input Operation command input Damping filter switching Alarm reset Torque limit switching Positioning completion output 1 Servo ready completed
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (-) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B- Encoder phase B- Encoder phase Z- Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output Positioning completed input General-purpose input	4 50 39 38 37 36 35 34 33 32 31 30 41 45 44 42 43 49 48 48 47						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48 23 24 7 30 29 26 31 27 39 38 35 34 37 36	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD -CWLD +CCWLD -CCWLD +A -A +B -B +Z -Z +24VIN ECRST RUN DFSEL RESET TLSEL INP INPCOM READY REDYCOM /ALM ALMCOM	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A+output Encoder phase B+output Encoder phase B-output Encoder phase Z-output Encoder phase Z-output Hencoder phase Z-output Encoder phase Z-output Hencoder phase Z-output H
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (-) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B- Encoder phase B- Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output Positioning completed input General-purpose input	4 50 39 38 37 36 35 34 33 32 31 30 41 45 44 42 43 49 48 48 47 29						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48 23 24 7 30 29 26 31 27 39 26 31 27 39 38 35 34 37 36 20	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD -CWLD +A -A +B -B +Z -Z +24VIN ECRST RUN DFSEL RESET TLSEL INP INPCOM READY REDYCOM /ALM ALMCOM SEN	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A+output Encoder phase B+output Encoder phase B-output Encoder phase Z-output Encoder phase Z-output Hencoder phase Z-output Encoder phase Z-output Hencoder phase Z-output H
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (-) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B- Encoder phase B- Encoder phase Z- Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output Positioning completed input General-purpose input	4 50 39 38 37 36 35 34 33 32 31 30 41 45 44 42 43 49 48 48 47						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48 23 24 7 30 29 26 31 27 39 26 31 27 39 38 35 34 37 36 20 13	visted pair 1 m Blue: BKIF Black: BKI Drive side (for axi- 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD -CWLD +A -A +B -B +Z -Z +24VIN ECRST RUN DFSEL RESET TLSEL INP INPCOM READY REDYCOM /ALM ALMCOM SEN SENGND	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A+output Encoder phase B+output Encoder phase B-output Encoder phase Z+output Encoder phase Z-output +24-V power supply for controls Error counter reset input Operation command input Damping filter switching Alarm reset Torque limit switching Positioning completion output 1 Servo ready completed output Alarm output Sensor ON input
24-V GND for output Input common Forward direction pulse output (+) Forward direction pulse output (-) Reverse direction pulse output (-) Reverse direction pulse output (-) Encoder phase A+ Encoder phase A- Encoder phase B- Encoder phase B- Encoder phase B- Encoder phase Z+ Encoder phase Z- Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output Positioning completed input General-purpose input Alarm input SEN output Signal ground	4 50 39 38 37 36 35 34 33 32 31 30 41 45 44 42 43 49 48 48 49 29 28						G18 tw Servo 10150- 11 10 44 45 46 47 21 22 49 48 23 24 7 30 29 26 31 27 39 26 31 27 39 26 31 27 39 38 35 34 37 36 20 13 Shell	visted pair 1 m Blue: BKIF Black: BKI Black: BKI Drive side (for axis 3000PE (Sumitor BKIR BKIRCOM +CWLD -CWLD +CCWLD -CWLD +CCWLD -CCWLD +A -A +B -B +Z -Z +24VIN ECRST RUN DFSEL RESET TLSEL INP INPCOM READY REDYCOM /ALM ALMCOM SEN SENGND FG	ACOM R s 2 or 4) no 3M) Brake interlock output Reverse pulse (*1) (input for line driver only) Forward pulse (*1) (input for line driver only) Encoder phase A+output Encoder phase A+output Encoder phase B+output Encoder phase B-output Encoder phase Z-output +24-V power supply for controls Error counter reset input Operation command input Damping filter switching Alarm reset Torque limit switching Positioning completion output 1 Servo ready completed output

*1 Since the PCU handles forward direction commands as CW-direction/phase-A advance pulses (selectable by the output pulse direction selection parameter), connect the wires as shown here.

Cable for open collector output for 2 axes

AWG18 twiste Red: 24 VDC				1				wisted pair 1 m	M
Black: 24 VDC GND						Ιг	_/	Black: BKIR	
PCU side XG4M-5030-T (OMRO							Sonio	Drive side (for axis 1	or 3)
		1					10150	-3000PE (Sumitomo	3M)
24-V power supply for output	1	Π				IL	10100	BKIR	
24-V GND for output	3	Π							Brake interlock outpu
Input common	5	H	-		_I		10	BKIRCOM	
Forward direction pulse output	16				$\neg \checkmark$ т		3	+CW/+PULS/+FA	Reverse pulses, feed puls
(with 1.6 kΩ Resistor)	10	H			—⁄ `+		4	-CW/-PULS/-FA	or phase A (*1)
Reverse direction pulse output	40			ΗV	$-\sqrt{1}$		- 5	+CCW/+SIGN/+FB	Forward pulse, direction sig
(with 1.6 kΩ Resistor)	18	\vdash		⊢i∕∕_	⁄\Į		- 6	-CCW/-SIGN/-FB	or phase B (*1)
Encoder phase A+	21						21	+A	Encoder phase A+outp
Encoder phase A-	20	\vdash		┝᠇╯╲─			22	A	Encoder phase A-outp
Encoder phase B+	23			+	$-\sqrt{1}$		- 49	+B	Encoder phase B+outp
Encoder phase B-	22			++-	—^		- 48	-B	Encoder phase B-outp
Encoder phase Z+	25	Н			—⁄i		- 23	+Z	Encoder phase Z+outp
Encoder phase Z-	24			\vdash	-		24	-Z	Encoder phase Z-outp
			•		<u> </u>		- 7	+24VIN	+24-V power supply for contr
Error counter reset output	15	\vdash		$\vdash \sim$	^+		- 30	ECRST	Error counter reset inp
RUN output	11	Н					29	RUN	Operation command in
General-purpose output	10	Н		Li			- 26	DFSEL	Damping filter switchin
Alarm reset output	12	Н			<u> </u>		- 31	RESET	Alarm reset
Torque limit output	13	Ц		<u> </u>	I		- 27	TLSEL	Torque limit switching
Positioning completed input	7			Ц _			- 39	INP	Positioning completion
Positioning completed input	/				_X'		- 38	INPCOM	output 1
<u></u>	~						35	READY	Servo ready complete
General-purpose input	6			$\Box X$	—Xi		34	REDYCOM	output
					(L		- 37	/ALM	· ·
Alarm input	9				-Xī		36	ALMCOM	Alarm output
			-				- 20	SEN	
SEN output	26				$\neg \sqrt{1}$		-	-	Sensor ON input
Signal ground	27				— ` `T		- <u>13</u> Shell	SENGND FG	Frame ground
								Drive side (for axis 2)-3000PE (Sumitomo	
24-V power supply for output	2	Η	-						
24-V GND for output	4	H				15	11	BKIR	Brake interlock output
Input common	50	\vdash	-		1		· <u>10</u>	BKIRCOM	· ·
Forward direction pulse output	38		•				. 3	+CW/+PULS/+FA	Reverse pulses, feed
(with 1.6 kΩ Resistor)	00	\vdash		+ -			4	-CW/-PULS/-FA	pulses, or phase A (*1)
Reverse direction pulse output	36				!		- 5	+CCW/+SIGN/+FB	Forward pulse, direction
(with 1.6 kΩ Resistor)	50	Н		┝╁╲─	Ļ		6	-CCW/-SIGN/-FB	signal, or phase B (*1)
Encoder phase A+	35	-		\vdash	\neg		. 21	+A	Encoder phase A+output
Encoder phase A-	34	Н		$\perp \times$	X¦		. 22	-A	Encoder phase A-output
Encoder phase B+	33	\square		\vdash	/		49	+B	Encoder phase B+output
Encoder phase B-	32	Ц		μ×_	_Xi		. 48	B	Encoder phase B-output
Encoder phase Z+	31	Н		\vdash	, /+		- 23	+Z	Encoder phase Z+output
Encoder phase Z-	30	Ц		⊢¦×_	_XI		24	-Z	Encoder phase Z-output
	00			Ці, —			- 7	+24VIN	+24-V power supply for controls
				X	_X!		30	ECRST	Error counter reset input
•	11	1		1			. 29	RUN	Operation command input
Error counter reset output	41						26	DFSEL	Damping filter switching
Error counter reset output RUN output	45				i		<u> </u>		
Error counter reset output RUN output General-purpose output	45 44				i		31	BESET	Alarm reset
Error counter reset output RUN output General-purpose output Alarm reset output	45 44 42						. 31	RESET	Alarm reset
Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output	45 44 42 43						. 27	TLSEL	Torque limit switching
Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output	45 44 42						<u>27</u> 39	TLSEL INP	Torque limit switching Positioning completion
Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output Positioning completed input	45 44 42 43 49						27 39 38	TLSEL INP INPCOM	Torque limit switching Positioning completion output 1
Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output Positioning completed input	45 44 42 43		•				27 39 38 38	TLSEL INP INPCOM READY	Torque limit switching Positioning completion output 1 Servo ready completed
Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output Positioning completed input General-purpose input	45 44 42 43 49 48		•				27 39 38 35 34	TLSEL INP INPCOM READY REDYCOM	Torque limit switching Positioning completion output 1
Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output Positioning completed input General-purpose input	45 44 42 43 49						27 39 38 38 35 34 37	TLSEL INP INPCOM READY REDYCOM /ALM	Torque limit switching Positioning completion output 1 Servo ready completed
Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output Positioning completed input General-purpose input Alarm input	45 44 42 43 49 48		•				27 39 38 35 34 37 36	TLSEL INP INPCOM READY REDYCOM /ALM ALMCOM	Torque limit switching Positioning completion output 1 Servo ready completed output
Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output Positioning completed input General-purpose input	45 44 42 43 49 48		• • • • • • • • • • • • • • • • • • •				27 39 38 35 34 37 36 20	TLSEL INP INPCOM READY REDYCOM /ALM ALMCOM SEN	Torque limit switching Positioning completion output 1 Servo ready completed output Alarm output
Error counter reset output RUN output General-purpose output Alarm reset output Torque limit output Positioning completed input General-purpose input Alarm input	45 44 42 43 49 49 48 48 47						27 39 38 35 34 37 36	TLSEL INP INPCOM READY REDYCOM /ALM ALMCOM	Torque limit switching Positioning completion output 1 Servo ready completed output

*1 Since the PCU handles forward direction commands as CW-direction/phase-A advance pulses (selectable by the output pulse direction selection parameter), connect the wires as shown here.

General-purpose Control Cables (R88A-CPG


This is a cable attached to the connector to be connected to the drive's control I/O connector (CN1). The connector for the controller is not provided. When connecting to a Position Control Unit which does not have a specified cable or connecting to another company's controller, prepare wiring suited for the controller to be connected.

• When connecting to a controller which does not have a specified cable, either use a generalpurpose control cable or a connector-terminal block cable and a connector-terminal block.

Cable types

Model	Length (L)	Outer diameter of sheath	Weight
R88A-CPG001S	1 m	12.8 dia.	Approx. 0.3 kg
R88A-CPG002S	2 m	12.0 01a.	Approx. 0.6 kg

Connection configuration and external dimensions



Number	Wire/Mark color	Symbol	Number	Wire/Mark color	Symbol
1	Orange/Red (1)	+24VCW	27	Pink/Black (3)	SI4
2	Orange/Black (1)	+24VCCW	28	White/Black (3)	SI5
3	Gray/Red (1)	+CW/+PULS/+FA	29	Yellow/Red (3)	SI6
4	Gray/Black (1)	-CW/-PULS/-FA	30	Pink/Red (3)	SI7
5	White/Red (1)	+CCW/+SIGN/+FB	31	Yellow/Black (3)	SI8
6	White/Black (1)	-CCW/-SIGN/-FB	32	Gray/Black (4)	SI9
7	Yellow/Red (1)	+24VIN	33	Orange/Red (4)	SI10
8	Pink/Red (1)	SI1	34	White/Red (4)	SO2-
9	Pink/Black (1)	SI2	35	White/Black (4)	SO2+
10	Orange/Red (2)	SO1-	36	Yellow/Red (4)	ALMCOM
11	Orange/Black (2)	SO1+	37	Yellow/Black (4)	/ALM
12	Yellow/Black (1)		38	Pink/Red (4)	SO4-
13	Gray/Black (2)	SENGND	39	Pink/Black (4)	SO4+
14	White/Red (2)	REF/TREF1/VLIM	40	Gray/Red (4)	
15	White/Black (2)	AGND1	41	Orange/Black (4)	
16	Yellow/Red (2)	PCL/TREF2	42	Gray/Red (5)	BAT
17	Yellow/Black (2), Pink/Black (2)	AGND2	43	Gray/Black (5)	BATGND
18	Pink/Red (2)	NCL	44	White/Red (5)	+CWLD
19	Orange/Red (5)	Z	45	White/Black (5)	-CWLD
20	Gray/Red (2)	SEN	46	Yellow/Red (5)	+CCWLD
21	Orange/Red (3)	+A	47	Yellow/Black (5)	-CCWLD
22	Orange/Black (3)	-A	48	Pink/Black (5)	-В
23	Gray/Red (3)	+Z	49	Pink/Red (5)	+B
24	Gray/Black (3)	-Z	50		
25	Orange/Black (5)	ZGND	Shell		FG
26	White/Red (3)	SI3		1	

 $\label{eq:connector plug model: 10150-3000PE (Sumitomo 3M) \\ Connector case model: 10350-52A0-008 (Sumitomo 3M) \\ Cable: AWG24 \times 25P \ UL20276 \\ \end{tabular}$

• Wires with the same wire color and the same number of marks form a twisted pair. Example: Wires with respective wire and mark colors of orange/red (1) and orange/black (1) form a twisted pair.


Terminal Block Cables (XW2Z-□J-B24)

This is a cable to connect the Servo drive I/O signals (CN1 connector) to a terminal block for general-purpose. All servo drive I/O signals are wired.

Cable types

Model	Length (L)	Outer diameter of sheath	Weight
XW2Z-100J-B24	1 m	11.2 dia.	Approx. 0.2 kg
XW2Z-200J-B24	2 m		Approx. 0.4 kg

Connection configuration and external dimensions




Number	Number		Number	Wire and mark color	Cumple al	
		,,			Symbol	
1			- 1	Blue/Red (1)	+24VCW	
2			2	Blue/Black (1)	+24VCCW	• 1 Wires with the same wire color
3 –	3		3	Pink/Red (1)	+CW/+PULS/+FA	and the same number of marks
4	4		4	Pink/Black (1)	-CW/-PULS/-FA	form a twisted pair
5	5		5	Green/Red (1)	+CCW/+SIGN/+FB	
6	<u> </u>		6	Green/Black (1)	-CCW/-SIGN/-FB	wire and mark colors
7 -			7	Orange/Red (1)	+24VIN	of Yellow/Black (1) and
8	8		8	Gray/Red (1)	SI1	Pink/Black (1) form a
9	9		9	Gray/Black (1)	SI2	twisted pair
10 -			10	Blue/Red (2)	SO1-	twisted pair
11		\rightarrow \sim	- 11	Blue/Black (2)	SO1+	
13			13	Pink/Red (2)	SENGND	
20 -	20		20	Pink/Black (2)	SEN	
14			14	Green/Red (2)	REF/TREF1/VLIM	
15 -			15	Green/Black (2)	AGND1	
16			16	Orange/Red(2)	PCL/TREF2	
17			- 17	Orange/Black (2)	AGND2	
18			18	Gray/Red (1)	NCL	
12			- 12	Gray/Black(2)		
19			- 19	Blue/Red (3)	Z	
25	25		25	Blue/Black (3)	ZGND	
21			21	Pink/Red (3)	+A	
22 -	22		22	Pink/Black(3)	<u>–A</u>	
23	23		23	Green/Red (3)	+Z	
24		•	24	Green/Black (3)	<u>–Z</u>	
26			26	Orange/Red(3)	SI3	
27			27	Orange/Black(3)	SI4	
28			28	Gray/Red (3)	SI5	
29	29		29	Gray/Black(3)	SI6	
30			30	Blue/Red (4)	SI7	
31			31	Blue/Black (4)	SI8	
32	32		32	Pink/Red (4) Pink/Black (4)	SI9	
33			33		SI10	Servo Drive Connector:
34	34 - 35 -		34	Green/Red (4)	SO2-	Connector plug model
<u>35</u> 36			35	Green/Black (4) Orange/Red(4)	SO2+ ALMCOM	
37	36 - 37 -		<u>36</u> 37	Orange/Black (4)	/ALM	10150-3000PE (Sumitomo 3M)
37	-37 -38		-37 -38	Gray/Red(4)	SO4-	Connector case model
39	39		30	Gray/Black(4)		10350-52A0-008 (Sumitomo 3M)
40	$-\frac{39}{40}$		$-\frac{39}{40}$	Blue/Red (5)	304+	
40			40	Blue/Black (5)		
42	42		42	Pink/Red (5)	BAT	Terminal Block Connector:
42 -	42		42	Pink/Black (5)	BATGND	Connector socket model
43	43	$ \rightarrow $	-43	Green/Red (5)	+CWLD	
44	45		44	Green/Black (5)		XG4M-5030 (OMRON)
46	45		45	Orange/Red (5)	+CCWLD	Strain relief model XG4T-5004 (OMRC
40	40		40	Orange/Black (5)	-CCWLD	
47			47	Gray/Red (5)	B	
40	40		40	Gray/Black(5)	В	Cable: AWG28 × 25P UL2464
50	50		<u>49</u> 50	Orange/Red(1)	- +D	
50	_ 00 K	֥	Shell	Jiange/neu(1)	FG	4


Connector-Terminal Block Conversion Unit

The Connector-Terminal Block Conversion Unit connects the servo drive I/O signals (CN1 connector) for general purpose. Use the cable (XW2Z-□J-B24) to connect the Connector-Terminal Block Conversion Unit to the CN1 connector.


XW2B-50G4 (M3 Screw Terminal Block)




Dimensions




- Use 0.3 to 1.25 mm² wire (AWG22 to 16).
- The wire inlet is 1.8 mm (height) \times 2.5 mm (width).
- Strip the insulation from the end of the wire for 6 mm as shown below.



XW2B-50G5 (M3.5 Screw Terminal Block)



Dimensions



- When using crimp terminals, use crimp terminals with the following dimensions.
- When connecting wires and crimp terminals to a terminal block, tighten them with a tightening torque of 0.59 N•m.

Round terminal


Fork terminal

¢3.2mm


6.8 mm max. . 6.8 mm max.

Applicable cr	Applicable wires	
Bound terminals	1.25–3	AWG22-16 (0.3 to 1.25 mm ²)
Nound terminals	2–3.5	AWG16-14 (1.25 to 2.0 mm ²)
Fork terminals	1.25Y–3	AWG22-16 (0.3 to 1.25 mm ²)
FOR terminals	2–3.5	AWG16-14 (1.25 to 2.0 mm ²)

XW2D-50G6 (M3 Screw Terminal Block)



Dimensions



- When using crimp terminals, use crimp terminals with the following dimensions.
- When connecting wires and crimp terminals to a terminal block, tighten them with a tightening torque of 0.7 N•m.

Round terminalFork terminal $\phi3.2 \text{ mm}$ 5.8 mm max.5.8 mm max.3.2 mm

Applicable cr	Applicable wires	
Round terminals	1.25–3	AWG22-16 (0.3 to 1.25 mm ²)
Fork terminals	1.25Y–3	AWG22-16 (0.3 to 1.25 mm ²)


3-5 Servo Relay Units and Cable Specifications

This section provides the specifications for the Servo Relay Unit and cables used for connecting to Position Control Units for OMRON Programmable Controllers (SYSMAC). Select the models that match the Position Control Unit to be used.

Servo Relay Units Specifications




This Servo Relay Unit connects to the following OMRON Position Control Units.




- + CJ1W-NC113/-NC133
- CS1W-NC113/-NC133
- + C200HW-NC113

Dimensions



• Terminal block pitch: 7.62 mm




*1. The XB contacts are used to turn ON/OFF the electromagnetic brake. Note 1.Do not connect unused terminals.

Note 2.The 0 V terminal is internally connected to the common terminals. Note 3.The applicable crimp terminal is R1.25-3 (round with open end).


XW2B-40J6-2B

This Servo Relay Unit connects to the following OMRON Position Control Units.




- CJ1W-NC213/-NC233/-NC413/-NC433
- CS1W-NC213/-NC233/-NC413/-NC433
- C200HW-NC213/-NC413

Dimensions



• Terminal block pitch: 7.62 mm




*1. The XB and YB contacts are used to turn ON/OFF the electromagnetic brake. Note 1.Do not connect unused terminals.

Note 2.The 0 V terminal is internally connected to the common terminals. Note 3.The applicable crimp terminal is R1.25-3 (round with open end).


XW2B-20J6-3B

This Servo Relay Unit connects to the following OMRON Programmable Controllers.




- CQM1-CPU43-V1
- CQM1-PLB21

Dimensions



• Terminal block pitch: 7.62 mm



*1. If this signal is input, the output pulse from the CQM1 will be input to the high-speed counter.

*2. Input this output signal to a CQM1 Input Unit.

*3. The XB contacts are used to turn ON/OFF the electromagnetic brake.

Note 1. The phase Z is an open collector.


Note 2.Do not connect unused terminals.

Note 3.The 0 V terminal is internally connected to the common terminals.

Note 4. The applicable crimp terminal is R1.25-3 (round with open end).


XW2B-20J6-8A

This Servo Relay Unit connects to the following OMRON Programmable Controllers.




CJ1M-CPU21/-CPU22/-CPU23 (for 1 axis)

Dimensions



Terminal block pitch: 7.62 mm

The Servo Drive phase Z output signal is wired to the origin signal in this terminal block.



*1. CW and CCW limit input signals can also be input through Input Units. The signal for the CW/CCW limit inputs in the CJ1M are as follows: CW: A540.08, CCW: A540.09 for pulse output 0 and CW: A541.08, CCW: A541.09 for pulse output 1. Accordingly, the actual inputs can be used as the CW/ CCW limit by outputting the flags below in the ladder program.

Example)


2960.06

- *2. The XB contacts are used to turn ON/OFF the electromagnetic brake.
- *3. Connection to the MING input terminal is disabled.

Note 1.Do not connect unused terminals.


Note 2.The 0 V terminal is internally connected to the common terminals.

Note 3.The applicable crimp terminal is R1.25-3 (round with open end).



+ CJ1M-CPU21/-CPU22/-CPU23 (for 2 axes)


Dimensions



• Terminal block pitch: 7.62 mm

Specifications

The Servo Drive phase Z output signal is wired to the origin signal in this terminal block.



*1. CW and CCW limit input signals can also be input through Input Units. The signal for the CW/CCW limit inputs in the CJ1M are as follows: CW: A540.08, CCW: A540.09 for pulse output 0 and CW: A541.08, CCW: A541.09 for pulse output 1. Accordingly, the actual inputs can be used as the CW/ CCW limit by outputting the flags below in the ladder program.

Example)

- *2. The XB and YB contacts are used to turn ON/OFF the electromagnetic brake.
- *3. Connection to the MING input terminal is disabled.
- *4. Do not connect unused terminals.
- *5. The 0 V terminal is internally connected to the common terminals.
- *6. The applicable crimp terminal is R1.25-3 (round with open end).

Servo Drive Cable (XW2Z-□J-B31)


This cable connects the drive to a Servo Relay Unit (XW2B-20J6-8A, XW2B-40J6-9A).

Cable types

Model	Length (L)	Outer diameter of sheath	Weight
XW2Z-100J-B31	1 m	8.1 dia.	Approx. 0.1 kg
XW2Z-200J-B31	2 m	0.1 dia.	Approx. 0.2 kg

Note: Do not use a Servo Relay Unit Cable for line receiver inputs (+CWLD: CN1 pin 44, -CWLD: CN1 pin 45, +CCWLD: CN1 pin 46, -CCWLD: CN1 pin 47). Use a General-purpose Control Cable (R88A-CPG \square S) and prepare wiring suited for the controller to be connected.

Connection configuration and external dimensions



Wiring

Servo Relay Ur	nit side		Servo Drive side
Wire and mark color	Number		Number
Blue/Red (1)	1		7
Blue/Black (1)	2		38
Pink/Red (1)	3		5
Pink/Black (1)	4		6
Green/Red (1)	5		3
Green/Black (1)	6		4
Orange/Red (1)	7		
_	8		30
_	9		L <u>10</u>
Gray/Red (1)	10		23
Gray/Black (1)	11		24
Blue/Red (2)	12		39
Blue/Black (2)	13		29
Orange/Black (1)	14		
Pink/Red (2)	15		27
Pink/Black (2)	16		31
Orange/Red (2)	17		11
Green/Black (2)	18		37
Orange/Red (2)	19		- 36
Any	20	<u>}</u>	Shell

[Servo Relay Unit connector]

Connector socket model: XG4M-2030 Strain relief model: XG4T-2004 [Cable] AWG28 \times 10P UL2464

[Drive connector]

Connector plug model: 10150-3000PE (Sumitomo 3M) Connector case model: 10350-52A0-008 (Sumitomo 3M)

Position Control Unit-Servo Relay Unit Cable Specifications


Position Control Unit Cable (XW2Z-□J-A3)

This cable connects a Programmable Controller (CQM1H-PLB21) to a Servo Relay Unit (XW2B-20J6-3B).

Cable types

Model	Length (L)	Outer diameter of sheath	Weight
XW2Z-050J-A3	50 cm	7.5 dia.	Approx. 0.1 kg
XW2Z-100J-A3	1 m	7.5 014.	Approx. 0.1 kg

Connection configuration and external dimensions



CQM1 side		Servo Relay Unit side
Number		Number
15 -	1	1
12 -		2
		3
13 –		- 4
		- 5
14		6
1 –		- 7
3 –		- 8
		9
4 –		10
5 –		- 11
6		12
Hood cover		13
	Cable: AWG28 \times 4P + AWG28 \times 4C	14
		15
		16

Position Control Unit Cable (XW2Z-□J-A6)


This cable connects a Position Control Unit (CS1W-NC113 and C200HW-NC113) to a Servo Relay Unit (XW2B-20J6-1B).

Cable types

Model	Length (L)	Outer diameter of sheath	Weight
XW2Z-050J-A6	50 cm	8.0 dia.	Approx. 0.1 kg
XW2Z-100J-A6	1 m	0.0 010.	Approx. 0.1 kg

3

Connection configuration and external dimensions



Position Control Unit side	Servo Relay Unit side
Number	Number
A1 +	1
A2	2
	3
A8	4
	5
A6	6
	7
A10	8
	9
A16	10
A14	11
A24	12
A12	13
	14
A21	15
	16
A23	17
	18
A22	19
	20
A19	21
	22
A20	23
	24
Crimp	25
terminal Cable: AWG28 × 4P	


Position Control Unit Cable (XW2Z-□J-A7)

This cable connects a Position Control Unit (CS1W-NC213/NC413 and C200HW-NC213/ NC413) to a Servo Relay Unit (XW2B-40J6-2B).

Cable types

Model	Length (L)	Outer diameter of sheath	Weight
XW2Z-050J-A7	50 cm	10.0 dia. Approx. 0.1 kg	Approx. 0.1 kg
XW2Z-100J-A7	1 m	10.0 dia.	Approx. 0.2 kg

Connection configuration and external dimensions



Number	Number
A1/B1	1
A2/B2	2
	3
A8	
	5
A6	
	7
A10	
	9
A16	10
A14	
A24/B24	12
A19	13
A21	14
A12	15
A23	16
A22	17
A20/B20	18
B8	
B6	
	23
B10	
	25
B16	
B14	
B23	28
B22	29
B21	
B19	31
B12	
	33
Crimp Cable: AWG2	28 × 6P + AWG28 × 16C 34


Position Control Unit Cable (XW2Z-□J-A10)

This cable connects a Position Control Unit (CS1W-NC133) to a Servo Relay Unit (XW2B-20J6-1B).

Cable types

Model	Length (L)	Outer diameter of sheath	Weight
XW2Z-050J-A10	50 cm	10.0 dia. Approx. 0.1 kg	Approx. 0.1 kg
XW2Z-100J-A10	1 m	10.0 dia.	Approx. 0.2 kg

Connection configuration and external dimensions



Wiring

Position Control Unit	side	Servo Relay Unit side
Number		Number
A3 —	AWG 20Black	
A4 —	XX AWG 20Red	
A1	•	1
A2 —		2
A7 —		3
A8 —	XX	4
A5 —		5
A6 —	X	6
		- 7
A10	XX	- 8
		9
A16 —		10
A14 —	XX	11
A24 —		12
A12		13
		14
A21		
		16
A23 —		17
		18
A22 —		
		20
A19 —		21
		22
A20 —		23
		24
Crimp ——		25
terminal	Cable: AWG28 \times 4P + AWG28 \times 10C	26


Position Control Unit Cable (XW2Z-DJ-A11)

This cable connects a Position Control Unit (CS1W-NC233/433) to a Servo Relay Unit (XW2B-40J6-1B).

Cable types

Model	Length (L)	Outer diameter of sheath	Weight
XW2Z-050J-A11	50 cm	10.0 dia.	Approx. 0.1 kg
XW2Z-100J-A11	1 m	10.0 dia.	Approx. 0.2 kg

Connection configuration and external dimensions



Wiring

Number		Number
A3/B3	AWG20 Black	
A4/B4	XX AWG20 Red	
A1/B1	•	1
A2/B2		2
A7	^	3
A8	XX	4
A5	^	5
A6	XX	6
		7
A10	XX	8
		9
A16		10
A14	XX	11
A24/B24		12
A19		13
A21		14
A12		15
A23		16
A22		17
A20/B20		18
B7		19
B8	XX	20
B5		21
B6	XX	22
		23
B10	X	24
	L	25
B16		26
B14	XX	27
B23		28
B22		29
B21		30
B19		31
B12		32
	,	33
Crimp ——	Cable: AWG28 × 6P + AWG28 × 16	C 34


Position Control Unit Cable (XW2Z-DJ-A14)

This cable connects a Position Control Unit (CJ1W-NC113) to a Servo Relay Unit (XW2B-20J6-1B).

Cable types

Model	Length (L)	Outer diameter of sheath	Weight
XW2Z-050J-A14	50 cm 10.0 dia.		Approx. 0.1 kg
XW2Z-100J-A14	1 m	10.0 dia.	Approx. 0.2 kg

Connection configuration and external dimensions



Position Control Unit side		Servo Relay Unit side
Number		Number
A1 +		1
A2		2
		3
A8	XX	4
		5
A6	XX	6
		- 7
A9 +	XX	- 8
		9
A14		10
A12	XX	11
A20		12
A11		13
		14
A17		15
		16
A19		17
		18
A18		19
		20
A15		21
		22
A16		23
	<u>لم</u>	24
Crimp		25
terminal	Cable: AWG28 \times 4P + AWG28 \times 10C	26


Position Control Unit Cable (XW2Z-DJ-A15)

This cable connects a Position Control Unit (CJ1W-NC213/NC413) to a Servo Relay Unit (XW2B-40J6-2B).

Cable types

Model	Length (L)	Outer diameter of sheath	Weight
XW2Z-050J-A15	50 cm 10.0 dia.		Approx. 0.1 kg
XW2Z-100J-A15	1 m	10.0 dia.	Approx. 0.2 kg

Connection configuration and external dimensions



Wiring

Number	Servo Relay Un Number
A1/B1	1
A2/B2	2
	3
A8	
A0	
	×× 5
A6	
	7
A9	
	9
A14	10
A12	
A20/B20	
A15	13
A17	14
A11	15
A19	16
A18	17
A16/B16	18
	¬∧∕19
B8	
	21
B6	
	23
B9	24
	25
B14	26
B12	27
B19	
B18	29
B17	
B15	
B13 B11	31
	33
	33

Specifications


Position Control Unit Cable (XW2Z-DJ-A18)

This cable connects a Position Control Unit (CJ1W-NC133) to a Servo Relay Unit (XW2B-20J6-1B).

Cable types

Model	Length (L)	Outer diameter of sheath	Weight
XW2Z-050J-A18	50 cm	10.0 dia.	Approx. 0.1 kg
XW2Z-100J-A18	1 m	10.0 dia.	Approx. 0.2 kg

Connection configuration and external dimensions



Number AWG20 Bla	Number
A4 XX AWG20 R	ed
A1 +	1
A2	2
A7	3
A8	4
A5	
A6	6
	7
A9	-~~
	9
A14	10
A12	
A20	
A11	13
	14
A17	15
	16
A19	17
	18
A18	
	20
A15	21
	22
A16	23
· · · · · · · · · · · · · · · · · · ·	24
Frimp	25
erminal Cable: AWG28	× 4P + AWG28 × 10C 26


Position Control Unit Cable (XW2Z-□J-A19)

This cable connects a Position Control Unit (CJ1W-NC233/433) to a Servo Relay Unit (XW2B-40J6-2B).

Cable types

Model	Length (L)	Outer diameter of sheath	Weight
XW2Z-050J-A19	50 cm	50 cm 10.0 dia.	
XW2Z-100J-A19	1 m	10.0 dia.	Approx. 0.2 kg

Connection configuration and external dimensions



Wiring

Number	AWG20 Black	Number
A3/B3		
A4/B4	AWG20 Red	
A1/B1	•	- 1
A2/B2		2
A7		3
A8	X	
A5		5
A6	X	6
		- 7
A9	XX	
A14		
A12	XX	11
A20/B20		12
A15		13
A17		14
A11		
A19		16
A18		17
A16/B16		18
B7		
B8	X	20
B5		21
B6	X	22
		23
B9		24
B14		26
B12		27
B19		28
B18		29
B17		
B15		31
B11		32
	<u>لر</u>	33
Crimp ——	Cable: AWG28 × 8P + AWG28 × 16	34


Position Control Unit Cable (XW2Z-□J-A33)

This cable connects a Programmable Controller (CJ1M-CPU21/CPU22/CPU23) to a Servo Relay Unit (XW2B-20J6-8A or XW2B-40J6-9A).

Cable types

Model	Length (L)	Outer diameter of sheath	Weight
XW2Z-050J-A33	50 cm) cm 10.0 dia.	
XW2Z-100J-A33	1 m	10.0 dia.	Approx. 0.2 kg

Connection configuration and external dimensions



M side	Servo Relay Uni
Number	Number
37	1
39	2
40	3
32	4
	5
31	
35	
3	
5	
17	12
6	
23	15
20	
34	
33	20
	20
36	
9	23
11	23
18	25
12	26
29	28
30	29
2	30
8	
13	
14	
19	
20	
25	
26	
Crimp Cable	e: AWG28 \times 6P + AWG28 \times 14C

3-6 External Regeneration Resistor Specifications

External Regeneration Resistor Specifications

R88A-RR08050S

Model	Resistance value	Nominal capacity	Regeneration absorption for 120°C temperature rise	Heat radiation condition	Thermal switch output specifications
R88A- RR08050S	50 Ω	80 W	20 W	Aluminum 350 × 350, Thickness: 3.0	Operating temperature: $150^{\circ}C \pm 5\%$ NC contact Rated output (resistive load): 125 VAC, 0.1 A max. 30 VDC, 0.1 A max. (minimum current: 1 mA)

R88A-RR080100S

Model	Resistance value	Nominal capacity	Regeneration absorption for 120°C temperature rise	Heat radiation condition	Thermal switch output specifications
R88A- RR080100S	100 Ω	80 W	20 W	Aluminum 350 × 350, Thickness: 3.0	Operating temperature: $150^{\circ}C \pm 5\%$ NC contact Rated output (resistive load): 125 VAC, 0.1 A max. 30 VDC, 0.1 A max. (minimum current: 1 mA)

R88A-RR22047S1

Model	Resistance value	Nominal capacity	Regeneration absorption for 120°C temperature rise	Heat radiation condition	Thermal switch output specifications
R88A- RR22047S1	47 Ω	220 W	70 W	Aluminum 350 × 350, Thickness:3.0	Operating temperature: 150°C ± 5% NC contact Rated output (resistive load): 250 VAC, 0.2 A max. 42 VDC, 0.2 A max. (minimum current: 1 mA)

3

OMNUC G5-SERIES AC SERVOMOTOR AND SERVO DRIVE USER'S MANUAL

R88A-RR50020S

Model	Resistance value	Nominal capacity	Regeneration absorption for 120°C temperature rise	Heat radiation condition	Thermal switch output specifications
R88A- RR50020S	20 Ω	500 W	180 W	Aluminum 600 × 600, Thickness: 3.0	Operating temperature 200°C ± 7°C NC contact Rated output (resistive load): 250 VAC, 0.2 A max. 42 VDC, 0.2 A max. (minimum current: 1 mA)

3-7 EMC Filter Specifications

Specifications

Applicable servo drive	Filter model	Rated current	Leakage current	Rated voltage
R88D-KT01H	R88A-FIK102-RE	2.4 A		
R88D-KT02H		2.47		
R88D-KT04H	R88A-FIK104-RE	4.1 A		250 VAC single-phase
R88D-KT08H	R88A-FIK107-RE	6.6 A		250 VAC single-phase
R88D-KT10H	R88A-FIK114-RE	14.2 A		
R88D-KT15H		14.2 A	3.5 mA	
R88D-KT06F	R88A-FIK304-RE		- 5.5 IIIA	
R88D-KT10F		4 A		
R88D-KT15F				400 VAC single-phase
R88D-KT20F	R88A-FIK306-RE	6 A		400 VAC single-phase
R88D-KT30F	R88A-FIK312-RE	12 A		
R88D-KT50F	1			

4

System Design

This chapter explains the installation conditions for the Servo Drive and Servomotor, wiring methods including wiring conforming to EMC Directives and regenerative energy calculation methods as well as the performance of External Regeneration Resistors.


4-1	Installation Conditions	4-1
	Space Conditions around Servo Drives	4-1
	Servomotor Installation Conditions	
	Decelerator Installation Conditions	4-6
4-2	Wiring	4-7
	Peripheral Equipment Connection Examples	4-8
	Main Circuit and Motor Connections	4-18
4-3	Wiring Conforming to EMC Directives	4-33
	Wiring Method	4-33
	Selecting Connection Component	4-41
4-4	Regenerative Energy Absorption	4-53
	Regenerative Energy Calculation	4-53
	Servo Drive Regeneration Absorption Capacity	4-56
	Regenerative Energy Absorption with an External Regeneration Resistor	
	Connecting an External Regeneration Resistor	4-58
4-5	Large Load Inertia Adjustment and Dynamic Brake	4-61
	Adjustment When the Load Inertia Is Large	4-61
	Dynamic Brake When the Load Inertia Is Large	4-61
4-6	Using DC Power	4-62
	Connection Examples for DC Power	4-63

Installation Conditions 4-1

Space Conditions around Servo Drives

Space Conditions around Equipment

· Install Servo Drives according to the dimensions shown in the following illustration to ensure proper dispersion of heat from inside the drive and convection inside the panel. If the drives are installed side by side, install a fan for air circulation to prevent uneven temperatures inside the panel.



- W must be 50 mm or more if 7.5-kW or 15-kW Servo Drives are installed.
- Servo Drives of 100 V or 200 V with a capacity of 750 W max. can be installed side by side with a 1-mm clearance (W in above illustration). For ambient temperature requirements, refer to Environment Operating Conditions below.
- + If the mounting surface of the Servo Drive is coated, remove the coating to allow electrical conduction. If you make your own mounting bracket, we recommend that you apply electrically conductive plating.

Mounting Direction

Mount the Servo Drive perpendicular on the panel so that the model number reads normally.

Environment Operating Conditions

- The environment in which drives are operated must meet the following conditions. Drives may malfunction if operated under any other conditions.
 - Operating ambient temperature: 0 to +55°C (Take into account temperature rises in the following individual drives themselves.)
 - Operating humidity: 85% max. (with no condensation)
 - Operating atmosphere: No corrosive gases.
 - Altitude: 1,000 m max.
- + For Servo Drives of 100 V or 200 V with a capacity of 750 W max., the specifications for operating ambient temperature depend on the Servo Drive (A, B, and C) when the clearance between Servo Drives is 1 mm.
 - Servo Drive A: 0 to 50 °C Servo Drive B: 0 to 40 °C Servo Drive C: 0 to 45 °C

Ambient Temperature Control

- Operation in an environment in which there is minimal temperature rise is recommended to maintain a high level of reliability.
- When the drive is installed in a closed space, such as a box, the ambient temperature may rise due to temperature rise in each unit. Use a fan or air conditioner to prevent the Servo Drive's ambient temperature from exceeding 55°C.
- Drive surface temperatures may rise to as much as 30°C above the ambient temperature. Use heat-resistant materials for wiring, and provide a distance from any devices or wiring that are sensitive to heat.
- The service life of a Servo Drive is largely determined by the ambient temperature around the internal electrolytic capacitors. When an electrolytic capacitor reaches its limit, electrostatic capacity drops and internal resistance increases. This leads to overvoltage alarms, malfunctioning due to noise, and damage to individual elements.
- If a drive is always operated at the ambient temperature of 55°C and with a 100% output of the rated torque and rated rotation speed, its life is expected to be approx. 28,000 hours (excluding the axial-flow fan). A drop of 10°C in the ambient temperature will double the expected life for drive.

Lifetime 25°C = Lifetime 55°C × 2 $\frac{55-25}{10}$ = 224000 hour

Keeping Foreign Objects Out of Units

- Place a cover over the drive or take other preventative measures to prevent foreign objects, such as drill filings, from getting into the drive during installation. Be sure to remove the cover after installation is complete. If the cover is left on during operation, drive's heat dissipation is blocked, which may result in malfunction.
- Take measures during installation and operation to prevent foreign objects such as metal particles, oil, machining oil, dust, or water from getting inside of the drives.

Servomotor Installation Conditions

Environment Operating Conditions

• The environment in which the motor is operated must meet the following conditions. Operating the motor outside of the following ranges may result in malfunction of the motor.

Operating ambient temperature: 0 to +40°C^{*1}

Operating humidity: 85% RH max. (with no condensation)

Operating atmosphere: No corrosive gases.


*1. The ambient operating temperature is the temperature at a point 50 mm from the motor.


Impact and Load

- The motor is resistant to impacts of up to 98 m/s². Do not apply heavy impacts or loads during transport, installation, or removal of the motor.
- When transporting the motor, hold the motor body itself. And do not hold the encoder, cable, or connector areas. Failure to follow this guideline may result in damaging the motor.
- Always use a pulley remover to remove pulleys, couplings, or other objects from the shaft.
- After assembly, secure cables so that there is no impact or load placed on the cable outlet.


Connecting to Mechanical Systems

- For the allowable axial loads for motors, refer to "Characteristics"(P.3-2). If an axial load greater than that specified is applied to a motor, it may reduce the limit of the motor bearings and may break the motor shaft.
- When connecting to a load, use couplings that can sufficiently absorb mechanical eccentricity and declination.
- For spur gears, an extremely large radial load may be applied depending on the gear precision. Use spur gears with a high degree of precision (for example, JIS class 2: normal line pitch error of 6 µm max. for a pitch circle diameter of 50 mm).
- If the gear precision is not adequate, allow backlash to ensure that no radial load is placed on the motor shaft.
- When using bevel gears, a load is applied in the thrust direction depending on the structural precision, the gear precision, and temperature changes. Provide appropriate backlash or take other measures to ensure that a thrust load larger than the specified level is not applied.
- Do not put rubber packing on the flange surface. If the flange is mounted with rubber packing, the motor flange may crack under the tightening force.





- When connecting to a V-belt or timing belt, consult the manufacturer for belt selection and tension.
- A radial load twice as large as the belt tension will be placed on the motor shaft. Do not allow a load that exceeds the allowable radial load to be placed on the motor shaft. If an excessive radial load is applied, the motor shaft and bearings may be damaged.
- Set up a movable pulley in the middle of the motor shaft and the load shaft so that the belt tension can be adjusted.



Water and Drip Resistance

 The protective structure for the motors is as follows: Equivalent to IP67 (except for through-shaft parts and motor connector pins and encoder connector pins)


Oil-water Measures

Use the Servomotor with an oil seal if you are using it in an environment where oil drops can adhere to the through-shaft part. The operating conditions of the Servomotor with an oil seal are as follows:

- Keep the oil level below the lip of the oil seal.
- Prepare a good lubricated condition under which only oil droplets splash on the oil seal.
- If you are using the Servomotor with the shaft in upward direction, make sure that no oil accumulates on the lip of the oil seal.

Radiator Plate Installation Conditions

 When you mount a Servomotor onto a small device, be sure to provide enough radiation space on the mounting area. Otherwise the Servomotor temperature rises too high. One of the preventive measures is to install a radiator plate between the motor attachment area and the motor flange. (Refer to the following figure.) If a radiator plate cannot be connected, the Servomotor may be damaged by an excessive rise in temperature. Refer to the "Servomotor Specifications" (P.3-59) for the radiator plate specifications.



• The temperature rise depends on the mounting part materials and the installation environment. Check the actual temperature rise by using a real Servomotor.

• Depending on the environment, such as when the Servomotor is installed near a heating element, the Servomotor temperature may rise significantly. In this case, take any of the following measures.

Lower the load ratio. Review the heat radiation conditions of the Servomotor. Install a cooling fan and apply forced air cooling to the Servomotor.

Other Precautions

• Take measures to protect the motor shaft from corrosion. The motor shaft is coated with anticorrosion oil when shipped, but anti-corrosion oil or grease should also be applied when connecting the components that apply load to the shaft.



<u>/!\</u> Caution

Do not apply a commercial power supply directly to the motor. Failure may result.



Never repair the Servo Drive by disassembling it. Electric shock or injury may result.

Decelerator Installation Conditions

Using Another Company's Decelerator (Reference)

If the system configuration requires another company's decelerator to be used in combination with an OMNUC G5-Series motor, select the decelerator so that the load on the motor shaft (i.e., both the radial and thrust loads) is within the allowable range. (Refer to "Characteristics"(P.3-2) for details on the allowable loads for the motors.)

Also, select the decelerator so that the allowable input rotation speed and allowable input torque of the decelerator are not exceeded.

4

4-2 Wiring

Power Cables for 1,500-r/min Servomotors

For a 1,500-r/min Servomotor with 11 kW or 15 kW, make the following cable yourself and use it to connect the Servomotor and Servo Drive.

Wiring

	Number	
Ded	Number	Symbol
Red White	A	Phase U
White Dhue	В	Phase V
	С	Phase W
Green/Yellow Cable: AWG4 × 4C, 111 62	D	FG

Cable: AWG4 × 4C UL62 M6 crimp terminal

[Servomotor side connector]

Straight plug model

N/MS3106B32-17S (Japan Aviation Electronics)


Cable clamp model

N/MS3057-20A (Japan Aviation Electronics)

- Note 1. The cable length between the Servomotor and Servo Drive must be 50 m or less. Use wire lengths that match the positions of the U, V, W, and FG terminals on the Servo Driver
 - (M6 crimp terminals).

Note 2. The power connector and brake connector are separate for Servomotors with brakes.

Connector Pin Arrangement on Servomotor End (Viewed from Soldered Side of Plug)




4


System Design

Peripheral Equipment Connection Examples


R88D-KTA5L/-KT01L/-KT02L/-KT04L R88D-KT01H/-KT02H/-KT04H/-KT08H/-KT10H/-KT15H (Single-phase Input)




R88D-KT01H/-KT02H/-KT04H/-KT08H/-KT10H/-KT15H (3-phase Input)




R88D-KT20H




R88D-KT30H/-KT50H




R88D-KT75H with AC Power Supply Input








R88D-KT06F/-KT10F/-KT15F/-KT20F



R88D-KT30F/-KT50F







Main Circuit and Motor Connections

When wiring the main circuit, use proper wire sizes, grounding systems, and noise resistance.

R88D-KTA5L/-KT01L/-KT02L/-KT04L R88D-KT01H/-KT02H/-KT04H/-KT08H/-KT10H/-KT15H

Main Circuit Connector Specifications (CNA)

Symbol	Name	Function
L1		R88D-KT□L
L2	Main circuit power supply input	(50 to 400 W) : Single-phase 100 to 120 VAC (85 to 132 V) 50/60 Hz R88D-KT□H
L3		(100 W to 1.5 kW) : Single-phase 200 to 240 VAC (170 to 264 V) 50/60 Hz (100 W to 1.5 kW): 3-phase 200 to 240 VAC (170 to 264 V) 50/60 Hz
L1C	Control circuit power	R88D-KT L : Single-phase 100 to 120 VAC (85 to 132 V) 50/60Hz
L2C	supply input	R88D-KT□H : Single-phase 200 to 240 VAC (170 to 264 V) 50/60 Hz

Motor Connector Specifications (CNB)

Symbol	Name	Function
B1		R88D-KTA5L/-KT01L/-KT02L/-KT01H/-KT02H/-KT04H:
B3		Normally, do not short B1 and B2. Doing so may cause malfunctions.
B2	External Regeneration Resistor connection terminals	If there is high regenerative energy, connect an External Regeneration Resistor between B1 and B2. R88D-KT04L/-KT08H/-KT10H/-KT15H: Normally B2 and B3 are shorted. Do not short B1 and B2. Doing so may cause malfunctions. If there is high regenerative energy, remove the short-circuit bar between B2 and B3 and connect an External Regeneration Resistor between B1 and B2.
U		These are the output terminals to the Servomotor.
V	Motor connection terminals	Be sure to wire them correctly.
W		
Ē		
	Frame ground	This is the ground terminal. Ground to 100 Ω or less.

R88D-KT20H

Main Circuit Connector Specifications (CNA)

Symbol	Name	Function
L1	Main circuit power supply	R88D-KT⊡H (2 kW) :
L2	input	3-phase: 200 to 230 VAC (170 to 253 V) 50/60 Hz
L3		
L1C	Control circuit power	R88D-KT H : Single-phase 200 to 230 VAC (170 to 253 V) 50/60
L2C	supply input	Hz

Motor Connector Specifications (CNB)

Symbol	Name		Function	
U	Motor connection	Red	These are the output terminals to the Servomotor.	
V	terminals	White	Be sure to wire them correctly.	
W		Blue		
÷		Green/ Yellow		
Ē	Frame ground	This is the ground terminal. Ground to 100 Ω or less.		

External Regeneration Resistor Connector Specifications (CNC)

Symbol	Name	Function
B1	External Regeneration Resistor connection	Normally B2 and B3 are shorted. Do not short B1 and B2. Doing so may cause malfunctions.
B3	terminals	If there is high regenerative energy, remove the short-circuit bar
B2		between B2 and B3 and connect an External Regeneration Resistor between B1 and B2.
NC	Do not connect.	

Precautions for Correct Use

Never connect an External Regeneration Resistor between the B1 and NC terminals.

R88D-KT30H/-KT50H

Terminal Block Specifications

Symbol	Name	Function		
L1				
L2	Main circuit power supply input	R88D-KT□H (3 to 5 kW): 3-phase 200 to 230 VAC (170 to 253 V) 50/60 Hz		
L3				
L1C	Control circuit power	R88D-KT□H: Single-phase 200 to 230 VAC (170 to 253 V) 50/60		
L2C	supply input	Hz		
B1	External Regeneration	Normally B2 and B3 are connected. Do not short B1 and B2. Doing so may cause malfunctions. If there is high regenerative energy, remove the short-circuit bar between B2 and B3 and connect an		
B3	Resistor connection			
B2	terminals	External Regeneration Resistor between B1 and B2.		
NC	Do not connect.			
U		These are the output terminals to the Servomotor. Be sure to wire them correctly.		
V	Motor connection			
W	terminals			
Ē				
(±	Frame ground	This is the ground terminal. Ground to 100 Ω or less.		

Precautions for Correct Use

R88D-KT75H

Terminal Block Specifications, Left Terminal Block (TB1)

Symbol	Name	Function			
L1		R88D-KT H (7.5 kW): 3-phase 200 to 230 VAC (170 to 253 V) 50/ 60 Hz			
L2	Main circuit power supply input				
L3		280 to 325 VDC (238 to 357 VDC)			
B1	External Regeneration	Connect an External Regeneration Resistor between B1 and B2. Terminal B1 is main circuit DC output (positive).			
B2	Resistor connection terminals				
N (NC)	terminals				
U		These are the output terminals to the Servomotor.			
V	Motor connection terminals	Be sure to wire them correctly.			
W					
Ē					

Terminal Block Specifications, Right Terminal Block (TB2)

Symbol	Name	Function	
L1C	Control circuit power	R88D-KT⊟H: Single-phase 200 to 230 VAC (170 to 253 V) 50/60 Hz	
L2C	supply input	280 to 325 VDC (238 to 357 VDC)	
DB1	Dynamic brake	These terminals are used to control the MC for externally connected	
DB2	resistance control terminals	dynamic brake resistance. The output contact specifications are 1 A max. at 300 VAC/100 VDC max. Connect them if required.	
DB3		Normally DB3 and DB4 are connected. When using an externally	
DB4		connected Dynamic Brake Resistor, remove the short bar from between DB3 and DB4.	
Ē	Frame ground	This is the ground terminal. Ground to 100 Ω or less.	

Precautions for Correct Use

R88D-KT150H

Terminal Block Specifications, Top Terminal Block (TB1)

Symbol	Name	Function		
L1C	Control circuit power	R88D-KT□H: Single-phase 200 to 230 VAC (170 to 253 V) 50/60		
L2C	supply input	Hz 280 to 325 VDC (238 to 357 VDC)		
DB1	Dynamic brake	These terminals are used to control the MC for externally connected		
DB2	resistance control terminals	dynamic brake resistance. The output contact specifications are 1 A max. at 300 VAC/100 VDC max. Connect them if required.		

Terminal Block Specifications, Bottom Terminal Block (TB2)

Symbol	Name	Function		
L1		R88D-KT□H (15 kW): 3-phase 200 to 230 VAC (170 to 253 V) 50/		
L2	Main circuit power supply input	60 Hz		
L3		280 to 325 VDC (238 to 357 VDC)		
B1	External Regeneration	Connect an External Regeneration Resistor between B1 and B2. Terminal B1 is main circuit DC output (positive).		
B2	Resistor connection			
N (NC)				
U		These are the output terminals to the Servomotor.		
V	Motor connection	Be sure to wire them correctly.		
W	terminals			
Ē				
Ē	Frame ground	This is the ground terminal. Ground to 100 Ω or less.		

Precautions for Correct Use

Never connect an External Regeneration Resistor between the B1 and N (NC) terminals

R88D-KT06F/-KT10F/-KT15F/-KT20F

Main Circuit Connector Specifications (CNA)

Symbol	Name	Function
L1	Main circuit power supply	
L2	input	(600 W to 2 kW) : 3-phase: 380 to 480 VAC (323 to 528 V) 50/60 Hz
L3		

Motor Connector Specifications (CNB)

Symbol	Name	Function	
U	Motor connection terminals	Red	These are the output terminals to the Servomotor.
V		White	Be sure to wire them correctly.
W		Blue	
Ē		Green/ Yellow	
Ē	Frame ground	This is the ground terminal. Ground to 10 Ω or less.	

Control Circuit Connector Specifications (CNC)

Symbol	Name	Function		
24 V	Control circuit power	24 VDC (21.6 to 26.4 V)		
0 V	supply input			

External Regeneration Resistor Connector Specifications (CND)

Symbol	Name	Function	
B1	External Regeneration Resistor connection	Normally B2 and B3 are connected. Do not short B1 and B2. Doing so may cause malfunctions.	
B3	terminals	If there is high regenerative energy, remove the short-circuit bar	
B2		between B2 and B3 and connect an External Regeneration Resistor between B1 and B2.	
NC	Do not connect.		

Precautions for Correct Use

Never connect an External Regeneration Resistor between the B1 and NC terminals.

R88D-KT30F/-KT50F

Terminal Block Specifications (TB1)

Symbol	Name	Function
24 V	Control circuit power	24 VDC (21.6 to 26.4 V)
0 V	supply input	

Terminal Block Specifications (TB2)

Symbol	Name	Function	
L1			
L2	Main circuit power supply input	R88D-K 50/60 H	T□F (3 to 5 kW): 3-phase 380 to 480 VAC (323 to 528 V) z
L3	mpor	00,0011	-
B1		-	y B2 and B3 are connected. Do not short B1 and B2. Doing
B3	External Regeneration Resistor connection		cause malfunctions. s high regenerative energy, remove the short-circuit bar
B2	terminals	between B2 and B3 and connect an External Regeneration Resistor between B1 and B2.	
NC	Do not connect.		
U		Red	These are the output terminals to the Servomotor.
V	Motor connection	White	Be sure to wire them correctly.
W	terminals	Blue	
÷		Green/ Yellow	
÷	Frame ground	This is the ground terminal. Ground to 10 Ω or less.	

R88D-KT75F

Terminal Block Specifications, Left Terminal Block (TB1)

Symbol	Name	Function			
L1					
L2	Main circuit power supply input	Н88D-К 60 Hz	R88D-KT□F (7.5 kW): 3-phase 380 to 480 VAC (323 to 528 V) 50/ 60 Hz		
L3		00112			
B1	External Regeneration Resistor connection	Connect an External Regeneration Resistor between B1 and B2.			
B2	terminals				
NC	Do not connect.	not connect.			
U		Red	These are the output terminals to the Servomotor.		
V	Motor connection	White	Be sure to wire them correctly.		
W	terminals	Blue			
(l)		Green/ Yellow			

Terminal Block Specifications, Right Terminal Block (TB2)

Symbol	Name	Function	
24 V	Control circuit power	24 VDC±15%	
0 V	supply input		
DB1	Dynamic brake resistance	These terminals are used to control the MC for externally	
DB2	control terminals	connected dynamic brake resistance. The output contact specifications are 1 A max. at 300 VAC/100 VDC max. Connect them if required.	
DB3		Normally DB3 and DB4 are connected. When using an externally	
DB4		connected Dynamic Brake Resistor, remove the short bar from between DB3 and DB4.	
	Frame ground	This is the ground terminal. Ground to 10 Ω or less.	

Precautions for Correct Use

R88D-KT150F

Terminal Block Specifications, Top Terminal Block (TB1)

Symbol	Name	Function
24 V	Control circuit power	24 VDC±15%
0 V	supply input	
DB1	Dynamic brake resistance	These terminals are used to control the MC for externally connected dynamic brake resistance. The output contact
DB2	control terminals	specifications are 1 A max. at 300 VAC/100 VDC max. Connect them if required.

Terminal Block Specifications, Bottom Terminal Block (TB2)

Symbol	Name	Function						
L1								
L2	Main circuit power supply input	R88D-KT□F (15 kW): 3-phase 380 to 480 VAC (323 to 528 V) 50/ 60 Hz						
L3								
B1	External Regeneration Resistor connection	Connect	Connect an External Regeneration Resistor between B1 and B2.					
B2	terminals							
NC	Do not connect.							
U		Red	These are the output terminals to the Servomotor.					
V	Motor connection	White	Be sure to wire them correctly.					
W	terminals	Blue						
(_		Green/ Yellow						
(±	Frame ground	This is t	The ground terminal. Ground to 10 Ω or less.					

Precautions for Correct Use

Terminal Block Wire Sizes

100-VAC Input Type Wire Sizes: R88D-KT

Мо	odel (R88D-)	KTA5L	KT01L	KT02L	KT04L	
Item	iem (RTAJE	RIVIL	KTU2L	KT04L
Power supply capac	ity	kVA	0.4	0.4	0.5	0.9
Main circuit power	Rated current	А	1.7	2.6	4.3	7.6
supply input (L1 and L3, or L1, L2 and L3)	Wire size	-	AWG 14 to 18			
Control circuit power supply input (L1C and L2C)	Wire size	-	AWG 18			
Motor connection	Rated current	А	1.2	1.7	2.5	4.6
terminals (U, V, W, and FG) ^{*1 *2}	Wire size	_	AWG 14 to 18			
Frame ground (FG)	Wire size	-	AWG 14			
	Screw size	-	M4			
	Tightening torque	N∙m	1.2			

*1. Use the same wire size for B1 and B2.

*2. Connect an OMRON power cable to the motor connection terminals.

М	odel (R88D-)		КТ01Н	КТ02Н	КТ04Н	КТ08Н	КТ10Н
Item	Item			KTU2H	KIU4H	КТООП	KIIUH
Power supply capacity	,	kVA	0.5	0.5	0.9	1.3	1.8
Main circuit power supply input (L1 and	Rated current	А	1.6/0.9 ^{*1}	2.4/1.3 *1	4.1/2.4 *1	6.6/3.6 *1	9.1/5.2 *1
L3, or L1, L2 and L3)	Wire size	-	AWG14 to	18			AWG14
	Screw size	-	-	-	-	-	-
	Tightening torque	N∙m	-	-	-	-	-
Control circuit power	Wire size	-	AWG18				
supply input (L1C and L2C)	Screw size	-	-	-	-	-	-
	Tightening torque	N∙m	-	-	-	-	-
Motor connection	Rated current	А	1.2	1.6	2.6	4.1	5.9
terminals (U, V, W, and FG) ^{*2 *3}	Wire size	-	AWG14 to	18			AWG14
	Screw size	-	-	-	-	-	-
	Tightening torque	N∙m	-	-	-	-	-
Frame ground (FG)	Wire size	-	AWG14				<u> </u>
	Screw size	-	M4				
	Tightening torque	N∙m	1.2				

200 VAC Input Type Wire Sizes: R88D-KT

*1. The first value is for single-phase input and the second value is for 3-phase input.

*2. Use the same wire size for B1 and B2.

*3. Connect an OMRON power cable to the motor connection terminals.

4

OMNUC G5-SERIES AC SERVOMOTOR AND SERVO DRIVE USER'S MANUAL

Mo	odel (R88D-)		KT15H	КТ20Н	КТ30Н	КТ50Н	КТ75Н	KT150H
Item	Unit	KIIDH	K120H	КТЗОП	КТЭОП	ктлэп	KIISUN	
Power supply capacity		kVA	2.3	3.3	4.5	7.5	11.0	22.0
Main circuit power supply input (L1 and	Rated current	А	14.2/ 8.1 ^{*1}	11.8	15.1 21.6		32.0	58.0
L3, or L1, L2 and L3)	Wire size	-	AWG14		AWG12		AWG10	AWG6
	Screw size	_	-	-	M5			M6
	Tightening torque	N∙m	-	-	2.0		2.0 to 2.4	2.2 to 2.5
Control circuit power	Wire size	-	AWG18				•	
supply input (L1C and L2C)	Screw size	-	-	-	M5			M4
	Tightening torque	N∙m	-	_			1.3 to 1.5	0.7 to 0.8
Motor connection	Rated current	А	9.4	13.4	18.7	33.0	44.0	66.1
terminals (U, V, W, and FG) *2	Wire size	_	AWG14		AWG12 AV		AWG6	AWG4
	Screw size	_	-	-	M5			M6
	Tightening torque	N∙m	-	-	2.0		2.0 to 2.4	2.2 to 2.5
Frame ground (FG)	Wire size	-	AWG14		AWG12		AWG6	AWG4
	Screw size	-	M4		M5			M6
	Tightening torque	N∙m	1.2		2.0		1.4 to 1.6	2.4 to 2.8
Dynamic brake	Wire size	-	-				AWG18	
resistance control terminals	Screw size	-					M5	M4
	Tightening torque	N∙m	1-				1.3 to 1.5	0.7 to 0.8

*1. The first value is for single-phase input and the second value is for 3-phase input.

*2. Use the same wire size for B1 and B2.

*3. Connect an OMRON power cable to the motor connection terminals.

Mod	Model (R88D-)		KT06F	KT10F	KT15F	KT20F	KT30F	KT50F	KT75F	KT150F
Item		Unit	KIUOF	KIIUF	KIISF	KI20F	KIJUF	KIDUF	KI75F	KIISUF
Main circuit power supply	Rated current	A	2.1	2.8	3.9	5.9	7.6	12.1	16.0	29.0
input (L1 and L3, or L1, L2	Wire size	-	AWG14	AWG14				•	AWG10	AWG6
and L3)	Screw size	-	-	-	-	-	M5			M6
	Tightening torque	N∙m	-	-	-	-	2.0		2.0 to 2.4	2.2 to 2.5
Control circuit	Wire size	-	AWG20	to 24			AWG18			
power supply input (L1C	Screw size	-	-	-	-	-	M5			M4
and L2C)	Tightening torque	N∙m	_	_	-	_	2.0 1.3 to 1.5			0.7 to 0.8
Motor connection	Rated current	А	1.5	2.9	4.7	6.7	9.4	16.5	22.0	33.1
terminals (U, V, W, and FG)	Wire size	-	AWG14				AWG12 AWG6			AWG4
*1 *2	Screw size	-	-	-	-	-	M5			M6
	Tightening torque	N∙m	-	-	-	-	2.0		2.0 to 2.4	2.2 to 2.5
Frame ground	Wire size	-	AWG14				AWG12		AWG6	AWG4
(FG)	Screw size	-	M4				M5			M6
	Tightening torque	N∙m	1.2				2.0		1.4 to 1.6	2.4 to 2.8
Dynamic	Wire size	-	-						AWG18	
brake resistance	Screw size	-							M5	M4
control terminals	Tightening torque	N∙m	-						1.3 to 1.5	0.7 to 0.8

400 VAC Input Type Wire Sizes: R88D-KT

*1. Use the same wire size for B1 and B2.

*2. Connect an OMRON power cable to the motor connection terminals.

Wire Sizes and Allowable Current (Reference)


The following table shows the allowable current when there are 3 power supply wires. Use a current below these specified values.

AWG size	Nominal cross- sectional area	Configuration (wires/mm ²)	Conductive resistance	Allowable current (A) for ambient temperature			
	(mm ²)	(wires/initry)	(Ω/ km)	30°C	40°C	50°C	
20	0.5	19/0.18	39.5	6.6	5.6	4.5	
_	0.75	30/0.18	26.0	8.8	7.0	5.5	
18	0.9	37/0.18	24.4	9.0	7.7	6.0	
16	1.25	50/0.18	15.6	12.0	11.0	8.5	
14	2.0	7/0.6	9.53	23	20	16	
12	3.5	7/0.8	5.41	33	29	24	
10	5.5	7/1.0	3.47	43	38	31	
8	8.0	7/1.2	2.41	55	49	40	
6	14.0	7/1.6	1.35	79	70	57	
4	22.0	7/2.0	0.85	99	88	70	


600-V Heat-resistant Vinyl Wire (HIV)

Terminal Block Wiring Procedure

On a Servo Drive with 2.0 kW or less, connector-type terminal blocks are used. The procedure for wiring these terminal blocks is explained below.



- Remove the terminal block from the Servo Drive before wiring. The Servo Drive may be damaged if the wiring is done with the terminal block in place.
- 2. Strip off 8 to 9 mm of the covering from the end of each wire. Refer to "Terminal Block Wire Sizes"(P.4-27) for applicable wire sizes.



3. Open the wire insertion slots in the terminal block using a tool.

There are 2 ways to open the wire insertion slots, as follows.

- Pry the slot open using the lever that comes with the Servo Drive. (Figure A)
- Insert a flat-blade screwdriver (end width: 3.0 to 3.5 mm) into the opening for the screwdriver on the terminal block, and press down firmly to open the slot. (Figure B)





Figure A



4. With the wire insertion slot held open, insert the end of the wire.

After inserting the wire, let the slot close by releasing the pressure from the lever or the screwdriver.

5. Mount the terminal block to the Servo Drive.

After all of the terminals have been wired, return the terminal block to its original position on the Servo Drive.

- Note. Some shapes of the ferrules that are connected to the lines may be difficult to insert into the connector. If so, use the following methods to insert the ferrules.
 - Rotate the connector insertion orientation by 90°.
 - Adjust the shape of the ferrules with pliers or other suitable tool and then insert the ferrules.

4-3 Wiring Conforming to EMC Directives


Conformance to the EMC Directives (EN 55011 Class A Group 1 (EMI) and EN 61000-6-2 (EMS)) can be ensured by wiring under the conditions described in this section. These conditions are for conformance of OMNUC G5-series products to the EMC directives. EMC-related performance of these products, however, may be influenced by the configuration, wiring, and other conditions of the equipment in which the products are installed. The EMC conformance of the system as a whole must be confirmed by the customer.

The following are the requirements for EMC Directive conformance.

- The Servo Drive must be installed in a metal case (control panel). (The motor does not, however, have to be covered with a metal plate.)
- Noise filters and lightening surge absorptive elements (surge absorbers) must be installed on power supply lines.
- Braided shielded cables must be used for all encoder cables. (Use tin-plated, mild steel wires for the shielding.)
- All cables, I/O wiring, and power lines connected to the Servo Drive must have clamp cores installed to improve the noise immunity.
- The shields of all cables must be directly connected to a ground plate.

Wiring Method

R88D-KTA5L/-KT01L/-KT02L/-KT04L/-KT01H/-KT02H/-KT04H/-KT08H/-KT10H/-KT15H/-KT20H/-KT30H/-KT50H/-KT75H/-KT150H



*1. For models with a single-phase power supply input (R88D-KTA5L/-KT01L/-KT02L/-KT04L/-KT01H/-KT02H/-KT04H/-KT08H/-KT10H/-KT15H), the main circuit power supply input terminals are L1 and L3.


- Ground the motor's frame to the machine ground when the motor is on a movable shaft.
- Use a ground plate for the frame ground for each unit, as shown in the above diagrams, and ground to a single point.
- Use ground lines with a minimum thickness of 3.5 mm², and arrange the wiring so that the ground lines are as short as possible.
- A no-fuse breaker, surge absorber, and noise filter should be positioned near the input terminal block (ground plate), and I/O lines should be separated and wired at the shortest distance.

Unit Details

Symbol	Name	Manufacturer	Model	Comment	
SG	Surge absorber	Okaya Electric Industries Co., Ltd.	R·A·V-781BXZ-4	3-phase 200 VAC	
			SUP-EK5-ER-6	Single-phase 100/200 VAC (5 A)	
		Okaya Electric	3SUP-HU10-ER-6	3-phase 200 VAC (10 A)	
NF	Noise filter	Industries Co., Ltd.	3SUP-HU30-ER-6	3-phase 200 VAC (30 A)	
INF	Noise inter		3SUP-HL50-ER-6B	3-phase 200 VAC (50 A)	
		Schaffner EMC Inc.	FS5559-60-34	3-phase 200 VAC (60 A)	
		Schaimer Ewic mc.	FS5559-80-34	3-phase 200 VAC (80 A)	
SD	Servo Drive	OMRON	_	*1	
SM	Servomotor	OMRON	-	*1	
FC1	Clamp core	TDK	ZCAT3035-1330	-	
FC2	Clamp core	Koppo Industry	RJ8035		
F02	Clamp core	Konno Industry	RJ8095	-	
FC3	Clamp core	MICROMETALS	T400-61D	For R88D-KT75H/-KT150H	
гоз	Clamp core	TDK	ZCAT3035-1330	For other models	
_	Controller	-	-	-	

*1. A specified combination of Servo Drive and Servomotor must be used.

R88D-KT75H/-KT150H with DC Power Supply Input



- the negative line to L3.
 - + Ground the motor's frame to the machine ground when the motor is on a movable shaft.
 - Use a ground plate for the frame ground for each Unit, as shown in the above diagrams, and ground to a single point.


- Use ground lines with a minimum thickness of 3.5 mm², and arrange the wiring so that the ground lines are as short as possible.
- A no-fuse breaker, surge absorber, and noise filter should be positioned near the input terminal block (ground plate), and I/O lines should be separated and wired at the shortest distance.

Unit Details

Symbol	Name	Manufacturer	Model	Comment
SG	Surge absorber	Okaya Electric Industries Co., Ltd.	R·A·V-781BXZ-4	3-phase 200 VAC
NF	Noise filter	Schaffner EMC Inc.	FN258-42-07	3-phase 200 VAC (42 A)
SD	Servo Drive	OMRON	-	*1
SM	Servomotor	OMRON	-	*1
FC1	Clamp core	TDK	ZCAT3035-1330	-
FC2	Clamp core	Konno Industry	RJ8095	-
FC3	Clamp core	MICROMETALS	T400-61D	-
-	Controller	-	-	-

*1. A specified combination of Servo Drive and Servomotor must be used.

R88D-KT06F/-KT10F/-KT15F/-KT20F/-KT30F/-KT50F/-KT75F/-KT150F



Symbol	Name	Manufacturer	Model	Comment
SG	Surge absorber	Okaya Electric Industries Co., Ltd.	R·A·V-801BXZ-4	
			FN258L-16-07	3-phase 400 VAC (16 A)
NF	Noise filter	Schaffner EMC Inc.	FN258L-30-07	3-phase 400 VAC (30 A)
			FN258-42-07	3-phase 400 VAC (42 A)
SD	Servo Drive	OMRON	-	*1
SM	Servomotor	OMRON	-	*1
FC1	Clamp core	TDK	ZCAT3035-1330	-
FC2		Kanna Industry	RJ8035	
FU2	Clamp core	Konno Industry	RJ8095	
FC3	Clamp coro	MICROMETALS	T400-61D	For R88D-KT75F/-KT150F
FUB	Clamp core	TDK	ZCAT3035-1330	For other models
-	Controller	_	-	-

Unit Details

*1. A specified combination of Servo Drive and Servomotor must be used.

Cable Details

Symbol	Supplies from	Connects to	Cable name	Length	Comment	Shielded	Ferrite
(1)	AC power supply	Noise filter	Power supply line	2 m	_	No	No
(2)	Noise filter	Servo Drive	Power supply line	2 m	-	No	Optional
(3)	Servo Drive	Servomotor	Power cable	20 m	_	No	Optional
(4)	Servo Drive	Servomotor	Encoder cable	20 m	-	Yes	Optional
(5)	Switch box	Servo Drive	I/O cable	2 m	_	No	Optional
(6)	Frame ground	Noise filter	FG line	1.5 m	_	No	No
(7)	Frame ground	Servo Drive	FG line	1.5 m	-	No	No
(8)	AC power supply	Controller	Power supply line	1.5 m	_	No	No


Noise Filter for Power Supply Input

We recommend you to use the noise filter for the Servo Drive.


Drive		Noise filter for power supply input			
Phase	Model	Model	Rated current	Leakage current (60 Hz) max	Manufacturer
Single-phase	R88D-K□A5L□□		5A	1.0mA (at 250 VAC)	
	R88D-K01L0	SUP-EK5-ER-6			
	R88D-K02L0				
Single-phase	R88D-K□04L□□	3SUP-HU10-ER-6	10A	3.5mA (at 500 VAC)	
Single-phase	R88D-K□01H□□	SUP-EK5-ER-6	5A	1.0mA (at 250 VAC)	
3-phase		3SUP-HU10-ER-6	10A	3.5mA (at 500 VAC)	
Single-phase	R88D-K□02H□□	SUP-EK5-ER-6	5A	1.0mA (at 250 VAC)	
3-phase		3SUP-HU10-ER-6	10A	3.5mA (at 500 VAC)	Okaya Electric
Single-phase	R88D-K□04H□□	SUP-EK5-ER-6	5A	1.0mA (at 250 VAC)	Industries
3-phase		3SUP-HU10-ER-6	10A	3.5mA (at 500 VAC)	Co., Ltd.
0: 1 0	R88D-K□08H□□		IUA	5.5mA (at 500 VAC)	
Single or 3- phase	R88D-K□10H□□	3SUP-HU30-ER-6	30A	3.5mA (at 500 VAC)	
	R88D-K□15H□□				
	R88D-K□20H□□	3SUP-HU50-ER-6	50A	3.5mA (at 500 VAC)	
	R88D-K□30H□□	3SUP-HL50-ER-6B	50A	8.0mA (at 500 VAC)	
	R88D-K□50H□□	3301 -HE30-EH-0D			
	R88D-K□75H□□	FS5559-60-34	60A	1.35mA (at 480 VAC/50 Hz)	
	R88D-K□150H□□	FS5559-80-34	80A	1.35mA (at 480 VAC/50 Hz)	
3-phase	R88D-K□06F□□				-
	R88D-K□10F□□	FN258L-16-07	16A	0.8mA	Schaffner
	R88D-K□15F□□	FIN236L-10-07	IOA	(at 440 VAC/50 Hz)	EMC Inc.
	R88D-K□20F□□				
	R88D-K□30F□□	FN258L-30-07	304	0.8mA	
	R88D-K□50F□□	T N230L-30-07	30A	(at 440 VAC/50 Hz)	
	R88D-K□75F□□	FN258-42-07	42A	25.8mA	
	R88D-K□150F□□	FIN200-42-07	42A	(at 440 VAC/50 Hz)	

• For operations, if no-fuse breakers are installed at the top and the power supply line is wired from the lower duct, use metal tubes for wiring or make sure that there is adequate distance between the input lines and the internal wiring. If input and output lines are wired together, noise resistance will decrease.

• The noise filter must be installed as close as possible to the entrance of the control panel. Wire as shown at the left in the following illustration.




• Use twisted-pair cables for the power supply cables, or bind the cables.




• Separate power supply lines and signal lines when wiring.


• External Dimensions




3SUP-HU30-ER-6



3SUP-HL50-ER-6B




3SUP-HU50-ER-6




unit

• Circuit Diagram






3SUP-HU10-ER-6/3SUP-HU30-ER-6 3SUP-HU50-ER-6



OMNUC G5-SERIES AC SERVOMOTOR AND SERVO DRIVE USER'S MANUAL

3SUP-HL50-ER-6B



Noise Filter for the Brake Power Supply

• We recommend using a noise filter for the Servo Drive.

Model	Rated current	Rated voltage	Leakage current	Manufacturer
SUP-EK5-ER-6	5 A	250 V	1.0 mA (at 250 Vrms, 60 Hz)	Okaya Electric Industries Co., Ltd.

Note. Noise can also be reduced by 1.5 turns with the ZCAT3035-1330 (TDK) Clamp Core.

Control Panel Structure


Openings in the control panel, such as holes for cables, panel mounting holes, and gaps around the door, may allow electromagnetic waves into the panel. To prevent this, observe the recommendations described below when designing or selecting a control panel.

Case Structure

- Use a metal control panel with welded joints at the top, bottom, and sides so that the surfaces are electrically conductive.
- If assembly is required, strip the paint off the joint areas (or mask them during painting), to make them electrically conductive.
- The panel may warp and gaps may appear when screws are tightened. Be sure that no gaps appear when tightening screws.
- Do not leave any conductive part unconnected.
- Ground all units within the case to the case itself.

Door Structure

- Use a metal door.
- Use a water-draining structure where the door and case fit together, and leave no gaps. (Refer to the diagrams.)
- Use a conductive gasket between the door and the case. (Refer to the diagrams.)
- Strip the paint off the sections of the door and case that will be in contact with the conductive gasket (or mask them during painting), so that they are electrically conductive.
- The panel may warp and gaps may appear when screws are tightened. Be sure that no gaps appear when tightening screws.



[Door (interior side)]

Selecting Connection Component

This section explains the criteria for selecting the connection components required to improve noise resistance. Understand each component's characteristics, such as its capacity, performance, and applicable range when selecting the connection components.

For more details, contact the manufacturers directly.

No-fuse Breaker (NFB)

When selecting a no-fuse breaker, consider the maximum input current and the inrush current.

Maximum Input Current

• The momentary maximum output of the Servo Drive is approx. 3 times the rated output, and can be output for up to 3 seconds.

Therefore, select no-fuse breakers with an operation time of at least 5 seconds at 300% of the rated current ratio. General and low-speed no-fuse breakers are generally suitable.

- Select a no-fuse breaker with a rated current greater than the total effective load current of all the motors (when multiple Servo Drives are used). (The rated current of the power supply input for each motor is provided in "Main Circuit and Motor Connections" (P.4-18).)
- Add the current consumption of other controllers, and any other components when selecting.

Inrush Current

- The following table lists the Servo Drive inrush currents.
- With low-speed no-fuse breakers, an inrush current 10 times the rated current can flow for 0.02 second.
- When the power of multiple Servo Drives are turned ON simultaneously, select a no-fuse breaker with a 20-ms allowable current that is greater than the total inrush current, shown in the following table.

	Inrush current (A0-p)		
Servo Drive model	Main circuit power supply	Control circuit power supply	
R88D-KTA5L	7	14	
R88D-KT01L	7	14	
R88D-KT02L	7	14	
R88D-KT04L	15	14	
R88D-KT01H	14	28	
R88D-KT02H	14	28	
R88D-KT04H	14	28	
R88D-KT08H	29	28	
R88D-KT10H	29	28	
R88D-KT15H	29	28	
R88D-KT20H	29	14	
R88D-KT30H	22	14	
R88D-KT50H	22	14	
R88D-KT75H	66	15	
R88D-KT150H	66	15	

	Inrush current (A0-p)			
Servo Drive model	Main circuit power supply	Control circuit power supply		
R88D-KT06F	28	48		
R88D-KT10F	28	48		
R88D-KT15F	28	48		
R88D-KT20F	32	48		
R88D-KT30F	32	48		
R88D-KT50F	32	48		
R88D-KT75F	32	48		
R88D-KT150F	32	48		

Leakage Breaker

- Select a leakage breaker for high frequencies and surge resistance.
- When selecting leakage breakers, remember to add the leakage current from devices other than

System Design

the motor, such as devices using a switching power supply, noise filters, inverters, and so on. To prevent malfunction due to inrush current, we recommend using a leakage breaker of 10 times the total of all leakage current values.

- The leakage breaker is activated at 50% of the rated current. Select a leakage breaker with approx. twice the capacity.
- For details on leakage breakers selection method, refer to the manufacturer's catalog.
- Because switching takes place inside the Servo Drives, high-frequency current leaks from the SW elements of the Servo Drive, the armature of the motor, and the cables.

High-frequency, surge-resistant leakage breakers, because they do not detect high-frequency current, can prevent operation with high-frequency leakage current.

When using a general leakage breaker, use 3 times the total of the leakage current given in the following table as a reference value.

Servo Drive model	Input power supply	Leakage current (Cable: 3 m)	Increase per 10 m of cable
R88D-KTA5L	Single-phase 100 V	0.38 mA	
R88D-KT01L	Single-phase 100 V	0.39 mA	0.1 mA
R88D-KT02L	Single-phase 100 V	0.41 mA	
R88D-KT04L	Single-phase 100 V	0.46 mA	0.12 mA
R88D-KT01H	Single-phase 200 V	0.83 mA	
R00D-KIUIH	3-phase 200 V	1.03 mA	0.23 mA
R88D-KT02H	Single-phase 200 V	0.84 mA	- 0.23 MA
R00D-K102H	3-phase 200 V	1.02 mA	
	Single-phase 200 V	0.96 mA	- 0.3 mA
R88D-KT04H	3-phase 200 V	1.27 mA	- 0.3 MA
	Single-phase 200 V	1.01 mA	1.1 m A
R88D-KT08H	3-phase 200 V	1.39 mA	– 1.1 mA
	Single-phase 200 V	0.88 mA	
R88D-KT10H	3-phase 200 V	1.14 mA	0.02 m 1
	Single-phase 200 V	0.96 mA	– 0.93 mA
R88D-KT15H	3-phase 200 V	1.18 mA	
R88D-KT20H	3-phase 200 V	1.53 mA	
R88D-KT30H	3-phase 200 V	1.52 mA	1.23 mA
R88D-KT50H	3-phase 200 V	1.39 mA	
R88D-KT75H	3-phase 200 V	3.50 mA	2.07 mA
R88D-KT150H	3-phase 200 V	5.30 mA	1.13 mA
R88D-KT06F	3-phase 400 V	2.28 mA	1.0
R88D-KT10F	3-phase 400 V	2.20 mA	– 1.8 mA
R88D-KT15F	3-phase 400 V	2.55 mA	2.03 mA
R88D-KT20F	3-phase 400 V	2.92 mA	2.4 mA
R88D-KT30F	3-phase 400 V	3.92 mA	3.23 mA
R88D-KT50F	3-phase 400 V	3.54 mA	2.9 mA
R88D-KT75F	3-phase 400 V	6.70 mA	3.73 mA
R88D-KT150F	3-phase 400 V	10.40 mA	2.73 mA

Note: These values vary greatly depending on the installation conditions of the motor power cable and the measurement conditions. Use them for reference only.

Surge Absorber

- Use surge absorbers to absorb lightning surge voltage and abnormal voltage from power supply input lines.
- When selecting surge absorbers, take into account the varistor voltage, the surge immunity and the energy tolerated dose.
- + For 200-VAC systems, use surge absorbers with a varistor voltage of 620 V.
- The surge absorbers shown in the following table are recommended.


Manufacturer	Model	Surge immunity		Туре	Comment
Okaya Electric Industries Co., Ltd.	R•A•V-781BWZ-4	700 V \pm 20%	2500 A		Single-phase 100/200 VAC
Okaya Electric Industries Co., Ltd.	R•A•V-781BXZ-4	700 V ± 20%	2500 A	Block	3-phase 200 VAC
Okaya Electric Industries Co., Ltd.	R•A•V-801BXZ-4	800 V ± 20%	2500 A		3-phase 400 VAC


Note 1. Refer to the manufacturers' catalog for operating details.


Note 2. The surge immunity is for a standard impulse current of 8/20 µs. If pulses are wide, either decrease the current or change to a larger-capacity surge absorber.


External Dimensions

For single-phase (BWZ series)










For 3-phase (BXZ series)

Equalizing Circuits

For single-phase (BWZ series) For 3-phase (BXZ series)



Radio Noise Filter and Emission Noise Prevention Clamp Core

Use one of the following filters to prevent switching noise of PWM of the Servo Drive and to prevent noise emitted from the internal clock circuit.

Model	Manufacturer	Application
3G3AX-ZCL1 *1	OMRON	For Drive output and power cable
3G3AX-ZCL2 *2	OMRON	For Drive output and power cable
ESD-R-47B *3	NEC TOKIN	For Drive output and power cable
ZCAT3035-1330 *4	ТДК	For Encoder cable and I/O cable
RJ8035	Konno Industry	For power lines
RJ8095	Konno Industry	For power lines
T400-61D	MICROMETALS	For Servo Drive output and power cables


*1. Generally used for 1.5 kW or higher.

*2. Generally used for 1.5 kW or lower. The maximum number of windings is 3 turns.

*3. Generally used for 50/100 W. The maximum number of windings is 2 turns.

*4. Also used on the Drive output power lines to comply with the EMC Directives. Only a clamp is used. This clamp can also be used to reduce noise current on a FG line.

External Dimensions



Ū
\leq
ž
er
3
ē
es
ū
Б

4

35 A

95 A

RJ8035

RJ8095

170

200

23

34

150

180

80

130

53

107

7


7

thickness


R3.5


R3.5

24



Impedance Characteristics





Surge Suppressor

- Install surge suppressors for loads that have induction coils, such as relays, solenoids, brakes, clutches, etc.
- The following table shows the types of surge suppressors and recommended products.

Туре	Feature	Recommended product
Diodes	Diodes are used for relatively small loads such as relays when the reset time is not a critical issue. At power shutoff the surge voltage is the lowest, but the reset time takes longer. Used for 24/48-VDC systems.	Use a fast-recovery diode with a short reverse recovery time. (e.g., RU2 of Sanken Electric Co., Ltd.).
Thyristors and varistors	Thyristors and varistors are used for loads when induction coils are large, as in electromagnetic brakes, solenoids, etc., and when reset time is critical. The surge voltage at power shutoff is approx. 1.5 times the varistor voltage.	Select the varistor voltage as follows. 24-VDC systems: varistor voltage 39 V 100-VDC systems: varistor voltage 200 V 100-VAC systems: varistor voltage 270 V 200-VAC systems: varistor voltage 470 V
Capacitor + resistor	The capacitor plus resistor combination is used to absorb vibration in the surge at power supply shutoff. The reset time can be shortened by selecting the appropriate capacitance and resistance.	Okaya Electric Industries Co., Ltd. XEB12002 0.2 μ F-120 Ω XEB12003 0.3 μ F-120 Ω

• Thyristors and varistors are made by the following manufacturers. Refer to manufacturer's documentation for details on these components.

Thyristors: Ishizuka Electronics Co.

Varistor: Ishizuka Electronics Co., Panasonic Corporation

Contactor

- Select contactors based on the circuit's inrush current and the maximum momentary phase current.
- The drive inrush current is covered in the preceding explanation of no-fuse breaker selection. And the maximum momentary phase current is approx. twice the rated current.

Improving Encoder Cable Noise Resistance

Take the following steps during wiring and installation to improve the encoder's noise resistance.


- Always use the specified encoder cables.
- + Do not coil cables. If cables are long and are coiled, mutual induction and inductance will increase and cause malfunctions. Always use cables fully extended.
- When installing noise filters for encoder cables, use clamp cores.
- The following table shows the recommended clamp cores.


Manufacturer	Product name	Model	Specifications
NEC TOKIN	Clamp core	ESD-SR-250	For cable dia. up to 13 mm
TDK	Clamp core	ZCAT3035-1330	For cable dia. up to 13 mm

• Do not place the encoder cable with the following cables in the same duct. Control cables for brakes, solenoids, clutches, and valves.


External Dimensions

ESD-SR-250





Impedance Characteristics



Refer to the following sections for the dimensions and impedance characteristics of the ZCAT3035-1330: "External Dimensions" (P.4-46) and "Impedance Characteristics" (P.4-47).

Improving Control I/O Signal Noise Resistance

Positioning can be affected and I/O signal errors can occur if control I/O is influenced by noise.

- Use completely separate power supplies for the control I/O power supply (especially 24 VDC) and the external operation power supply. In particular, do not connect the 2 power supply ground wires.
- Install a noise filter on the primary side of the control I/O power supply.
- If motors with brakes are being used, do not use the same 24-VDC power supply for both the brakes and the control I/O. Additionally, do not connect the ground wires. Connecting the ground wires may cause I/O signal errors.
- Keep the power supply for pulse commands and error counter reset input lines separated from the control I/O power supply as far as possible. In particular, do not connect the 2 power supply ground wires.
- We recommend using line drivers for the pulse command outputs.
- Always use twisted-pair shielded cable for the pulse command and error counter reset signal lines, and connect both ends of the shield cable to frame grounds.
- If the control I/O power supply wiring is long, noise resistance can be improved by adding 1-µF laminated ceramic capacitors between the control I/O power supply and ground at the drive input section or the controller output section.
- For open collector inputs/outputs, keep the length of wires to within 2 m.

Reactor to Reduce Harmonic Current

Harmonic Current Measures

- Use a Reactor to suppress harmonic currents. The Reactor functions to suppress sudden and quick changes in electric currents.
- The Guidelines for Suppressing Harmonic Currents in Home Appliances and General Purpose Components requires that manufacturers take appropriate remedies to suppress harmonic current emissions onto power supply lines.
- Select the proper Reactor model according to the Servo Drive to be used.

Servo Drive		Reactor				
Model	Number of power phases	Model	Rated current	Inductance	Weight	
R88D-KTA5L		3G3AX-DL2002	1.6 A	21.4 mH	Approx. 0.8 kg	
R88D-KT01L	Single-phase	3G3AX-DL2004	3.2 A	10.7 mH	Approx. 1.0 kg	
R88D-KT02L	Single-phase	3G3AX-DL2007	6.1 A	6.75 mH	Approx. 1.3 kg	
R88D-KT04L		3G3AX-DL2015	9.3 A	3.51 mH	Approx. 1.6 kg	
R88D-KT01H	Single-phase	3G3AX-DL2002	1.6 A	21.4 mH	Approx. 0.8 kg	
	Three-phase	3G3AX-AL2025	10.0 A	2.8 mH	Approx. 2.8 kg	
R88D-KT02H	Single-phase	3G3AX-DL2004	3.2 A	10.7 mH	Approx. 1.0 kg	
N00D-K102H	Three-phase	3G3AX-AL2025	10.0 A	2.8 mH	Approx. 2.8 kg	
R88D-KT04H	Single-phase	3G3AX-DL2007	6.1 A	6.75 mH	Approx. 1.3 kg	
R00D-K104H	Three-phase	3G3AX-AL2025	10.0 A	2.8 mH	Approx. 2.8 kg	
R88D-KT08H	Single-phase	3G3AX-DL2015	9.3 A	3.51 mH	Approx. 1.6 kg	
H00D-K10011	Three-phase	3G3AX-AL2025	10.0 A	2.8 mH	Approx. 2.8 kg	
R88D-KT10H	Single-phase	3G3AX-DL2015	9.3 A	3.51 mH	Approx. 1.6 kg	
	Three-phase	3G3AX-AL2025	10.0 A	2.8 mH	Approx. 2.8 kg	
R88D-KT15H	Single-phase	3G3AX-DL2022	13.8 A	2.51 mH	Approx. 2.1 kg	
H00D-K11511	Three-phase	3G3AX-AL2025	10.0 A	2.8 mH	Approx. 2.8 kg	
R88D-KT20H	-	3G3AX-AL2055	20.0 A	0.88 mH	Approx. 4.0 kg	
R88D-KT30H	-					
R88D-KT50H	-	3G3AX-AL2110	37.0 A	0.35 mH	Approx. 5.0 kg	
R88D-KT75H	-	3G3AX-AL2220	70.0 A	0.18 mH	Approx. 10.0 kg	
R88D-KT150H	-					
R88D-KT06F	-					
R88D-KT10F	Three-phase	3G3AX-AL4025	6.0 A	7.7 mH	Approx. 2.7 kg	
R88D-KT15F						
R88D-KT20F		3G3AX-AL4055	10.0 A	3.5 mH	Approx. 4.0 kg	
R88D-KT30F						
R88D-KT50F		3G3AX-AL4110	20.0 A	1.3 mH	Approx. 6.0 kg	
R88D-KT75F		3G3AX-AL4220	36.0 A	0.74 mH	Approx. 10.0 kg	
R88D-KT150F		000AA-AL4220			7.ppioz. 10.0 kg	

4-4 Regenerative Energy Absorption

A Servo Drive uses its built-in capacitors to absorb the regenerative energy produced during motor deceleration. If the amount of regenerative energy is too much for the built-in capacitors to absorb, it also uses an Internal Regeneration Resistor. An overvoltage error occurs, however, if the amount of regenerative energy from the Servomotor is too large. If this occurs, reduce the regenerative energy by changing operating patterns or increase the regeneration process capacity by connecting External Regeneration Units.

Precautions for Correct Use


- Some Servo Drive models do not have any built-in Internal Regeneration Resistor.
- The regeneration absorption capacity of a Servo Drive varies depending on the Servo Drive model.

For information on whether or not your Servo Drive has an Internal Regeneration Resistor and its regeneration absorption capacity, refer to Servo Drive Regeneration Absorption Capacity (P.4-56).

Regenerative Energy Calculation

1 0 ---

The method for calculating regenerative energy on the horizontal axis is indicated below.



- In the output torque graph, acceleration in the forward direction is shown as positive, and acceleration in the reverse direction is shown as negative.
- The regenerative energy values in each region can be derived from the following equations.


$$E_{g1} = \frac{1}{2} \cdot \frac{2\pi}{60} \cdot N_1 \cdot T_{D1} \cdot t_1 \quad [J]$$

$$E_{g2} = \frac{1}{2} \cdot \frac{2\pi}{60} \cdot N_2 \cdot T_{D2} \cdot t_2 \quad [J]$$

$$N_1, N_2 \quad : \text{Rotation speed at start of deceleration [r/min]}$$

$$T_{D1}, T_{D2} \quad : \text{Deceleration torque} \qquad [N \cdot m]$$

t1, t2 : Deceleration time [s] Note. Due to the loss of motor winding resistance and PWM, the actual regenerative energy will be approx. 90% of the values derived from these equations.



The method for calculating regenerative energy on the vertical axis is indicated below.

- In the output torque graph, acceleration in the forward direction (rising) is shown as positive, and acceleration in the reverse direction (falling) is shown as negative.
- The regenerative energy values in each region can be derived from the following equations.

$\cdot E_{g1} = \frac{1}{2}$	$-\frac{2\pi}{60}$ · N ₁ · T _{D1} · t ₁	[J]	
$\cdot E_{g^{21}} = \frac{2}{6}$	$\frac{2}{60}$ · N ₂ · T _{L2} · t ₂	[J]	
$\cdot E_{g^{22}} = \frac{2}{2}$	$\frac{1}{2} \cdot \frac{2\pi}{60} \cdot N_2 \cdot T_{D2} \cdot t_3$	[J]	
$\cdot E_{g^2} = E$	g21 + E g22	[J]	
N1, N2	: Rotation speed at st	art of deceleratior	n [r/min]
Td1 , Td2	2 : Deceleration torque		[N⋅m]
T _{L2}	: Torque during down	ward movement	[N⋅m]
t1, t3	: Deceleration time		[s]
t2	: Constant-speed driving time d	uring downward movemer	it [s]
Note Due t	o the loss of winding resid	stance the actual re	nenerativ

Note. Due to the loss of winding resistance, the actual regenerative energy will be approx. 90% of the values derived from these equations.

Determining the Capacity of Regenerative Energy Absorption by Built-in Capacitors

If both the values E_{g1} and E_{g2} [J] mentioned above are equal to or less than the value of the Servo Drive's regenerative energy that can be absorbed by built-in capacitors Ec [J], the Servo Drive can process regenerative energy only by its built-in capacitors.

If either the value E_{g1} or E_{g2} [J] exceeds the value of the Servo Drive's regenerative energy that can be absorbed by built-in capacitors Ec [J], however, use the following equations to determine the average regeneration power Pr [W].

$$\begin{array}{ll} \cdot E_g = & (E_{g1} - E_c) + (E_{g2} - E_c) & [J] \\ \cdot P_r = & E_g/T & [W] \end{array}$$

Pr: Average regeneration power that must be absorbed in 1 cycle of operation [W]

Eg: Regenerative energy that must be absorbed in 1 cycle of operation [J]

 E_c : Regenerative energy that can be absorbed by built-in capacitors [J]

T : Operation cycle [s]

Note. If the expression (E_{g1} - E_c) result is zero or less, regard it as 0. The expression (E_{g2} - E_c) must also be handled in the same way.

The above expressions calculate the average regeneration power Pr [W], which cannot be absorbed by the built-in capacitors. If this average regeneration power Pr [W] is equal to or less than the average amount of regeneration that can be absorbed by the Servo Drive's Internal Regeneration Resistor, the Servo Drive can independently process the regenerative energy.

If this average regeneration power Pr [W] cannot be processed only by the Servo Drive, take the following processes.

- Connect an External Regeneration Resistor. (Regeneration process capacity improves.)
- Reduce the rotation speed. (The amount of regeneration is proportional to the square of the rotation speed.)
- Lengthen the deceleration time. (Regenerative energy per unit time decreases.)
- Lengthen the operation cycle, i.e., the cycle time. (Average regenerative power decreases.)

Servo Drive Regeneration Absorption Capacity

The following table shows the regenerative energy (and amount of regeneration) that each Servo Drive can absorb. If these values are exceeded, take the processes above.

Servo Drive model	Regenerative energy to be absorbed by built-in capacitor [J]	Internal regeneration resistor Average amount of regenerative energy to be absorbed [W]	Allowable minimum regeneration resistance [Ω]
R88D-KTA5L	11	-	17
R88D-KT01L	11	-	17
R88D-KT02L	15	-	17
R88D-KT04L	22	17	13
R88D-KT01H	18	-	34
R88D-KT02H	18	-	34
R88D-KT04H	26	-	34
R88D-KT08H	46	12	25
R88D-KT10H	74	18	25
R88D-KT15H	74	18	25
R88D-KT20H	74	72	10
R88D-KT30H	113	60	7
R88D-KT50H	113	60	5
R88D-KT75H	282	-	4
R88D-KT150H	254	-	4
R88D-KT06F	64	21	100
R88D-KT10F	64	21	100
R88D-KT15F	64	21	100
R88D-KT20F	64	29	40
R88D-KT30F	106	60	40
R88D-KT50F	106	60	29
R88D-KT75F	273	-	14
R88D-KT150F	492	-	14

Regenerative energy to be absorbed by built-in capacitor varies depending on the input voltage to the main circuit power supply for the Servo Drive. The above value for each Servo Drive model is calculated when the input voltage is as follows.

Model	Main circuit power supply input voltage
R88D-K□□L	100 VAC
R88D-K□□H	200 VAC
R88D-K□□F	400 VAC

4

Regenerative Energy Absorption with an External Regeneration Resistor

If the regenerative energy exceeds the regeneration absorption capacity of the Servo Drive, connect an External Regeneration Resistor.

Connect the External Regeneration Resistor between B1 and B2 terminals on the Servo Drive. Double-check the terminal names when connecting the resistor because the drive may be damaged if connected to the wrong terminals.

The External Regeneration Resistor will heat up to approx. 120°C. Do not place it near equipment and wiring that is easily affected by heat. Attach radiator plates suitable for the heat radiation conditions.

External Regeneration Resistor

Characteristics


Model	Resistance value	Nominal capacity	Regeneration absorption for 120°C temperature rise	Heat radiation condition	Thermal switch output specifications
R88A- RR08050S	50 Ω	80 W	20 W	Aluminum 350 × 350, Thickness: 3.0	Operating temperature: 150°C ± 5% NC contact Rated output (resistive load): 125 VAC, 0.1 A max. 30 VDC, 0.1 A max. (minimum current: 1 mA)
R88A- RR080100S	100 Ω	80 W	20 W	Aluminum 350 × 350, Thickness: 3.0	Operating temperature: 150°C ± 5% NC contact Rated output (resistive load): 125 VAC, 0.1 A max. 30 VDC, 0.1 A max. (minimum current: 1 mA)
R88A- RR22047S1	47 Ω	220 W	70 W	Aluminum 350 × 350, Thickness: 3.0	Operating temperature: $150^{\circ}C \pm 5\%$ NC contact Rated output (resistive load): 250 VAC, 0.2 A max. 42 VDC, 0.2 A max. (minimum current: 1 mA)
R88A- RR50020S	20 Ω	500 W	180 W	Aluminum 600 × 600, Thickness: 3.0	Operating temperature 200°C ± 7°C NC contact Rated output (resistive load): 250 VAC, 0.2 A max. 42 VDC, 0.2 A max. (minimum current: 1 mA)

Connecting an External Regeneration Resistor

R88D-KTA5L/-KT01L/-KT02L/-KT01H/-KT02H/-KT04H

Normally B2 and B3 are open.

If an External Regeneration Resistor is necessary, remove the short-circuit bar between B2 and B3, and then connect the External Regeneration Resistor between B1 and B2 as shown in the diagram below.




• Connect the thermal switch output so that the main circuit power supply is shut OFF when the contacts open.

When using multiple External Regeneration Resistors, connect each thermal switch in series. The resistor may be damaged by burning, or cause fire if it is used without setting up a power supply shutoff sequence using the output from the thermal switch.

R88D-KT04L/-KT08H/-KT10H/-KT15H/-KT20H/-KT30H/-KT50H/-KT06F/-KT10F/-KT15F/-KT20F/-KT30F/-KT50F

Normally B2 and B3 are connected.

If an External Regeneration Resistor is necessary, remove the short-circuit bar between B2 and B3, and then connect the External Regeneration Resistor between B1 and B2 as shown in the diagram below.




Precautions for Correct Use

• Connect the thermal switch output so that the main circuit power supply is shut OFF when the contacts open.

When using multiple External Regeneration Resistors, connect each thermal switch in series. The resistor may be damaged by burning, or cause fire if it is used without setting up a power supply shutoff sequence using the output from the thermal switch.

R88D-KT75H/-KT150H/-KT75F/-KT150F

If an External Regeneration Resistor is necessary, connect the External Regeneration Resistor between B1 and B2 as shown in the diagram below.



• Connect the thermal switch output so that the main circuit power supply is shut OFF when the contacts open.

When using multiple External Regeneration Resistors, connect each thermal switch in series. The resistor may be damaged by burning, or cause fire if it is used without setting up a power supply shutoff sequence using the output from the thermal switch.

Combining External Regeneration Resistors

Regeneration absorption capacity *1	20 W	40 W	70 W	140 W
Model	R88A-RR08050S R88A-RR080100S	R88A-RR08050S R88A-RR080100S	R88A-RR22047S1	R88A-RR22047S1
Resistance value	50 Ω/100 Ω	25 Ω/50 Ω	47 Ω	94 Ω
Connection method	0 R 0		○ R }○	0- <u>R</u> - <u>R</u> -0

Regeneration absorption capacity *1	140 W	280 W	560 W
Model	R88A-RR22047S1	R88A-RR22047S1	R88A-RR22047S1
Resistance value *2	23.5 Ω	47 Ω	23.5 Ω
Connection method			$\begin{array}{c} \hline R \\ \hline R \\ \hline R \\ \hline R \\ \hline R \\ \hline R \\ \hline R \\ \hline R \\ \hline R \\ \hline R \\ \hline R \\ \hline \end{array}$

Regeneration absorption capacity ^{*1}	180 W	180 W 360 W 1440 W		
Model	R88A-RR50020S	R88A-RR50020S	R88A-RR50020S	
Resistance value *2	20 Ω	10 Ω 10 Ω		
Connection method	○ R]○		$ \begin{array}{c} $	

- *1. Select a combination that has an absorption capacity greater than the average regeneration power (Pr).
- *2. Do not use a combination with resistance values lower than the allowable minimum regeneration resistance of each drive. For information on the allowable minimum regeneration resistance, refer to Servo Drive Regeneration Absorption Capacity (P.4-56).



Precautions for Safe Use

• Surface temperatures on regeneration resistance can reach 200°C. Do not place objects that tend to catch fire nearby. To prevent people from touching them, install a cover that enables heat dissipation.

4-5 Large Load Inertia Adjustment and Dynamic Brake

The applicable load inertia of the Servomotor is the value of the load inertia at which the Servo Drive circuit is not destroyed in normal usage conditions. Use at a level below the applicable load inertia, and note the cautions below regarding adjustment and dynamic braking.

Adjustment When the Load Inertia Is Large

In the instances below, realtime autotuning may not function properly. In this event, improve the load conditions, or perform manual tuning to set the gain and the inertia ratio.

- When the load inertia is less than 3 times or over 20 times the rotor inertia, or is over the applicable load inertia ratio.
- When the load inertia varies.
- · When the load has low mechanical rigidity.
- When backlash or non-linear conditions occur in the load.
- When the acceleration/deceleration torque is less than the unbalanced load or viscous friction torque.
- When a speed of 100 r/min or higher or an acceleration/deceleration of 2000 r/min per second or higher continues for no more than 50 ms.

Dynamic Brake When the Load Inertia Is Large

Because the dynamic brake is used for emergency stopping, the rating is for short time intervals. To prevent wire breakage, smoke, and fire during dynamic braking, pay attention to the following points.

- · Do not intentionally start and stop the motor by Servo ON/OFF.
- Do not drive the motor using an externally applied power. Do not turn ON the power while the motor is rotating.
- If motor rotation stops due to dynamic braking, establish a stop time of at least 10 minutes until the Servo is turned ON again.

The dynamic brake converts the rotational energy of the motor into heat by the dynamic brake resistance.

The rotational energy of the motor is calculated using the equation below.

• Rotational energy of motor $= \frac{1}{2} \cdot J \cdot \omega^2 = \frac{1}{2} \cdot J \cdot (2\pi)^2 \cdot (\frac{N}{60})^2$

J: Load inertia + rotor inertia of motor [W]

N : Motor speed

[r/min]

When the load inertia is large or the rotation speed is high, the load on the dynamic brake circuit increases. Set the maximum operating rotation speed appropriately for the load inertia.

You can specify in the parameters whether or not the dynamic brake operates in the conditions below.

A 5 kW or less Servo Drive enters the dynamic braking state when the control power turns OFF, regardless of the settings.

- Main circuit power supply OFF (Pn507 Stop Selection with Main Power Supply OFF)
- When the Servo is OFF (Pn506 Stop Selection with Servo OFF)
- When an error occurs (Pn510 Stop Selection for Alarm Detection)
- + When drive prohibition is input (Pn505 Stop Selection for Drive Prohibition Input)


4

4-6 Using DC Power

You can use either an AC or DC power supply for the main power and control power for the following Servo Drives.

- R88D-KT75H
- R88D-KT150H


There are no Servo Drive parameters that you need to change to use an AC or DC power supply.



- If you use a DC power supply for the main power and control power, connect the positive side to L1 and L1C on the terminal block (TB1) and connect the negative side to L3 and L3C.
- Time is required to discharge power when the main power is turned OFF. High voltages remain inside the Servo Drive even after the power supply is turned OFF. Take sufficient precautions against electric shock. Before carrying out wiring or inspection, turn OFF the main power supply and wait for at least 15 minutes.
- Do not connect the power supply to the B1 or N terminal. Internal elements may be destroyed.
- Do not connect or disconnect the terminal block while the main power supply is ON. Arcs may cause burning.

Connection Examples for DC Power

R88D-KT75H with DC Power Supply Input



R88D-KT150H with DC Power Supply Input 3-phase 200 to 230 VAC, 50/60 Hz Noise filter (*1) 1 2 3 F NF Main circuit power supply Main circuit contactor (*1) 5 Λ OFF ON Х 1MC 2MC Ground to 100 Ω or less Li Surge suppressor (*1) 1MC Х PL Servo alarm display (*4) (*5) G5-series G5-series AC Servo Drive AC Servomotor Power cable TB1 ΧВ (*3) L1C AC/ В DC TB1 120 24 VDC U 1MC V Μ w TB1 11 AC/ L2 (**]** DC Ground to 100 Ω or less. CN2 13 B1 Encoder cable E Regeneration Resistor B2 *1. Recommended products are listed in 4-3 Wiring Conforming to EMC Directives. CN1

- *2. Recommended relays: MY Relays by OMRON (24-V)
- For example, MY2 Relays by OMRON can be used with all G5-series Servomotors with Brakes because itsrated inductive load is 2 A (24 VDC). *3. There is no polarity on the brake.
- *4. Provide auxiliary contacts to protect the system with an external sequence so that a Servo ON state will not occur due to deposition in the Dynamic Brake Resistor.
- *5. Use an external Dynamic Brake Resistor of 1.2 Ω, 400 W.
- *6. Install an external protective device, such as a thermal switch. Monitor the temperature of the external Dynamic Brake Resistor.
- *7. Wire the circuit so that the voltage between DB1 and DB2 is 300 VAC or less or 100 VDC or less. Use a separate power source to supply power to CN1.
- *8. Insert a surge suppressor if you use AC power.

x

Х

Control cable

2MC

(*8)

24 VDC

User-side

control

device

(*6)

24 VDC

37/ALM

CN1

36ALMCOM

DB1 DB2

(*7)

CN1

BKIR 11

BKIRCOM 10

24 VDC

ХВ

(*2)

4

4-64

5

Basic Control Mode


This chapter explains an outline of operations available in various control modes and explains the contents of setting.

5-1	Position Control	5-1
	Outline of Operation	5-1
	Parameters Requiring Settings	
	Related Functions	5-5
	Parameter Block Diagram for Position Control Mode	
5-2	Speed Control	5-7
	Outline of Operation	5-7
	Parameters Requiring Settings	
	Related Functions	
	Parameter Block Diagram for Speed Control Mode	5-13
5-3	Torque Control	5-14
	Outline of Operation	
	Parameters Requiring Settings	
	Related Functions	5-17
	Parameter Block Diagram for Torque Control Mode	5-18
5-4	Internally Set Speed Control	5-19
	Outline of Operation	
	Parameters Requiring Settings	
5-5	Switching Control	5-23
	Outline of Operation	
	Parameters Requiring Settings	
	Related Functions	
5-6	Fully-closed Control	5-26
	Outline of Operation	
	Parameters Requiring Settings	
	Parameter Block Diagram for Fully-closed Control Mode.	

5-1 Position Control

Outline of Operation

- Position control is performed based on the pulse train input received from the controller.
- The motor rotates using the value of the pulse train input multiplied by the Electronic Gear (Pn008 to Pn010).



Parameter number	Parameter name	Explanation	Reference
Pn000	Reference Direction	Select the relation between the reference command and the rotation direction in the motor.	P.8-1
Pn001	Control Mode Selection	Select the control mode.	P.8-2
Pn005	Command Pulse Input Selection	Select the command pulse input terminal.	P.8-3
Pn006	Command Pulse Rotation Direction Switching Selection	Set the count direction for the command pulse input.	P.8-3
Pn007	Command Pulse Mode Selection	Set the count method for the command pulse input.	P.8-4
Pn008	Electronic Gear Integer Setting	Define the number of command pulses per motor revolution. If this is zero, Pn009 and Pn010 become active.	P.8-5
Pn009	Electronic Gear Ratio Numerator 1	Set the numerator of the electronic gear ratio for the command pulse input.	P.8-5
Pn010	Electronic Gear Ratio Denominator	Set the denominator of the electronic gear ratio for the command pulse input.	P.8-6

Parameters Requiring Settings

Control Mode Selection (Pn001)

Select the position control (Set values: 0=Position control, 3=Switch between position control and speed control or 4=Switch between position control and torque control).

Command Pulse Input Process (Pn005, Pn006, Pn007)

Position command input terminals are classified into the input 1 system (+CW, -CW, +CCW, - CCW) and input 2 system (+CWLD, -CWLD, +CCWLD, -CCWLD).

If the position command output is an open collector output, set input 1. If it is a line-driver output, set input 2.

Although input 1 can also be used for a line-driver output, the allowable maximum input frequency will become lower than when input 2 is selected.

Parameter number	Parameter name	Explanation	Setting range	Unit
Pn005	Command Pulse Input Selection	Select the command pulse input terminal. 0: Photocoupler input (+CW, -CW, +CCW, -CCW) 1: Input for line driver only (+CWLD, -CWLD, +CCWLD, -CCWLD)	0 or 1	-
Pn006	Command Pulse Rotation Direction Switching Selection	Set the count direction for the command pulse input. 0: Command pulse, forward direction 1: Command pulse, reverse direction	0 or 1	-
Pn007	Command Pulse Mode Selection	 Set the count method for the command pulse input. 0: 90° phase difference (A/B) signal input) 1: Forward/reverse pulse 2: 90° phase difference (A/B) signal input) 3: Feed pulse/direction signal 	0 to 3	-

Pn006	Pn007	Command pulse pattern	Signal name	Forward direction command	Reverse direction command		
		90° phase difference,	CW				
	0 or 2	2-phase pulse (phase A + phase B)	ccw	Phase B is 90° ahead of phase A.	Phase B is 90° behind phase A.		
0	1	Forward direction pulse train + Reverse	CW	t3			
		direction pulse train	ccw		· · ·		
	3	Pulse train + Sign	CW		t4 t5		
			ccw				
	0.000	90° phase difference, 2-) or 2 phase pulse (phase A + phase B)	CW				
	0 or 2		ccw	Phase B is 90° behind phase A. Phase B is 90° ahead of pl			
1		Forward direction pulse	CW				
	1	train + Reverse direction pulse train	ccw	t3			
		Pulse train	cw	t4 t5	t4		
	3	+ Sign	ccw	t6 L <u>t6</u>	t6 H t6		

The settings for command pulse rotation direction and command pulse mode are as follows.

Symbol		Allowable	Minimum required duration [μ s]					
		input maximum frequency	t1	t2	t3	t4	t5	t6
+CWLD, -CWLD, +CCWLD, -CCWLD		4 Mpps	0.25	0.125	0.125	0.125	0.125	0.125
+CW, -CW,	Line driver	500 kpps	2	1	1	1	1	1
+CCW, -CCW	Open collector	200 kpps	5	2.5	2.5	2.5	2.5	2.5

Electronic Gear Function (Pn008, Pn009, Pn010)


This function allows you to multiply the pulse command input from the host controller by the specified gear ratio to determine the position command.

Parameter number	Parameter name	Explanation	Setting range	Unit
Pn008	Electronic Gear Integer Setting	Set the number of command pulses corresponding to 1 motor rotation.	0 to 2 ²⁰	Pulse
Pn009	Electronic Gear Ratio Numerator 1	Set the numerator of the electronic gear ratio for the command pulse input.	0 to 2 ³⁰	-
Pn010	Electronic Gear Ratio Denominator	Set the denominator of the electronic gear ratio for the command pulse input.	1 to 2 ³⁰	-

• For details on the electronic gear function, refer to "6-4 Electronic Gear Function" (P.6-10).

Related Functions

Parameter number	Parameter name	Explanation	Reference
Pn008	Electronic Gear Integer Setting	Set the number of command pulses corresponding to 1 motor rotation.	P.8-5
Pn011	Encoder Dividing Numerator	Set the pulse output resolution using the numbers of output pulses per rotation for phase A and phase B, respectively.	P.8-6
Pn012	Encoder Output Direction Switching Selection	Set the phase-B logic and output source for pulse output.	P.8-6
Pn222	Position Command Filter Time Constant	Set the time constant of the first-order lag filter for the position command.	P.8-23
Pn223	Smoothing Filter Time Constant	Set the time constant of the FIR filter for the position command.	P.8-24
Pn431	Positioning Completion Range 1	Set the threshold of position error for output of the positioning completion signal.	P.8-42
Pn432	Positioning Completion Condition Selection	Select the condition under which the positioning completion signal is output.	P.8-43
Pn433	Positioning Completion Hold Time	Set the INP signal output time.	P.8-42
Pn503	Encoder Dividing Denominator	You can set a dividing ratio by using Encoder Dividing Numerator (Pn011) as the dividing numerator and Encoder Dividing Denominator (Pn503) as the dividing denominator.	P.8-47
Pn517	Error Counter Reset Condition Selection	Set the reset condition under which the error counter reset input signal.	P.8-54
Pn518	Command Pulse Prohibition Input Setting	Set whether to enable or disable the command pulse prohibition input.	P.8-55



Parameter Block Diagram for Position Control Mode


OMNUC G5-SERIES AC SERVOMOTOR AND SERVO DRIVE USER'S MANUAL

5

5-2 Speed Control

Outline of Operation

- Motor speed control is performed based on the analog voltage input from the controller. You can also perform position control by combining with a controller that has a position control function.
- You can change the relation between the speed command and the rotation speed by setting the Speed Command Scale (Pn302).



Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn000	Reference direction	Select the relation between the reference command and the rotation direction in the motor.	P.8-2
Pn001	Control Mode Selection	Select the control mode.	P.8-2
Pn300	Command Speed Selection	Select the speed command input method.	P.8-25
Pn301	Speed Command Direction Selection	Set the method for designating the forward or reverse direction for the speed command.	P.8-25
Pn302	Speed Command Scale	Set the input gain for the analog speed command input.	P.8-27
Pn303	Analog Speed Command Rotation Direction Switching	Inverts the polarity of the analogue speed command.	P.8-27
Pn312	Soft Start Acceleration Time	Set the acceleration time for internally set speed control. Set the time until 1,000 r/min is reached.	P.8-28
Pn313	Soft Start Deceleration Time	Set the deceleration time for internally set speed control. Set the time until 1,000 r/min is reached.	P.8-29
Pn314	S-curve Acceleration/ Deceleration Time Setting	Set the S-curve time in the time width centered on the inflection points for acceleration and deceleration.	P.8-29

Control Mode Selection (Pn001)

Select the speed control (Set values: 1=Speed control, 3=Switching between position and speed control or 5=Switching between speed control and torque control).

Analog Speed Command Input Process (Pn300, Pn301, Pn302, Pn303)


Convert the voltage input by an analog input to a speed command to control the motor.

Parameter number	Parameter name	Explanation	Setting range	Unit
Pn300	Command Speed Selection	 Select the speed command input method. O: Analog torque command 1: No. 1 to 4 internally set speed 2: No. 1 to 3 internally set speed, analog torque command 3: No. 1 to 8 internally set speed 	0 to 3	_
Pn301	Speed Command Direction Selection	Select the method for designating the direction for the speed command. 0: Use the sign of the speed command Example: +: Forward -: Reverse 1: Use the speed command sign selection (VSIGN) Example: OFF: Forward ON: Reverse	0 or 1	_
Pn302	Speed Command Scale	Set the input gain for the analog speed command input.	10 to 2000	(r/min)/V
Pn303	Analog Speed Command Rotation Direction Switching	Set to reverse the polarity of the speed command input. 0: The rotation direction is controlled by the voltage of the analog speed command (REF). Positive voltage: Forward Negative voltage: Reverse 1: The rotation direction is controlled by the voltage of the analog speed command (REF). Positive voltage: Reverse Negative voltage: Forward	0 or 1	_

The conversion of analog speed command is explained below.

Command Speed Selection (Pn300)	Speed Command Direction Selection (Pn301)	Analog Speed Command Rotation Direction Switching (Pn303)	Analog speed command (REF)	Speed command sign selection (VSIGN)	Speed command direction ^{*1}	Conversion graph
	0	0	+ Voltage (0 to 10 V)		Forward direction	Figure A
			- Voltage (-10 to 0 V)	Not affected	Reverse direction	
		1	+ Voltage (0 to 10 V)		Reverse direction	
0			- Voltage (-10 to 0 V)		Forward direction	
	-		+ Voltage (0 to 10 V)	OFF	Forward	
	1	Not	- Voltage (-10 to 0 V)		direction	Figure C
		affected	+ Voltage (0 to 10 V)	ON	Reverse	
			- Voltage (-10 to 0 V)		direction	

*1. The motor rotation direction (CW, CCW) specified by the command direction is determined by the setting of Pn000.



Example) When Speed Command Scale (Pn302) = 500

Speed Command Acceleration/Deceleration Setting Function (Pn312, Pn313, Pn314)


With a step speed command, you can change the speed command based on this setting to reduce the shock caused by change in acceleration.

Parameter number	Parameter name	Explanation	Setting range	Unit
Pn312	Soft Start Acceleration Time	Set the acceleration time for acceleration process with respect to the speed command input.	0 to 10000	ms/(1,000 r/ min)
Pn313	Soft Start Deceleration Time	Set the deceleration processing deceleration time for speed command inputs.	0 to 10000	ms/(1,000 r/ min)
Pn314	S-curve Acceleration/ Deceleration Time Setting	Set the S-curve acceleration/ deceleration time.	0 to 1000	ms

Soft Start Acceleration Time (Pn312), Soft Start Deceleration Time (Pn313)

If a step speed command is input, set in Soft Start Acceleration Time (Pn312) the time needed for the speed command to reach 1,000 r/min. Also set in Soft Start Deceleration Time (Pn313) the time needed for the speed command to reach 0 r/min from 1,000 r/min.

Soft start acceleration time [ms] = Vc/1,000 \times Pn312 \times 1 ms Soft start deceleration time [ms] = Vc/1,000 \times Pn313 \times 1 ms




S-curve Acceleration/Deceleration Time Setting (Pn314)

Set the S-curve time in the time width centered on the inflection points in acceleration/deceleration relative to the acceleration or deceleration time set in Soft Start Acceleration Time (Pn312) or Soft Start Deceleration Time (Pn313).


ta = Vc/1,000 \times Pn312 \times 1 ms td = Vc/1,000 \times Pn313 \times 1 ms ts = Pn314 \times 1 ms

Set an appropriate time so that ta > ts and td > ts are satisfied.



Related Functions

Parameter number	Parameter name	Explanation	Reference
Pn315	Zero Speed Designation Selection	Set the zero speed designation.	P.8-30
Pn316	Position Lock Level Setting	Set the threshold for transition to the servo lock state under position control.	P.8-31
Pn435	Speed Conformity Detection Range	Set the detection threshold for the motor rotation speed detection output. If the difference between the speed command and motor speed is within the set threshold, a motor rotation speed detection output is output. This setting has a hysteresis of 10 r/min for detection.	P.8-44
Pn436	Rotation Speed for Motor Rotation Detection	Set the detection threshold for speed reached output. A speed reached output is output when the motor speed exceeds the set value. This setting has a hysteresis of 10 r/min for detection.	P.8-44
Pn422	Analog Input 1 Offset	Set the analog input 1 offset.	P.8-40
Pn423	Analog Input 1 Filter Time Constant	Set the filter for analog input 1.	P.8-41




Parameter Block Diagram for Speed Control Mode

5

5-3 Torque Control

Torque control is performed based on the torque command specified by the analog voltage. In addition to the torque command, torque control also requires a speed limit input to prevent the motor rotation speed from becoming excessively high.

Outline of Operation



• If the motor speed is limited by the speed limit, the motor speed will be limited and will not reach the speed corresponding to the analog torque command.

Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn001	Control Mode Selection	Select the control mode.	P.8-2
Pn317	Torque Command/Speed Limit Selection	Select the input location for the torque command and speed limit.	P.8-31
Pn318	Torque Command Direction Selection	Select the rotation direction of the torque command.	P.8-32
Pn319	Torque Command Scale	Set the input gain for analog torque command input.	P.8-34
Pn320	Analog Torque Command Rotation Direction Switching	Reverse the polarity of the torque command input.	P.8-34

Control Mode Selection (Pn001)

Select the torque control (Set values: 2=Torque control, 4=Switching between Position control and Torque control or 5=Switching between Speed control and torque control).

Analog Torque Command Input Process (Pn317, Pn318, Pn319, Pn320)


Convert the voltage input by an analog input to a torque command to control the motor.


Parameter number	Parameter name	Explanation	Setting range	Unit
Pn317	Torque Command/Speed Limit Selection	 Select the input location for the torque command and speed limit value. 0: Torque command: Analog input 1 speed limit: Pn321 1: Torque command: Analog input 2 speed limit: Analog input 1 2: Torque command: Analog input 1 speed limit: Pn321, Pn322 	0 to 2	_
Pn318	Torque Command Direction Selection	Select the method for selecting the direction for the torque command. 0: Use the sign 1: Use TVSIGN	0 or 1	-
Pn319	Torque Command Scale	Set the input gain for analog torque command input.	10 to 100	0.1 V/100%
Pn320	Analog Torque Command Rotation Direction Switching	Reverse the polarity of the torque command input. 0: Forward operation 1: Reverse operation	0 or 1	-

The conversion of analog torque command is explained below.

Torque Command/ Speed Limit Selection (Pn317)	Torque Command Direction Selection (Pn318)	Analog Torque Command Rotation Direction Switching (Pn320)	Analog torque command (TREF)	Torque command sign selection (TSIGN)	Torque command direction* ¹	Conversion graph
		0	+Voltage (0 to 10 V)		Forward direction	Figure A
	0	Ū.	-Voltage (-10 to 0 V)	Not affected	Reverse direction	
0		1	+Voltage (0 to 10 V)		Reverse direction	Figure B
U			-Voltage (-10 to 0 V)		Forward direction	
	1	Not affected	Not affected	OFF	Forward direction	Figure C
				ON	Reverse direction	


*1. The motor rotation direction (CW, CCW) specified by the command direction is determined by the setting of Pn000.





Related Functions

Parameter number	Parameter name	Explanation	Reference
Pn315	Zero Speed Designation Selection	Set the zero speed designation function.	P.8-30
Pn321	Speed Limit Value Setting	Set the speed limit value applicable during torque control. During torque control, the speed is controlled so as not to exceed the level set by the speed limit value.	P.8-34
Pn322	Reverse Direction Speed Limit Value Setting	Set this if you want to change the speed limit value depending on whether the direction is forward or reverse.	P.8-34
Pn422	Analog Input 1 Offset	Set the offset for analog input 1.	P.8-40
Pn423	Analog Input 1 Filter Time Constant	Set the filter for analog input 1.	P.8-41
Pn425	Analog Input 2 Offset	Set the offset for analog input 2.	P.8-41
Pn426	Analog Input 2 Filter Time Constant	Set the filter for analog input 2.	P.8-41




Parameter Block Diagram for Torque Control Mode

5-4 Internally Set Speed Control

Outline of Operation

- Performs motor speed control using the speeds set in the No. 1 to 8 Internally Speed Settings.
- Select the internally set speed using Internally Set Speed Selections 1 to 3 of the control input terminals (VSEL1: CN-1 to 33 pins, VSEL2: CN-1 to 30 pins, VSEL3: CN-1 to 28 pins).



Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn001	Control Mode Selection	Select the control mode for internally set speed control. (Set values: 1, 3 and 5)	P.8-2
Pn300	Command Speed Selection	Select the speed command input method.	P.8-25
Pn304	No. 1 Internally Set Speed	Set the internally set speeds (r/min).	
Pn305	No. 2 Internally Set Speed	The settings can be made from -20,000 to 20,000 r/min. Be sure to set the speeds within the allowable range of	
Pn306	No. 3 Internally Set Speed	rotation speed of the motor.	
Pn307	No. 4 Internally Set Speed		P.8-27
Pn308	No. 5 Internally Set Speed		1.0 21
Pn309	No. 6 Internally Set Speed		
Pn310	No. 7 Internally Set Speed		
Pn311	No. 8 Internally Set Speed		

Selecting the Internally Set Speeds

The following tables show the internally set speeds that are set with VSEL1, VSEL2 and VSEL3 (internally set speed selection 1, 2 and 3).

Pn300 = 1

Number	VSEL1	VSEL2	VSEL3	Set speed
0	OFF	OFF	Disabled	Pn304
1	ON	OFF	Disabled	Pn305
2	OFF	ON	Disabled	Pn306
3	ON	ON	Disabled	Pn307

Pn300 = 2

Number	VSEL1	VSEL2	VSEL3	Set speed
0	OFF	OFF	Disabled	Pn304
1	ON	OFF	Disabled	Pn305
2	OFF	ON	Disabled	Pn306
3	ON	ON	Disabled	*1


*1. The mode will be analog speed control. Input the proper current to REF.

Pn300 = 3

Number	VSEL1	VSEL2	VSEL3	Set speed
0	OFF	OFF	OFF	Pn304
1	ON	OFF	OFF	Pn305
2	OFF	ON	OFF	Pn306
3	ON	ON	OFF	Pn307
4	OFF	OFF	ON	Pn308
5	ON	OFF	ON	Pn309
6	OFF	ON	ON	Pn310
7	ON	ON	ON	Pn311

Operation Example

Internally set speed control with 4 speed changes when Pn300 = 1



*1. The acceleration time, deceleration time, and S-curve acceleration/deceleration time can be set using parameters (Pn312, Pn313, and Pn314).

Precautions for Correct Use

If more than one internally set speed selection signals are changed at the same time (e.g., as when changing from speed 2 to speed 3), the internally set speed selection signals between them may be temporarily selected. (For example, speed 1 or speed 4 may be temporarily selected.)

Observe the following precautions if an acceleration time or deceleration time of 0 or close to 0 is used, if the sign of the internally set speed command changes, or if the change in the internally set speed command is large. Any of these may cause a sudden change in the internally set speed command.

- 1) Do not change between more than one internally set speed signal at the same time.
- 2) Set soft start acceleration and soft start deceleration and change the speed gradually (i.e., do not change the speed suddenly).

Internal Speed Command (Pn304 to 311)

Control the motor speed according to the internal speed command value set by a parameter. The internally set speed becomes valid when the setting of Speed Setting Internal/External Switching is 1 to 3.


Up to 8 internally set speeds can be set.

Parameter number	Parameter name	Explanation	Setting range	Unit
Pn304	No. 1 Internally Set Speed	Set the speed 1 internally set speed.	-20,000 to 20,000	r/min
Pn305	No. 2 Internally Set Speed	Set the speed 2 internally set speed.	-20,000 to 20,000	r/min
Pn306	No. 3 Internally Set Speed	Set the speed 3 internally set speed.	-20,000 to 20,000	r/min
Pn307	No. 4 Internally Set Speed	Set the speed 4 internally set speed.	-20,000 to 20,000	r/min
Pn308	No. 5 Internally Set Speed	Set the speed 5 internally set speed.	-20,000 to 20,000	r/min
Pn309	No. 6 Internally Set Speed	Set the speed 6 internally set speed.	-20,000 to 20,000	r/min
Pn310	No. 7 Internally Set Speed	Set the speed 7 internally set speed.	-20,000 to 20,000	r/min
Pn311	No. 8 Internally Set Speed	Set the speed 8 internally set speed.	-20,000 to 20,000	r/min

5-5 Switching Control

Outline of Operation

- This function controls the motor by switching between two control modes via external inputs.
- The control mode switching is performed by the control mode switching input (TVSEL: CN-1 pin 32).



Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn001	Control Mode Selection	Select control mode for switching control. (Set values: 3, 4 and 5)	P.8-2

Control Mode Selected by TVSEL (Control Mode Switching Input)


• The following table shows the relation between TVSEL (control mode switching input) and the control mode selected.

Control Mode	TVSEL		
Selection (Pn001) setting	OFF	ON	
3	Position control	Speed control	
4	Position control	Torque control	
5	Speed control	Torque control	

Note. Use caution when switching control mode. Operation may change suddenly depending on the control mode settings.


Operation Example

Position and Speed Control Switching Example (Pn001 = 3)




- There is a maximum delay of 10 ms in reading the input signal.
- When switching from speed control to position control, turn OFF the control mode switching input (TVSEL) and wait at least 10 ms after the positioning completion output (INP) turns ON before inputting the pulse command. The pulses input before INP turns ON will be ignored.
- The shaded areas for the positioning completion output (INP) in the time chart show that the signal is turned ON as the motor rotation speed detection output (TGON). (The meaning of the signal depends on the control mode.)

Position and Torque Control Switching Example (Pn001 = 4)



- This time chart shows an example of torgue thrust.
- There is a maximum delay of 10 ms in reading the input signal.
- When switching from torque control to position control, turn OFF the control mode switching input (TVSEL) and wait at least 10 ms after the positioning completion output (INP) turns ON before inputting the pulse command. The pulses input before INP turns ON will be ignored.

Basic Control Mode



Speed and Torque Control Switching Example (Pn001 = 5)

- *1. Deceleration for the torque command.
- *2. Deceleration due to load inertia energy and load friction torque.
- There is a maximum delay of 10 ms in reading the input signal.
- Motor operation in torque control changes according to the motor load conditions (e.g., friction, external power, inertia). Take safety measures on the machine side to prevent motor runaway.
- Adjust the torque command using Analog Input 2 Offset (Pn425) and Analog Input 2 Filter Time Constant (Pn426) because the torque command input is analog input 2.


Related Functions

Refer to the related functions for each control mode.

5-6 Fully-closed Control

Outline of Operation

 An externally provided encoder is used to directly detect the position of the control target and feedback the detected machine position to perform position control. This way, controls can be performed without being affected by ball screw error, temperature changes, etc. You can achieve highly accurate positioning by configuring a fully-closed control system.



You cannot connect an external encoder with absolute encoder specifications.

Setting Procedure for Fully-closed Control

- 1. Set the Control Mode Selection (Pn001) to 6.
- 2. Set the Encoder Output Direction Switching Selection (Pn012) to 2 or 3. For details on encoder dividing function, refer to "6-5 Encoder Dividing Function" (P.6-14).
- 3. Set the Electronic Gear Integer Setting (Pn008) to 0, and set the Electronic Gear Ratio Numerator 1 (Pn009) and Electronic Gear Ratio Denominator (Pn010).

For fully-closed control, the command pulse or external encoder input is used as the reference. If the gear ratio (Pn009 and Pn010) is set to 1/1, one command pulse or one input pulse from the external encoder will determine the travel distance.

Example: Using an External Encoder with a Resolution of 0.1 μm

 If the gear ratio (Pn009 and Pn010) is set to 1/1 and a command of 100 pulses is applied to the Servo Drive, a positioning operation of 10 μm will be performed for the external encoder.

100 command units \times 1/1 (gear ratio) \times 0.1 μ m = 10 μ m

• If the gear ratio (Pn009 and Pn010) is set to 1/2 and a command of 200 pulses is applied to the Servo Drive, a positioning operation of 10 μ m will be performed for the external encoder.

200 command units \times 1/2 (gear ratio) \times 0.1 μ m = 10 μ m

- 4. Set the External Feedback Pulse Dividing Ratio (Pn324 and Pn325) according to information in " External Feedback Pulse Dividing Ratio Setting (Pn324, Pn325)" (P. 5-33).
- 5. Set the Internal/External Feedback Pulse Error Counter Overflow Level (Pn328) and Internal/External Feedback Pulse Error Counter Reset (Pn329) according to information in " External Feedback Pulse Error Setting (Pn328, Pn329)" (P. 5-34).

Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn000	Rotation Direction Switching	Set the relation between the command direction and the motor rotation direction.	
Pn001	Control Mode Selection	Select the control mode.	P.8-2
Pn005	Command Pulse Input Selection	Select the command pulse input.	P.8-3
Pn006	Command Pulse Rotation Direction Switching Selection	Set the count direction for the command pulse input.	P.8-3
Pn007	Command Pulse Mode Selection	Set the count method for the command pulse input.	P.8-4
Pn008	Electronic Gear Integer Setting	Set the number of command pulses corresponding to 1 motor rotation.	P.8-5
Pn009	Electronic Gear Ratio Numerator 1	Set the numerator of the electronic gear ratio for the command pulse input.	P.8-5
Pn010	Electronic Gear Ratio Denominator	Use this parameter to set the denominator of the electronic gear ratio for the command pulse input.	P.8-6
Pn011	Encoder Dividing Numerator	Set the number of phase A and phase B output pulses, respectively per motor rotation.	P.8-6
Pn012	Encoder Output Direction Switching Selection	Select the phase B logic for pulse regeneration output and the output source.	P.8-6
Pn323	3 External Feedback Pulse Select the external encoder type. Type Selection		P.8-34
Pn324	External Feedback Pulse Dividing Numerator	Set the numerator of the external encoder divider setting.	P.8-35
Pn325	External Feedback Pulse Dividing Denominator	Set the denominator of the external encoder divider setting.	P.8-35
Pn326	External Feedback Pulse Direction Switching	Set the polarity of the external encoder feedback pulse.	P.8-35
Pn327	Pn327 External Feedback Pulse Phase-Z Setting Set whether to enable or disable the disconnection detection function of phase Z when a 90° phase difference output type external encoder is used.		P.8-36
Pn328	Pn328 Internal/External Feedback Pulse Error Counter Overflow Level Set the threshold of A250 "internal/external feedback pulse error counter overflow" in the command unit.		P.8-36
Pn329	Internal/External Feedback Pulse Error Counter Reset	The hybrid error becomes 0 every time the motor rotates by the set value.	P.8-36
Pn503	Encoder DividingSet the denominator when the number of pulses per motorDenominatorrotation in pulse regeneration is not an integer.		P.8-47
Pn620	External Encoder Phase-Z Setting	Set the external encoder phase-Z output width.	P.8-63

Rotation Direction Switching (Pn000)

Set the relation between the command direction and the motor rotation direction. 0: A forward direction command sets the direction to CW as viewed from the shaft end 1: A forward direction command sets the direction to CCW as viewed from the shaft end Take note that if Pn000 = 1, the scale count direction becomes opposite to the count direction used for monitoring the total external encoder feedback pulses, etc.

Control Mode Selection (Pn001)

Select the fully-closed control (set value: 6).

Command Pulse Input Process (Pn005, Pn006, Pn007)

Position command input terminals are classified into the input 1 system (+CW, -CW, +CCW, - CCW) and input 2 system (+CWLD, -CWLD, +CCWLD, -CCWLD).

If the position command output is a line-driver output, set input 2. If it is an open collector output, set input 1. Although input 2 can also be used for a line-driver output, the allowable maximum input frequency will become lower than when input 1 is selected.

Parameter number	Parameter name	Explanation	Setting range	Unit
Pn005	Command Pulse Input Selection	Select the command pulse input terminal. When using a Servo Relay Unit cable, set to 0 (photocoupler input). 0: Photocoupler input (+CW, -CW, +CCW, -CCW) 1: Input for line driver only (+CWLD, -CWLD, +CCWLD, -CCWLD)	0 or 1	-
Pn006	Command Pulse Rotation Direction Switching Selection	Set the count direction for the command pulse input. 0: Command pulse, forward direction 1: Command pulse, reverse direction	0 or 1	-
Pn007	Command Pulse Mode Selection	Set the count method for the command pulse input. 0: 90° phase difference (A/B) signal input 1: Forward/reverse pulse 2: 90° phase difference (A/B) signal input 3: Feed pulse/direction signal	0 to 3	_

• For information on the settings for command pulse rotation direction and command pulse mode, refer to "5-1 Position Control" (P.5-1).

Electronic Gear Function (Pn008, Pn009, Pn010)

This function sets the position command for the position control part a value calculated by multiplying the pulse command input from the Host Controller with the set electronic gear ratio.

Parameter number	Parameter name	Explanation	Setting range	Unit
Pn008	Electronic Gear Integer Setting	Set the number of command pulses corresponding to 1 motor rotation.	0 to 2 ²⁰	Pulse
Pn009	Electronic Gear Ratio Numerator 1	Set the numerator of the electronic gear ratio for the command pulse input.	0 to 2 ³⁰	_
Pn010	Electronic Gear Ratio Denominator	Set the denominator of the electronic gear ratio for the command pulse input.	1 to 2 ³⁰	_

• For details on the electronic gear function, refer to "6-4 Electronic Gear Function"(P.6-10).

• For fully-closed control, set the Electronic Gear Integer Setting (Pn008) to 0, and set the Electronic Gear Ratio Numerator 1 (Pn009) and Electronic Gear Ratio Denominator (Pn010).

Encoder Dividing Function (Pn011, Pn012, Pn503)

Parameter number	Parameter name		Explanation		Setting range	Unit
Pn011	Encoder Dividing Numerator	phase B	number of phase output pulses, r or rotation.		1 to 262144	Pulse/r
	Encoder Output Direction Switching Selection	regenera source.	ne phase B logic ation output and For fully-closed on external encod ource.	the output control,		
Pn012		Set value	Output source	Phase B logic	0 to 3	-
		0	Encoder	Non-reverse		
		1	Encoder	Reverse		
		2	External	Non-reverse		
		3	encoder	Reverse		
Pn503	Encoder Dividing Denominator	rotation a dividin value he and usir	e number of outp is not an integer, g ratio by setting re to a number o ng Pn011 as the or and Pn503 as nator.	you can set I the set ther than 0, dividing	0 and 1 to 262144	-

The number of pulses can be set for the encoder signals output from the drive.

• For details on encoder dividing function, refer to "6-5 Encoder Dividing Function" (P.6-14).

5

External Feedback Pulse Type Selection (Pn323, Pn326)

Parameter number	Parameter name		Explanation	Setting range	Unit
	External Feedback Pulse Type Selection	Select the ty used.	ype of the external encoder to be		
		Set value	External encoder type		
Pn323		0	90° phase difference output type	0 to 2	_
		1	Incremental encoder with serial communications		
		2	Reserved (Do not use this setting.)		
Pn326	External Feedback Pulse Direction Switching	feedback pu feedback pu external end this setting.	directions of the external encoder ulse and the encoder total ulses do not match, reverse the coder feedback pulse direction in sed, 1: Reversed	0 or 1	-

Set the external encoder output type and direction.


The corresponding external encoders for each output type are given in the following table.

Pn323 set value	External encoder type	Corresponding external encoder examples	Maximum input frequency * ²
0	90° phase difference output type ^{*1}	90° phase difference output type external encoder	0 to 4 Mpps (After × 4)
1	Incremental encoder with serial communications	Sony Manufacturing Systems Corporation SR75, SR85	0 to 400 Mpps
2	Reserved (Do not use this s	setting.)	

*1. These are the directions in which the Servo Drive counts the pulses from a 90° phase difference output type external encoder.

Count-down direction

Count-up direction



*2. These are the feedback speeds from the external encoder at which Servo Drive can respond. Check the external encoder operation manual for its maximum output frequency. For example, the maximum speed when an external encoder with a resolution of 0.01 μ m is used for the serial communication type is 0.01 μ m × (400 × 10⁶) pps = 4.00 m/s. An overspeed error protection is generated, however, if the motor shaft rotation speed exceeds the maximum speed.

Precautions for Correct Use

- For the external encoder connection direction, set the rotation direction so that count-up occurs when the motor shaft is rotating counterclockwise, and count-down occurs when the motor shaft is rotating clockwise. If the connection direction cannot be selected due to installation conditions, etc., the count direction can be reversed using External Feedback Pulse Direction Switching (Pn326).
- Take note that if Pn000 = 1, the encoder count direction becomes opposite to the count direction used for monitoring the total external encoder feedback pulses, etc.
 - If Pn000 = 0, the count direction matches the count direction for monitoring.
- Even when the speed command is within the Drive's speed command range, an acceleration error will occur if the speed command exceeds the maximum speed of motor shaft rotation.
- To confirm that the installation direction is correct, use the front-panel monitor or the CX-Drive monitor function to check the counting direction of the total external encoder feedback pulses and the total encoder feedback pulses. If the counting directions are the same, the connections are correct.

External Feedback Pulse Dividing Ratio Setting (Pn324, Pn325)

Parameter number	Parameter name	Explanation	Setting range	Unit
Pn324	External Feedback Pulse Dividing Numerator	Set the numerator of the external encoder divider setting. Normally, set the number of encoder output pulses per motor rotation. If the set value is 0, the encoder resolution is set automatically.	0 to 2 ²⁰	-
Pn325	External Feedback Pulse Dividing Denominator	Set the denominator of the external encoder divider setting. Normally, set the number of external encoder output pulses per motor rotation.	1 to 2 ²⁰	-

Set the dividing ratio for the encoder resolution and external encoder resolution.

Check the number of encoder feedback pulses and the number of external encoder output pulses per motor rotation, and set External Feedback Pulse Dividing Numerator (Pn324) and External Feedback Pulse Dividing Denominator (Pn325) so that the following formula works out.


Pn324 Number of encoder output pulses per motor rotation

Pn325 Number of external encoder output pulses per motor rotation

If this divider setting is wrong, there will be deviations between the position calculated from encoder pulses and the position calculated from external encoder. If the movement distance is long, these deviations accumulate and cause an internal/external feedback pulse error counter overflow level error.

Setting Examples

- Ball screw pitch: 10 mm
- + External encoder resolution: 0.1 μm
- Encoder resolution: 20 bits



External Feedback Pulse Error Setting (Pn328, Pn329)


The difference between the encoder position and external encoder position is detected, and if the difference exceeds the value of Internal/External Feedback Pulse Error Counter Overflow Level (Pn328), an alarm will occur.

Parameter number	Parameter name	Explanation	Setting range	Unit
Pn328	Internal/External Feedback Pulse Error Counter Overflow Level	Set the allowable difference (hybrid error) between the encoder-detected position and external encoder-detected position in command units.	1 to 2 ²⁷	Command units
Pn329	Internal/External Feedback Pulse Error Counter Reset	The hybrid error becomes 0 every time the motor rotates by the set value. If the set value is 0, the hybrid error is not cleared.	0 to 100	Rotations

Pn329: Internal/External Feedback Pulse Error Counter Reset

Every time the motor rotates for the amount set by Pn329, the internal/external feedback pulse error is cleared.

This function can be used when there is deviation between the position calculated from encoder pulses and the position calculated from external encoder due to slipping, etc, and internal/external feedback pulse errors accumulate.




5



Precautions for Correct Use

- An internal/external feedback pulse error counter overflow level error occurs when the external encoder is abnormal, connection is wrong, or connection point between the motor and load is loose, among others. Accordingly, check these items when an alarm occurs.
- Be sure to set an appropriate value for Internal/External Feedback Pulse Error Counter Reset (Pn329). If an extremely small value is set, this function may not operate.
- Take sufficient safety measures, such as installing limit sensors.



5-35

Basic Control Mode

6

Applied Functions

This chapter gives outline of applied functions such as damping control, electronic gears, gain switching and disturbance observer, and explains the contents of setting.

6-1	Damping Control	6-1
	Outline of Operation	
	Parameters Requiring Settings	
6-2	Adaptive Filter	6-5
	Outline of Operation	
	Parameters Requiring Settings	
6-3	Notch Filter	6-7
	Outline of Operation Parameters Requiring Settings	
6-4	Electronic Gear Function	6-10
	Outline of Operation	6-10
	Parameters Requiring Settings	6-10
	Operation Example	
6-5	Encoder Dividing Function	6-14
	Outline of Operation	
	Parameters Requiring Settings	
6-6	Brake Interlock	6-19
	Outline of Operation	
	Parameters Requiring Settings	6-19
	Parameters Requiring Settings Precautions for Correct Use of Holding Brake	6-19 6-19
6-7	Parameters Requiring Settings Precautions for Correct Use of Holding Brake Operation	
6-7	Parameters Requiring Settings Precautions for Correct Use of Holding Brake Operation Gain Switching Function	6-19 6-19 6-20 6-24
6-7	Parameters Requiring Settings Precautions for Correct Use of Holding Brake Operation Gain Switching Function Outline of Operation	
	Parameters Requiring Settings Precautions for Correct Use of Holding Brake Operation Gain Switching Function Outline of Operation Parameters Requiring Settings	
6-7 6-8	Parameters Requiring Settings Precautions for Correct Use of Holding Brake Operation Gain Switching Function Outline of Operation Parameters Requiring Settings Torque Limit	
	Parameters Requiring Settings Precautions for Correct Use of Holding Brake Operation Gain Switching Function. Outline of Operation Parameters Requiring Settings Torque Limit Outline of Operation	
	Parameters Requiring Settings Precautions for Correct Use of Holding Brake Operation Gain Switching Function Outline of Operation Parameters Requiring Settings Torque Limit Outline of Operation Parameters Requiring Settings	
6-8	Parameters Requiring Settings Precautions for Correct Use of Holding Brake Operation Gain Switching Function. Outline of Operation Parameters Requiring Settings Torque Limit Outline of Operation Parameters Requiring Settings Sequence I/O Signal	
6-8	Parameters Requiring Settings Precautions for Correct Use of Holding Brake Operation Gain Switching Function Outline of Operation Parameters Requiring Settings Torque Limit Outline of Operation Parameters Requiring Settings	
6-8 6-9	Parameters Requiring Settings Precautions for Correct Use of Holding Brake Operation Gain Switching Function Outline of Operation Parameters Requiring Settings Torque Limit Outline of Operation Parameters Requiring Settings Sequence I/O Signal Outline of Operation Input Signals Output Signals	
6-8 6-9	Parameters Requiring Settings Precautions for Correct Use of Holding Brake Operation Gain Switching Function. Outline of Operation Parameters Requiring Settings Torque Limit Outline of Operation Parameters Requiring Settings Sequence I/O Signal Outline of Operation Input Signals	
6-8 6-9	Parameters Requiring Settings Precautions for Correct Use of Holding Brake Operation Gain Switching Function Outline of Operation Parameters Requiring Settings Torque Limit Outline of Operation Parameters Requiring Settings Sequence I/O Signal Outline of Operation Input Signals Output Signals	6-19 6-20 6-24 6-24 6-25 6-25 6-32 6-32 6-32 6-35 6-35 6-35 6-35 6-38 n Functions .6-41

6-11 Disturbance Observer Function	6-44
Outline of Operation	6-44
Parameters Requiring Settings	
Operating Procedure	6-45
6-12 Gain Switching 3 Function	6-46
Outline of Operation	6-46
Parameters Requiring Settings	
Operation	
6-13 Friction Torque Compensation Function	6-47
Outline of Operation	
Parameters Requiring Settings	
Operation Example	
6-14 Inertia Ratio Switching Function	6-49
Outline of Operation	
Parameters Requiring Settings	
Operating Procedure	
6-15 Hybrid Vibration Suppression Function	
Outline of Operation	
Parameters Requiring Settings	
Operating Procedure	
6-16 Feed-forward Function	6-51
Outline of Operation	
Parameters Requiring Settings	
Operating Procedure	
6-17 Instantaneous Speed Observer Function	6-55
Outline of Operation	
Parameters Requiring Settings	
Operating Procedure	6-56


6-1 Damping Control

Outline of Operation

If the tip of the mechanical unit vibrates, you can use the damping control function to reduce vibration.

This is effective on vibration generated by a machine of low rigidity. The applicable frequencies are from 1 to 200 Hz.

Since damping control is performed using position commands, it cannot be used with speed or torque control.



Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn001	Control Mode Selection	Set to the Position Control Mode or Fully-closed Control Mode. 0: Position control 3: First control mode for position/speed control 4: First control mode for position/torque control 6: Fully-closed control	P.8-2
Pn213	Damping Filter Selection	Select the damping filter switching mode according to the condition of the unit. 0: Damping filter 1 or 2 enabled 1: Switching by external input (DFSEL1) 2: Switching by external input (DFSEL1, DFSEL2) 3: Switching with command direction	P.8-21
Pn214	Damping Frequency 1	Set damping frequency 1 to suppress vibration at the end of the load in damping control. If the damping control function is not used, set 0.	P.8-22
Pn215	Damping Filter 1 Setting	When the Damping Frequency 1 (Pn214) is set, reduce the setting if torque saturation occurs or increase the setting to increase operation speed. Normally 0 is set. If the damping filter 1 is disabled, this parameter is also disabled.	P.8-22
Pn216	Damping Frequency 2	The function is the same with Pn214.	P.8-22
Pn217	Damping Filter 2 Setting	The function is the same with Pn215.	P.8-22
Pn218	Damping Frequency 3	The function is the same with Pn214.	P.8-23
Pn219	Damping Filter 3 Setting	The function is the same with Pn215.	P.8-23
Pn220	Damping Frequency 4	The function is the same with Pn214.	P.8-23
Pn221	Damping Filter 4 Setting	The function is the same with Pn215.	P.8-23



Precautions for Correct Use

- Stop operation before changing the parameters or switching with DFSEL.
- Damping control may not function properly or the effect may not be apparent under the following conditions.

Item	Conditions under which the effect of damping control is inhibited
Control mode	- Speed Control Mode or Torque Control Mode
Load condition	 If forces other than position commands, such as external forces, cause vibration. If the damping frequency is outside the range of 1 to 200 Hz. If the ratio of the resonance frequency to anti-resonance frequency is large.

Operating Procedure

1. Adjust the position loop gain and speed loop gain.

Adjust Position Loop Gain (Pn100), Speed Loop Gain (Pn101), Speed Loop Integral Time Constant (Pn102) and Torgue Command Filter Time Constant (Pn104).

If no problem occurs in realtime autotuning, you can continue to use the settings.

Measure the damping frequency at the tip of the mechanical unit.


Measure the damping frequency by using a measurement device such as a laser displacement sensor, servo acceleration meter, or acceleration pick-up.

Set the damping frequency in one of Damping Frequency 1 to Damping Frequency 4 (1: Pn214, 2: Pn216, 3: Pn218, 4: Pn220) according to the operation.

Also set the switching mode using Damping Filter Selection (Pn213).

If the measurement device cannot be used, use CX-Drive tracing function, and read the residual damping frequency (Hz) from the position error waveform as shown in the following figure.

f



 The damping frequency in the figure is calculated with the following formula:

$$(Hz) = \frac{1}{T(s)}$$

Since the parameter unit is 0.1 Hz: (Pn214, Pn216, Pn218, Pn220) = $10 \times f$

Application example


If the damping cycle is 100 ms or 20 ms, set 100 or 500 in the parameter so that the damping frequency becomes 10 Hz or 50 Hz.

If vibration persists after setting the frequency, increase or decrease the damping frequency to find the frequency at which vibration decreases.

3. Make the damping filter settings.

Make the damping filter settings (1: Pn215, 2: Pn217, 3: Pn219, 4: Pn221). First, set to 0.

The stabilization time can be reduced by setting a large value; however, torque ripple will increase at the command change point as shown in the following figure. Set a range that will not cause torgue saturation under actual operation conditions. The effects of vibration suppression will be lost if torgue saturation occurs.



When the Damping Frequency 1 (Pn214) is set, reduce the setting if torque saturation occurs or increase the setting to increase operation speed. Normally 0 is set.

If the damping filter 1 is enabled, use the following setting range.

Setting range: $100 \le Pn214 + Pn215 \le Pn214 \times 2 \text{ or } 2,000$

Note: If the damping filter 1 is disabled under Damping Filter Selection (Pn213), this parameter is also disabled.

6

4. Set the Damping Filter Selection (Pn213).

Damping filters 1 to 4 can be switched according to the conditions of the machine vibration.

Set value	Switching mode				
0	Damping filter 1 and 2 enabled				
1	Switching by external input (DFSEL1) Open: Damping filter 1 or 3 enabled Shorted: Damping filter 2 or 4 enabled				
2	Switching by external input (DFSEL1, DFSEL2) When DFSEL1 and DFSEL2 are both open: Damping filter 1 enabled When DFSEL1 is shorted and DFSEL2 is open: Damping filter 2 enabled When DFSEL1 is open and DFSEL2 is shorted: Damping filter 3 enabled When DFSEL1 and DFSEL2 are both shorted: Damping filter 4 enabled				
3	Switching with command direction Forward: Damping filters 1 and 3 enabled Reverse: Damping filters 2 and 4 enabled				


6-2 Adaptive Filter

Outline of Operation

The adaptive filter reduces resonance point vibration by estimating the resonance frequency from the vibration component that appears in the motor speed during actual operation and automatically sets the frequency of the notch filter, which removes the resonance component from the torque command.

The automatically set notch filter frequency is set in Notch 3 (Pn207 to Pn209) or Notch 4 (Pn210 to Pn212).

Refer to "6-3 Notch Filter" (P.6-7) for information on notch filter.



Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn200	Adaptive Filter Selection	 Set the number of resonance frequencies to be estimated by the adaptive filter and the operation to be performed after estimation. O: Adaptive filter disabled 1: 1 adaptive filters enabled 2: 2 adaptive filters enabled 3: Resonance Frequency Measurement Mode The servo drive measures the resonant frequency automatically. 4: Adaptive result clear The notch filter 3 and notch filter 4 parameters are disabled, and adaptive result is cleared. 	P.8-20

Precautions for Correct Use

• Adaptive filter may not operate correctly under the following conditions.

Item	Conditions under which the adaptive filter not operates properly
Control mode	Torque Control Mode
Resonance points	 If the resonance frequency is 300 Hz or lower. If the resonance peak or control gain is too low to affect the motor speed. If there are three or more resonance points.
Load	 If the motor speed with high-frequency components changes due to backlash or other non-linear elements.
Command pattern	The acceleration/deceleration is sudden.

• If the adaptive filter does not operate properly, use Notch 1 (Pn201 to Pn203) or Notch 2 (Pn204 to Pn206) to implement resonance measures according to the manual adjustment procedure. Refer to "6-3 Notch Filter" (P.6-7) for information on notch filter.


- An unusual noise or vibration may occur until the adaptive filter stabilizes after startup, immediately after the first servo ON, or when the Realtime Autotuning Machine Rigidity Selection (Pn003) is increased, but this is not a problem if it disappears right away. If the vibration or unusual noise, however, continues for three or more reciprocating operations, take the following measures in the possible order.
 - $\cdot\,$ Write the parameters used during normal operation to the EEPROM.
 - · Lower the Realtime Autotuning Machine Rigidity Selection (Pn003).
 - Disable the adaptive filter by setting the Adaptive Filter Selection (Pn200) to 0. (Resetting of inertial estimation and adaptive operation)
 - · Manually set the notch filter.
- If unusual noise or vibration occurred, the setting of Notch 3 (Pn207 to Pn209) or Notch 4 (Pn210 to Pn212) may have changed to an extreme value. In this case, set Adaptive Filter Selection (Pn200) to 0 to disable the parameter and then set Notch 3 Frequency Setting (Pn207) and Notch 4 Frequency Setting (Pn210) to 5,000 (disabled). Next, enable Adaptive Filter Selection again.
- Notch 3 Frequency Setting (Pn207) and Notch 4 Frequency Setting (Pn210) are written to the EEPROM every 30 minutes. When the power supply is turned OFF and then turned ON again, this data will be used as the default settings to perform adaptive operation.
- The adaptive filter is disabled when torque control is performed, but the adaptive filter frequency used in the control mode before switching will be held if torque control has been selected by setting the Control Mode Selection (Pn001) to 5 or 6.

6


6-3 Notch Filter

Outline of Operation

You can set up to 4 notch filters for the torque command. If a ball screw or other controlled device causes resonance at a specific location, you can set the resonance frequency using a notch filter to eliminate resonance. A notch filter is used to eliminate a specified frequency component.




If machine resonance occurs, use this notch filter to eliminate resonance.



Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn201	Notch 1 Frequency Setting	Set the center frequency of notch filter 1. The notch filter is enabled at 50 to 4,999 Hz, and disabled at 5,000 Hz.	P.8-20
Pn202	Notch 1 Width Setting	Select the width of the notch filter 1 frequency. Increasing the value widens the notch width. (Setting range: 0 to 20)	P.8-20
Pn203	Notch 1 Depth Setting	Select the depth of the notch filter 1 center frequency. Increasing the value decreases the notch depth and thereby reduces the phase delay. The notch filter is disabled if 100 is set. (Setting range: 0 to 99)	P.8-20
Pn204	Notch 2 Frequency Setting	Set the center frequency of the notch filter 2. The details are the same with the notch filter 1 frequency.	P.8-20
Pn205	Notch 2 Width Setting	Select the width of the notch filter 2 frequency. The details are the same with the notch filter 1 width.	P.8-20
Pn206	Notch 2 Depth Setting	Select the depth of the notch filter 2 center frequency. The details are the same with the notch filter 1 depth.	P.8-21
Pn207	Notch 3 Frequency Setting ^{*1}	Set the center frequency of the notch filter 3. The details are the same with the notch filter 1 frequency.	P.8-21
Pn208	Notch 3 Width Setting ^{*1}	Select the width of the notch filter 3 frequency. The details are the same with the notch filter 1 width.	P.8-21
Pn209	Notch 3 Depth Setting ^{*1}	Select the depth of the notch filter 3 center frequency. The details are the same with the notch filter 1 depth.	P.8-21
Pn210	Notch 4 Frequency Setting *1	Set the center frequency of the notch filter 4. The details are the same with the notch filter 1 frequency.	P.8-21
Pn211	Notch 4 Width Setting ^{*1}	Select the width of the notch filter 4 frequency. The details are the same with the notch filter 1 width.	P.8-21
Pn212	Notch 4 Depth Setting ^{*1}	Select the depth of the notch filter 4 center frequency. The details are the same with the notch filter 1 depth.	P.8-21

*1 If an adaptive filter is used, these are set automatically.



• Identify the resonance frequency using the frequency characteristics measurement function, resonance frequency monitor or operation waveform of the waveform graphics function of CX-Drive and set the identified frequency as the notch filter frequency.

Notch Filter Width and Depth

Width Setting


This is the ratio of the frequency bandwidth at a damping factor of -3 [dB] relative to the center frequency when the depth is 0. This value should conform to the left column in the table below.

Depth Setting

This is the I/O ratio at which the center frequency input is completely cut off at a set value of 0 and completely passed at a set value of 100. If the indication unit is [dB], this value should conform to the right column in the table below.

Width			
Set value	Bandwidth/center frequency		
0	0.50		
1	0.59		
2	0.71		
3	0.84		
4	1.00		
5	1.19		
6	1.41		
7	1.68		
8	2.00		
9	2.38		
10	2.83		
11	3.36		
12	4.00		
13	4.76		
14	5.66		
15	6.73		
16	8.00		
17	9.51		
18	11.31		
19	13.45		
20	16.00		

Depth				
Set value	I/O ratio (%)	Damping factor (dB)		
0	0 (Cut off)	-∞		
1	1	-40.0		
2	2	-34.0		
3	3	-30.5		
4	4	-28.0		
5	5	-26.0		
10	10	-20.0		
15	15	-16.5		
20	20	-14.0		
25	25	-12.0		
30	30	-10.5		
35	35	-9.1		
40	40	-8.0		
45	45	-6.9		
50	50	-6.0		
60	60	-4.4		
70	70	-3.1		
80	80	-1.9		
90	90	-0.9		
100	100 (Passed)	0.0		



6-4 Electronic Gear Function

Outline of Operation

- The motor can be rotated for the number of pulses obtained by multiplying the position command values by the electronic gear ratio.
- This function supports position and fully-closed control.

Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn008	Electronic Gear Integer Setting	Set the number of command pulses corresponding to 1 motor rotation.	
Pn009	Electronic Gear Ratio Numerator 1	Set the numerator of the electronic gear ratio. If the set value is 0, the encoder resolution is automatically set as the numerator. • 131,072 for a 17-bit absolute encoder • 1,048,576 for a 20-bit incremental encoder	
Pn010	Electronic Gear Ratio Denominator	Set the denominator of the electronic gear ratio.	P.8-5
Pn500	Electronic Gear Ratio Numerator 2 ^{*1}	Set the numerator of the electronic gear ratio 2.	
Pn501	Electronic Gear Ratio Numerator 3 ^{*1}	Set the numerator of the electronic gear ratio 3.	
Pn502	Electronic Gear Ratio Numerator 4 ^{*1}	Set the numerator of the electronic gear ratio 4.	

*1. Switching among Electronic Gear Ratio Numerators 2 to 4 (Pn500 to Pn502) is performed using the electronic gear switching input (GESEL1/GESEL2).

The settings of GESEL1 and GESEL2 are as follows.

GESEL1	GESEL2	Applicable parameters
OFF	OFF	Electronic Gear Ratio Numerator 1 (Pn009)
ON	OFF	Electronic Gear Ratio Numerator 2 (Pn500)
OFF	ON	Electronic Gear Ratio Numerator 3 (Pn501)
ON	ON	Electronic Gear Ratio Numerator 4 (Pn502)

Any values can be set for PN008, Pn009, and Pn010, but operation may not be correct if you set an extreme electronic gear ratio. Set the electronic gear ratio to between 1/1,000 and 1,000.

6

Electronic Gear Ratio Setting (Pn008, Pn009, Pn010)

Electronic Gear Integer Setting (Pn008)	Electronic Gear Ratio Numerator 1 (Pn009)	Electronic Gear Ratio Denominator (Pn010)	Explanation
1 to 1048576	_	_	When the Electronic Gear Integer Setting (Pn008) $\neq 0$ The processing will be based on the set value of Electronic Gear Integer Setting (Pn008) regardless of the set values of Electronic Gear Ratio Numerator 1 (Pn009) and Electronic Gear Ratio Denominator (Pn010). Command pulse input Encoder resolution * Electronic Gear Integer Setting (Pn008) Position Command pulse = Encoder resolution / Electronic Gear Integer Setting (Pn008) Switching among electronic gear ratio numerators 1 to 4 is disabled when the Electronic Gear Integer Setting (Pn008) $\neq 0$.
0	0		When the Electronic Gear Integer Setting (Pn008) = 0, or Electronic Gear Ratio Numerator 1 (Pn009) = 0 The processing will be based on the set value of Electronic Gear Ratio Denominator (Pn010). Command pulse input Electronic Gear Ratio Denominator (Pn010) Position Command pulse = Encode resolution / Electronic Gear Ratio Denominator (Pn010)
	1 to 1073741824	1 to 1073741824	When the Electronic Gear Integer Setting (Pn008) = 0, or Electronic Gear Ratio Numerator 1 (Pn009) \neq 0 The processing will be based on the set values of Electronic Gear Ratio Numerator 1 (Pn009) and Electronic Gear Ratio Denominator (Pn010). Command pulse input Electronic Gear Ratio Denominator (Pn009) Electronic Gear Ratio Denominator (Pn010) Position command pulse = Electronic Gear Ratio Numerator 1 (Pn009) / Electronic Gear Ratio Denominator (Pn010)


* The encoder resolution is set as the numerator for fully-closed control. The command pulse is the external encoder reference for fully-closed control. Accordingly, please be cautious that the Pn008 set value will not be the number of command pulses per motor rotation.

Operation Example

• Example of a motor with a 20-bit encoder (1,048,576 pulses/rotation)


When the Electronic Gear Integer Setting (Pn008) \neq 0

• If you set Pn008 = 2,000, it will operate the same as the 2,000 (pulses/rotation) Servomotor.




When the Electronic Gear Integer Setting (Pn008) = 0 and the Electronic Gear Ratio Numerator = 0

• If you set Pn010 = 2,000, it will operate the same as the 2,000 (pulses/rotation) Servomotor.



When the Electronic Gear Integer Setting (Pn008) = 0 and the Electronic Gear Ratio Numerator \neq 0

• If you set Pn009 and Pn010 = 512/1, it will operate the same as the 2,048 (pulses/rotation) Servomotor.



Precautions for Correct Use

- Set the parameters so that the command pulse frequency multiplied by the electronic gear ratio does not exceed 175 Mpps*. If 175 Mpps* is exceeded, alarm 27.2 will occur. Example:
 - The following calculation is for an incremental encoder with a resolution of 1,048,576, an electronic gear setting of 500 (Pn008 = 500), and a command pulse frequency of 100 kpps. 100 Kpps \times 1,048,576/500 = 209,715,200 = 209.7152 Mpps, which exceeds 175 Mpps*. The calculation changes as follows if the electronic gear is set to 5,000 (Pn008 = 5,000) and the command pulse frequency is 100 kpps.

100 Kpps \times 1,048,576/5,000 = 20,971,520 =20.97152 Mpps, which does not exceed 175 Mpps^{*}.

 * Alarm 27.2 will occur if 3 Gpps is exceeded when using software version 1.10 or higher. The software version can be checked on the front panel or with the CX-Drive. For information on checking the software version on the front panel, refer to *9-4 Setting the Mode*.

6-5 Encoder Dividing Function

Outline of Operation

- The number of output pulses from the drive can be adjusted.
- You can set the number of pulses per motor rotation in the range of 1 to (the number of encoder resolution pulses).
- This function is used in the following cases:
 - When you use a controller with a low response frequency
 - When you want to set the pulse rate corresponding to a certain value
 - Example: Set the encoder dividing ratio to 2,000 (pulses/rotation) for when the resolution is set to 5 μ m/pulse on mechanical systems that travel 10 mm per motor rotation.

Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn011	1Encoder Dividing NumeratorSet the number of phase-A and phase-B output pulses, respectively per motor rotation.		P.8-6
Pn012 Encoder Output Direction Switching Selection		Select the phase B logic for pulse regeneration output and the output source.	P.8-6
Pn503	3 Encoder Dividing Denominator Set the denominator when the number of pulses per motor rotation in pulse regeneration is not an integer.		P.8-47
Pn533	Pulse Regeneration Output Limit Setting	Set whether to enable or disable the detection of Alarm 28.0 "pulse regeneration error." 0: Disabled, 1: Enabled	P.8-59
Pn620	External Encoder Phase-Z Setting	Set the external encoder phase-Z output width.	P.8-63
Pn622	90° Phase Difference Output External Encoder Pulse Output Method Selection	Select the regeneration method of pulse outputs A and B when a 90° phase difference output type external encoder is used. 0: Without signal regeneration. 1: With signal regeneration for phase-A and phase-B. Without signal regeneration for phase-Z.	P.8-63


Encoder Dividing Ratio Setting (Pn011, Pn503)

Encoder Dividing Numerator (Pn011)	Encoder Dividing Denominator (Pn503)	Explanation			
		When the output source is the encoder When Encoder Dividing Denominator (Pn503) = 0 This is set by Encoder Dividing Numerator (Pn011), and the output pulse is the number of pulses set by Encoder Dividing Numerator (Pn011) as follows.			
		Encoder pulse Pn011 set value × 4 Output pulse from the drive			
1 to 262144	0	Number of pulse output per rotation = Encoder Dividing Numerator (Pn011) $\times 4$			
		When the output source is the external encoder When Encoder Dividing Denominator (Pn503) = 0 The dividing ratio is 1:1.			
		External encoder pulse 1 1 1 1 Output pulse from the drive			
	1 to 262144	When Encoder Dividing Denominator (Pn503) $\neq 0$ The output pulse will be as follows based on Encoder Dividing Numerator (Pn011) and Encoder Dividing Denominator (Pn503).			
1 to 262144		Encoder pulse or external encoder pulse Pn011 set value Pn503 set value Output pulse from the drive			
		Number of pulse output per rotation = $\frac{\text{Encoder Dividing Numerator (Pn011)}}{\text{Encoder Dividing Denominator (Pn503)}} \times \text{encoder resolution}$			


Phase Z Signal Output

1 phase-Z signal is output by 1 pulse per motor rotation. When the Encoder Dividing Denominator (Pn503) \neq 0, and if the pulse output resolution per rotation is not a multiple of 4, phase-Z and phase-A outputs are not synchronized. The output will be made as an encoder resolution, resulting in narrower width.

If Pn011 and Pn503 are integers



If Pn011 and Pn503 are not integers



Encoder Output Direction Switching Selection (Pn012)


The corresponding external encoders for each output type are given in the following table.

Pn012 set value	Output source	Phase B logic	CCW direction operation	CW direction operation
0	Encoder	Non- reverse	Non- A reverse	Phase
2	External encoder			
1	Encoder	Reverse	Phase	Phase
3	External encoder	i level se	Phase	Phase B

External Encoder Pulse Regeneration Function

Serial Incremental External Encoder

Phase Z is output without dividing the phase Z of the serial incremental external encoder. In addition, take note that there are differences as illustrated in the figure below depending on the direction passing phase Z.



- *1. Phase-Z position and its relationship with phases A and B vary depending on the scale.
- *2. Phase Z is regenerated for 1 pulse. If the width is narrow, the output time can be extended by the External Encoder Phase Z Setting (Pn620).

90° Phase Difference Output Type External Encoder

- Phase Z is output without dividing the Z signal that is input from the 90° phase difference output type external encoder.
- When 90° Phase Difference Output External Encoder Pulse Output Method Selection (Pn622) =

 the phase AB signal can be input into the amplifier and regenerated. Note, in this case, that the
 phase-AB regeneration will be delayed compared to when Pn622 is set to 0.

External Encoder Common Items


• When detection cannot be made because the phase-Z signal width is narrow due to the external encoder travel distance, if you set the phase-Z signal output time in the External Encoder-Z Setting (Pn620), phase Z can be output at least for that period of time.

In addition, take note that the output is made from when the phase-Z signal starts and, therefore, it will be different from the actual phase-Z signal width. Take note, also, that the direction of the time extension varies depending on the direction of the operation.


Phase-Z output for pulse regeneration (before time extension)		
		Operating direction
Phase-Z output for pulse regeneration (after time extension)	Pn620 External Encod	Jer Phase-Z Setting
Opera	ting direction	
Pn620 Externa	al Encoder Phase-Z Settin	9

Precautions for Correct Use

• The maximum output frequency of the pulse regeneration output will be 4 Mpps (after quadruple multiplier). If operated at a speed that exceeds this, the regeneration function may not operate properly and position misalignment may result.



- You can generate Alarm 28.0 "pulse regeneration error" when the pulse regeneration limit is reached based on the Pulse Regeneration Output Limit Setting (Pn533). Note that this alarm is generated when the pulse regeneration output limit is detected. Therefore, the alarm does not occur due to the maximum output frequency. Depending on the motor rotation status (uneven rotations), the alarm may occur when the detection is made at the frequency that goes up momentarily.
- Take not that if the encoder is used as the output source and the pulse output resolution per rotation is not a multiple of 4, phase Z and phase A are not synchronized, and the width may be narrow.



When the dividing ratio is multiple of 4

When the dividing ratio is not multiple of 4

Note: When Pn503 = 0 and the output resolution is set to Pn011, the dividing ratio is always a multiple of 4.

• When en encoder with the incremental specifications is used, the first phase Z output after the power supply is turned ON may not always be within the above pulse width. When you are using the phase-Z signal, rotate the motor more than once after turning ON the power supply, and confirm that phase-Z regeneration has been performed once before using the second and subsequent phase Z outputs.

6

Outline of Operation

• This function lets you set the output timing for the brake interlock (BKIR) signal that activates the holding brake when the servo is turned ON, an alarm generates, or the servo is turned OFF.

Parameters Requiring Settings


Parameter number	Parameter name	Explanation	Reference
Pn437	Brake Timing when Stopped	Set the time after a servo OFF command is issued upon servo lock stop, until the brake interlock output (BKIR) signal turns OFF and power supply stops.	P.8-45
Pn438	Brake Timing During Operation	Set the time after a servo OFF command is issued while the motor is rotating, until the brake interlock output (BKIR) turns OFF and power supply stops. If the speed drops to the speed set inPn439 or below before the time set here elapses, BKIR will turn OFF.	P.8-45
Pn439	Brake Clear Speed Setting	To set the speed threshold for run time mechanical brake output determination.	P.8-46

Precautions for Correct Use of Holding Brake

- The brake on a Servomotor with a brake is a normally closed brake designed only to hold when the operation is stopped.
 - Accordingly, set an appropriate time so that the brake actuates after the motor stops.
- If the brake is engaged while the Servomotor is rotating, the brake disc will wear abnormally or sustain damage, resulting in a bearing or encoder failure in the Servomotor.

Operation

Servo ON/OFF Operation Timings < when Motor Is Stopped>



*1. The servo does not turn ON until the motor rotation speed drops to approx. 30 r/min or below.

*2. The dynamic brake operation when the servo is OFF depends on Stop Selection with Servo OFF (Pn506).


*3. The brake interlock (BKIR) signal is output upon a release request from servo control. The BKIR signal is assigned to the general-purpose output (CN1).

Note:The brake application time and release time vary depending on the Servomotor brake. For details, refer to "3-3 Servomotor Specifications" (P.3-59).


Servo ON/OFF Operation Timings < When Motor Is Rotating>

Based on these operation timings, regenerative energy is produced if the motor rotation stops abnormally.

Accordingly, repeated operation cannot be performed. Provide a wait time of at least 10 minutes for the motor to cool down.



- *1. The servo does not turn ON until the motor rotation speed drops to approx. 30 r/min or below.
- *2. The dynamic brake operation when the servo is OFF depends on Stop Selection with Servo OFF (Pn506).
- *3. The brake interlock (BKIR) signal is output upon a release request from servo control. The BKIR signal is assigned to the general-purpose output (CN1).
- *4. "t1" is either the time set for the Brake Timing During Operation (Pn438), or the time needed for the motor speed to drop to speed set in Brake Release Speed Setting (Pn439) or below, whichever comes first.
- Note: Even when the servo ON input is turned ON again while the motor is decelerating, the system does not enter the servo ON state until the motor stops.



Operation Timings when Alarm Generates (Servo ON)

*1. The dynamic brake operation when an alarm generates depends on Stop Selection with Servo OFF (Pn506).


*2. "t1" is either the time set for the Brake Timing During Operation (Pn438), or the time needed for the motor speed to drop to speed set in Brake Release Speed Setting (Pn439) or below, whichever comes first.

Note 1.Even when the servo ON input is turned ON again while the motor is decelerating, the system does not enter the servo ON state until the motor stops. The BKIR signal is assigned to the general-purpose output (CN1).

Note 2.If the main circuit power supply turns OFF while the motor is operating, a phase loss alarm or main circuit voltage low alarm will occur, in which case this operation timing will be applied.

Operation Timings at Alarm Reset

Reset alarms by turning OFF the power supply and then turning it ON again. The alarm reset input recognition time can be changed using Alarm Reset Condition Selection (Pn516). The default setting is 120 ms.



*1. The servo does not turn ON until the motor rotation speed drops to approx. 30 r/min or below.

*2. The brake interlock (BKIR) signal is output upon a release request from servo control. The BKIR signal is assigned to the general-purpose output (CN1).

Note:After the alarm has been reset, the system enters the servo OFF state (motor not excited). To turn the servo ON, issue a servo ON command again after resetting the alarm, according to the above timings.

6-7 Gain Switching Function

Outline of Operation

- This function switches the position loop and speed loop gain.
- Select enable or disable using Gain Switching Input Operating Mode Selection (Pn114). Set the switching condition using the gain switching setting.
- If the load inertia changes or you want to change the responsiveness depending on whether the motor is stopping and operating, you can perform optimal control by using gain switching.
- Use gain switching when the realtime autotuning does not work effectively, etc. (See below.)
 - When the load inertia fluctuates in 200 ms or less.
 - When the motor rotation speed does not exceed 500 r/min, or load torque does not exceed 50% of the rated torque.
 - When an external force is constantly applied, as with a vertical axis.
- Note. When Gain 2 has been selected, realtime autotuning does not operate normally. If using the gain switching, set the Realtime Autotuning to "disabled" (Pn002 = 0).

Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn114	Gain Switching Input Operating Mode Selection	Set whether to enable or disable the gain switching function.	P.8-12
Position Con	trol Mode		
Pn115	Switching Mode in Position Control	Set the condition for switching between Gain 1 and Gain 2.	P.8-13
Pn116	Gain Switching Delay Time in Position Control	Set the time to return from Gain 2 to Gain 1. (Unit: 0.1 ms)	P.8-14
Pn117	Gain Switching Level in Position Control	Set the judgment level for switching between Gain 1 and Gain 2.	P.8-15
Pn118	Gain Switching Hysteresis in Position Control	Set the hysteresis width to be provided in the judgment level set in Gain Switching Level (Pn117).	P.8-15
Pn119	Position Gain Switching Time	Set the number of phased switches from low to high gain. (Unit: 0.1 ms)	P.8-15
Speed Contro	ol mode		
Pn120	Switching Mode in Speed Control	Set the condition for switching between Gain 1 and Gain 2.	P.8-16
Pn121	Gain Switching Delay Time in Speed Control	Set the time to return from Gain 2 to Gain 1. (Unit: 0.1 ms)	P.8-17
Pn122	Gain Switching Level in Speed Control	Set the judgment level for switching between Gain 1 and Gain 2.	P.8-17
Pn123	Gain Switching Hysteresis in Speed Control	Set the hysteresis width to be provided in the judgment level set in Gain Switching Level (Pn122).	P.8-18

Torque Control Mode

Pn124	Switching Mode in Torque Control	Set the condition for switching between Gain 1 and Gain 2.	P.8-18
Pn125	Gain Switching Delay Time in Torque Control	Set the time to return from Gain 2 to Gain 1. (Unit: 0.1 ms)	P.8-19
Pn126	Gain Switching Level in Torque Control	Set the judgment level for switching between Gain 1 and Gain 2.	P.8-19
Pn127	Gain Switching Hysteresis in Torque Control	Set the hysteresis width to be provided in the judgment level set in Gain Switching Level (Pn126).	P.8-19

Diagrams of Gain Switching Setting


Switching between Gain 1 (Pn100 to Pn104) and Gain 2 (Pn105 to Pn109) occurs at the following times. Take note that, in the case of position loop gains, switching occurs based on the setting of Pn119.

For the details of each gain, refer to "Chapter 8, Parameter Details".

The details of the gain switching setting vary depending on the control mode used. For the details of settings available in each mode, refer to "Gain Switching Setting for Each Control Mode" (P.6-30).

Gain Switching Mode = 2: Gain Switching (GSEL)

The gain is switched instantly when a gain switching command is issued by external input.




Gain Switching Mode = 3: Switching by Torque Command Change Amount


Torque command change amount (angular acceleration and deceleration speed command) is set in units of 0.05%/166 $\mu s.$

If the amount of change fluctuates and the switching time is not met, the switching will be cancelled.

In the case of switching due to a change amount of 4% over 2 ms, a value of approx. 6 will apply. (Change of 0.33% per 166 μ s.)




Gain Switching Mode = 5 or 9: Switching by Speed Command or Actual Motor Speed




Gain Switching Mode (Pn031) = 6: Switching by Amount of Position Error

Gain switching is performed based on the accumulated count in the error counter.




Gain Switching Mode = 7: Switching by Position Command Received

Gain switching is performed when a position command corresponding to 1 command unit or more is received.



Gain Switching Mode = 8: Switching by Positioning Completion Signal OFF


Switching to the gain 2 is performed when the error counter accumulated pulse exceeds the Positioning Completion Range 1 (Pn431).



Gain Switching Mode = 10: Switching by Combination of Position Command Received and Speed

Switching to the gain 2 occurs when a position command is received.

If no position command is issued for the period of Gain Switching Delay Time in Speed Control (Pn121) and the speed also becomes the same as or less than the result of Gain Switching Level (Pn122) - Gain Switching Hysteresis (Pn123) [r/min], switching to the gain 1 will occur.



Timing for Position Gain Switching Time (Pn119)


You can suppress rapid increases in the position loop gain during position control when there is a large difference between Position Loop Gain 1 (Pn100) and Position Loop Gain 2 (Pn105). When the position loop gain increases, it will be changed over the specified time.

Position Gain Switching Time

The Position Gain Switching Time (Pn119) can be set to reduce torque variations and vibration caused by a rapid increase in the position loop gain that can occur when the gain is switched during position control or fully closed control.

Precautions for Correct Use

 When the position loop gain is switched to a smaller value, the setting of this parameter will be ignored and the gain will be switched immediately.
 Example Gain 1 (Pn100) > Gain 2 (Pn105)



Gain Switching Setting for Each Control Mode

The settable switching conditions vary depending on the control mode used. Set the parameters for each control mode.

Position Control Mode

In the Position Control Mode, it varies as follows according to gain switching mode in Position Control (Pn115).

($\sqrt{:}$ Enabled, -: Disabled)

Pn115 set value	Switching conditions	Gain Switching Delay Time (Pn116)	Gain Switching Level (Pn117)	Gain Switching Hysteresis (Pn118)	Position Gain Switching Time (Pn119)
0	Always gain 1	-	-	-	-
1	Always gain 2	-	-	-	-
2	Switching from gain switching (GSEL)	-	-	-	\checkmark
3	Torque command change amount	\checkmark	√ [× 0.05%]	√ [× 0.05%]	\checkmark
4	Always gain 1	-	-	-	-
5	Command speed	\checkmark	√ [r/min]	√ [r/min]	\checkmark
6	Amount of position error	\checkmark	√ [pulse]	√ [pulse]	\checkmark
7	Position command received		-	-	
8	Positioning completion signal (INP1) OFF	\checkmark	-	-	\checkmark
9	Actual motor speed	\checkmark	√ [r/min]	√ [r/min]	\checkmark
10	Combination of position command received and speed	\checkmark	\checkmark	\checkmark	\checkmark

Speed Control Mode

In the Speed Control Mode, it varies as follows according to switching mode in Speed Control (Pn120).

($\sqrt{:}$ Enabled, -: Disabled)

Pn120 set value	Switching conditions	Gain Switching Delay Time (Pn121)	Gain Switching Level (Pn122)	Gain Switching Hysteresis (Pn123)
0	Always gain 1	_	_	_
1	Always gain 2	-	-	-
2	Switching from gain switching (GSEL)	-	-	-
3	Torque command change amount	\checkmark	√ [× 0.05%]	√ [× 0.05%]
4	Amount of change in speed command	-	-	-
5	Speed command	\checkmark	√ [r/min]	√ [r/min]

Torque Control Mode

In the Torque Control Mode, it varies as follows according to switching mode in Torque Control (Pn124).

($\sqrt{:}$ Enabled, -: Disabled)

Pn124 set value	Switching conditions	Gain Switching Delay Time (Pn125)	Gain Switching Level (Pn126)	Gain Switching Hysteresis (Pn127)
0	Always Gain 1	_	_	-
1	Always Gain 2	-	-	-
2	Switching from gain switching (GSEL)	-	-	-
3	Torque command change amount	\checkmark	√ [× 0.05%]	√ [× 0.05%]

6-8 Torque Limit

Outline of Operation

- The output torque by the Servomotor can be limited.
- This function is used in the following conditions.
 - When push-motion operation, such as pressing, is performed.
 - When the torque at startup and during deceleration should be suppressed to protect the mechanical system, etc.
- Various methods are available according to Torque Control Selection (Pn521).

Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn521	Torque Limit Selection	Select the torque limit based on the various parameters and input signals.	P.8-56
Pn013	No. 1 Torque Limit	Set the No. 1 motor output torque limit value.	P.8-7
Pn522	No. 2 Torque Limit	Set the No. 2 motor output torque limit value.	P.8-56
Pn523	Torque Limit Switching Setting 1	Set the rate of change (fluctuate) when switching from the No. 1 torque limit to No. 2 torque limit.	P.8-57
Pn524	Torque Limit Switching Setting 2	Set the rate of change (fluctuate) when switching from the No. 2 torque limit to No. 1 torque limit.	P.8-57
Pn525	Forward External Torque Limit	Set the forward torque limit for a network signal.	P.8-57
Pn526	Reverse External Torque Limit	Set the reverse torque limit for a network signal.	P.8-57
Pn527	Analog Torque Limit Scale	Set the gain for conversion for the analog torque limit input.	P.8-57
Pn425	Analog Input 2 Offset	Set the offset adjustment value for the voltage applied to analog input 2.	P.8-41
Pn426	Analog Input 2 Filter Time Constant	Set the time constant of the first-order lag filter for the voltage applied to analog input 2.	P.8-41
Pn428	Analog Input 3 Offset	Set the offset adjustment value for the voltage applied to analog input 3.	P.8-42
Pn429	Analog Input 3 Filter Time Constant	Set the time constant of the first-order lag filter for the voltage applied to analog input 3.	P.8-42

Torque Limit in Position, Speed and Fully-Closed Controls

Pn521 set value	Explanation
0	Forward operation: Set by PCL (0 to 10 V) Reverse operation: Set by NCL (-10 to 0 V)
1	Limit in both forward and reverse operation: Set by Pn013
2	Forward operation: Set by Pn013 Reverse operation: Set by Pn522
3	Switch the limit value using torque limit switching (TLSEL). When TLSEL is OFF Limit in both forward and reverse operation: Pn013 When TLSEL is ON Limit in both forward and reverse operation: Pn522
4	Forward operation: Set by PCL (0 to 10 V) Reverse operation: Set by NCL (0 to 10 V)
5	Limit in both forward and reverse operation: Set by PCL (0 to 10 V)
6	Switch the limit value using torque limit switching (TLSEL). When TLSEL is OFF Forward operation: Pn013 Reverse operation: Pn522 When TLSEL is ON Forward operation: Pn525 Reverse operation: Pn526

• For the torque limit in torque control, always select No. 1 Torque Limit (Pn013).

• The torque limit under torque feed-forward selection is enable only during speed control when the set value is 1 to 3.

• PCL signal is assigned to the terminal 16 in CN1. For details, refer to "Torque Command Input 2 (TREF2) and Forward Torque Limit Input (PCL)" (P. 3-37).

• NCL signal is assigned to the terminal 18 in CN1. For details, refer to "Reverse Torque Limit Input (NCL)" (P. 3-37).

Rate of Change Setting at Switching (Pn521 = 3)


If 3 is set in Torque Limit Selection (Pn521), you can add fluctuate the change at the time of switching. This function is disabled in any other setting.

How to Set Rate of Change (Fluctuate)

Set the parameter according to the switching type.

- From No. 1 torque limit to No. 2 torque limit: Pn523
- From No. 2 torque limit to No. 1 torque limit: Pn524

The sign of the rate of change switches automatically inside the drive based on the magnitude correlation of the No. 1 torque limit and No. 2 torque limit.



If the setting of No. 1 Torque Limit (Pn013) or No. 2 Torque Limit (Pn522) is changed from the front panel or CX-Drive, the rate of change setting will be ignored and the new torque limit value will be applied immediately.

Torque Limit Settings by Servomotors

• The torque limit setting range is between 0% and 300%. The default setting is 300%. This is not the case when a Servo Drive and a Servomotor are used in the following combinations.

Servo Drive	Applicable Servomotor	Maximum torque limit [%]
R88D-KT15	R88M-K90010	225
R88D-KT30	R88M-K2K010	250
R88D-KT50	R88M-K3K010	250
	R88M-K4K510	263
R88D-KT75	R88M-K6K010	272
R88D-KT75H	R88M-K7K515T	265
R88D-KT75F	R88M-K7K515C	267
R88D-KT150	R88M-K11K015	265
	R88M-K15K015	253

6-9 Sequence I/O Signal

Outline of Operation

- You can set sequences in various operating conditions.
- For the connection of I/O signals and processing of external signals, refer to "Control I/O Connector Specifications (CN1)" (P.3-18).

Input Signals

You can allocate any function of input signals to the input pins for the control I/O connector (CN1). In addition, you can change logic. However, refer to "Input Signal Allocation Method" (P.6-36) for more information because some signals have allocation limitations.

If a G-series Servo Drive is being replaced with a G5-series Servo Drive, use the G5-series Servo Drive with the default settings.

Input Signal Default Setting

The allocations of the default input signals are as follows. Refer to "Input Signal Allocation Method" when you change the allocation to use.

				Default setting state					
Applicable parameters	Input signals	Factory default setting (hex)	fully-c	Position control or fully-closed control		Speed control		Torque control	
			Signal name	Logic	Signal name	Logic	Signal name	Logic	
Pn400	SI1 input	00828282h (8553090)	NOT	NC	NOT	NC	NOT	NC	
Pn401	SI2 input	00818181h (8487297)	POT	NC	POT	NC	POT	NC	
Pn402	SI3 input	0091910Ah (9539850)	DFSEL1	NO	VZERO	NC	VZERO	NC	
Pn403	SI4 input	00060606h (394758)	GSEL	NO	GSEL	NO	GSEL	NO	
Pn404	SI5 input	0000100Ch (4108)	GESEL1	NO	VSEL3	NO	_	-	
Pn405	SI6 input	00030303h (197379)	RUN	NO	RUN	NO	RUN	NO	
Pn406	SI7 input	00000f07h (3847)	ECRST	NO	VSEL2	NO	_	-	
Pn407	SI8 input	00040404h (263172)	RESET	NO	RESET	NO	RESET	NO	
Pn408	SI9 input	00050505h (328965)	TVSEL	NO	TVSEL	NO	TVSEL	NO	
Pn409	SI10 input	00000E88h (3720)	IPG	NC	VSEL1	NO	_	_	

Contacts NO and NC in the logic fields indicate the following statuses.

- NO: Disabled (OFF) when signal input is open with COM– Enabled (ON) when signal input is shorted with COM–
- NC: Disabled (OFF) when signal input is shorted with COM– Enabled (ON) when signal input is open with COM–
- "-" indicates the status where no function is allocated.

Parameters that Can Be Allocated

Use the following parameters when changing the input signal allocation to use. For the setting method, refer to "Input Signal Allocation Method".

Parameter number	Parameter name	Explanation	Reference
Pn400	Input Signal Selection 1	Set the SI1 input function allocation. This parameter is based on the hex display standard. (The display on the front panel is based on decimal.)	P.8-37
Pn401	Input Signal Selection 2	Set the SI2 input function allocation.	P.8-37
Pn402	Input Signal Selection 3	Set the SI3 input function allocation.	P.8-37
Pn403	Input Signal Selection 4	Set the SI4 input function allocation.	P.8-37
Pn404	Input Signal Selection 5	Set the SI5 input function allocation.	P.8-37
Pn405	Input Signal Selection 6	Set the SI6 input function allocation.	P.8-37
Pn406	Input Signal Selection 7	Set the SI7 input function allocation.	P.8-37
Pn407	Input Signal Selection 8	Set the SI8 input function allocation.	P.8-37
Pn408	Input Signal Selection 9	Set the SI9 input function allocation.	P.8-37
Pn409	Input Signal Selection 10	Set the SI10 input function allocation.	P.8-37


Input Signal Allocation Method

Input the setting for each control mode in any of the parameters of Pn400 to Pn409 to allocate signals.

Set the parameters based on the hex display standard.


Set the set value of the function for each control mode in "**" below.

Refer to the function number table provided below for the set value of each function. The logic setting is included in the function numbers.



Example:

Position control or fully-closed control:Electronic gear switching input 1 for contact NO (0Ch)Speed control:Internally set speed selection 1 for contact NC (8Eh)Torque control:Disabled (00h)



This will be 36364 since the front panel display is in decimal numbers.

Function Number Table

The set values to be used for allocations are as follows:

Signal name	Symbol	Set value			
Signal name	Symbol	NO	NC		
Disabled	-	00h	Setting not available		
Forward drive prohibition input	POT	01h	81h		
Reverse drive prohibition input	NOT	02h	82h		
Operation command ^{*1}	RUN	03h	83h		
Alarm reset input	RESET	04h	Setting not available		
Control mode switching input	TVSEL	05h	85h		
Gain switching	GSEL	06h	86h		
Error counter reset input *2	ECRST	07h	Setting not available		
Pulse prohibition input *3	IPG	08h	88h		
Torque limit switching	TLSEL	09h	89h		
Damping filter switching 1	DFSEL1	0Ah	8Ah		
Damping filter switching 2	DFSEL2	0Bh	8Bh		
Electronic gear switching input 1	GESEL1	0Ch	8Ch		
Electronic gear switching input 2	GESEL2	0Dh	8Dh		
Internally set speed selection 1	VSEL1	0Eh	8Eh		
Internally set speed selection 2	VSEL2	0Fh	8Fh		
Internally set speed selection 3	VSEL3	10h	90h		
Zero speed designation input	VZERO	11h	91h		
Speed command sign input	VSIGN	12h	92h		
Torque command sign input	TSIGN	13h	93h		
Emergency stop input	STOP	14h	94h		
Inertia ratio switching input	J-SEL	15h	95h		

*1 The operation command (RUN) always needs to be allocated. Servo cannot be turned ON if it is not allocated.

*2 Allocate this to Input Signal Selection 7 (Pn406). An alarm will occur if it is allocated to anything other than that.

*3 Allocate this to Input Signal Selection 10 (Pn409). An alarm will occur if it is allocated to anything other than that.

Precautions for Correct Use

• Do not use any values other than the settings listed.

- If you allocate the same function to multiple input signals, interface input duplicate allocation error 1 (Alarm 33.0) or interface input duplicate allocation error 2 (Alarm 33.1) will occur.
- You can allocate error counter reset input (ECRST) to Input Signal Selection 7 (Pn406) only. If you allocate it to anything other than that, a counter reset allocation error (Alarm 33.6) will occur.
- You can allocate pulse prohibition input (IPG) to Input Signal Selection 10 (Pn409) only. If you allocate it to anything other than that, a command pulse prohibition input allocation error (Alarm 33.7) will occur.
- If you are using the control mode switching input (TVSEL), you must set it for all control mode. If you do not set it for all control mode, interface input function number error 1 (Alarm 33.2) or interface input function number error 2 (Alarm 33.3) will occur.
- If you set Zero Speed Designation Selection (Pn315) to 2 or 3, you must always allocate zero speed designation input (VZERO) in speed control for the same pin where zero speed designation input (VZERO) is allocated for speed control. In addition, specify the same settings for the logic.
- Be sure to allocate the functions that are used by multiple control mode (such as operation command and alarm reset input) to the same pin, and do the same for the logic. If this is not set correctly, interface input duplicate allocation error 1 (Alarm 33.0) or interface input duplicate allocation error 2 (Alarm 33.1) will occur.
- You must always allocate the operation command (RUN). Servo cannot be turned ON if it is not allocated.

Output Signals

You can allocate output signal functions to the output pins for the control I/O connector (CN1). If a G-series Servo Drive is being replaced with a G5-series Servo Drive, use the G5-series Servo Drive with the default settings.

Output Signal Default Setting

The allocations of the default output signals are as follows. Refer to "Output Signal Allocation Method" when you change the allocation to use.

			Default setting state			
Applicable parameters	Output Signals	Default set value	Position control or fully-closed control	Speed control	Torque control	
			Signal name	Signal name	Signal name	
Pn410	SO1 output	00030303h (197379)	BKIR	BKIR	BKIR	
Pn411	SO2 output	00020202h (131586)	READY	READY	READY	
Pn412	SO3 output	*1	ALM	ALM	ALM	
Pn413	SO4 output	00050504h (328964)	INP	TGON	TGON	

*1 Alarm output signal allocations cannot be changed.

Parameters that Can Be Allocated

Use the following parameters when changing the output signal allocation to use. For the setting method, refer to "Output Signal Allocation Method".

Parameter number	Parameter name	Explanation	Reference
Pn410	Output Signal Selection 1	Set the SO1 output function allocation. This parameter is set in hexadecimal standard. Refer to the output signal function number table for details.	P.8-37
Pn411	Output Signal Selection 2	Set the SO2 output function allocation.	P.8-37
Pn412	Output Signal Selection 3	Set the SO3 output function allocation. This parameter is always fixed to the alarm output signals.	P.8-37
Pn413	Output Signal Selection 4	Set the SO4 output function allocation.	P.8-37


Output Signal Allocation Method

Input the setting for each control mode in any of the parameters of Pn410 to Pn413 to allocate signals.


Set up the parameters based on the hex display standard in the same manner as the input signal allocation method.

Set the set value of the function for each control mode in "**" below.

Refer to the function number table provided below for the set value of each function. The logic setting is included in the function numbers.



Example:Position control or fully-closed control:Speed conformity output (08h)Speed control:Motor rotation speed detection output (05h)Torque control:Zero speed detection signal (07h)



This will be 460040 since the front panel display is in decimal numbers.

Function Number Table

The set values to be used for allocations are as follows:

Signal name	Symbol	Set value
Disabled	-	00h
Servo ready completed output	READY	02h
Brake interlock output	BKIR	03h
Positioning completion output	INP	04h
Motor rotation speed detection output	TGON	05h
Torque limiting signal	TLC	06h
Zero speed detection output	ZSP	07h
Speed conformity output	VCMP	08h
Warning output 1	WARN1	09h
Warning output 2	WARN2	0Ah
Position command status output	P-CMD	0Bh
Positioning completion output 2	INP2	0Ch
Output during speed limit	V-LIMIT	0Dh
Alarm attribute output	ALM-ATB	0Eh
Speed command status output	V-CMD	0Fh



Precautions for Correct Use

- Do not use any values other than the settings listed.
- You can allocate the same function to more than one output signal.
- You cannot change the output signal logic. When the function is disabled (OFF), signal input is open with COM–, and when the function is enabled (ON), signal input is shorted with COM–.

6-10 Forward and Reverse Drive Prohibition Functions

Outline of Operation

- When the forward drive prohibition input (POT) and the reverse drive prohibition input (NOT) are turned OFF, the motor will stop rotating.
- You can stop the motor from rotating beyond the device's operating range by connecting limit inputs.

Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn400 to Pn409	Input Signal Selection 1 to 10	Set the input signal allocations and logic. In the default settings, the allocations are as follows. Pn400 (CN1 - pin 8): NOT (Logic contact NC) Pn401 (CN1 - pin 9): POT (Logic contact NC)	
Pn504	Drive Prohibition Input Selection	Set the operation to be performed upon forward and reverse drive prohibition input.	
Pn505	Stop Selection for Drive Prohibition Input	Set the deceleration and stop methods upon forward and reverse drive prohibition input.	

Input Signal Selection Function (Default setting: Pn400, Pn401)

In the default setting, the allocations are as follows.

		Default setting				
Parameter number	Parameter name	Set value	Position Control or fully-closed control	Speed control	Torque control	
Pn400	Input Signal Selection 1	00828282h (8553090)	NOT (NC)	NOT (NC)	NOT (NC)	
Pn401	Input Signal Selection 2	00818181h (8487297)	POT (NC)	POT (NC)	POT (NC)	

• Refer to "6-9 Sequence I/O Signal" (P.6-35) for details on input signal selections 1 to 10.

Drive Prohibition Input Selection (Pn504)

Install limit switches at both ends of the axis to prohibit the Servomotor from driving in the direction specified by the switch. This can be used to prevent the workpiece from driving too far and thus prevent damage to the machine. Set the operation to be performed upon forward and reverse drive prohibition input.

Drive Prohibition Input Selection (Pn504)	Explanation
0	 Forward drive prohibition input and reverse drive prohibition input enabled. The operation when a signal is input is as follows. Forward drive prohibition input closed: Forward limit switch not operating and status normal. Forward drive prohibition input closed: Reverse limit switch not operating and status normal. Reverse drive prohibition input closed: Reverse limit switch not operating and status normal. Reverse drive prohibition input closed: Reverse limit switch not operating and status normal. Reverse drive prohibition input open: Reverse direction prohibited and forward direction permitted. The Servomotor will decelerate and stop according to the sequence set in Stop Selection for Drive Prohibition Input (Pn505). For details, refer to explanation for Stop Selection for Drive Prohibition Input (Pn505). If the forward and the reverse prohibition inputs are both open, a drive prohibition input error 1 (Alarm 38.0) occurs because it is taken that Servo Drive is in error condition.
1	Forward and reverse drive prohibition input disabled.
2	Forward and reverse drive prohibition input enabled. If either the forward or the reverse prohibition input is open, a drive prohibition input error (Alarm 38.0) occurs.


Precautions for Correct Use

Drive Prohibition Input Selection (Pn504) is set to 1 (disabled) in the default settings. If prohibiting the drive input is required, set the Drive Prohibit Input Selection (Pn504) to either 0 or 2. The setting on the Input Signal Selection 1 to 10 (Pn400 to Pn409) can change the logic and allocation for the respective Input terminals (CN1 to 8, 9 and 26 to 33).

Stop Selection for Drive Prohibition Input (Pn505)

Stop Selection for Drive Prohibition Input (Pn505)	Deceleration method	After stopping	Error counter
0	Dynamic brake	Torque command in drive- prohibited direction = 0	Held
1	Free-run (Torque command = 0 for drive prohibition direction)	Torque command in drive- prohibited direction = 0	Held
2	Immediate stop	Servo lock	Clear before and after deceleration.

Set the deceleration and stop methods upon a forward or reverse drive prohibition input.



While the Forward Drive Prohibition Input (POT) is OFF, the Servomotor cannot be driven in the forward direction, but it can be driven in the reverse direction. Conversely, while the reverse drive prohibition input (NOT) is OFF, the Servomotor cannot be driven in the reverse direction, but it can be driven in the forward direction.

If immediate stop torque is set for deceleration and servo lock is set for stop (set value: 2), torque limit during deceleration will be limited with the set value of the Immediate Stop Torque (Pn511).

rkh

Precautions for Correct Use

- A load on the vertical axis and so forth may fall due to its own weight in the drive prohibition input state. To prevent the load from falling, set emergency stop torque for deceleration and servo lock for stop (set value: 2) in Stop Selection for Drive Prohibition Input (Pn505), or limit the operation using the Host Controller rather than using this function.
- Because an immediate stop will force the motor to decelerate quickly, the position error will momentarily be a large value during position control, and Alarm 24.0 "error counter overflow" or Alarm 34.0 "overrun limit error" may occur. In such a case, set the Position Counter Overflow Level (Pn014) and the Overrun Limit Setting (Pn514) to appropriate values.


6-11 Disturbance Observer Function

Outline of Operation

You can lower the effect of the disturbance torque and reduce vibration by using the estimated disturbance torque value.

You can use the disturbance observer in the following situations for position control or speed control.

- When servo is ON
- When there is no trouble with the motor's normal rotation
- When realtime autotuning function is disabled
- · When instantaneous speed observer function is disabled



• If there is a resonance point below the cut-off frequency estimated by the disturbance observer or if a large amount of high-frequency elements is found in the disturbance torque, the disturbance observer may not be effective.

Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn610	Function Expansion Setting	Set the bits related to the disturbance observer.	P.8-60
Pn623	Disturbance Torque Compensation Gain	Set the compensation gain for the disturbance torque.	P.8-63
Pn624	Disturbance Observer Filter Setting	Set the filter time constant for disturbance torque compensation.	P.8-63

Operating Procedure

1. Set the Function Expansion Setting (Pn610).

Set whether to enable or disable the disturbance observer in bit 1.

0: Disabled

1: Enabled

Set the operating conditions to be enabled in bit 2.

- 0: Enabled at all time
- 1: Enabled only when gain 1 is selected

2. Set the Disturbance Observer Filter Setting (Pn624).

Set Disturbance Torque Compensation Gain (Pn623) to a small value, and then change the value of Disturbance Observer Filter Setting (Pn624) from a large value to a small value. And set to the set value in which the effectiveness of suppressing the impact of disturbance and the operating noise level are balanced.

3. Set the Disturbance Torque Compensation Gain (Pn623).

Change the value of Disturbance Torque Compensation Gain (Pn623) from a small value to a large value. And set to the set value in which the effectiveness of suppressing the impact of disturbance and the operating noise level are balanced.

6-12 Gain Switching 3 Function

Outline of Operation

You can newly set gain 3 right before stopping to the gain switching function of Gain Switching Input Operating Mode Selection (Pn114).

You can use the gain 3 switching function in the following situations for position control or fullyclosed control.

- When servo is ON
- · When there is no trouble with the motor's normal rotation


Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn605	Gain 3 Effective Time	Set effective time of gain 3.	P.8-60
Pn606	Gain 3 Ratio Setting	Set gain 3 as a multiple of gain 1.	P.8-60

Operation

Operation Timings of Gain 1, 2 and 3

Example: When the switching mode in position control = 7 and the switching condition is set to position command received



The gain 1 value is used for the speed loop integral time constant, speed feedback filter time constant, and torque command filter time constant.

Precautions for Correct Use

- If gain 3 is not used, set the Gain 3 Effective Time (Pn605) to 0 and Gain 3 Ratio Setting (Pn606) to 0.
- In the gain 3 region, only the position loop gain and the speed loop gain are treated as gain 3, and the gain 1 setting is applied for all other gains.
- If the gain 2 switching condition is established in the gain 3 region, operation switches to gain 2.
- If gain 2 is switching to gain 3, Position Gain Switching Time (Pn119) is enabled.
- Take note that there will be a gain 3 region even when gain 2 is switched to gain 1 due to a parameter change and so forth.

6-13 Friction Torque Compensation Function

Outline of Operation

As a function to reduce the effect of friction, you can set the unbalanced load compensation that always compensates the constantly working offset torque, and the dynamic friction compensation that changes its direction depending on the operating direction. You can use the function under the following conditions:


- When Servo is ON
- + When there is no trouble with the motor's normal rotation

Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn607	Torque Command Value Offset	Set the unbalanced load compensation value that is always added to the torque command in the control mode other than torque control.	P.8-60
Pn608	Forward Direction Torque Offset	Set the dynamic friction compensation value that is added to the torque command when a forward direction position command is input for position control or fully-closed control.	P.8-60
Pn609	Reverse Direction Torque Offset	Set the dynamic friction compensation value that is added to the torque command when a reverse direction position command is input for position control or fully-closed control.	P.8-60

Operation Example

Torque Command Value Offset (Pn607) reduces the variations of positioning operations due to the movement directions when a certain amount of unbalanced load torque is always applied to the motor at the vertical axis and so forth if that torque command value is set. Forward Direction Torque Offset (Pn608) and Reverse Direction Torque Offset (Pn609) are used with loads that require a large amount of dynamic friction torque due to the radial load, such as the belt drive axis. By setting the friction torque for each rotation direction for all parameters, you can reduce the deterioration and inconsistencies of positioning stabilization time due to dynamic friction.



Precautions for Correct Use

You can use the unbalanced load compensation and the dynamic friction compensation together or separately. Take note that the following use limit is applied upon control mode switching or servo ON.

- During torque control
 - The unbalanced load compensation and the dynamic friction compensation are 0 regardless of the parameter setting.
- When servo is OFF during speed control
 - The load compensation is enabled based on Pn607 when the servo is turned OFF. The dynamic friction compensation will be 0 regardless of the parameter setting.
- When the servo is turned ON during position control or fully-closed control
 - The unbalanced load compensation and the dynamic friction compensation values are held until the first position command is input. When the position command is input, the unbalanced load compensation will be updated based on Pn607. Also, based on the command direction, the dynamic friction compensation value will be updated according to parameters Pn608 or Pn609.

6-14 Inertia Ratio Switching Function

Outline of Operation

You can switch the inertia ratio from 1 or 2 using inertia ratio switching input (JSEL). This functions effectively if used when the load inertia changes in 2 levels. You can use inertia ratio switching in the following situations.

- When Servo is ON
- When there is no trouble with the motor's normal rotation
- · When realtime autotuning is disabled
- When adaptive filter function is disabled
- · When instantaneous speed observer function is disabled
- When disturbance observer function is disabled

Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn610	Function Expansion Setting	Set the bits related to inertia ratio switching.	P.8-60
Pn004	Inertia Ratio	Set the inertia ratio 1.	P.8-3
Pn613	Inertia Ratio 2	Set the inertia ratio 2.	P.8-61

Operating Procedure

1. Set the Function Expansion Setting (Pn610).

Set whether to enable or disable inertia ratio switching in bit 3. 0: Disabled 1: Enabled

- 2. Set the Inertia Ratio 1 (Pn004).
- 3. Set the Inertia Ratio 2 (Pn613).
- 4. Set the inertia ratio switching input (JSEL).

Function Expansion Setting (Pn610)	Inertia ratio switching input (JSEL)	Applicable inertia ratio
When bit 3 = 0: Inertia ratio switching is disabled	OFF	
	ON	Inertia Ratio 1 (Pn004)
When bit 3 = 1: Inertia ratio	OFF	
switching is enabled	ON	Inertia Ratio 2 (Pn613)

Precautions for Correct Use

- Be sure that the motor is stopped when using the inertia ratio switching function.
- If the difference between inertia ratio 1 and inertia ratio 2 is large, a vibration may occur even if the motor is stopped. Use it upon confirming that there is no problem with vibration on the actual machine.

Applied Functions

6-15 Hybrid Vibration Suppression Function

Outline of Operation

This function suppresses the vibration that is caused by the amount of the torsion between the motor and the load in the Fully-closed Control Mode. You can use this function to raise the gain setting.

The hybrid vibration suppression function can be used in the following situations.

- Fully-closed Control Mode
- When Servo is ON
- · When there is no trouble with the motor's normal rotation

Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference
Pn634	Hybrid Vibration Suppression Gain	Set the hybrid vibration suppression gain. In general, set it to the same value as the position loop gain, and finely adjust it based on the situation.	P.8-66
Pn635	Hybrid Vibration Suppression Filter	Set the hybrid vibration suppression filter.	P.8-66

Operating Procedure

- 1. Set the Hybrid Vibration Suppression Gain (Pn634) to the same value as the position loop gain.
- 2. Gradually increase the set value of the Hybrid Vibration Suppression Filter (Pn635) while driving with fully-closed control and check the changes in the response. If the response improves, find the combination of Pn634 and Pn635 that result in the optimal response by adjusting them.

Precautions for Correct Use

• This function is effective when the amount of torsion between the motor shaft and the load is large. It may be less effective when the amount of torsion is small.

6-16 Feed-forward Function

Outline of Operation

The feed-forward function come in 2 types: speed feed-forward and torque feed-forward. The speed feed forward can minimize the position error and increase the responsiveness by calculating the speed control command that is required for the operation based on the internal positioning command during position or fully-closed control, and adding it to the speed command that is calculated based on the comparison with the position feedback. The torque feed forward can increase the responsiveness during speed control by calculating

the torque command that is required for the operation based on the speed control command, and adding it to the torque command that is calculated based on the comparison with the speed feedback.

Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference	
Pn110	Speed Feed-forward Amount	Use this parameter to add the speed control command calculated from the internal positioning command that is multiplied by this parameter's ratio to the speed command from the position control process.	P.8-12	
Pn111	Speed Feed-forward Command Filter	Set the time constant for the first-order lag filter that is applied to speed feed-forward input.	P.8-12	
Pn112	Torque Feed-forward Amount	Use this parameter to add the torque command calculated from the speed control command that is multiplied by this parameter's ratio to the torque command from the speed control process.	P.8-12	
Pn113	Torque Feed-forward Command Filter	Set the time constant for the first-order lag filter that is applied to torque feed-forward input.	P.8-12	
Pn600	Analog Torque Feed- forward Gain Setting	Set the input gain of analog torque feed-forward. 0 to 9 will be disabled.	P.8-60	
Pn610	Function Expansion Setting	Set the bits related to inertia ratio switching.	P.8-60	

Operating Procedure

Speed Feed-forward Operating Method


- **1. Set the Speed Feed-forward Command Filter (Pn111).** Set it to approx. 50 (0.5 ms).
- 2. Adjust the Speed Feed-forward Amount (Pn110).

Gradually increase the value of Speed Feed-forward Amount (Pn110) and finely adjust it to avoid overshooting during acceleration/deceleration.

If the speed feed-forward amount is set to 100%, the position error will be 0 in calculation. However, a large overshooting will occur during acceleration/deceleration.

The position error during an operation at a constant speed will decrease based on the following formula according to the speed feed-forward gain value.

Position error [command unit] = command speed [command unit/s] / position loop gain $[1/s] \times (100 - speed feed-forward amount [%]) / 100$



The position error in the range of constant speed becomes smaller as the speed feed-forward gain increases.

Precautions for Correct Use

 The operating noise may increase when the speed feed forward is enabled if the update cycle of the position command input is longer than the Servo Drive's control cycle, or if the pulse frequency is not uniform. Apply the position command filter (first-order lag or FIR smoothing) or increase the speed feed-forward filter setting.

Torque Feed-forward Operating Method

1. Set the Inertia Ratio (Pn004).

Set the inertia ratio as correctly as possible.


- If the inertia ratio is calculated for the selected motor, input the calculated value.
- + If the inertia ratio is not known, perform autotuning and set the inertia ratio.
- 2. Set the Torque Feed-forward Command Filter (Pn113).

Set it to approx. 50 (0.5 ms).

3. Adjust the Torque Feed-forward Amount (Pn112).

Gradually increase the value of Torque Feed-forward Amount (Pn112).

Since the position error during acceleration/deceleration at a certain speed can be brought close to 0, it can be controlled almost to 0 throughout the entire operation range during a trapezoidal speed pattern under ideal conditions where no disturbance torque is working. In reality, disturbance torque is always present and, therefore, the position error cannot be completely 0.



Torque feed-forward can reduce the position error in a range of constant acceleration/ deceleration.

• When operating in position control, this function normally is used together with the speed feedforward.


Precautions for Correct Use

• If you increase the torque feed-forward filter time constant, the operation noise will be reduced. However, the position error where the acceleration changes will become larger.

Application Example of Analog Torque Feed Forward

The analog torque feed forward is enabled when bit 5 of the Function Expansion Setting (Pn610) is set to 1. In addition, if analog input 3 is used by another function (for example, analog torque limit), this function is disabled.

It is converted to torque from the voltage [V] that is applied to analog input 3 based on the Analog Torque Feed-forward Gain Setting (Pn600) and is added to the torque command [%]. The conversion from the input voltage [V] to analog input 3 to a torque command [%] to the motor is performed as illustrated in the graph below. The slope of the graph is when Pn600 = 30.The slope changes based on the Pn600 set value.




6-17 Instantaneous Speed Observer Function

Outline of Operation

Estimating the motor speed using a load inertia increases responsiveness and reduces vibration at stopping and improves the speed detection accuracy. This function can be used for position control.

The instantaneous speed observer function can be used in the following situations.

- When Servo is ON
- · When there is no trouble with the motor's normal rotation
- · When realtime autotuning is disabled



Parameters Requiring Settings

Parameter number	Parameter name	Explanation	Reference	
Pn610	Function Expansion Setting	Set whether to enable or disable the instantaneous observer function.	P.8-60	
Pn004	Inertia Ratio	Set the inertia ratio 1.	P.8-3	
Pn100	Position Loop Gain	Set the position loop gain.	P.8-9	
Pn101	Speed Loop Gain	Set the speed loop gain.	P.8-10	
Pn103	Speed Feedback Fllter Time Constant	Set six filter time constants.	P.8-11	
Pn108	Speed Feedback Fllter Time Constant 2	Set six filter time constants.	P.8-11	

Operating Procedure

1. Set the Inertia Ratio (Pn004).

- Set the inertia ratio as correctly as possible.
- If the Inertia Ratio (Pn004) is requested in a realtime auto gain tuning, use the set value.
- If the inertia ratio is calculated for the selected motor, input the calculated value.
- If the inertia ratio is not known, perform autotuning and set the inertia ratio.

2. Adjust the position loop gain and speed loop gain.

Adjust Position Loop Gain (Pn100), Speed Loop Gain (Pn101), Speed Loop Integral Time Constant (Pn102) and Torque Command Filter Time Constant (Pn104).

If no problem occurs in realtime autotuning, you can continue to use the settings.

3. Set the Function Expansion Setting (Pn610).

Set whether to enable or disable the instantaneous speed observer function in bit 0.

0: Disabled

1: Enabled

If you set this to 1 (enabled), the speed detection method will switch to instantaneous speed observer.

- If the machine operation noise or vibration, or a change in the torque monitor waveform is significant enough to cause any problem, return the setting to 0 and make sure that the inertia ratio or the adjustment parameters are correct.
- If the machine operation noise or vibration, or a change in the torque monitor waveform is small, make small adjustments to the Inertia Ratio (Pn004) to find the setting that makes the smallest change while monitoring the position error waveform and the actual speed waveform.
- If Position Loop Gain (Pn100), Speed Loop Gain (Pn101) or Speed Loop Integral Time Constant (Pn102) is changed, the optimal value for the Inertia Ratio (Pn004) may have changed, so make small adjustments on the value for the Inertia Ratio (Pn004) again to set a value that makes the smallest change.

Precautions for Correct Use

- This function may not function properly or the effect may not be apparent under the following conditions.
 - $\cdot\,$ If the margin of error with the actual device is large for the inertia load
 - · If there are multiple resonance points
 - $\cdot\,$ If there is a large resonance point at a frequency of 300 Hz or lower
 - $\cdot\,$ If there is a non-linear element (play), such as a large backlash
 - If the load inertia changes
 - · If there is a large disturbance torque with high-frequency elements is applied
 - · If the setting range for positioning is small



Safety Function

This function stops the Servomotor based on a signal from a safety controller or safety sensor.

An outline of the function is given together with operation and connection examples.

7-1	Safe Torque OFF (STO) Function	7-1
	Outline of Operation	7-1
	I/O Signal Specifications	7-2
7-2	Operation Example	7-4
7-3	Connection Example	7-6

7-1 Safe Torque OFF (STO) Function

Outline of Operation

The safe torque OFF (hereinafter referred to as STO according to IEC61800-5-2) function is used to cut off the motor current and stop the motor through the input signals from a safety equipment, such as a Safety Controller or safety sensor, that is connected to the safety connector (CN8).

When the STO function is operating, the Servo Drive turns OFF the servo ready completed output (READY) to go into the safety status.

• The PFH value is 2.30×10^{-8} .



Precautions for Safe Use

- When using the STO function, be sure to execute a risk assessment of the equipment to confirm that the system safety requirements are met.
- There are the following risks even when the STO function is operating. Be sure to take safety into account as part of the risk assessment.
 - The motor runs if an external force is present (e.g., force of gravity on a vertical axis). If holding
 is required, implement appropriate measures, such as providing external brakes. The brakes
 for a Servo Drive with brakes are used for the holding purpose only, and cannot be used for
 control.
 - Even if there is no external force, when Stop Selection for Alarm Detection (Pn510) is set to free-run (with the dynamic brake disabled), the motor operates as free-run and the stop distance is long.
 - The motor may operate in the range of up to 180 degrees of electrical angle due to a power transistor trouble and so forth.
 - The power supply to the motor is cut off by the STO function, but the power supply to the Servo Drive will not be cut off nor electrically isolated. For Servo Drive maintenance, cut off the power supply to the Servo Drive through another means.
- The EDM output signal is not a safety output. Do not use the EDM output for any purpose other than the failure monitoring function.
- Be sure to check the wiring when installing. Especially check the following:
 - The wiring is not short-circuited or disconnected.
 - The polarity of EDM circuit is not reversed.
 - SF1, SF2 and EDM operate properly.
- The system with incorrect wiring may damage the safety function.
- The dynamic brake and external brake release signal outputs are not safety-related parts. Make sure to design the equipment so that it is not dangerous even if the external brake release fails during the STO status.
- When using the STO function, connect equipment that meets the safety standards.
- · Following certifications are fulfilled:
 - CAT-3 (EN 954-1, EN/ISO 13849-1)
 - Performance level d (EN/ISO 13849-1)
 - SIL 2 (IEC/EN 62061)

I/O Signal Specifications

Safety Input Signal

There are 2 safety input circuits to operate the STO function.

	Symbol	Pin number	Description		Control mode			
Signal name					Speed	Torque	Fully- closed	
Safety input 1	SF+	CN8-4	• The upper arm drive signal of the power transistor inside the Servo		\checkmark	\checkmark	\checkmark	
	SF-	CN8-3	Drive is cut off.	\checkmark	\checkmark	\checkmark	\checkmark	
Safety input 2	SF2+	CN8-6	The lower arm drive signal of the power transistor inside the Servo	\checkmark	\checkmark	\checkmark	\checkmark	
	SF2-	CN8-5	Drive is cut off.	\checkmark	\checkmark	\checkmark	\checkmark	

• When safety input 1 or 2 turns OFF, the STO function will start operating within 5 ms of the input, and the motor output torque will be reduced to 0.


- Connect the equipment so that the safety input circuit is turned OFF to operate the STO function.
- Use Stop Selection for Alarm Detection (Pn510) to set the operation when the safety input is turned OFF.



Precautions for Correct Use

+ L-pulses for self-diagnosis of safety equipment

When you are connecting a safety device, such as a safety controller or a safety sensor, the safety output signal of the device may include L pulses for self-diagnosis. To avoid malfunction due to the L pulses for self-diagnosis, a filter that removes the L pulses is built into the safety input circuit. If the OFF time of the safety input signal is 1 ms or less, the safety input circuit does not recognize it as OFF. To make sure that OFF is recognized, maintain the OFF status of safety input signal for at least 5 ms.



External Device Monitor (EDM) Output Signal

This is a monitor output signal that is used to monitor the status of safety input signals using an external device.

Connect a safety device, such as a safety controller or a safety sensor. Connect the EDM output signal to the monitoring terminal on a safety device.

Signal name	Symbol	Pin number			Control mode			
			Description	Position	Speed	Torque	Fully- closed	
EDM output	EDM+	CN8-8	 A monitor signal is output to detect a safety function failure. * This is not a safety output. 	\checkmark	\checkmark			
	EDM-	CN8-7		\checkmark	\checkmark	\checkmark		

Relationship Between Safety Input Signals and EDM Output Signal

Normally when both safety inputs 1 and 2 are OFF, i.e., when the STO function is activated for both safety input circuits, the EDM output is ON.

You can detect a failure of the safety input circuit and the EDM output circuit by monitoring all of the following 4 signal states using an external device. Errors occur in the following two cases:


- Both safety inputs 1 and 2 are OFF, but the EDM output circuit signal does not turn ON.
- Either or both safety inputs 1 and 2 are ON, but the EDM output circuit signal is ON.

Signal name	Symbol	Signal status				
Safety input 1	SF1	ON	ON	OFF	OFF	
Safety input 2	SF2	ON	OFF	ON	OFF	
EDM output	EDM	OFF	OFF	OFF	ON	

• The maximum delay time is 6 ms after the safety input signal is input until the EDM output signal is output.

7-2 Operation Example

Operation Timings to a Safety Status



- *1. t1 is the set value of the Brake Timing During Operation (Pn438), or the time needed for the motor rotation speed to drop to or below the Brake Release Speed Setting (Pn439), whichever occurs first.
- *2. The dynamic brake is based on the Stop Selection for Alarm Detection (Pn510) setting.
- *3. STO status is entered when either safety input 1 or 2 turns OFF.

Operation command (RUN) *1	Servo OFF command	1	Servo ON
Safety input 1 Safety input 2	STO status Normal status	;	Follow the normal servo ON/OFF operation timing
Motor power	No powe	r supply	diagram upon input of the operation
is supplied.	Response time	= 6 ms max.	command (RUN). For details, refer to
EDM output	ON OFF		"6-6 Brake Interlock."
Dynamic	DB released/engaged *2	DB released/engaged *3	
brake relay	Alarm occurrence status	Servo OFF	
Servo ready completed output (READY)		READY	
Alarm reset input (RESET) *1	Reset		
Alarm output (ALM)	Alarm	Normal	
Brake interlock output (BKIR)	Brake held		


Timing of Return from the Safety Status

- *1. Make sure that servo ON input is turned OFF when you return the input signals of safety inputs 1 and 2 to ON. Alarm clear must be performed because alarms will occur. Be sure to execute the alarm clear when both safety inputs 1 and 2 are returned to the ON status. An alarm will occur immediately if the alarm reset is executed when even one of these is still in the OFF status. Depending on the timing, another error (Alarm No. 99.0) may occur. If another error occurs, you must turn OFF the power supply, then turn it ON again.
- *2. Since this is a status where alarms will occur, the dynamic brake is based on the Stop Selection for Alarm Detection (Pn510).
- *3. Since this is a normal servo OFF status, the dynamic brake is based on the Stop Selection with Servo OFF (Pn506) setting.

OMNUC G5-SERIES AC SERVOMOTOR AND SERVO DRIVE USER'S MANUAL

7-3 Connection Example

Connection with a Safety Controller (Two Safety Inputs and One EDM Output)



8

Parameter Details

This chapter explains the set value and contents of setting of each parameter.

8-1	Basic Parameters	8-1
8-2	Gain Parameters	8-9
8-3	Vibration Suppression Parameters	8-20
8-4	Analog Control Parameters	8-25
8-5	Interface Monitor Setting Parameters	8-37
8-6	Extended Parameters	8-47
8-7	Special Parameters	8-60


8-1 Basic Parameters

Pn000	Rotation Direction Switching				A		
Setting range	0 or 1	Unit	-	Default setting	1	Power OFF and ON	Yes

Explanation of Set Values

•This object switches the motor rotation direction for a position, speed, or torque command.

Set value	Description
0	A forward direction command sets the motor rotation direction to CW.
1	A forward direction command sets the motor rotation direction to CCW.



• Regarding the motor rotation direction, when seen from load-side axis, clockwise is referred to as CW and counterclockwise as CCW.

Pn001	Control Mode Selection					A	.
Setting range	0 to 6	Unit	-	Default setting	0	Power OFF and ON	Yes


Explanation of Set Values

Set value	Description
0	Position control (pulse train command)
1	Speed control (analog command)
2	Torque control (analog command)
3	Mode 1: Position control, Mode 2: Speed control
4	Mode 1: Position control, Mode 2: Torque control
5	Mode 1: Speed control, Mode 2: Torque control
6	Fully-closed control

• Set the control mode to be used.

• If a composite mode is set (set values: 3 to 5), mode 1 or mode 2 can be selected using the control mode switching input (TVSEL).

- · When the control mode switching input is open: Select mode 1.
- \cdot When the control mode switching input is short-circuited: Select mode 2.
- Do not input a command within 10 ms before or after switching.



Pn002	Realtime Autotuning Mode Selection					A	All
Setting range	0 to 6	Unit	-	Default setting	1	Power OFF and ON	-

Explanation of Set Values

Set value	Description
0	Disabled
1	This mode focuses on stability.
2	This mode focuses on positioning.
3	Used when an unbalanced load is present such as a vertical axis.
4	Used when friction is large (unbalanced load also calculated).
5	Used only for estimating load characteristics.
6	Used when customizing Realtime Autotuning Mode.

• Refer to "10-2 Realtime Autotuning" (P.10-3) for details on the settings

Parameter Details

Pn003	Realtime Autotuning Machine Rigidity Setting					A	.
Setting range	0 to 31	Unit	-	Default setting	13 *	Power OFF and ON	_

Default settings:

* Pn003 = 11 - For 200V drives of 1 kW or upper and 400V drives

• Set the machine rigidity to one of 32 levels when realtime autotuning is enabled.

Low ←Responsiveness→ High

• If the set value is changed suddenly by a large amount, the gain may change rapidly, subjecting the machine to shock. Always start with a small setting, and gradually increase the setting while monitoring machine operation.

Pn004	Inertia Ratio					A	.
Setting range	0 to 10,000	Unit	%	Default setting	250	Power OFF and ON	-

- Set the load inertia as a percentage of the motor rotor inertia.
- Pn004 = (Load inertia / Rotor inertia) × 100%
- When realtime autotuning is enabled, the inertia ratio is continuously estimated and saved in EEPROM every 30 minutes.
- If the inertia ratio is set correctly, the setting unit for the Speed Loop Gain (Pn101) and Speed Loop Gain 2 (Pn106) is Hz.
- •If the Inertia Ratio (Pn004) is set larger than the actual value, the setting for speed loop gain will increase. If the Inertia Ratio (Pn004) is set smaller than the actual value, the setting for speed loop gain will decrease.

Pn005	Command Pulse Input Selection			Pos	sition Fully-clo	sed	
Setting range	0 or 1	Unit	_	Default setting	0	Power OFF and ON	Yes

Explanation of Set Values

Set value	Description
0	Photocoupler input (+PULS: CN1 pin 3, -PULS: CN1 pin 4, +SIGN: CN1 pin 5, -SIGN: CN1 pin 6)
1	Input for line driver only (+CWLD: CN1 pin 44, -CWLD: CN1 pin 45, +CCWLD: CN1 pin 46, -CCWLD: CN1 pin 47)

• Selects whether to use photocoupler or input for line driver only for the command pulse input.

• When using a Servo Relay Unit cable, set to 0 (photocoupler input).

Pn006	Command Pulse Rotation Direction Switching Selection					sition Fully-clo	sed
Setting range	0 or 1	Unit	_	Default setting	0	Power OFF and ON	Yes

Explanation of Set Values

Set value	Description
0	The motor rotates in the direction specified by the command pulse.
1	The motor rotates in the opposite direction from the direction specified by the command pulse.

• Set the motor rotation direction for the command pulse input.

Pn007	Command Pulse Mode Sel	Command Pulse Mode Selection					sed
Setting range	0 to 3	Unit	-	Default setting	1	Power OFF and ON	Yes

• Set the count method for the command pulse input.

Command Pulse Rotation Direction Switching Selection (Pn006)	Command Pulse Mode Setting (Pn007)	Command pulse mode	Motor forward command	Motor reverse command
	0 or 2	90° phase difference (phases A and B) signal inputs	Phase t_{11} t_{11} t_{11} t_{11} t_{11} t_{11} t_{11} t_{11} t_{11} t_{11} t_{11} t_{11} t_{11} t_{12} t_{13} t_{1	collector: $t1 \ge 5 \ \mu s$
0	1	Reverse pulse/ forward pulse	Line driver: $t2 \ge 1 \ \mu s \ Open$	collector: $t2 \ge 2.5 \ \mu s$
	3	Feed pulse/ direction signal	Line driver: $t^2 \ge 1 \ \mu s \ Open$	t4 $t5$ $t6$ $t6$ $t6$ $t6$ $t6$ $t6$ $t6$ $t6$

Command Pulse Rotation Direction Switching Selection (Pn006)	Command Pulse Mode Setting (Pn007)	Command pulse mode	Motor forward command	Motor reverse command
	0 or 2	90° phase difference (phases A and B) signal inputs	Phase t1 t1 Phase t1 t1 Phase B Line driver: t1 \ge 2 µs Open	collector: $t1 \ge 5 \ \mu s$
1	1	Reverse pulse/ forward pulse	Line driver: $t2 \ge 1 \ \mu s$ Open	collector: $t2 \ge 2.5 \ \mu s$
	3	Feed pulse/ direction signal	Line driver: $t2 \ge 1 \ \mu s$ Open	tto to the second seco

• Set the form of the pulse inputs sent as command to the drive from a Position Controller.

• Modes 0 and 2 are exactly the same.

• For fully-closed control, set the parameter to 0, and set the Electronic Gear Ratio Numerator 1 (Pn009) and Electronic Gear Ratio Denominator (Pn010).

Pn008	Electronic Gear Integer Se	Electronic Gear Integer Setting					sed
Setting range	0 to 2 ²⁰	Unit	pulse	Default setting	10000	Power OFF and ON	Yes


• Set the number of command pulses corresponding to 1 motor rotation.

• If the set value is 0, Electronic Gear Ratio Numerator 1 (Pn009) and Electronic Gear Ratio Denominator (Pn010) become valid.

Pn009	Electronic Gear Ratio Numerator 1					Pos	ition
Setting range	0 to 2 ³⁰	Unit	_	Default setting	0	Power OFF and ON	-

Pn010	Electronic Gear Ratio Denominator						
Setting range	1 to 2 ³⁰	Unit	-	Default setting	10000	Power OFF and ON	-

- Set the electronic gear function.
 - It is enabled when Pn008 is 0.
- The electronic gear can be used for the following:
 - $\cdot\,$ To set the amount of motor rotation or travel distance per input command pulse.
 - To increase the nominal command pulse frequency by using a multiplier when the desired motor speed cannot be achieved due to the limited pulse generation capability of the host device (possible maximum output frequency).
- Electronic Gear Block Diagram:



*1. Numerator 2 to 4 is selected using the electronic gear switching (GESEL1 and GESEL2).

GESEL1	GESEL2	Selected numerator
OFF	OFF	Electronic Gear Ratio Numerator 1
ON	OFF	Electronic Gear Ratio Numerator 2
OFF	ON	Electronic Gear Ratio Numerator 3
ON	ON	Electronic Gear Ratio Numerator 4

Any values can be set for PN008, Pn009, and Pn010, but operation may not be correct if you set an extreme electronic gear ratio. Set the electronic gear ratio to between 1/1,000 and 1,000. Refer to "6-4 Electronic Gear Function" (P.6-10) for information on the settings.

Pn011	Encoder Dividing Numerator						
Setting range	1 to 262,144	Unit	P/r	Default setting	2500	Power OFF and ON	Yes

• If Encoder Dividing Denominator (Pn503) = 0, the encoder resolution becomes the pulse output dividing denominator.

• Note that 1 pulse corresponds to 4 counts. Encoder resolution corresponds with counts.

Encoder pulse \rightarrow	Pn011×4 (When the host side uses a 4 multiplier process)	\rightarrow Output pulse
	Encoder resolution	,

Pn012	Encoder Output Direction Switching Selection					A	
Setting range	0 to 3	Unit	-	Default setting	0	Power OFF and ON	Yes

• Set the phase-B logic and output source for pulse output. For fully-closed control, select an external encoder for the output source. For other control modes, set the encoder.

8

Explanation of Set Values

Pn012 set value	Output source	Phase B logic	CCW direction operation	CW direction operation
0	Encoder	Non-	Phase	Phase
2	External encoder	reverse	Phase	Phase B
1	Encoder	Reverse	Phase	Phase
3	External encoder	nevelse	Phase	PhaseB

Pn013	No. 1 Torque Limit						
Setting range	0 to 500	Unit	%	Default setting	500	Power OFF and ON	_
Tange				setting			

• Set the No. 1 limit value for the output torque of the motor.

Pn014	Error Counter Overflow Lev	Error Counter Overflow Level					sed
Setting range	0 to 2 ²⁷	Unit	Command unit	Default setting	100000	Power OFF and ON	-
Set the range of the error counter overflow level.							

Pn015	Operation Switch when Using Absolute Encoder					sition Fully-clos	sed
Setting range	0 to 2	Unit	_	Default setting	1	Power OFF and ON	Yes

Explanation of Set Values

Set value	Description
0	Use as absolute encoder.
1	Use as incremental encoder.
2	Use as absolute encoder but ignore multi-rotation counter overflow.
0.11	

• Set the operating method for the 17-bit absolute encoder.

Pn016	Regeneration Resistor Selection					A	
Setting range	0 to 3	Unit	_	Default setting	3 *	Power OFF and ON	Yes

* The default setting is 0 for 100-V Servo Drives of 400 W, 200-V Servo Drives of 750 W to 5 kW, and 400-V Servo Drives of 5 kW or lower.

Explanation of Set Values

Set value	Description
0	Regeneration Resistor used: Built-in Resistor The regeneration processing circuit operates and the regeneration overload (Alarm No. 18) will be enabled according to the Built-in Resistor (with approx. 1% duty).
1	Regeneration Resistor used: External Resistor The regeneration processing circuit operates, and regeneration overload (Alarm No. 18) will cause a trip when the operating rate of the Regeneration Resistor exceeds 10%.
2	Regeneration Resistor used: External Resistor The regeneration processing circuit operates, but regeneration overload (Alarm No. 18) will not occur.
3	Regeneration Resistor used: None The regeneration processing circuit and regeneration overload (Alarm No. 18) will not operate, and all regenerative energy will be processed by the built-in capacitor.
	touch the External Regeneration Resistor. A burn injury may result.

•Always provide a temperature fuse or other protective measure when using an External Regeneration Resistor. Regardless of whether the regeneration overload error is enabled or disabled, the Regeneration Resistor can generate heat and may cause burning.

•Set this parameter depending on whether the Built-in Regeneration Resistor is used, or the Builtin Regeneration Resistor is disconnected and an External Regeneration Resistor is connected. (The External Regeneration Resistor connection terminal is connected.)

 $\bullet To$ use the Built-in Regeneration Resistor, always set this parameter to 0.

Pn017	External Regeneration Resistor Setting					A	.
Setting range	0 to 4	Unit	_	Default setting	0	Power OFF and ON	Yes

Explanation of Set Values

Set value	Description
0	Regeneration load ratio is 100% when operating rate of the External Regeneration Resistor is 10%.
1	Reserved
2	Reserved
3	Reserved
4	Reserved

8-2 Gain Parameters

Pn100	Position Loop Gain				Po	sition Fully-clos	sed
Setting range	0 to 30,000	Unit	0.1/s	Default setting	480 *	Power OFF and ON	_


• The default setting is 320 for 200-V Servo Drives of 1 kW or higher, and 400-V Servo Drives.

- Adjust the position loop response to suit the machine rigidity.
- •The responsiveness of the servo system is determined by the position loop gain. Servo systems with a high position loop gain have a high responsiveness and fast positioning. To increase the position loop gain, you must improve machine rigidity and increase the specific damping frequency. This should be 500 to 700 (0.1/s) for ordinary machine tools, 300 to 500 (0.1/s) for general-use and assembly machines, and 100 to 300 (0.1/s) for industrial robots. The default position loop gain is 400 (0.1/s), so be sure to lower the set value for machines with low machine rigidity.
- •Increasing the position loop gain in systems with low machine rigidity or systems with low specific damping frequencies may cause machine resonance, resulting in an overload alarm.
- +If the position loop gain is low, you can shorten the positioning time using feed-forward.
- •This parameter is automatically changed by executing realtime autotuning function. To set it manually, set the Realtime Autotuning Mode Selection (Pn002) to 0. Position loop gain is generally expressed as follows:


sp gan le generally expressed as follows.

Position loop gain (Kp) = $\frac{\text{Command pulse frequency (pulses/s)}}{\text{Error counter accumulated pulse (pulse)}}$ (0.1/s)

Response when the position loop gain is operated



• If the speed loop gain and position loop gain are optimally set, the motor operation for the command will be delayed 2/Kp at acceleration and delayed 3/Kp at deceleration.



Pn101	Speed Loop Gain					A	
Setting range	1 to 32,767	Unit	0.1 Hz	Default setting	270 *	Power OFF and ON	-


 \bullet The default setting is 180 for 200-V Servo Drives of 1 kW or higher, and 400-V Servo Drives.

• Determine speed loop responsiveness.

•The setting for the speed loop gain must be increased to increase the position loop gain and improve the responsiveness of the entire servo system. Setting too high, however, may result in vibration.

•The setting unit for Pn101 will be Hz if the Inertia Ratio (Pn004) is set correctly.

When the speed loop gain is changed, the response is as shown in the following diagram.




Pn102	Speed Loop Integral Time C	Speed Loop Integral Time Constant					
Setting range	1 to 10,000	Unit	0.1 ms	Default setting	210 *	Power OFF and ON	_

• The default setting is 310 for 200-V Servo Drives of 1 kW or higher, and 400-V Servo Drives.

• Set the speed loop integral time constant.

• The smaller the set value, the faster the error approaches 0 when stopping. Set to 9,999 to maintain integration. Set to 10,000 to invalidate the effect of integration.

When the speed loop integral time constant is changed, the response is as shown in the following diagram.



8

	Speed Feedback Filter T	me Consta	ant			ļ	All 🛛		
Setting range	0 to 5	Unit	-	Default setting	0	Power OFF and ON	_		
	 Set the time constant for Increasing the set value motor. Responsiveness Normally, use the default 	e increase , however	es the time constant , also decreases.	•					
Pn104	Torque Command Filter	Time Cons	tant				411		
Setting range	0 to 2,500	Unit	0.01 ms	Default setting	84 *	Power OFF and ON	-		
	 The default setting is 12 Set the time constant for This parameter may be 	or the first-	order lag filter inserte	ed into the tor	que comn	nand.	es.		
Pn105	Position Loop Gain 2				Po	sition Fully-clo	osed		
Setting range	1 to 30,000	Unit	0.1/s	Default setting	570 *	Power OFF and ON	-		
	The default setting is 380 for 200-V Servo Drives of 1 kW or higher, and 400-V Servo Drives. Set the responsiveness of the position control system for the second position loop.								
Pn106	Speed Loop Gain 2					ŀ	١I		
Setting ange	1 to 32,767	Unit	0.1 Hz	Default setting	1*	Power OFF and ON	-		
	The shefe of a string of the s	0. (
Pn107	The default setting is 18 Set the responsiveness	of the sec	cond speed loop.	kW or higher,	and 400-				
	•Set the responsiveness Speed Loop Integral Tim	of the sec e Constant	cond speed loop.	kW or higher,			×s.		
Setting	•Set the responsiveness	of the sec	cond speed loop.		and 400-				
Pn107 Setting range	•Set the responsiveness Speed Loop Integral Tim	of the sec e Constant Unit	cond speed loop. 2 0.1 ms	Default		/ Power OFF			
Setting range	•Set the responsiveness Speed Loop Integral Tim 1 to 10,000	of the sec e Constant Unit loop integ	cond speed loop. 2 0.1 ms ral time constant.	Default		Power OFF and ON			
Setting	Set the responsiveness Speed Loop Integral Tim 1 to 10,000 Set the second speed	of the sec e Constant Unit loop integ	cond speed loop. 2 0.1 ms ral time constant.	Default		Power OFF and ON	<u> </u> _		
Setting range Pn108 Setting	•Set the responsiveness Speed Loop Integral Tim 1 to 10,000 • Set the second speed Speed Feedback Filter T	of the sec e Constant Unit loop integ me Consta Unit	cond speed loop. 2 0.1 ms ral time constant. ant 2 -	Default setting Default	10000	Power OFF and ON	<u> </u> _		
Setting range Pn108 Setting range	 Set the responsiveness Speed Loop Integral Time 1 to 10,000 Set the second speed Speed Feedback Filter T 0 to 5 Set the second speed 	of the sec e Constant Unit loop integ me Consta Unit feedback	cond speed loop. 2 0.1 ms ral time constant. ant 2 – filter.	Default setting Default	10000	Power OFF and ON Power OFF and ON			
Setting range Pn108 Setting range Pn109 Setting	•Set the responsiveness Speed Loop Integral Tim 1 to 10,000 • Set the second speed Speed Feedback Filter T 0 to 5	of the sec e Constant Unit loop integ me Consta Unit feedback	cond speed loop. 2 0.1 ms ral time constant. ant 2 – filter.	Default setting Default setting Default	10000	Power OFF and ON Power OFF and ON	<u> </u> _		
Setting range Pn108 Setting range Pn109	•Set the responsiveness Speed Loop Integral Tim 1 to 10,000 • Set the second speed Speed Feedback Filter T 0 to 5 • Set the second speed Torque Command Filter	of the sec e Constant Unit loop integ me Consta Unit feedback Fime Cons Unit	cond speed loop. 2 0.1 ms ral time constant. ant 2 - filter. tant 2 0.01 ms	Default setting Default setting Default setting	10000 0 84 *	Power OFF and ON Power OFF and ON			

Pn110	Speed Feed-forward Amou	unt			Po	sition Fully-clo	sed		
Setting range	0 to 1,000	Unit	0.1%	Default setting	300	Power OFF and ON	_		
	 Set the feed-forward amount. Increasing the set value decreases the position error and increases the responsiveness. Overshooting, however, will occur more easily. 								
Pn111	Speed Feed-forward Com	Speed Feed-forward Command Filter Position Fully-closed							
Setting range	0 to 6,400	Unit	0.01 ms	Default setting	50	Power OFF and ON	_		
Pn112	Set the time constant for Setting the filter may impu- is large when the feed-fo Torque Feed-forward Amo	rove ope rward is	ration if speed oversh	ooting occurs	or the noi				
Setting range	0 to 1,000	Unit	0.1%	Default setting	0	Power OFF and ON	-		
	•Set the feed-forward am error and increases the r			-		•	osition		
Pn113	Torque Feed-forward Com	mand Fil	ter	Po	sition Sp	eed Fully-clo	sed		
Setting range	0 to 6,400	Unit	0.01 ms	Default setting	0	Power OFF and ON	_		
	• Set the time constant for	the first-	order lag filter inserte	ed into the fee	d forward				

•Setting the filter may improve operation if speed overshooting occurs or the noise during operation is large when the feed-forward is set high.

Pn114	Gain Switching Input Operating Mode Selection				A	'II	
Setting range	0 or 1	Unit	_	Default setting	1	Power OFF and ON	_

Explanation of Set Values

Set value	Description
0	Gain 1 (PI/P switching enabled)
1	Gain 1/gain 2 switching available

• Select either PI/P operation switching or gain 1/gain 2 switching.

•PI/P operation switching is performed using gain switching (GSEL: CN1 pin 27). PI is not changed, however, if the Torque Limit Selection (Pn521) is set to 3.

Gain input	Speed loop operation
GSEL OFF	PI operation
GSEL ON	P operation

• For information on switching conditions between gain 1 and gain 2, refer to "6-7 Gain Switching Function" (P.6-24).

•If autotuning is enabled, feedforward gain and filter are set at a fixed value.

Pn115	Switching Mode in Position Control					sition Fully-clos	sed
Setting range	0 to 10	Unit	_	Default setting	0	Power OFF and ON	_

Explanation of Settings


($\sqrt{:}$ Enabled, -: Disabled)

		Explanation		
Set value	Gain switching conditions	Gain Switching Delay Time in Position Control (Pn116) ^{*1}	Gain Switching Level in Position Control (Pn117)	Gain Switching 1 Hysteresis in Position Control (Pn118) *2
0	Always Gain 1 (Pn100 to Pn104)	-	-	-
1	Always Gain 2 (Pn105 to Pn109)	_	-	-
2	Switching using gain switching input (GSEL) for CN1 pin 27	-	-	-
3	Torque command variation (Refer to Figure A)	\checkmark	√ ^{*3} (× 0.05%)	√ ^{*3} (× 0.05%)
4	Always Gain 1 (Pn100 to Pn104)	_	_	_
5	Command speed (Refer to Figure B)	\checkmark	$\sqrt{(r/min)}$	$\sqrt{(r/min)}$
6	Amount of position error (Refer to Figure C)	\checkmark	$\sqrt{*4}$ (pulse)	$\sqrt{*4}$ (pulse)
7	Command pulses received (Refer to Figure D)	\checkmark	-	-
8	Positioning completion signal (INP) OFF (Refer to Figure E)	\checkmark	-	-
9	Actual motor speed (Refer to Figure B)	\checkmark	$\sqrt{(r/min)}$	$\sqrt{(r/min)}$
10	Combination of command pulse input and speed (Refer to Figure F)	\checkmark	$\sqrt{*5}$ (r/min)	$\sqrt{*5}$ (r/min)

• Select the conditions for switching between gain 1 and gain 2 when the Gain Switching Input Operating Mode Selection (Pn114) is set to 1.


• The gain is always gain 1 regardless of the gain input if the Gain Switch input is not assigned to any input if this setting is 2.

- *1. The Gain Switching Delay Time in Position Control (Pn116) becomes effective when the gain is switched from 2 to 1.
- *2. The Gain Switching Hysteresis in Position Control (Pn118) is defined in the drawing below.



- *3. The variation means the change amount in a millisecond (ms).
 - E.g. The set value is 200 when the condition is a 10% change in torque in 1 millisecond.
- *4. This is the encoder resolution.

*5. The meanings of the gain switching delay time in position control, gain switching level in position control, and gain switching hysteresis in position control are different from normal if this is set to 10. (Refer to Figure F)



Pn116	Gain Switching Delay Time in Position Control				Position Fully-closed			
Setting range	0 to 10,000	Unit	0.1 ms	Default setting	50	Power OFF and ON	_	

• Set the delay time when returning from gain 2 to gain 1 if the Switching Mode in Position Control (Pn115) is set to 3 or 5 to 10.


Pn117	Gain Switching Level in Pos	Gain Switching Level in Position Control					sed
Setting range	0 to 20,000	Unit	-	Default setting	50	Power OFF and ON	-

• This is enabled when the Switching Mode in Position Control (Pn115) is set to 3, 5, 6, 9 or 10. It sets the judgment level for switching between gain 1 and gain 2. The unit depends on the Switching Mode in Position Control (Pn115).

Pn118	Gain Switching Hysteresis i	Gain Switching Hysteresis in Position Control				Position Fully-closed		
Setting range	0 to 20,000	Unit	_	Default setting	33	Power OFF and ON	-	

• Set the hysteresis width above and below the judgment level set in the Gain Switching Level in Position Control (Pn117). The unit depends on the setting of the Switching Mode in Position Control (Pn115).

The following shows the definitions for the Gain Switching Delay Time in Position Control (Pn116), Gain Switching Level in Position Control (Pn117), and Gain Switching Hysteresis in Position Control (Pn118).



• The settings for the Gain Switching Level in Position Control (Pn117) and the Gain Switching Hysteresis in Position Control (Pn118) are enabled as absolute values (positive/negative).

Pn119	Position Gain Switching Time					Position Fully-closed		
Setting range	0 to 10,000	Unit	0.1 ms	Default setting	33	Power OFF and ON	-	

If the difference between the Position Loop Gain (Pn100) and Position Loop Gain 2 (Pn105) is large during position control, this parameter can be used to suppress a rapid increase in the position loop gain. When the gain increases, it will change by the time set for this parameter.


Position Gain Switching Time

The Position Gain Switching Time (Pn119) can be set to more smoothly change the gain and reduce vibration when a large change is being made in the position loop gain during position control or fully-closed control. This smooths vibration and the changes in torque that can occur when the position loop gain is changed too quickly.



Precautions for Correct Use

 If the gain is changed to a smaller value, the setting of this parameter is ignored and the gain is changed immediately. Example: Pn100 > Pn105



Pn120	Switching Mode in Speed Control					Spe	ed
Setting range	0 to 5	Unit	-	Default setting	0	Power OFF and ON	-

Explanation of Settings


($\sqrt{:}$ Enabled, -: Disabled)

		Explanation		
Set value	Gain switching conditions	Gain Switching Delay Time in Speed Control (Pn121) ^{*1}	Gain Switching Level in Speed Control (Pn122)	Gain Switching Hysteresis in Speed Control (Pn123) ^{*2}
0	Always the Gain 1 (Pn100 to Pn104)	-	-	-
1	Always the Gain 2 (Pn105 to Pn109)	-	-	-
2	Switching using gain switching input (GSEL) for CN1 pin 27	_	_	_
3	Torque command variation (Refer to Figure A)	\checkmark	√ ^{*3} (0.05%)	√ ^{*3} (0.05%)
4	Speed command variation (Refer to Figure B)	\checkmark	√ ^{*4} (10 r/min/s)	√ ^{*4} (10 r/min/s)
5	Speed command (Refer to Figure C)		$\sqrt{(r/min)}$	√ (r/min)

• Select the conditions for switching between gain 1 and gain 2 when the Gain Switching Input Operating Mode Selection (Pn114) is set to 1.

•The gain is always gain 1 regardless of the gain input if the switching input is not assigned when Pn120 = 2.


- *1. The Gain Switching Delay Time in Speed Control (Pn121) becomes effective when the gain is switched from 2 to 1.
- *2. The Gain Switching Hysteresis in Speed Control (Pn123) is defined as shown in the drawing below.



*3. The variation means the change amount in a millisecond (ms).

E.g. The set value is 200 when the condition is a 10% change in torque in 1 millisecond.

*4. The meanings of the Gain Switching Delay Time in Speed Control (Pn121), Gain Switching Level in Speed Control (Pn122), and Gain Switching Hysteresis in Speed Control (Pn123) are different from normal if this is set to 10. (Refer to Figure D) 8




Pn121	Gain Switching Delay Time in Speed Control						
Setting range	0 to 10,000	Unit	0.1 ms	Default setting	0	Power OFF and ON	_
	Set the delay time who (Pn120) is set to 3 to 5		g from gain 2 to gain	1 if the Switc	hing Mod	le in Speed C	ontrol

Pn122	Gain Switching Level in Speed Control					Speed	
Setting range	0 to 20,000	Unit	_	Default setting	0	Power OFF and ON	_

 In Speed Control Mode, this is enabled when the Switching Mode in Speed Control (Pn120) is set to 3 to 5. Set the judgment level for switching between gain 1 and gain 2. The unit depends on the Switching Mode in Speed Control (Pn120).

Pn123	Gain Switching Hysteresis i	n Speed	Control			Spe	ed
Setting range	0 to 20,000	Unit	-	Default setting	0	Power OFF and ON	-

 Set the hysteresis width above and below the judgment level set in the Gain Switching Level in Speed Control (Pn122). The unit depends on the setting of the Switching Mode in Speed Control (Pn120). The following shows the definitions for the Gain Switching Delay Time in Speed Control (Pn121), Gain Switching Level in Speed Control (Pn122), and Gain Switching Hysteresis in Speed Control (Pn123).



• The settings for the Gain Switching Level in Speed Control (Pn122) and the Gain Switching Hysteresis in Speed Control (Pn123) are enabled absolute values (positive/negative).

Pn124	Switching Mode in Torque (Control				Tor	que
Setting range	0 to 3	Unit	-	Default setting	0	Power OFF and ON	-


Explanation of Settings

		Explanation		
Set value	Gain switching conditions	Gain Switching Delay Time in Torque Control (Pn125) ^{*1}	Gain Switching Level in Torque Control (Pn126)	Gain Switching Hysteresis in Torque Control (Pn127) ^{*2}
0	Always Gain 1 (Pn100 to Pn104)	-	-	-
1	Always Gain 2 (Pn105 to Pn109)	-	_	-
2	Switching using gain switching input (GSEL) for CN1 pin 27	_	-	_
3	Torque command variation (Refer to Figure A)	\checkmark	√ *3 (0.05%)	√ *3 (0.05%)

• Select the switching condition between gain 1 and gain 2 when the Gain Switching Input Operating Mode Selection (Pn114) is set to 1.


•The gain is always gain 1 regardless of the gain input if the switching input is not assigned when Pn124=2.

- *1. The Gain Switching Delay Time in Torque Control (Pn125) becomes effective the gain is switched from 2 to 1.
- *2. The Gain Switching Hysteresis in Torque Control (Pn127) is defined as shown in the following figure.



- *3. The variation means the change amount in a millisecond (ms).
 - E.g. The set value is 200 when the condition is a 10% change in torque in 1 millisecond.

8



Pn125	Gain Switching Delay Time in Torque Control						que		
Setting range	0 to 10,000	Unit	0.1 ms	Default setting	0	Power OFF and ON	-		
	. Cet the delay time when veturing from goin 0 to goin 1 if the Switching Made in Torque Control								

• Set the delay time when returning from gain 2 to gain 1 if the Switching Mode in Torque Control (Pn124) is set to 3.


Pn126	Gain Switching Level in Torque Control						que
Setting range	0 to 20,000	Unit	_	Default setting	0	Power OFF and ON	_

• This is enabled when the Switching Mode in Torque Control (Pn124) is set to 3. It sets the judgment level for switching between gain 1 and gain 2. The unit depends on the setting of Switching Mode in Torque Control (Pn124).

Pn127	Gain Switching Hysteresis in Torque Control					Tor	que
Setting range	0 to 20,000	Unit	_	Default setting	0	Power OFF and ON	-

 Set the hysteresis width above and below the judgment level set in the Gain Switching Level in Torque Control (Pn126). The unit depends on the setting of Switching Mode in Torque Control (Pn124).

The following shows the definitions for the Gain Switching Delay Time in Torque Control (Pn125), Gain Switching Level in Torque Control (Pn126), and Gain Switching Hysteresis in Torque Control (Pn127).



• The settings for the Gain Switching Level in Torque Control (Pn126) and the Gain Switching Hysteresis in Torque Control (Pn127) are enabled as absolute values (positive/negative).

8-3 Vibration Suppression Parameters

Pn200	Adaptive Filter Selection			Pc	sition Sp	eed Fully-clos	sed
Setting range	0 to 4	Unit	-	Default setting	0	Power OFF and ON	-

Explanation of Set Values

Set value	Description
0	Disabled. The current values are held for the parameters related to notch filters 3 and 4.
1	One adaptive filter is enabled. The parameter related to notch filter 3 is updated based on the applicable result.
2	Two adaptive filter is enabled. The parameters related to notch filters 3 and 4 are updated based on the applicable result.
3	The resonance frequency is measured. The measurement result can be checked using CX- Drive. The current values are held for the parameters related to notch filters 3 and 4.
4	Adaptive result is cleared.Parameters related to notch filters 3 and 4 are disabled and the adaptive result is cleared.

• Set the operation of the adaptive filter.

• The adaptive filter is normally disabled in the Torque Control Mode.

Pn201	Notch 1 Frequency Setting						
Setting range	50 to 5,000	Unit	Hz	Default setting	5000	Power OFF and ON	_

• Set the frequency of resonance suppression notch filter 1.

• The notch filter function will be disabled if this parameter is set to 5,000.

Pn202	Notch 1 Width Setting		All				
Setting range	0 to 20	Unit	-	Default setting	2	Power OFF and ON	-

• Set the width of resonance suppression notch filter 1 to one of 20 levels.

• Increasing the set value widens the notch width. Normally, use the default set value.

Pn203	Notch 1 Depth Setting		All				
Setting range	0 to 99	Unit	_	Default setting	0	Power OFF and ON	-

• Set the notch depth of resonance suppression notch filter 1.

• Increasing the set value shortens the notch depth and the phase lag.

Pn204	Notch 2 Frequency Setting	A					
Setting range	50 to 5,000	Unit	Hz	Default setting	5000	Power OFF and ON	-

Set the notch frequency of resonance suppression notch filter 2.

• The notch filter function will be disabled if this parameter is set to 5,000.

Pn205	Notch 2 Width Setting		All				
Setting range	0 to 20	Unit	-	Default setting	2	Power OFF and ON	-

• Select the notch width of resonance suppression notch filter 2.

• Increasing the set value widens the notch width. Normally, use the default set value.

8-3 Vibration Suppression Parameters

Pn206	Notch 2 Depth Setting	9				AI					
Setting range	0 to 99	Unit	-	Default setting	0	Power OFF and ON	_				
	 Set the notch depth Increasing the set v 		••		ag.	· · · · ·					
Pn207	Notch 3 Frequency S	etting				AI					
Setting range	50 to 5,000	Unit	Hz	Default setting	5000	Power OFF and ON	_				
	 Set the notch freque The notch filter function 	-	••		5,000.						
Pn208	Notch 3 Width Setting)				AI					
Setting range	0 to 20	Unit	_	Default setting	2	Power OFF and ON	-				
	 Select the notch width of resonance suppression notch filter 3. Increasing the set value widens the notch width. Normally, use the default set value. 										
Pn209	Notch 3 Depth Setting	9				AI					
Setting range	0 to 99	Unit	-	Default setting	0	Power OFF and ON	_				
	 Set the notch depth Increasing the set v 		••		ag.						
Pn210	Notch 4 Frequency S	etting				AI					
Setting range	50 to 5,000	Unit	Hz	Default setting	5000	Power OFF and ON	_				
	 Set the notch freque The notch filter function 	-	••		5,000.						
Pn211	Notch 4 Width Setting)				AI					
Setting range	0 to 20	Unit	-	Default setting	2	Power OFF and ON	_				
	 Select the notch wid Increasing the set v 		••		e default s	et value.					
Pn212	Notch 4 Depth Setting	9				AI					
Setting range	0 to 99	Unit	-	Default setting	0	Power OFF and ON	_				
	 Set the notch depth Increasing the set v 				ag.		_				
Pn213	Damping Filter Select	lion				Posi	itio				
Setting	0 to 3	Unit		Default	0	Power OFF					

Explanation of Set Values

Set value	Description
0	Damping filter 1 and 2 enabled
1	 With external input (DFSEL1), either 1 and 3 or 2 and 4 can be selected. Open: Damping filters 1 and 3 enabled Shorted: Damping filters 2 and 4 enabled
2	 With external input (DFSEL1 and DFSEL2), one of the filters 1 to 4 can be selected. When DFSEL1 and DFSEL2 are both open: Damping filter 1 enabled When DFSEL1 is shorted and DFSEL2 is open: Damping filter 2 enabled When DFSEL1 is open and DFSEL2 is shorted: Damping filter 3 enabled When DFSEL1 and DFSEL2 are both shorted: Damping filter 4 enabled
3	 The damping filters are switched with position command direction. Forward direction: Damping filters 1 and 3 enabled Reverse direction: Damping filters 2 and 4 enabled

Pn214	Damping Frequency 1					Pos	ition
Setting range	0 to 2,000	Unit	0.1 Hz	Default setting	0	Power OFF and ON	_

• Set damping frequency 1 to suppress vibration at the end of the load in damping control.

• Measure the frequency of vibration at the end of the load and make the setting in units of 0.1 Hz.

• The range of frequency setting is 1.0 to 200.0 Hz. The function is disabled if the setting is 0 to 0.9 Hz.

• Refer to "6-1 Damping Control" (P.6-1) for more information on settings.

Pn215	Damping Filter 1 Setting					Pos	ition
Setting range	0 to 1,000	Unit	0.1 Hz	Default setting	0	Power OFF and ON	-

• First set the Damping Frequency 1 (Pn214). Then reduce the setting if torque saturation occurs or increase the setting to increase operation speed. Normally, use a setting of 0.

•Set value is restricted in the following manner.

Upper limit: Corresponding damping frequency

Lower limit: Damping frequency + damping filter setting ≥ 100

•Refer to "6-1 Damping Control" (P.6-1) for more information on settings.

Pn216	Damping Frequency 2					Pos	ition
Setting range	0 to 2,000	Unit	0.1 Hz	Default setting	0	Power OFF and ON	_

• Set Damping Frequency 2 to suppress vibration at the end of the load in damping control.

• Measure the frequency of vibration at the end of the load and make the setting in units of 0.1 Hz.

• The range of frequency setting is 1.0 to 200.0 Hz. The function is disabled if the setting is 0 to 0.9 Hz.

• Refer to "6-1 Damping Control" (P.6-1) for more information on settings.

Pn217	Damping Filter 2 Setting					Pos	ition
Setting range	0 to 1,000	Unit	0.1 Hz	Default setting	0	Power OFF and ON	_

• First set the Damping Frequency 2 (Pn216). Then reduce the setting if torque saturation occurs or increase the setting to increase operation speed. Normally, use a setting of 0.

•Set value is restricted in the following manner.

Upper limit: Corresponding damping frequency

Lower limit: Damping frequency + damping filter setting ≥ 100

8

*Refer to "6-1 Damping Control" (P.6-1) for more information on settings.

Pn218	Damping Frequency 3					Pos	ition
Setting range	0 to 2,000	Unit	0.1 Hz	Default setting	0	Power OFF and ON	_

• Set Damping Frequency 3 to suppress vibration at the end of the load in damping control.

- Measure the frequency of vibration at the end of the load and make the setting in units of 0.1 Hz.
 - The range of frequency setting is 1.0 to 200.0 Hz. The function is disabled if the setting is 0 to 0.9 Hz.

• Refer to "6-1 Damping Control" (P.6-1) for more information on settings.

Pn219	Damping Filter 3 Setting					Pos	ition
Setting range	0 to 1,000	Unit	0.1 Hz	Default setting	0	Power OFF and ON	-

• First set the Damping Frequency 3 (Pn218). Then reduce the setting if torque saturation occurs or increase the setting to increase operation speed. Normally, use a setting of 0.

•Set value is restricted in the following manner.

Upper limit: Corresponding damping frequency

Lower limit: Damping frequency + damping filter setting \geq 100

•Refer to "6-1 Damping Control" (P.6-1) for more information on settings.

Pn220	Damping Frequency 4					Pos	ition
Setting range	0 to 2,000	Unit	0.1 Hz	Default setting	0	Power OFF and ON	-

• Set Damping Frequency 4 to suppress vibration at the end of the load in damping control.

• Measure the frequency of vibration at the end of the load and make the setting in units of 0.1 Hz.

• The range of frequency setting is 1.0 to 200.0 Hz. The function is disabled if the setting is 0 to 0.9 Hz.

• Refer to "6-1 Damping Control" (P.6-1) for more information on settings.

Pn221	Damping Filter 4 Setting					Pos	ition
Setting range	0 to 1,000	Unit	0.1 Hz	Default setting	0	Power OFF and ON	_

• First set the Damping Frequency 4 (Pn220). Then reduce the setting if torque saturation occurs or increase the setting to increase operation speed. Normally, use a setting of 0.

•Set value is restricted in the following manner.

Upper limit: Corresponding damping frequency

Lower limit: Damping frequency + damping filter setting \geq 100


•Refer to "6-1 Damping Control" (P.6-1) for more information on settings.

Pn222	Position Command Filter Ti	me Cons	stant		Pos	sition Fully-clos	sed
Setting range	0 to 10,000	Unit	0.1 ms	Default setting	0	Power OFF and ON	_

• The position command filter time constant is the first-order lag filter inserted after the electronic gear ratio for the command pulse input.

•The position command filter time constant can be used for the following:

- · If the command pulses change abruptly, the filter can be used to reduce the stepping movement of the motor.
- $\cdot\;$ The following are examples of when the command pulses can change abruptly:
- The electronic gear ratio setting is high (10 times or higher).
- The command pulse frequency is low.




*1 The actual process involves calculation error.

*2 If accumulated pulses remain within the filter after the filter set value has been changed, etc., the motor may operate at a speed higher than the command speed immediately after switching the filter.

Pn223	Smoothing Filter Time Cons	stant			Pos	sition Fully-clo	sed
Setting range	0 to 10,000	Unit	0.1 ms	Default setting	0	Power OFF and ON	-

Set the FIR filter time constant used for command pulse input. (FIR: Finite impulse response)
The higher the set value, the smoother the command pulses.



8

8-24

8-4 Analog Control Parameters

Pn300	Command Speed Selection					Spe	ed
Setting range	0 to 3	Unit	-	Default setting	0	Power OFF and ON	-

Explanation of Set Values

Set value	Description
0	Analog speed command
1	No. 1 Internally Set Speed to No. 4 Internally Set Speed (Pn304 to Pn307)
2	No. 1 Internally Set Speed to No. 3 Internally Set Speed (Pn304 to Pn306), analog speed command
3	No. 1 Internally Set Speed to No. 8 Internally Set Speed (Pn304 to Pn311)

• Select the speed command when using speed control. The drive has internally set speed function that can be used to easily achieve speed control by using contact inputs.

+For details on internally set speed function, refer to "5-4 Internally Set Speed Control" (P.5-19).

Pn301	Speed Command Direction	Selectio	n			Spe	ed
Setting range	0 or 1	Unit	-	Default setting	0	Power OFF and ON	_


Explanation of Set Values


Set value	Description
0	Use the sign of the speed command: Example: +: Forward, -: Reverse
1	Use the speed command sign selection (VSIGN); Example: OFF: Forward, ON: Reverse

• Set to reverse the polarity of the speed command input (REF: CN1 pin 14). This is used to change the motor rotation direction without changing the polarity of host device command signals.

- •The default setting for this parameter is 0. By rotating to the reverse direction with the +command keeps the compatibility with all OMNUC W-Series Servo Drives.
- The operation of the Servomotor may be abnormal if the polarity of the speed command signal from the Position Control Unit does not agree with the setting of this parameter when the Servo Drive system is comprised of the combination of the Servo Drive set to the Speed Control Mode and an external Position Control Unit.

Command Speed Selection (Pn300)	Speed Command Direction Selection (Pn301)	Analog Speed Command Rotation Direction Switching (Pn303)	Analog speed command (REF)	Speed command sign selection (VSIGN)	Speed command direction ^{*1}	Conversion graph
		0	+ Voltage (0 to 10 V)		Forward direction	Figure A
	0	0	- Voltage (-10 to 0 V)	Not affected	Reverse direction	riguie A
	0	1	+ Voltage (0 to 10 V)	Not allected	Reverse direction	Figure B
0			- Voltage (-10 to 0 V)		Forward direction	
			+ Voltage (0 to 10 V)	OFF	Forward	
	1	Not	- Voltage (-10 to 0 V)	011	direction	Figure C
		affected	+ Voltage (0 to 10 V) - Voltage (-10 to 0 V)	ON	Reverse direction	





Pn302	Speed Command Scale					Speed Tor	que
Setting range	10 to 2,000	Unit	(r/min)/V	Default setting	500	Power OFF and ON	_

Set the relation between the voltage applied to the speed command input (REF: CN1 pin 14) and the motor speed.
For details on speed control, refer to "5-2 Speed Control" (P.5-7).

•This parameter sets the relation between voltage and speed limit when applying an analog speed limit in Torque Control Mode

Pn303	Analog Speed Command R	otation D	Direction Switching			Spe	ed
Setting range	0 or 1	Unit	_	Default setting	1	Power OFF and ON	-

Explanation of Set Values

Set value	Description
0	Rotation direction is changed by analog speed command (REF) voltage. +Voltage: Forward direction -Voltage: Reverse direction
1	Rotation direction is changed by analog speed command voltage. +Voltage: Reverse direction -Voltage: Forward direction

o = =	-
ower OFF nd ON	_
Spe	ed

Setting range	-20,000 to 20,000	Unit	r/min	Default setting	0	Power OFF and ON	_
Pn306	No. 3 Internally Set Speed					Spe	ed

Setting range -20,000 to 20,000 Unit r/min Default setting 0 Power OFF and ON -
--

Pn307	No. 4 Internally Set Speed					Spe	ed
Setting range	-20,000 to 20,000	Unit	r/min	Default setting	0	Power OFF and ON	_

Pn308	No. 5 Internally Set Speed					Spe	eed
Setting range	-20,000 to 20,000	Unit	r/min	Default setting	0	Power OFF and ON	-
Pn309	No. 6 Internally Set Speed Sp					Spe	eed
Setting range	-20,000 to 20,000	Unit	r/min	Default setting	0	Power OFF and ON	_

Pn310	No. 7 Internally Set Speed					Spe	ed
Setting range	-20,000 to 20,000	Unit	r/min	Default setting	0	Power OFF and ON	-

Pn311	No. 8 Internally Set Speed					Spe	ed
Setting range	-20,000 to 20,000	Unit	r/min	Default setting	0	Power OFF and ON	-


• If internal speed settings are enabled in the Command Speed Selection (Pn300), set the No. 1 to 4 internally set speed in Pn304 to Pn307 and the No. 5 to 8 internally set speed in Pn308 to Pn311. Set the speed in r/min.

•The polarity of the set values indicates the polarity of the internally set speed.

+	The forward direction as viewed from the shaft end
-	The reverse direction as viewed from the shaft end


• The absolute value of the parameter setting is limited by the Overspeed Level Setting (Pn513).

Pn312	Soft Start Acceleration Time	Э				Spe	ed
Setting range	0 to 10,000	Unit	ms/(1,000 r/min)	Default setting	0	Power OFF and ON	_




• Control the speed by setting acceleration/deceleration to the speed command inside the drive.

- •A soft start can be set when inputting speed commands of stepping movement or when using internal speed setting.
- •Do not set acceleration/deceleration time settings when using the drive in combination with an external position loop. (Set both Pn312 and Pn313 to 0.)



Pn314	S-curve Acceleration/Decel	eration T	ime Setting			Spe	eed
Setting range	0 to 1,000	Unit	ms	Default setting	0	Power OFF and ON	-

• Set the pseudo-S-curve acceleration/deceleration value to add to the speed command to enable smooth operation. This is useful for applications where impact may occur due to a large change in acceleration or deceleration when starting or stopping with linear acceleration or deceleration.




- Basic linear acceleration time and deceleration time are set by Pn312 and Pn313, respectively.
- The S-curve time is set by Pn314 (unit: 2 ms) based on the time width around the point of inflection during linear acceleration and deceleration.

ta: Pn312 Use
$$\frac{ta}{2}$$
 > ts, and $\frac{td}{2}$ > ts
ts: Pn314 as settings.


Pn315	Zero Speed Designation Se	election				Speed Toro	que
Setting range	0 to 3	Unit	-	Default setting	0	Power OFF and ON	_

Explanation of Set Values

Set value	Description
0	Zero speed designation function is disabled.
1	Speed command becomes 0 upon zero speed designation input. (Refer to Figure A)
2	Speed command becomes 0 upon zero speed designation input, and servo locks with position control when actual speed reaches below Position Lock Level Setting (Pn316). (Refer to Figure B)
3	Servo locks with position control upon zero speed designation input and when speed command reaches below Zero Destination Level (Pn316). (Refer to Figure C)




- When the zero speed designation input is turned ON, the speed command is forcibly set to 0.
- Set the acceleration/deceleration setting of the speed command using Soft Start Acceleration Time (Pn312), Soft Start Deceleration Time (Pn313) or S-curve Acceleration/Deceleration Time Setting (Pn314).



- When the zero speed designation input is ON, the speed command is forcibly set to 0, and if the actual speed is equal to or less than the Position Lock Level Setting (Pn316), operation switches to position control and the servo lock is applied. When the zero speed designation input is OFF, operation switches to speed control. Once the servo lock is applied in position control, this state continues as long as the zero speed designation input is ON, even if the actual speed becomes greater than the Position Lock Level Setting (Pn316) by external forces.
- Since the position command for position control is forced to be 0, properly set the position loop gain, various error detection functions and other settings.
- Use this parameter when the Control Mode Selection (Pn001) is set to 1 (speed control).


This may not operate correctly if the Control Mode Setting (Pn001) is set to 3 (position or speed control) or 4 (position or torque control).



- The zero speed designation input is turned ON, and when the speed command is equal to or less than the Position Lock Level Setting (Pn316) minus 10 r/min, operation switches to position control and the servo lock is applied. When the speed command is equal to or more than the Position Lock Level Setting (Pn316) plus 10 r/min, operation switches to speed control and the motor speed follows the command speed.
- When the zero speed designation input is turned ON, the speed command will never be 0. You need to change the speed command.
- Since the operation is executed as a normal position control during position control, properly set the position loop gain, various alarm detection functions and other settings.
- Use this parameter when the Control Mode Selection (Pn001) is set to 1 (speed control). This may not operate correctly if the Control Mode Setting (Pn001) is set to 3 (position or speed control) or 4 (position or torque control).

Pn316	Position Lock Level Setting	Speed Torque					
Setting range	10 to 20,000	Unit	r/min	Default setting	30	Power OFF and ON	_

- Servo locks with position control when the speed of the motor is lower than the setting of this parameter.
- •The setting of this parameter is valid for both forward and reverse direction regardless of the motor rotation direction.



Pn317	Torque Command/Speed L	Torque					
Setting range	0 to 2	Unit	_	Default setting	0	Power OFF and ON	_

Set value	Torque command	Speed limit
0	Analog input 1 (TREF1)	Pn321
1	Analog input 2 (TREF2)	Analog input 1 (VLIM)
2	Analog input 1 (TREF1)	Pn321, Pn322


• It depends on the control mode.

• When the control mode is set to speed control/torque control, the torque command input is set to analog input 2.

•If analog input 1 is used for the speed limit, the speed control scale is set in Pn302. The applied voltage is converted to a speed limit as shown below when the analog speed limit is in effect.

Speed limit [r/min] = IPn302 × Input voltage [V]I

An example is shown below for Pn302 = 500 [r/min/V]




Pn318	Torque Command Direction Selection					Tor	que
Setting range	0 or 1	Unit	-	Default setting	0	Power OFF and ON	_

Explanation of Set Values

Set value	Description
0	The direction is specified by the sign of the torque command
1	The direction is specified by the torque command sign input (TSIGN)

Torque Command / Speed Limit Selection (Pn317)	Torque Command Direction Selection (Pn318)	Analog Torque Command Rotation Direction Switching (Pn320)	Analog torque command (TREF)	Torque command sign selection (TSIGN)	Torque command direction* ¹	Conversion graph	
		0	+Voltage (0 to 10 V)	direction		Figure A	
	0	0	-Voltage (-10 to 0 V)	Not	Reverse direction		
0	0	1	+Voltage (0 to 10 V)	affected	affected Reverse direction	Figure B	
0	0		-Voltage (-10 to 0 V)		Forward direction		
	1	Not affected	Not affected	OFF	Forward direction	Figure C	
				ON	Reverse direction		

*1. The motor rotation direction (CW, CCW) specified by the command direction is determined by the setting of Pn000.



Pn319	Torque Command Scale					Toro	que
Setting range	10 to 100	Unit	0.1 V/100%	Default setting	30	Power OFF and ON	-

• Set the relation between the voltage applied to the torque reference input (TREF1: CN1 pin 14, TREF2: CN2 pin 16) and the motor speed.

•Refer to "5-3 Torque Control" (P.5-14) for more information on torque command scale.

Pn320	Analog Torque Command Rotation Direction Switching					Tor	que
Setting range	0 to 1	Unit	_	Default setting	0	Power OFF and ON	_

Explanation of Set Values

Set value	Description
0	Direction of motor torque: The +command indicates the forward direction as viewed from the shaft end.
1	Direction of motor torque: The +command indicates the reverse direction as viewed from the shaft end.

• Reverse the polarity of the torque command input (REF/TREF1: CN1 pin 14 or PCL/TREF2: CN1 pin 16).

Pn321	Speed Limit Value Setting					Toro	que
Setting range	0 to 20,000	Unit	r/min	Default setting	0	Power OFF and ON	-

Pn322	Reverse Direction Speed Limit Value Setting					Tore	que
Setting range	0 to 20,000	Unit	r/min	Default setting	0	Power OFF and ON	_


• Corresponding speed limit values during torque control is shown in the table below.

Torque Command/ Speed Limit Selection (Pn317)	Speed Limit Value Setting (Pn321)	Reverse Direction Speed Limit Value Setting (Pn322)	Zero Speed Designation Selection (Pn315)	Zero speed clamp	Analog torque command direction	Speed limit value
			0	Not affected		Pn321 set value
0	0 to 20,000	Not affected	1 to 3	OFF	Not affected	Pn321 set value
				ON		0
	0 to 20,000	0 to 20.000	0	Not affected	Forward direction	Pn321 set value
	0 10 20,000	0 10 20,000	0	NOI AIIECIEU	Reverse direction	Pn322 set value
2	0 to 20.000	1 to 20.000	1 to 3	OFF	Forward direction	Pn321 set value
	0 10 20,000	1 10 20,000	1103	OFF	Reverse direction	Pn322 set value
	0 to 20,000	1 to 20,000	1 to 3	ON	Not affected	0

Pn323	External Feedback Pulse Type Selection					Fully-clos	sed
Setting range	0 to 2	Unit	_	Default setting	0	Power OFF and ON	Yes

Set value	Description			
0	90° phase difference output type *1			
1	Incremental encoder with serial communications			
2	Reserved (Do not use this setting.)			

*1. These are the directions in which the Servo Drive counts the pulses from a 90° phase difference output type external encoder.



- For the external encoder connection direction, set the direction so that count-up occurs when the motor shaft is rotating counterclockwise, and count-down occurs when the motor shaft is rotating clockwise. If the connection direction cannot be selected due to installation conditions, etc., the count direction can be reversed using External Feedback Pulse Direction Switching (Pn326).
- •Take note that if Pn000 = 1, the encoder count direction becomes opposite to the count direction used for monitoring the total external encoder feedback pulses, etc.
- If Pn000 = 0, the count direction matches the count direction for monitoring. •Even when the speed command is within the Drive's speed command range, an acceleration error will occur if the speed command exceeds the maximum speed of motor shaft rotation.

Pn324	External Feedback Pulse D	ividing N	umerator			Fully-clos	sed
Setting range	0 to 2 ²⁰	Unit	_	Default setting	0	Power OFF and ON	Yes

Pn325	External Feedback Pulse Dividing Denominator Fully-					Fully-clos	sed
Setting range	1 to 2 ²⁰	Unit	_	Default setting	10000	Power OFF and ON	Yes

• Check the number of encoder pulses per motor rotation and number of external encoder pulses per motor rotation, and set External Feedback Pulse Dividing Numerator (Pn324) and External Feedback Pulse Dividing Denominator (Pn325).

Pn324 Encoder resolution per motor rotation [pulses]

- Pn325 External encoder resolution per motor rotation [pulses]
- •If this ratio is incorrect, the deviation between the position calculated from encoder pulses and position calculated from external encoder pulses will increase. Particularly when the moving distance is long, an excessive deviation error will occur.
- •Set Pn324 to 0 to have encoder resolution automatically set as numerator.

Pn326	External Feedback Pulse Direction Switching Fully-close					sed	
Setting range	0 or 1	Unit	_	Default setting	0	Power OFF and ON	Yes

Set value	Description
0	External encoder feedback pulse count direction not reversed
1	External encoder feedback pulse count direction reversed

Pn327	External Feedback Pulse P	xternal Feedback Pulse Phase-Z Setting				Fully-clos	sed
Setting range	0 or 1	Unit	-	Default setting	0	Power OFF and ON	Yes

•Set to enable or disable phase-Z disconnection detection when a 90° phase difference output type external encoder is used.

Explanation of Set Values


Set value	Description
0	Phase-Z disconnection detection enabled
1	Phase-Z disconnection detection disabled

Pn328	Internal/External Feedback	nternal/External Feedback Pulse Error Counter Overflow Level					sed
Setting range	1 to 2 ²⁷	Unit	Command unit	Default setting	16000	Power OFF and ON	Yes

• Set the allowable difference (feedback pulse error) between the motor (encoder) position and load (external encoder) position in command units.

Pn329	Internal/External Feedback	nternal/External Feedback Pulse Error Counter Reset					sed
Setting range	0 to 100	Unit	Rotation	Default setting	0	Power OFF and ON	Yes

•The feedback pulse error is reset every time the motor rotates for the amount set by the Internal/ External Feedback Pulse Error Counter Reset (Pn329). This can be used for applications where feedback pulse error accumulates due to slippage.



• When using feedback pulse error reset, make sure the feedback pulse error reset setting is set to a proper value. When the set value is extremely small, the protective function may not work to prevent any erroneous operation due to improper connection of the external encoder. Take sufficient care to ensure safety.

8-5 Interface Monitor Setting Parameters

	1					
Pn400	Input Signal Selection 1					All
Setting range	0 to 00FFFFFh	Unit	-	Default setting	8553090	Power OFF and ON Yes
						· · ·
Pn401	Input Signal Selection 2					All
Setting range	0 to 00FFFFFh	Unit	-	Default setting	8487297	Power OFF and ON Yes
						•
Pn402	Input Signal Selection 3					All
Setting range	0 to 00FFFFFh	Unit	-	Default setting	9539850	Power OFF and ON Yes
		•				· · ·
Pn403	Input Signal Selection 4					All
Setting range	0 to 00FFFFFh	Unit	-	Default setting	394758	Power OFF and ON Yes
					1	
Pn404	Input Signal Selection 5					All
Setting range	0 to 00FFFFFh	Unit	-	Default setting	4108	Power OFF and ON Yes
		•				
Pn405	Input Signal Selection 6					All
Setting range	0 to 00FFFFFh	Unit	-	Default setting	197379	Power OFF and ON Yes
		•	•			· · ·
Pn406	Input Signal Selection 7					All
Setting range	0 to 00FFFFFh	Unit	-	Default setting	3847	Power OFF and ON Yes
Pn407	Input Signal Selection 8					All
Setting range	0 to 00FFFFFh	Unit	-	Default setting	263172	Power OFF and ON Yes
Pn408	Input Signal Selection 9					All
Setting range	0 to 00FFFFFh	Unit	-	Default setting	328965	Power OFF and ON Yes
				·	·	
Pn409	Input Signal Selection 10					All
Setting range	0 to 00FFFFFh	Unit	-	Default setting	3720	Power OFF and ON Yes
Pn410	Output Signal Selection 1					All
Setting range	0 to 00FFFFFh	Unit	-	Default setting	197379	Power OFF and ON Yes
Pn411	Output Signal Selection 2					All
Setting range	0 to 00FFFFFh	Unit	-	Default setting	131586	Power OFF and ON Yes
Pn412	Not used					All
Setting range	-	Unit	-	Default setting	-	Power OFF and ON –
	1	1	I	1	1	<u> </u>
Dn/112						

Pn413	Output Signal Selection 4					A	.
Setting range	0 to 00FFFFFh	Unit	-	Default setting	328964	Power OFF and ON	Yes

•Refer to "6-9 Sequence I/O Signal" (P.6-35)for more information on settings.

Pn416	Analog Monitor 1 Selection					All
Setting range	0 to 21	Unit	_	Default setting	0	Power OFF and ON $-$


Set		Explanation	
value	Monitor type	Unit	Output gain when Pn417 = 0
0	Motor speed	r/min	500
1	Position command speed * ³	r/min	500
2	Internal position command speed * ³	r/min	500
3	Speed control command	r/min	500
4	Torque command	% (rated torque ratio)	33
5	Position command error * ⁴	pulse (command units)	3,000
6	Encoder position error * ⁴	pulse (encoder units)	3,000
7	Fully-closed error * ⁴	pulse (external encoder units)	3,000
8	Hybrid Error	pulse (command units)	3,000
9	P-N voltage	V	80
10	Regeneration load ratio	%	33
11	Overload load ratio	%	33
12	Forward direction torque limit	% (rated torque ratio)	33
13	Reverse direction torque limit	% (rated torque ratio)	33
14	Speed limit value	r/min	500
15	Inertia ratio	%	500
16	Analog input 1 * ²	V	1
17	Analog input 2 * ²	V	1
18	Analog input 3 * ²	V	1
19	Encoder temperature	°C	10
20	Drive temperature	°C	10
21	Encoder 1-rotation data * 1	pulse (encoder units)	110,000

*1. Forward and reverse directions of monitor data are the direction set in Pn000. However, CCW will be the forward direction for the absolute encoder 1-rotation data. A normal value is output from the incremental encoder after the first phase Z is input.


*2. Analog inputs 1 to 3 will output terminal voltage even when terminal is not used.

*3. Corresponding to command pulse input, command pulse speed is before command filter (position command filter time constant and smoothing filter time constant), and internal command speed is after command filter.

*4. The position command error is an error from the command pulse input, while the encoder position error or fully-closed position error is the error at the input of the position loop.



*4. Position error and feedback pulse error come in 2 types, encoder unit/external encoder unit and command unit. Encoder unit/external encoder unit will be an error of position control input section and command unit will be an error of command pulse input.



Position command error (command unit) /command feedback pulse error (command unit)

Pn417	Analog Monitor 1 Scale Set	Analog Monitor 1 Scale Setting						
Setting range	0 to 214,748,364	Unit	-	Default setting	0	Power OFF and ON	_	
	• Set output gain for analog	g monito	r 1.					

Pn418	Analog Monitor 2 Selection	Analog Monitor 2 Selection					
Setting range	0 to 21	Unit	-	Default setting	4	Power OFF and ON	_

• Select the type of analog monitor 2.

•The set value for this parameter is same as Analog Monitor 1 Type (Pn416).

Pn419	Analog Monitor 2 Scale Set		All				
Setting range	0 to 214,748,364	Unit	-	Default setting	0	Power OFF and ON	_

• Set the output gain for analog monitor 2.

Analog I	Monitor Output Selection	All
0 to 2	Unit -	- Default 0 Power OFF and ON -
 Select t 	the analog monitor output vo	bltage direction.
Set value	Output range	Data output
0	–10 to 10 V	Output voltage [V] 10 V 0 V -5,000 5,000 [r/min] -10 V
1	0 to 10 V	Output voltage [V] 10 V Motor speed -5,000 0 V 5,000 [r/min]
2	0 to 10 V	Output voltage [V] 10 V 5 V 5 V 0 2,500 [r/min] -2,500
	0 to 2 • Select t Set value 0	Select the analog monitor output volume Set value Output range 0 -10 to 10 V 1 0 to 10 V

• When monitor type is motor speed and gain of conversion is 500 (1 V = 500 r/min)

Pn422	Analog Input 1 Offset					A	.
Setting range	-5,578 to 5,578	Unit	0.359 mV	Default setting	0	Power OFF and ON	-

• Adjust the offset of the speed command input (REF: CN1 pin 14).

•The offset amount is approx. the set value times 0.359 mV.

•There are 2 ways to adjust the offset.

- · Manual adjustment
- · Automatic adjustment
- The manual adjustment is as follows:
 - To adjust the offset for individual drives, accurately input 0 V to the speed command input/torque command input (REF/TREF1) (or connect to the signal ground), and then set this parameter so that the motor does not rotate.
 - If you use a position loop in the host device, set this parameter so that there are no accumulated pulses at servo lock stop status.
- The automatic adjustment is as follows:

This parameter will be automatically set when automatic offset adjustment is executed. Refer to "Analog Input Automatic Offset Adjustment" (P.9-26) for the automatic offset adjustment method.

Pn423	Analog Input 1 Filter Time C	Analog Input 1 Filter Time Constant					
Setting range	0 to 6,400	Unit	0.01 ms	Default setting	0	Power OFF and ON	-

• Set the first-order lag filter time constant in the speed command input (REF: CN1 pin 14).

Pn424	Excessive Analog Input 1					A	
Setting range	0 to 100	Unit	0.1 V	Default setting	0	Power OFF and ON	-

• Set the overflow level for speed command input (REF: CN1 pin 14) or torque command input (TREF1: CN1 pin 14) using voltage after offset compensation.

•Excessive analog input (Alarm No. 39) will be disabled if this parameter is set to 0.

Pn425	Analog Input 2 Offset					A	.
Setting range	-342 to 342	Unit	5.86 mV	Default setting	0	Power OFF and ON	-

• Adjust the offset of the speed command input (REF: CN1 pin 16).

•The offset amount is approx. the set value times 5.86 mV.

- •There are 2 ways to adjust the offset.
 - Manual adjustment
 - Automatic adjustment

• The manual adjustment is as follows:

- To adjust the offset for individual drives, accurately input 0 V to the speed command input/ torque command input (REF/TREF1) (or connect to the signal ground), and then set this parameter so that the motor does not rotate.
- · If you use a position loop in the host device, set this parameter so that there are no accumulated pulses at servo lock stop status.

• The automatic adjustment is as follows:

This parameter will be automatically set when automatic offset adjustment is executed. Refer to "Analog Input Automatic Offset Adjustment" (P.9-26) for the automatic offset adjustment method.

Pn426	Analog Input 2 Filter Time C	A	11				
Setting range	0 to 6,400	Unit	0.01 ms	Default setting	0	Power OFF and ON	_

• Set the first-order lag filter time constant in the speed command input (REF: CN1 pin 16).

Pn427	Excessive Analog Input 2					A	
Setting range	0 to 100	Unit	0.1 V	Default setting	0	Power OFF and ON	_

• Set the overflow level for speed command input (REF: CN1 pin 16) or torque command input (TREF1: CN1 pin 14) using voltage after offset compensation.

•Excessive analog input (Alarm No. 39) will be disabled if this parameter is set to 0.

040 += 040					All			
-342 to 342	Unit	5.86 mV	Default setting	0	Power OFF and ON	-		
•The offset amount is appro •There are 2 ways to adjust Manual adjustment	ox. the s t the offs	et value times 5 mV.	• •					
 To adjust the offset fo torque command inpu parameter so that the If you use a position logo 	r individ t (REF/ ⁻ motor d pop in th	ual drives, accurately IREF1) (or connect to loes not rotate. ne host device, set thi	o the signal g	round), ar	nd then set this			
 The automatic adjustment is as follows: This parameter will be automatically set when automatic offset adjustment is executed. Refer to "Analog Input Automatic Offset Adjustment" (P.9-26) for the automatic offset adjustment method. 								
Analog Input 3 Filter Time Constant								
0 to 6,400	Unit	0.01 ms	Default setting	0	Power OFF _	-		
	 The offset amount is approven the offset amount is approven to adjust the offset of the manual adjustment is a transformer to adjust the offset for the manual adjustment is to adjust the offset for the torque command input parameter so that the original offset of the automatic adjustment of the autom	 The offset amount is approx. the set offset are 2 ways to adjust the offset offset and adjustment Automatic adjustment Automatic adjustment is as follo To adjust the offset for individ torque command input (REF/parameter so that the motor of lf you use a position loop in the accumulated pulses at server level of the automatic adjustment is as for This parameter will be automatical "Analog Input 3 Filter Time Constant 	 The offset amount is approx. the set value times 5 mV. There are 2 ways to adjust the offset. Manual adjustment Automatic adjustment is as follows: To adjust the offset for individual drives, accurately torque command input (REF/TREF1) (or connect to parameter so that the motor does not rotate. If you use a position loop in the host device, set thi accumulated pulses at servo lock stop status. The automatic adjustment is as follows: The automatic adjustment is as follows: The automatic adjustment is as follows: Analog Input Automatic Offset Adjustment" (P.9-26) for Analog Input 3 Filter Time Constant 	 Manual adjustment Automatic adjustment The manual adjustment is as follows: To adjust the offset for individual drives, accurately input 0 V to t torque command input (REF/TREF1) (or connect to the signal grameter so that the motor does not rotate. If you use a position loop in the host device, set this parameter so accumulated pulses at servo lock stop status. The automatic adjustment is as follows: The automatic adjustment is as follows: This parameter will be automatically set when automatic offset adju "Analog Input Automatic Offset Adjustment" (P.9-26) for the automatic Analog Input 3 Filter Time Constant 0 to 6 400 Unit 0 0 1 ms 	 The offset amount is approx. the set value times 5 mV. There are 2 ways to adjust the offset. Manual adjustment Automatic adjustment The manual adjustment is as follows: To adjust the offset for individual drives, accurately input 0 V to the speed torque command input (REF/TREF1) (or connect to the signal ground), ar parameter so that the motor does not rotate. If you use a position loop in the host device, set this parameter so that the accumulated pulses at servo lock stop status. The automatic adjustment is as follows: The automatic adjustment is as follows: The automatic adjustment is as follows: The automatic adjustment is as follows: This parameter will be automatically set when automatic offset adjustment is "Analog Input Automatic Offset Adjustment" (P.9-26) for the automatic offset adjustment at a postal analog Input 3 Filter Time Constant 	 The offset amount is approx. the set value times 5 mV. There are 2 ways to adjust the offset. Manual adjustment Automatic adjustment The manual adjustment is as follows: To adjust the offset for individual drives, accurately input 0 V to the speed command input torque command input (REF/TREF1) (or connect to the signal ground), and then set this parameter so that the motor does not rotate. If you use a position loop in the host device, set this parameter so that there are no accumulated pulses at servo lock stop status. The automatic adjustment is as follows: The automatic adjustment is as follows: This parameter will be automatically set when automatic offset adjustment is executed. Referrance in the automatic offset adjustment methed in the follows: Analog Input 3 Filter Time Constant All 0 to 6 400 Unit 0.01 ms 		


Pn430	Excessive Analog Input 3					Α	
Setting range	0 to 100	Unit	0.1 V	Default setting	0	Power OFF and ON	-

• Set the overflow level for speed command input (REF: CN1 pin 18) or torque command input (TREF1: CN1 pin 14) using voltage after offset compensation.

•Excessive analog input (Alarm No. 39) will be disabled if this parameter is set to 0.

Pn431	Positioning Completion Rai	Positioning Completion Range 1					Position Fully-closed			
Setting range	0 to 262,144	Unit	Command unit	Default setting	10	Power OFF and ON	-			

- Use this parameter in combination with the Positioning Completion Condition Selection (Pn432) to set the timing to output the positioning completion output (INP1). The positioning completion output (INP) will output when the Servomotor (workpiece) movement stops and the number of the accumulated pulses in the error counter is within the set value of this parameter, after command pulse input is completed.
- •Unit for setting is command unit, but it can be changed to encoder unit with Position Setting Unit Selection (Pn520). However, note that the unit for error counter overflow level will be changed as well.
- •If this parameter is set to a very small value, the time required for the INP signal to be output will increase and the chattering may occur during output. The setting of the positioning completion range does not affect the precision of the final positioning.



Pn432	Positioning Completion Cor	Positioning Completion Condition Selection					Position Fully-closed		
Setting range	0 to 3	Unit	_	Default setting	0	Power OFF and ON	-		

Set value	Description
0	Positioning completion output (INP1) turns ON when the position error is within the Positioning Completion Range 1 (Pn431).
1	Positioning completion output turns ON when the position error is within the Positioning Completion Range 1 (Pn431) and there is no position command.
2	Positioning completion output (INP1) turns ON when the zero speed detection output (ZSP) is ON, the position error is within the Positioning Completion Range 1 (Pn431), and there is no position command.
3	Positioning completion output turns ON when the position error is within the Positioning Completion Range 1 (Pn431) and there is no position command. The ON status is then held until the Positioning Completion Hold Time (Pn433) elapses. After that, if turns ON or OFF based on the position error at the time.

• Use this in combination with the Positioning Completion Range 1 (Pn431) to set the operation for positioning completion output (INP: CN1 pin 39).

Pn433	Positioning Completion Hold Time					Position Fully-closed		
Setting range	0 to 30,000	Unit	1 ms	Default setting	0	Power OFF and ON	_	


• When Positioning Completion Hold Time (Pn433) is set to 0, hold time becomes infinite and ON status is held until the next position command comes in.


Pn434	Zero Speed Detection					A	11
Setting range	10 to 20,000	Unit	r/min	Default setting	50	Power OFF and ON	-


• General-purpose output timing is set by rotation speed r/min.

+General-purpose output 1 (ZSP) will be turned ON when the speed of the motor is lower than the setting of this parameter.

•The set value in this parameter is valid in both forward and reverse directions, regardless of the actual motor rotation direction. The setting has a hysteresis of 10 r/min.








Brake timing when stopped (set value $\times 1 \text{ ms}$) $\geq \text{tb}$

•For details, refer to "6-6 Brake Interlock" (P.6-19).


Pn438	Brake Timing During Opera		A	.			
Setting range	0 to 10,000	Unit	1 ms	Default setting	0	Power OFF and ON	-

Set the required time for the brake interlock output (BKIR: CN1 pin 10) to turn OFF after the operation command (RUN: CN1 pin 29) is detected to be OFF when servo OFF status is entered while the Servomotor is operating. When the operation command (RUN) is turned OFF while the motor is operating, the motor will decelerate to reduce speed, and the brake interlock signal (BKIR) will turn ON after the setting time (set value × 1 ms) has elapsed.



•"TB" in the above figure is the Brake Timing During Operation (Pn438) (set value × 1 ms) or the time until the motor rotation speed falls to the speed set for the Brake Release Speed Setting (Pn439) or lower, whichever is shorter.

•For details, refer to "6-6 Brake Interlock" (P.6-19).



An OR output of all alarm status
Overload warning
Excessive regeneration warning
Battery warning
Fan warning
Encoder communications warning
Encoder overheating warning
Vibration detection warning
Service life detection warning
External encoder error warning
External encoder communications error warning

• Refer to "11-2 Warning List" (P.11-4) for more information on settings.

Pn441	Warning Output Selection 2)				A	
Setting range	0 to 7	Unit	_	Default setting	0	Power OFF and ON	_

• The set values for this parameter are same as Warning Output Selection 1 (Pn440).

Pn442	Positioning Completion Rar	Positioning Completion Range 2					sed
Setting range	0 to 262,144	Unit	Command unit	Default setting	10	Power OFF and ON	-

• Set the positioning completion range.

•The set values for this parameter are same as Positioning Completion Range 1 (Pn431).

8-6 Extended Parameters

Pn500	Electronic Gear Ratio Num	erator 2				Pos	ition
Setting range	0 to 2 ³⁰	Unit	-	Default setting	0	Power OFF and ON	_

Pn501	Electronic Gear Ratio Nume	erator 3				Pos	ition
Setting range	0 to 2 ³⁰	Unit	_	Default setting	0	Power OFF and ON	-


Pn502	Electronic Gear Ratio Numerator 4						ition
Setting range	0 to 2 ³⁰	Unit	_	Default setting	0	Power OFF and ON	_

Pn503	Encoder Dividing Denominator					A	
Setting range	0 to 262,144	Unit	_	Default setting	0	Power OFF and ON	Yes

 If encoder dividing denominator ≠ 0, division is performed at the rate according to the formula below.

Encoder FB pulse \rightarrow $\begin{array}{|c|} \hline Pn011 \\ \hline Pn503 \end{array}$ \rightarrow Output pulse

- •Therefore, the formula will be as follows when the host side counts pulses through processing with quadruple multiplier.
 - Number of pulse output resolution per rotation = $\frac{Pn011}{Pn053}$ × Encoder resolution
- •The pulse output resolution per rotation will never exceed the encoder resolution. (If the above settings are used, the pulse output resolution per rotation will be equal to the encoder resolution.)
- •1 phase-Z signal is output for each rotation of the motor.
- •If the pulse output resolution per rotation from the above equation is a multiple of 4, phases Z and A are output in synchronization. In all other cases, the output width of phase Z will be output as the encoder resolution, resulting to be narrower than phase A. Accordingly, phases A and Z will not be synchronized.



Pn504	Drive Prohibition Input Sele	A					
Setting range	0 to 2	Unit	-	Default setting	1	Power OFF and ON	Yes

Set value	Description
0	Forward drive prohibition input and reverse drive prohibition input enabled.
1	Forward drive prohibition input and reverse drive prohibition input disabled.
2	Forward drive prohibition input and reverse drive prohibition input enabled.

•Install limit switches at both ends of the axis to prohibit the motor from traveling in the direction where one of the switches operates. This can be used to prevent the workpiece from traveling too far and thus prevent damage to the machine.

•Operation will be as follows if 0 is set.

- Forward drive prohibition input (POT: CN1 pin 9) and COM connected: Normal status when the forward limit switch does not operate
- Forward drive prohibition input (POT: CN1 pin 9) and COM open: Forward direction prohibited
 and reverse direction permitted
- Reverse drive prohibition input (NOT: CN1 pin 8) and COM connected: Normal status when the reverse limit switch does not operate
- Reverse drive prohibition input (NOT: CN1 pin 8) and COM open: Reverse direction prohibited
 and forward direction permitted.
- If this parameter is set to 0, the Servomotor will decelerate and stop according to the sequence set in the Stop Selection for Drive Prohibition Input (Pn505) For details, refer to explanation for Stop Selection for Drive Prohibition Input (Pn505).
- If this parameter is set to 0 and the forward and reverse prohibition inputs are both open, a drive prohibition input error (Alarm No.38) occurs because it is taken that Servo Drive is in error condition.
- If this parameter is set to 2, a drive prohibition input error (Alarm No. 38) will occur when the connection between either the forward or reverse prohibition input and COM is open.
- If a limit switch above the workpiece is turned OFF when using a vertical axis, the upward torque will be eliminated, and there may be repeated vertical movement of the workpiece. If this occurs, set the Stop Selection for Drive Prohibition Input (Pn505) to 2 or perform limit processing using the Host Controller rather than using this function.

Pn505	Stop Selection for Drive Prohibition Input					A	ll l
Setting range	0 to 2	Unit	_	Default setting	0	Power OFF and ON	Yes

Explanation of Set Values

Set value	Description
0	During deceleration: Dynamic brake operation After stop: Torque command is 0 for drive prohibition direction Error counter: Held
1	During deceleration: Torque command is 0 for drive prohibition direction After stop: Torque command is 0 for drive prohibition direction Error counter: Held
2	During deceleration: Immediate stop After stop: Torque command is 0 for drive prohibition direction Error counter: Clear before and after deceleration

• Set the drive conditions during deceleration or after stopping after the drive prohibition input (POT: CN1 pin 9 or NOT: CN1 pin 8) is enabled.

• If this is set to 2, the Immediate Stop Torque (Pn511) will be used to torque limit during deceleration.

•The dynamic brake is designed only for emergency stopping. Design the system to stop within about ten minutes after the dynamic brake operates.

Pn506	Stop Selection with Servo OFF					A	
Setting range	0 to 9	Unit	-	Default setting	0	Power OFF and ON	_

Explanation of Set Values

Set		Explanation						
value	During deceleration * ³	After stopping	Error counter					
0	Dynamic brake operation	Dynamic brake operation	Clear * ⁴					
1	Free-run	Dynamic brake operation	Clear * ⁴					
2	Dynamic brake operation	Servo free	Clear * ⁴					
3	Free-run	Servo free	Clear * ⁴					
4	Dynamic brake operation	Dynamic brake operation	Hold * ²					
5	Free-run	Dynamic brake operation	Hold * ²					
6	Dynamic brake operation	Servo free	Hold * ²					
7	Free-run	Servo free	Hold * ²					
8	Immediate stop * 1	Dynamic brake operation	Clear * ⁴					
9	Immediate stop * 1	Servo free	Clear * ⁴					

• If an alarm occurs when servo is turned OFF, the operation will be based on the Stop Selection for Alarm Detection (Pn510). Additionally, if the main power supply is turned OFF when servo is OFF, it will be based on the Stop Selection with Main Power Supply OFF (Pn507).

•The dynamic brake is designed only for emergency stopping. Design the system to stop within about ten minutes after the dynamic brake operates.

*1. Emergency stop refers to an immediate stop operation applying control while servo is still ON and stopping the operation immediately.

At that time, the torque command value is restricted by the Immediate Stop Torque (Pn511).

- *2. If the position command is given or the motor runs continuously when servo is turned OFF, the position error accumulates and Alarm 24.0, "error counter overflow," may occur. In addition, if servo is turned ON when the position error or external encoder error is a large value, the motor may operate abruptly to perform a control operation to bring the error to 0. Take sufficient care when using while holding the position error or external encoder error.
- *3. Decelerating is the time between when the motor is running and when the motor speed reaches 30 r/ min or less. Once the motor reaches 30 r/min or less and moves to the after-stop status, subsequent operation is based on the after-stop status regardless of the motor speed.
- *4. The position error or external encoder error will always be cleared to 0.

Pn507	Stop Selection with Main Power Supply OFF					A	
Setting range	0 to 9	Unit	_	Default setting	0	Power OFF and ON	_

Set		Explanation						
value	During deceleration * ³	After stopping	Error counter					
0	Dynamic brake operation	Dynamic brake operation	Clear * ⁴					
1	Free-run	Dynamic brake operation	Clear * ⁴					
2	Dynamic brake operation	Servo free	Clear * ⁴					
3	Free-run	Servo free	Clear * ⁴					
4	Dynamic brake operation	Dynamic brake operation	Hold * ²					
5	Free-run	Dynamic brake operation	Hold * ²					
6	Dynamic brake operation	Servo free	Hold * ²					
7	Free-run	Servo free	Hold * ²					
8	Immediate stop * 1	Dynamic brake operation	Clear * ⁴					
9	Immediate stop * ¹	Servo free	Clear * ⁴					

 If an alarm occurs when the main power supply is turned OFF, the operation will be based on the Stop Selection for Alarm Detection (Pn510). If the main power supply is turned OFF when Servo is ON, and if the Undervoltage Alarm Selection (Pn508) is set to 1, Alarm 13.1, "main power supply undervoltage (AC cut-off detection)," will occur. Follow the Stop Selection for Alarm Detection (Pn510).

•The dynamic brake is designed only for emergency stopping. Design the system to stop within about ten minutes after the dynamic brake operates.

- *1. Emergency stop refers to an immediate stop operation applying control while servo is still ON and stopping the operation immediately.
 - At that time, the torque command value is restricted by the Immediate Stop Torque (Pn511).
- *2. If the position command is given or the motor runs continuously when the main power supply is turned OFF, the position error accumulates and Alarm 24.0, "error counter overflow," may occur. In addition, if servo is turned ON when the position error or external encoder error is a large value, the motor may operate abruptly to perform a control operation to bring the error to 0. Take sufficient care when using while holding the position error or external encoder error.
- *3. Decelerating is the time between when the motor is running and when the motor speed reaches 30 r/ min or less. Once the motor reaches 30 r/min or less and moves to the after-stop status, subsequent operation is based on the after-stop status regardless of the motor speed.

*4. The position error or external encoder error will always be cleared to 0.

Pn508	Undervoltage Alarm Selection						
Setting range	0 or 1	Unit	-	Default setting	1	Power OFF and ON	_

Explanation of Set Values

Set value	Description
0	The servo is turned OFF based on the setting of the Stop Selection with Main Power Supply OFF (Pn507) and turn it back to servo ON state by turning ON the main power supply.
1	Alarm 13.1 "main power supply undervoltage" will occur and a trip will be caused.

Pn509	Momentary Hold Time					A	
Setting range	70 to 2,000	Unit	1 ms	Default setting	70	Power OFF and ON	Yes

- Set main power supply alarm detection time.
- The main power supply OFF detection will be disabled if this is set to 2,000.

Pn510	Stop Selection for Alarm De	etection				A	.11
Setting range	0 to 7	Unit	-	Default setting	0	Power OFF and ON	-

Set		Explanation	
value	During deceleration * ³	After stopping	Error counter
0	Dynamic brake operation	Dynamic brake operation	Clear * ¹
1	Free-run	Dynamic brake operation	Clear * ¹
2	Dynamic brake operation	Servo free	Clear * ¹
3	Free-run	Servo free	Clear * ¹
4	Operation A: Immediate stop * ² Operation B: Dynamic brake operation	Dynamic brake operation	Clear * ¹
5	Operation A: Immediate stop * ² Operation B: Free-run	Dynamic brake operation	Clear * ¹
6	Operation A: Immediate stop * ² Operation B: Dynamic brake operation	Servo free	Clear * ¹
7	Operation A: Immediate stop * ² Operation B: Free-run	Servo free	Clear * ¹


• Set the operation to be performed after stopping or during deceleration when any protective function of the drive operates and an alarm occurs.

•The dynamic brake is designed only for emergency stopping. Design the system to stop within about ten minutes after the dynamic brake operates.

*1. The error counter is cleared when an alarm is reset.

*2. Operations A and B indicate whether immediate stop takes place upon alarm generation. If an immediate stop alarm is generated, immediate stop in operation A is executed. If an alarm that does not support immediate stop is generated, immediate stop in operation B will take place.

*3. Decelerating is the time between when the motor is running and when the motor speed reaches 30 r/ min or less. Once the motor reaches 30 r/min or less and moves to the after-stop status, subsequent operation is based on the after-stop status regardless of the motor speed.



Immediate Stop Operation when an Alarm that Supports Immediate Stop is Generated

- If the actual speed is not 30 r/min or less after the time set by the Alarm Detection Allowable Time Setting (Pn614) elapses, an immediate alarm status will occur. In addition, if an alarm that does not support immediate stop occurs inside the drive at immediate stop, an immediate alarm status will occur.
- Set the allowable overspeed level to Pn615, "Overspeed Detection Level Setting at Immediate Stop," as a protective measure against runaway at an immediate stop. Alarm 26.1, "overspeed 2," if it occurs, will cause an immediate alarm trip because it is an alarm that does not support immediate stop. However, if the setting is below Pn513, "Overspeed Detection Level Setting," an immediate stop will not take place because Alarm 26.1, "overspeed 2," will occur before Alarm 26.0, "overspeed."

In addition, if Alarm 26.0 and Alarm 26.1 are detected at the same time, Alarm 26.0 will be displayed. However, an immediate stop will not take place because Alarm 26.1 has also occurred internally.

Pn511	Immediate Stop Torque					A	
Setting range	0 to 500	Unit	%	Default setting	0	Power OFF and ON	_

- Set the torque limit for the following cases.
 - · Drive prohibition deceleration with the Stop Selection for Drive Prohibition Input (Pn505) set to 2.

 $\cdot\,$ Deceleration with the Stop Selection with Main Power Supply OFF (Pn507) set to 8 or 9.

- $\cdot\,$ Deceleration with the Stop Selection with Servo OFF (Pn506) set to 8 or 9.
- The normal torque limit will be used if this parameter is set to 0.
- This object is set in units of 0.1% of the rated torque.

Pn512	Overload Detection Level Setting						
Setting range	0 to 500	Unit	%	Default setting	0	Power OFF and ON	-

• Set the overload detection level.

•If this setting is 0, the level is set to 115% of nominal torque

Internally there is a limit of 115%, so higher values are limited to 115%

•This object is set as a percentage of the rated torque.

Pn513	Overspeed Detection Level	Overspeed Detection Level Setting				A	.
Setting range	0 to 20,000	Unit	r/min	Default setting	0	Power OFF and ON	-

• Set the overspeed detection level.

•The overspeed detection level setting is 1.2 times the maximum motor rotation speed if this parameter is set to 0.

•This parameter should normally be set to 0. The setting should be changed only when it is necessary to lower the overspeed detection level.

•The set value of this parameter is limited to 1.2 times the maximum motor rotation speed.


•The detection margin of error for the set value is ± 3 r/min for 17 bit absolute encoder and ± 36 r/min for a 20 bit incremental encoder

Pn514	Overrun Limit Setting	Overrun Limit Setting				sition Fully-clos	sed
Setting range	0 to 1,000	Unit	0.1 rotation	Default setting	10	Power OFF and ON	-


• Set the allowable operating range for the position command input range.

• If the set value is exceeded, motor operation range setting protection is activated.

When position command is not input



When position command is input



Pn515	Control Input Signal Read S	Setting				A	
Setting range	0 to 3	Unit	-	Default setting	0	Power OFF and ON	Yes

Set value	Description
0	0.166 ms
1	0.333 ms
2	1 ms
3	1.666 ms

• Select the signal read cycle for control input (digital input).

• The Servo Drive reads an input signal multiple times at the specified cycle. If the Servo Drive reads the same signal for multiple consecutive cycles, then the input signal is valid.

Pn516	Alarm Reset Condition Sele	ection				A	.11
Setting range	0 or 1	Unit	_	Default setting	0	Power OFF and ON	Yes

Explanation of Set Values


Set value	Description				
0	120 ms				
1	Follow the Control Input Signal Read Setting (Pn515).				
Select the select	he signal confirmation time for alarm reset input signal (RESET).				

Pn517	Error Counter Reset Condit	Error Counter Reset Condition Selection			Pos	sition Fully-clos	sed
Setting range	0 to 4	Unit	_	Default setting	3	Power OFF and ON	_


Explanation of Set Values

Description
Disabled
Clears the error counter at level when the signal is shorted for 500 μs or longer.
Clears the error counter at level when the signal is shorted for 1 ms or longer.
Clears the error counter at edge when the signal changes from open to shorted for 100 μs or longer.
Clears the error counter at edge when the signal changes from open to shorted for 1 ms or longer.

• When set to 1 or 2, the minimum time width will be as follows.



• When set to 3 or 4, the minimum time width will be as follows.



Pn518	Command Pulse Prohibition Input Setting					sition Fully-clos	sed
Setting range	0 or 1	Unit	-	Default setting	1	Power OFF and ON	-

Set value	Description
0	Enabled
1	Disabled

• Enable or disable the pulse prohibition input signal (IPG).

When command pulse prohibition input is enabled, command pulse input count process is force stopped.

Pn519	Command Pulse Prohibition Input Read Setting					sition Fully-clo	sed
Setting range	0 to 3	Unit	_	Default setting	0	Power OFF and ON	Yes

Explanation of Set Values

Set value	Description
0	0.166 ms
1	0.333 ms
2	1 ms
3	1.666 ms
4	0.166 ms (No judgment of multiple matches)

• Select the signal read cycle for the pulse prohibition input signal (IPG).

•The signal status is updated when the signal status in each signal read cycle that has been set matches multiple times.

•You can lower the possibility of incorrect operation caused by noise by extending the signal read cycle. However, the responsiveness to signal inputs will be reduced.

Pn520	Position Setting Unit Select	Po	Position Fully-closed				
Setting range	0 or 1	Unit	_	Default setting	0	Power OFF and ON	Yes

Explanation of Set Values

Set value	Description
0	Command units
1	Encoder units

• Select the setting unit of Positioning Completion Range 1 and 2 (Pn431 and Pn442), and Error Counter Overflow Level (Pn014).

Pn521	Torque Limit Selection Position Speed Fully-clo						sed
Setting range	0 to 6	Unit	-	Default setting	1	Power OFF and ON	_

Torque Limit Selection (Pn521)	Torque limit switching input (TLSEL)	Torque Limit Switching Setting (Pn523 and 524)	Forward torque limit input (PCL)	Reverse torque limit input (NCL)	Forward direction torque limit	Reverse direction torque limit
0			0 to 10 V	-10 to 0 V	PCL	NCL
1	-	-			Pn013	
2	-	_			Pn013	Pn522
3	OFF	Enabled			Pn013	
0	ON	Enabled			Pn522	
4			0 to 10 V	0 to 10 V	PCL	NCL
5			0 to 10 V	Not affected	PCL	PCL
6	OFF	-			Pn013	Pn522
<u> </u>	ON	_			Pn525	Pn526

• Select the method to set the forward and reverse torque limits.

•If this parameter is set to 1, the forward and reverse torque limit input will be limited by the No. 1 Torque Limit (Pn013).

•When using torque control, the No. 1 Torque Limit (Pn013) will be the limit value for forward and reverse operation regardless of the setting of this parameter.


Pn522	No. 2 Torque Limit	Po	Position Speed Fully-closed				
Setting range	0 to 500	Unit	%	Default setting	500	Power OFF and ON	_

• Set the limit value for the output torque (Pn013: No. 1 Torque Limit, Pn522: No. 2 Torque Limit) of the motor.

•Refer to information on the Torque Limit Selection (Pn521) to select the torque limits.


•During torque control, maximum torques for both forward and reverse directions are limited. Settings in Torque Limit Selection (Pn521) and No. 2 Torque Limit (Pn522) will be ignored.

•Make the settings as a percentage of the rated torque. [Example] Maximum torque is limited to 150%





8-6 Extended Parameters



Set value	Description
0	Position command error
1	Motor speed
2	Position command speed
3	Speed control command
4	Torque command
5	Total encoder pulses
6	Total command pulses
8	Total external encoder feedback pulses
9	Control mode
10	I/O signal status
11	Analog input value
12	Alarm factor, history
13	Warning number
14	Regeneration resistance load ratio
15	Overload load ratio
16	Inertia ratio
17	Reason for no rotation
18	Display of the number of I/O signal changes
20	Absolute encoder data
21	Absolute external encoder position
22	Monitor for the number of encoder communications errors
23	Display of axis numbers for communication
24	Position error (encoder unit)
25	External encoder error (external encoder unit)
26	Hybrid error
27	P-N voltage
28	Soft version
29	Drive serial number
30	Motor serial number
31	Accumulative operation time
32	Automatic motor recognition function
33	Temperature information
35	Safety status monitor
A Soloct t	he data to be displayed on the 7-segment LED on the front namel after the power supply

• Select the data to be displayed on the 7-segment LED on the front panel after the power supply is turned ON.

• For information on the display, refer to "9-4 Setting the Mode" (P.9-7).

Pn531	Axis Number						
Setting range	0 to 127	Unit	_	Default setting	1	Power OFF and ON	Yes

• Set the axis number for USB communications. Normally, do not change the set value.

Pn532	Command Pulse Input Maximum Setting					sition Fully-clo	sed
Setting range	250 to 4,000	Unit	kpps	Default setting	4000	Power OFF and ON	Yes

- Set the maximum number of pulses for a command pulse input. If the command pulse input frequency exceeds 1.2 multiplied by this set value, alarm 27.0 (command pulse frequency error) will occur.
- •Command pulse input frequency errors are detected for the number of pulses that are received by the Servo Drive. If the number of pulses that is input greatly exceeds this set value, normal detection of the error may not be possible. Also, if the set value is less than 1,000, one of the following digital filters is applied to the command pulse input.

Pn532 set value	Digital filter
250 to 499	200 ns × 2 readings
500 to 999	100 ns × 2 readings
1,000 to 4,000	None (through)

Pn533	Pulse Regeneration Output Limit Setting						II
Setting range	0 or 1	Unit	_	Default setting	0	Power OFF and ON	Yes

Set value	Description
0	Error detection disabled
1	Error detection enabled

•Set the detection of Alarm 28.0 "pulse regeneration error".

Pn535	Front Key Protection Setting						
Setting range	0 or 1	Unit	_	Default setting	0	Power OFF and ON	Yes

Explanation of Set Values

Set value	Description
0	Front panel operation not blocked
1	Front panel operation blocked

• Set the operation limitation from the front panel.

• The operation limits depend on the mode. The operation limits are as follows.

Mode	Operation limits
Monitor Mode	All monitor data can be checked.
Parameter Setting Mode	Parameters cannot be changed. However, parameter set values can be checked.
EEPROM Write Mode	Cannot be executed. (Will not be displayed)
Auxiliary Function Mode	Operations other than the release of the front key protection setting cannot be executed. (Will not be displayed)

8-7 Special Parameters

Pn600	Analog Torque Feed-form	ard Gain	Setting	Po	sition	Speed Fully-closed
Setting range	0 to 100	Unit	0.1 V/100%	Default setting	0	Power OFF and ON -
	• Set the input gain for ar	nalog toro	ue feed-forward. 0 t	to 9 will disable t	he fun	ction.
Pn602	Excessive Speed Error S	etting				All
Setting range	0 to 20000	Unit	r/min	Default setting	0	Power OFF and ON –
	• Set the detection level f	or excess	sive speed error (ala	arm 24.1).		
	 If 0 is set, excessive sp 	eed error	will not be detected	l.		
Pn604	Jog Speed					All
Setting range	0 to 500	Unit	r/min	Default setting	300	Power OFF and ON –
	• Set the command spee	d during	JOG trial operation ((speed control).		· · ·
Pn605	Gain 3 Effective Time				[Position Fully-closed
Setting range	0 to 10,000	Unit	0.1 ms	Default setting	0	Power OFF and ON $-$
	 Set effective time of gai 	n 3 of 3-s	step gain switching.			
Pn606	Gain 3 Ratio Setting				[Position Fully-closed
Setting range	100 to 1,000	Unit	%	Default setting	100	Power OFF and ON –
	 Set gain 3 as a multiple 	of gain 1				
Pn607	Torque Command Value	Offset				All
Setting range	-100 to 100	Unit	%	Default setting	0	Power OFF and ON $-$
	• Set offset torque to add	to torque	command.			
	 This object is set as a p 	ercentage	e of the rated torque).		
Pn608	Forward Direction Torque	Offset				All
Setting range	-100 to 100	Unit	%	Default setting	0	Power OFF and ON –
	• Set the value to add to	the torque	e command in the fo	orward direction	operat	ion.
	 This object is set as a p 	ercentage	e of the rated torque).		
Pn609	Reverse Direction Torque	Offset				All
Setting range	-100 to 100	Unit	%	Default setting	0	Power OFF and ON $-$
	Set offset torque to add	to torque	e command for reve	rse direction ope	eration.	
	 This object is set as a p 	ercentage	e of the rated torque	9.		
Pn610	Function Expansion Setti	ng				Position

Pn610	Function Expansion Setting						tion
Setting range	0 to 63	Unit	-	Default setting	0	Power OFF and ON	_

• Set the functions by bit.

Bit	Function	Set value			
Dit		0	1		
bit 0	Instantaneous speed observer function	Disabled	Enabled		
bit 1	Disturbance observer function	Disabled	Enabled		
bit 2	Disturbance observer operation setting	Always enabled	Only when gain 1 is selected		
bit 3	Inertia ratio switching function	Disabled	Enabled		
bit 4	Electric current response improvement function	Disabled	Enabled		
bit 5	Analog Torque Feed-forward	Disabled	Enabled		

• Set the decimal value that has been converted from the bits. [Example]

- Instantaneous speed observer function: enabled
- Disturbance observer function: enabled
- Disturbance observer operation setting: always enabled
- Inertia ratio switching function: disabled
- Electric current response improvement function: enabled

• Analog torque feed-forward: disabled If the settings are as described above, the bits will be 010011, and the decimal value will be 19. Therefore, the set value will be 19.

Pn611	Electric Current Response Setting						
Setting range	50 to 100	Unit	%	Default setting	100	Power OFF and ON	-

• Make fine adjustment to electric current response. The default setting is 100%.

Pn613	Inertia Ratio 2						
Setting range	0 to 10,000	Unit	%	Default setting	250	Power OFF and ON	_

• Set the second load inertia as a percentage of the motor rotor inertia.

Pn614	Alarm Detection Allowable Time Setting					A	
Setting range	0 to 1,000	Unit	ms	Default setting	200	Power OFF and ON	_

• Set the allowable time required until the motor stops by an emergency stop due to an alarm.

• When the time exceeds the set value, the operation forcibly turns to an alarming state.

• When the parameter is set to 0, the protection by allowable time does not function.

• Refer to the "Stop Selection for Alarm Detection" (Pn510) (P.8-51).

Pn615	Overspeed Detection Level Setting at Immediate Stop					A	
Setting range	0 to 20,000	Unit	r/min	Default setting	0	Power OFF and ON	_

• Set overspeed detection level upon generation of immediate stop alarm.

•The overspeed detection level setting will be 1.2 times the maximum motor rotation speed if this parameter is set to 0.

•This parameter should normally be set to 0. The setting should be changed only when it is necessary to lower the overspeed detection level.

•The set value of this parameter is limited to 1.2 times the maximum motor rotation speed.

Pn616	Absolute Interface Function	Selectio	n			A	
Setting range	0 or 1	Unit	-	Default setting	1	Power OFF and ON	Yes

Explanation of Set Values

Set value	Explanation
0	Disabled
1	Enabled

• Set this parameter to 1.

Pn617	Front Panel Parameter Write Selection					A	
Setting range	0 or 1	Unit	_	Default setting	0	Power OFF and ON	Yes

Explanation of Set Values

Set value	Explanation
0	EEPROM write not performed when a parameter is changed from the front panel
1	EEPROM write performed at the same time

• Set the EEPROM write conditions when the front panel parameter is changed.

Pn618	Power Supply ON Initialization Time					A	.
Setting range	0 to 100	Unit	0.1 s	Default setting	0	Power OFF and ON	Yes

• Set initialization time after power supply ON to the standard 1.5 seconds plus some.

Pn619	Encoder Phase-Z Setting					A	
Setting range	0 to 32,767	Unit	Pulse	Default setting	0	Power OFF and ON	Yes

• Finely adjust the ON width of encoder phase-Z signal output.

• This is enabled when the phase-Z output and phase-A output are not synchronized (Pn011/Pn503 \times Encoder resolution is not a multiple of 4) due to the encoder dividing ratio setting.

•The set value of Pn619 and the ON width of phase-Z output are related as follows: Phase-Z output width [s] = 30/(Pn619 × Motor speed [r/min])

Pn620	External Encoder Phase-2	External Encoder Phase-Z Setting					sed
Setting range	0 to 400	Unit	μs	Default setting	0	Power OFF and ON	Yes

• Set the external encoder phase-Z regeneration width with time.

•You can output the phase-Z signal at least for the period of time that has been set if the phase-Z signal width is too short for detection due to the travel distance from the external encoder.

Pn622	90° Phase Difference Output T	ype Exte	rnal Encoder Phase-AB F	Regeneration Me	ethod Selec	tion Fully-clo	sed
Setting range	0 or 1	Unit	-	Default setting	0	Power OFF and ON	Yes

• Select the regeneration method of pulse outputs A and B when a 90° phase difference output type external encoder is used.

Explanation of Set Values

Set value	Explanation
0	Without signal regeneration
1	With signal regeneration *1,*2

*1. Through outputs are always made for phase Z without signal regeneration.

*2. If the signal regeneration setting is selected, the duties of A and B are regenerated on the amplifier side and disturbance of waveforms can be suppressed. Take note, however, that this causes delays in phase Z.

Pn623	Disturbance Torque Compensation Gain					Position Fully-closed		
Setting range	-100 to 100	Unit	%	Default setting	0	Power OFF and ON	_	
A Set the componentian agin for the disturbance targue								

• Set the compensation gain for the disturbance torque.

Pn624	Disturbance Observer Filter Setting					sition Fully-clo	sed
Setting range	10 to 2,500	Unit	0.01 ms	Default setting	53	Power OFF and ON	-

• Set the filter time constant for disturbance torque compensation.

Pn627	Warning Latch Hold Time Selection					A	
Setting range	0 to 10	Unit	S	Default setting	5	Power OFF and ON	Yes

• After the cause of a warning is cleared, the warning state is held for the number of seconds set with Warning Latch Hold Time Selection (Pn627).

• When 0 is set, the warning state is held even after the cause of the warning is cleared.

Explanation of Set Values

Set value	Explanation
0	The warning state is held even after the cause of the warning is cleared. To clear the warning state, execute the alarm clear.
1 to 10	The warning state is held for the set number of seconds after the cause of the warning is cleared. For example, when 3 is set, the warning state is held for 3 seconds after the cause of the warning is cleared.

Pn628	Not used	Not used						
Setting range	-	Unit	-	Default setting	_	Power OFF and ON	-	
Pn631	Realtime Autotuning Estin	nated Spe	ed Selection			A	.	
Setting range	0 to 3	Unit	-	Default setting	1	Power OFF and ON	Yes	

Set value	Explanation						
0	Finalize estimated results when load estimation becomes stable.						
1	Estimates every minute from the load characteristic changes.						
2	Estimates every second from the load characteristic changes.						
3	Estimates the optimum speed from the load characteristic changes.						

Pn632	Realtime Autotuning Custo		All				
Setting range	-32,768 to 32,767	Unit	_	Default setting	0	Power OFF and ON	-

• Set details of autotuning when the Realtime Autotuning Mode Selection (Pn002) is set to 6.

• Refer to "10-2 Realtime Autotuning" (P.10-3) for information on realtime Autotuning.

Explanation of Set Values

Bits	Name	Explanation			
0 or 1	Load characteristics estimation ^{*1}	Enable or disable load characteristics change, the estimation. 0: Disabled 1: Enabled			
2 or 3	Change inertia ratio	Set how to update the results of load characteristics estimation for the Inertia Ratio (Pn004). 0: Use the present set value 1: Update with the estimation result			
4 to 6	Torque compensation	 Set how to update the results of load characteristics estimatic for the Torque Command Offset (Pn607), Forward Torque Offset (Pn608), and Reverse Torque Offset (Pn609). 0: Use the present set value 1: Disable torque compensation and clear the above parameter to 0. 2: Vertical mode. Update Pn607 and clear Pn608 and Pn609 0. 3: Weak friction compensation. Update Pn607 and set Pn608 and Pn609 for weak friction compensation. 4: Medium friction compensation. Update Pn607 and set Pn608 and Pn609 for medium friction compensation. 5: Strong friction compensation. Update Pn607 and set Pn608 and Pn609 for strong friction compensation. 			
7	Rigidity setting	Enable or disable the basic gain settings for the Realtime Autotuning Machine Rigidity Selection (Pn003). 0: Disabled 1: Enabled			

Bits	Name	Explanation
8	Fixed parameter setting	Enable or disable the normally fixed parameters. 0: Use the current settings 1: Set to fixed values
9 to 10	Gain switching setting	Select the setting method for parameters related to gain switching when realtime autotuning is enabled. 0: Use the current settings 1: Disable gain switching 2: Enable gain switching

*1 When load characteristic estimation is disabled, inertia ratio updating is also disabled, even if the latter is set to be updated with the estimation result. When torque compensation is updated with the estimation result, load characteristic estimation is disabled.



Safety Points

• This parameter is set at the bit level. Unexpected operation may occur if the bits are not set correctly. Set this parameter with care.



Reference

Setting Bit-level Parameters

Use the following procedure to calculate the set value if all settings are not 0.

- (1) Check the lowest bit for each setting.
 - Example: Lowest bit for torque compensation: 4
- (2) Multiply the set value by 2 to the power of the lowest bit.
 - Example: The value for weak friction compensation for the torque compensation would be 2⁴ \times 3 = 48.
- (3) Repeat steps 1 and 2 for all settings and add the results to obtain the set value for Pn632. Example: The calculation is as follows for the following settings: Load characteristic estimation: Enabled, Inertia ratio updating: Enabled, Torque compensation: Weak friction compensation, Rigidity setting: Enabled, Fixed parameters: Set to fixed values, and Gain switching: Enabled.

 $2^{0} \times 1 + 2^{2} \times 1 + 2^{4} \times 3 + 2^{7} \times 1 + 2^{8} \times 1 + 2^{9} \times 2 = 1461$

Pn633	Absolute Encoder Initial Pu	A					
Setting range	1,000 to 3,000	Unit	r/min	Default setting	1000	Power OFF and ON	_

• Set the pulse regeneration speed when the initial pulse is output.

- Connection with OMRON controller For the Host Controller to correctly receive the position from the absolute encoder, the pulse output from the drive must be set to be completed before the controller's timeout.
- •Pulse are outputted to a speed equivalent to a motor rotating at a speed specified by this parameter.

The following values or more are recommended for use.

OMRON controller	Pn633
CJ1W-NC□□4	1000
CS1W-MC	1000
CV500-MC	3000
3F88M-DRT141	1500

*1. You can set the timeout setting time on the controller side.

Pn634	Hybrid Vibration Suppress	Fully-clos	sed				
Setting range	0 to 30,000	Unit	0.1/s	Default setting	0	Power OFF and ON	_

•Set the hybrid vibration suppression gain.

•In general, set it to the same value as the position loop gain, and finely adjust it based on the situation.

Pn635	Hybrid Vibration Suppress	Fully-closed					
Setting range	0 to 6,400	Unit	0.01 ms	Default setting	10	Power OFF and ON	_

•Set the hybrid vibration suppression filter.

Pn637	Vibration Detection Thresho	All					
Setting range	0 to 1,000	Unit	0.1%	Default setting	0	Power OFF and ON	-

•Set the vibration detection threshold.

If torque vibration that exceeds this setting is detected, the vibration detection warning will occur.
This object is set in units of 0.1% of the rated torque.

Pn638	Warning Mask Setting					All	
Setting range	-32,768 to 32,767	Unit	-	Default setting	4	Power OFF and ON	Yes

• Set a mask for warning detection.

• If you set the corresponding bit to 1, the corresponding warning detection will be disabled.

• Refer to "11-2 Warning List" (P.11-4) for details on the setting method.

Precautions for Correct Use

Parameters between Pn700 and Pn800 are not used. Do not change the settings.

9

Operation

This chapter gives the operating procedures and explains how to operate in each mode.

9-1	Operational Procedure	9-1
9-2	Preparing for Operation	9-2
	Items to Check Before Turning ON the Power Supply	
	Turning ON the Power Supply	
	Checking the Displays	
	Absolute Encoder Setup	
9-3	Using the Front Display	9-6
9-4	Setting the Mode	9-7
	Changing the Mode	
	Monitor Mode	
	Parameter Setting Mode	9-22
	Parameter Write Mode	
	Auxiliary Function Mode	9-25
9-5	Trial Operation	9-33
	Preparation for Trial Operation	
	Trial Operation in Position Control Mode	
	Trial Operation in Speed Control Mode	
	Trial Operation in Torque Control Mode	
	Trial Operation in Fully-closed Control Mode	9-37

9-1 Operational Procedure

Turn ON the power supply after the correct installation and wiring to check the operation of the individual motor and drive.

Then make the function settings as required according to the use of the motor and drive. If the user parameters are set incorrectly, there is a risk of an unpredictable motor operation, which is dangerous. Set the parameters securely according to the setting methods in this manual.

Item	Contents	Reference
Mounting and installation	Install the motor and drive according to the installation conditions.(Do not connect the motor to the mechanical system before checking no-load operation.)	Chapter 4, 4-1
+		
Wiring and connections Connect the motor and drive to the power supply and peripheral equipment. Specified installation and wiring conditions must be satisfied, particularly for models conforming to the EC Directives.		Chapter 4, 4-2
•		•
Preparing for operation	Check the necessary items and then turn ON the power supply. Check on the display to see whether there are any internal errors in the drive. When using a Servomotor with an absolute encoder, set up the absolute encoder.	Chapter 9, 9-2
•		•
Function settings	By means of the user parameters, set the functions according to the operating conditions.	Chapter 8
Ļ	1	ł
Trial operation	First, check the motor operation with no-load. Then turn the power supply OFF and connect the motor to the mechanical system. If using a motor with an absolute encoder, set up the absolute encoder and set the Motion Control Unit's initial parameters. Turn ON the power supply again, and check to see whether protective functions, such as the emergency stop and operational limits, work properly. Check operation at both low speed and high speed using the system without a workpiece, or with dummy workpieces.	Chapter 9, 9-5
Adjustment	Manually adjust the gain if necessary. Further adjust the various functions to improve the control performance.	Chapter 10
Operation	Operation can now be started. If any problems should occur, refer to "Chapter 11, Troubleshooting and Maintenance".	Chapter 11

9-2 Preparing for Operation

This section explains the procedure to prepare the mechanical system for operation following installation and wiring of the motor and drive. It explains items to check both before and after turning ON the power supply.

It also explains the setup procedure required if using a motor with an absolute encoder.

Items to Check Before Turning ON the Power Supply

Checking Power Supply Voltage

- Check to be sure that the power supply voltage is within the ranges shown below.
- R88D-KTA5L/KT01L/KT02L/KT04L (Single-phase 100-VAC input) Main circuit power supply: Single-phase 100 to 120 VAC (85 to 132) 50/60 Hz Control circuit power supply: Single-phase 100 to 120 VAC (85 to 132) 50/60 Hz
- R88D-KT01H/02H/04H/08H/10H/15H (Single-phase or single-phase/3-phase 200-VAC input) Main circuit power supply: Single-phase or single-phase/3-phase 200 to 240 VAC (170 to 264 V) 50/60 Hz Control circuit power supply: Single-phase 200 to 240 VAC (170 to 264 V) 50/60 Hz
- R88D-KT20H/30H/50H/75H/150H (3-phase 200-VAC input) Main circuit power supply: 3-phase 200 to 230 VAC (170 to 253 V) 50/60 Hz Control circuit power supply: Single-phase 200 to 230 VAC (170 to 253 V) 50/60 Hz
- R88D-KT06F/KT10F/KT15F/KT20F/KT30F/KT50F/KT75F/KT150F (3-phase 400-VAC input) Main circuit power supply: 3-phase 380 to 480 VAC (323 to 528 V) 50/60 Hz Control circuit power supply: 24 VDC \pm 15%

Checking Terminal Block Wiring

- The main circuit power supply inputs (L1/L3 or L1/L2/L3) must be properly connected to the terminal block.
- The control circuit power supply inputs (L1C/L2C) must be properly connected to the terminal block.
- The motor's U, V, and W power lines and the green/yellow () must be properly connected to the terminal block.

Checking the Motor

- There should be no load on the motor. (Do not connect the mechanical system.)
- The motor side power lines and the power cables must be securely connected.

Checking the Encoder Wiring

- The encoder cable must be securely connected to the encoder connector (CN2) at the drive.
- The encoder cable must be securely connected to the encoder connector at the motor.

Checking the Control I/O Connector

- The control cable must be securely connected to the control I/O connector (CN1).
- The operation command (RUN) must be OFF.


Turning ON the Power Supply

- First carry out the preliminary checks, and then turn ON the control circuit power supply. It makes no difference whether or not the main circuit power supply is turned ON.
- The alarm output (/ALM) will take approx. 2 seconds to turn ON after the power supply has been turned ON. Do not attempt to detect an alarm using the Host Controller during this time. (If power supply is turned ON while the Host Controller is connected.)

Checking the Displays

Displays on the Drive

• The following will appear on the display area on the drive when the power supply is turned ON.



Absolute Encoder Setup ABS

You must set up the absolute encoder if using a motor with an absolute encoder. The setup is required when you turn ON the power supply for the first time, when an absolute encoder system down error (Alarm No. 40) occurs, or when the encoder cable is disconnected and then connected again.

When using an absolute encoder, set Pn015 to 0 or 2 and set Pn616 to 1.

Set up an absolute encoder while the servo is OFF. Always cycle the power supply after completing the setup.

Absolute Encoder Setup Procedure

1. Turn ON the power supply and align the origin position.


Turn ON the power supply, perform the origin adjustment operation, and move the machine to the origin position.

2. Go to Auxiliary Function Mode.

Press (3) and (MAR) on the drive. Auxiliary Function Mode will be displayed.

3. Use the Increment and Decrement keys to go to the Absolute Encoder Clear Mode. Press again. Absolute Encoder Clear Mode will be displayed.

(AUXILIARY FUNCTION mode)




4. Start clearing the absolute encoder.

Hold down \bigotimes . Clearing the absolute encoder will be started.

9

9-2 Preparing for Operation




Note. $\boxed{\mathcal{E} \ r \ r \ o \ r}$ will be displayed if absolute encoder clear is performed on an incremental encoder.

5. Restart the drive.


Turn OFF the control power supply to the drive and then turn it back ON.

9-3 Using the Front Display




9-4 Setting the Mode

Changing the Mode



*1. The display will be based on the Default Display (Pn528) setting after the power supply is turned ON.

Monitor Mode





When () is pressed, the display position will move in the direction of the arrow.

When \bigotimes is pressed, it will move in the opposite direction.

• The motor rotation speed will be displayed the first time the power supply is turned ON after purchase. To change the initial display when the power supply is turned ON, change the setting for the Default Display (Pn528). For details, refer to Pn528 "Default Display" (P.8-57).

9






9

Control Mode	UDBcnt
PoScat	Position Control Mode
SPdcnt	Speed Control Mode
tr9cnt	Torque Control Mode
Felent	Fully-closed Control Mode
 Displays which co 	ontrol mode is being used: position control, speed control, torque control, or fully-






□ ⊑ ...Output

closed control.

· Displays the status of the control input and output signals connected to CN1.

Switching between Input Signals and Output Signals




If the decimal point is on the right side of the signal number, the signal number can be changed.

Use (() to move the flashing decimal point.


If the decimal point is on the right side of the I/O switching point, you can switch between input and output.

Switch between input and output.

Press \bigotimes \bigotimes to select the signal you want to monitor.




Operation




Input signal Input voltage (V)

Press () to select the signal you want to monitor.



Note. Voltages exceeding +/-10 V are not displayed accurately.

Alarm Factor, History



- E -....Present alarm
- E D....History 0 (latest history)
- E I 3. ...History 13 (oldest history)
- Up to the most recent 14 alarms, including the current one, can be viewed in the reason of error.
- The display area will flash when an alarm occurs.
- If an alarm that is recorded in the history occurs, the alarm code for the current alarm and for history 0 will be the same.
- "st" will flash on the display if a safety input error (alarm 30.0) occurs.

Operation

Alarm Codes and Meanings

Alarm codes	Contents	Alarm codes	Contents
11	Control power supply undervoltage	36	Parameter error
12	Overvoltage	37	Parameters destruction
13	Main power supply undervoltage	38	Drive prohibition input error
14	Overcurrent	39	Excessive analog input
15	Servo Drive overheat	40	Absolute encoder system down error ABS
16	Overload	41	Absolute encoder counter overflow error ABS
18	Regeneration overload	42	Absolute encoder overspeed error ABS
21	Encoder communications error	44	Absolute encoder 1-rotation counter error ABS
23	Encoder communications data error	45	Absolute encoder multi-rotation counter error ABS
24	Error counter overflow	46	Encoder error 1
26	Overspeed	47	Absolute encoder status error ABS
27	Electronic gear setting error	48	Encoder phase-Z error
34	Overrun limit error	49	Encoder CS signal error

Note. The following alarms are not recorded in the history.

11: Control power supply undervoltage


13: Main power supply undervoltage

36: Parameter error

37: Parameters destruction

38: Drive prohibition input error

95: Motor non-conformity







R_c -

-C 80.0

Regeneration Load Ratio

• Displays the regeneration resistance load ratio as a percentage when the detection level for the regeneration overload is 100%.

]

o.L 1000

• Displays the overload ratio as a percentage when the rated load corresponds to 100%.

814. -6



U 15.Jィモ


L I D The inertia ratio (%) is displayed.


9

	A number is display	ed to indica	ate the reason the motor does not rotate.
	□ □ □ ↓ □ ↓ Control mode Reason number	₽Posit ⊆ Spee	tion control /Torque control ed control /Fully-closed control
Number	Item	Relevant control mode	Description
Flashing	Alarm or warning has occurred	All	An alarm has occurred. Warning has occurred.
0	No reason	All	No reason has been detected. The motor operation should be possible.
1	Main power supply interrupted	All	The main power supply to the drive is not turned ON.
2	No RUN input	All	The operation command (RUN) is not connected to COM.
3	Drive prohibition input is enabled.	All	 When Pn504 = 0 (drive prohibition input enabled): The forward drive prohibition input (POT) is open and the speed command is in the forward direction. The reverse drive prohibition input (NOT) is open and the speed command is in the reverse direction.
4	Low torque limit setting	All	The currently effective torque limit set value, Pn013 (No. 1 Torque Limit) or Pn522 (No. 2 Torque Limit), is less than 5% of the rated torque.
5	Analog torque limit input is enabled.	P, S	 When Pn527 = 0 (analog torque limit scale): The forward analog torque limit input is negative and the speed command is in the forward direction. The reverse analog torque limit input is positive and the speed command is in the reverse direction.
6	IPG input is enabled.	Р	Pn518 = 0 (command pulse prohibition input enabled) and the IPG input is open.
7	Frequency of command pulse input is low.	Ρ	 The command pulse is not input correctly. The input selected in Pn005 is not connected correctly. The type of input selected in Pn006 or Pn007 is not correct. The position command per control cycle is 1 pulse or less and the above are some of the possible causes.
8	ECRST input is enabled.	Р	Pn517 = 0 (Error counter reset at the level) and the error counter reset input (ECRST) is connected to COM.
9	VZERO input is enabled.	S, T	Pn315 = 1 (zero speed designation enabled) and the zero speed designation input (VZERO) is open.
10	External speed command is low.	S	The analog speed command is 0.06 V or lower when the analog speed command is selected.
11	Internal speed command is 0.	S	The internal speed command is 30 r/min or less when the internal speed command is selected.
12	Torque command is low	т	The analog torque command input (REF or PCL) is 5% or less of the rated torque.
13	Speed limit is low	Т	 Pn317 = 0 (speed limit with No. 4 internally set speed) and the No. 4 Internally Set Speed (Pn307) is 30 r/min or lower. Pn317 = 1 (speed limit with REF input) and the analog speed command input (REF) is 0.06 V or lower.


Number	Item	Relevant control mode	Description
14	Other reasons	All	Reasons 1 to 13 do not apply, but the motor is rotating at 20 r/min or lower. (Low command, heavy, locked, or crashed load, faulty drive or motor, etc.)


Note. The motor may rotate even if a reason number other than 0 is displayed.







The value set by the Axis Number (Pn531) is displayed.









Parameter Setting Mode

1. Displaying Parameter Mode

Key operation	Display example	Explanation
	r 0	The item set for the Default Display (Pn528) is displayed.
DATA	Un_SPd.	Press the DATA key to display Monitor Mode.
(-)	Pr 10.	Press (5) key to display Parameter Setting Mode.

2. Setting the parameter number

Key operation	Display example	Explanation
$\overset{\textup{l}}{\circledast}$	<u> </u>	 Use (*) (*) (*) (*) (*) (*) (*) (*) (*) (*)

3. Displaying parameter set values

Key operation	Display example	Explanation
DATA	Ч ().	Press the Data key to display the set value.

4. Changing the parameter set value

Key operation	Display example	Explanation
$\overset{\textup{l}}{\circledast}$	100.	 Use the keys to change the value. Press to move "." to the left and change the digit to be set. Press to increase the value of the digit with ".". Press to decrease the value of the digit with ".".
DATA	100.	 Press the ATA key to save the new set value. To cancel the change, instead of pressing ATA, press (to return to the display in procedure 2.

5. Returning to Parameter Setting Mode

	Key operation	Display example	Explanation
	DATA	Pr. 10.	Press the PATA key to return to Parameter Setting Mode.
Precautions for Correct Use			

- Some parameters will be displayed with an "r" before the number when the display returns to the Parameter Setting Mode. To enable the set values that have been changed for these parameters, you must turn the power supply OFF and ON after saving the parameters to the EEPROM.
- If the Front Panel Parameter Write Selection (Pn617) is set to 1, the parameter set value is automatically written to EEPROM when changed.
- When the set value for a parameter is saved, the new setting will be used for control. Make gradual changes instead of changing the large numbers at once, when changing values for parameters that greatly affect motor operation (speed loop gain, position loop gain, etc. in particular).
- For details on parameters, refer to "Chapter 8, Parameter Details".

Parameter Write Mode

Set values changed in Parameter Setting Mode must be saved to EEPROM. To do so, the following operation must be performed.

1. Saving changed set values

Key operation	Display example	Explanation
(-)	EELSEE	Press the (5) key to display Parameter Write Mode.
DATA	EEP	Press the (ATA) key to enter Parameter Write Mode.
\bigotimes	<u> 227</u>	Press and hold the \bigotimes key for 5 seconds or longer until $5 \pm R - E$ is displayed.
		The bar indicator will increase.
	SERrE	Writing will start. (This display will appear only momentarily.)
	F .n .Sh.	This indicates a normal completion. In addition to this display, either $r \in S \subseteq E$ or $E r \cap O r$ may be displayed. If $r \in S \subseteq E$ is displayed, writing has been completed normally, but some of the changed parameters will be valid only after the power supply has been turned OFF and ON again. Turn OFF the drive power supply and then turn it ON again. $E r \cap O r$ will be displayed if there is a write alarm. Write the data again.

2. Returning to Parameter Write Mode

	Key operation	Display example	Explanation
	DATA	88-988	Press the (ATA) key to return to Parameter Write Mode.
ſ	Precautio	ns for Correct Use	

- If a write alarm occurs, write the data again. If write alarms continue to occur, there may be a fault in the drive.
- Do not turn OFF the power supply while writing to EEPROM. Incorrect data may be written if the power supply is turned OFF. If the power supply is turned OFF, perform the settings again for all parameters, and write the data again.

Auxiliary Function Mode

Auxiliary Function Mode includes the alarm clear, analog input automatic offset adjustment, absolute encoder reset, jog operation, parameter initialization, and front panel lock/release.

Displaying Auxiliary Function Mode

Key operation	Display example	Explanation
	r 0	The item set for the Default Display (Pn528) is displayed.
DATA	Un_SPd.	Press the (ATA) key to display Monitor Mode.
	Fn_RcL.	Press the 🕞 key 3 times to display Auxiliary Function Mode.

Alarm Clear

This releases the alarm generation status. Some alarms cannot be released. Refer to "11-3 Alarm List" (P.11-5) for details.

1. Execute alarm clear

Key operation	Display example	Explanation
DATA	ReL	Press the DATA key to enter Alarm Clear Mode.
$\langle \approx \rangle$	Rel	Press and hold the $\textcircled{>}$ key for 5 seconds or longer until $\boxed{5 \pm 8 - \pm}$ is displayed.
		The bar indicator will increase.
	SERrE	Alarm clear will start.
	FiniSh.	This indicates a normal completion. $\boxed{\underline{\mathcal{E}}_{r,r,o,r,o,r,o,r,o,r,o,r,o,r,o,r,o,r,o,r$

2. Returning to Auxiliary Function Mode display

Key operation	Display example	Explanation
DATA	Fn_RcL.	Press the DATA key to return to Auxiliary Function Mode.

Analog Input Automatic Offset Adjustment

This performs automatic adjustment on the Offset Values (Pn422, Pn425 and Pn428) of Analog Inputs 1 to 3 (AI1 to AI3).

Do not perform this operation if a position loop has been configured with the host system.

1. Execute automatic offset adjustment

Key operation	Display example	Explanation
 	Fn_oFl or Fn_oF2. or Fn_oF3.	Press the Rey to display the Analog Input Automatic Offset Adjustment Mode from the alarm clear display in the Auxiliary Function Mode.
DATA	oF or or or or or	Press the bara key to enter the Automatic Offset Adjustment Mode of the analog input number to be set.
	oF ! or oF 2 or oF 3	Press and hold the \textcircled{R} key for 5 seconds or longer until $\boxed{5 \pm Rr \pm}$ is displayed.
	<u>-</u> .	The bar indicator will increase.
	SERFE	Automatic offset adjustment will start.
	FiniSh.	This indicates a normal completion. $\boxed{\underline{\mathcal{E}} \ r \ o \ r}$ will be displayed if the automatic offset adjustment could not be performed. Set a valid control mode or make the setting so that the offset value does not exceed the range for the Speed Command Offset Value (Pn422, Pn425, or Pn428), and then execute the procedure again.

2. Returning to Auxiliary Function Mode display

Key operation	Display example	Explanation
DATA	Fn_oF (or Fn_oF2) or Fn_oF3)	Press the (ATA) key to return to Auxiliary Function Mode.

Operation

Precautions for Correct Use

- Automatic offset adjustment function cannot be performed in Position Control Mode.
- Data is not written to the EEPROM simply by performing automatic offset adjustment. The data must be written to the EEPROM for the results to be saved.

Jog Operation

You can perform a trial operation of the motor with no load without wiring the control I/O connector (CN1).

1. Prepare for a jog operation

Key operation	Display example	Explanation
\bigcirc	Fn_Job.	Press the local key to display the Jog Operation Mode from the alarm clear display in Auxiliary Function Mode.
DATA	Job	Press the (ATA) key to enter Jog Operation Mode.
$\langle \approx \rangle$	Job	Press and hold the \bigotimes key for 5 seconds or longer until $5 \pm Rr \pm$ is displayed.
	<u>-</u> .	The bar indicator will increase.
	<u>- 2839</u> .	This completes preparations for jog operation. $\boxed{\underline{\mathcal{E}}_{rror}}$ will be displayed if the servo is not ready.
	r E 8 d 4.	Press and hold the \textcircled{key} for 5 seconds or longer until $\boxed{5 \pm Rr \pm}$ is displayed.
	r.8834	The decimal point will move to the left.
	Srulon	The Servo will turn ON.

2. Execute jog operation

Key operation	Display example	Explanation
	SrUlon	Forward direction operation will be performed while the key is pressed, and reverse direction operation will be performed while the key is pressed. The motor will stop when the key is released. The rotation speed at this time will be the speed set for the Jog Speed (Pn604). $\boxed{\underline{\mathcal{E}_{\Gamma\Gamma Q\Gamma}}}$ will be displayed if the servo is not ready.

3. Returning to Auxiliary Function Mode display

Key operation	Display example	Explanation
DATA	Fr-Job.	Press the \widehat{D} key to return to Auxiliary Function Mode. The servo lock will be released and the servo will be unlocked.

Precautions for Correct Use

- When performing a jog operation, be sure to first disconnect the motor from any load and remove the control I/O connector (CN1).
- When performing a jog operation, set the parameter related to gains to an appropriate value to avoid any troubles, such as vibration. Set the Inertia Ratio (Pn004) to 0.
- The motor operates in the Speed Control Mode during a jog operation. Set each of the various settings so that the motor operates correctly for speed control.
- If the operation command (RUN) is turned ON during a jog operation, <u>Error</u> will be displayed, and the jog operation will be cancelled and a normal operation through an external command will be performed.

Absolute Encoder Reset ABS

This resets the multi-rotation data and alarms of the absolute encoder.

1. Execute absolute encoder reset

Key operation	Display example	Explanation
\bigotimes	Fn_Enc	Press the \bigotimes key to display the Absolute Encoder Reset Mode from the alarm clear display in Auxiliary Function Mode.
DATA	Enc	Press the DATA key to enter Absolute Encoder Reset Mode.
$\langle \approx \rangle$	Enc	Press and hold the \bigotimes key for 5 seconds or longer until $5 \pm Rr \pm$ is displayed.
	<u>-</u> .	The bar indicator will increase.
	SERFE	Absolute encoder reset will start.
	FiniSh.	This indicates a normal completion. $\boxed{\underline{\mathcal{E}} \ r \ c \ c}$ will be displayed if the absolute encoder reset could not be performed. Check whether an unsupported encoder is connected, and then execute the procedure again.

2. Returning to Auxiliary Function Mode display

Key operation	Display example	Explanation
DATA	Fn_Enc	Press the \widehat{P} key to return to Auxiliary Function Mod.

Operation

Precautions for Correct Use

• The absolute encoder reset function can be used only with systems that use an absolute encoder.

Parameter Initialization

This initializes the parameters.

1. Execute the initialization of the parameter.

Key operation	Display example	Explanation
DATA	Fo	Press the \widehat{P} key to enter Parameter Initialization Mode.
$\langle \approx \rangle$	· · · ·	Press and hold the $$ key for 5 seconds or longer until $\boxed{5 \pm R - \pm}$ is displayed.
		The bar indicator will increase.
	SERFE	The initialization of the parameter will start.
	FiniSh.	This indicates a normal completion. $\boxed{\underline{\mathcal{E}}_{r,r,Q,r}}$ will be displayed if the parameter could not be initialized. Turn OFF the drive power supply and then execute again.

2. Returning to Auxiliary Function Mode display

	Key operation	Display example	Explanation
-	DATA	Fn_Enc	Press the DATA key to return to Auxiliary Function Mode.
_			

Precautions for Correct Use

• If Alarm No. 11 (power supply undervoltage), 36 (parameter error) or 37 (parameter destruction) is displayed, the parameter cannot be initialized.

Front Panel Lock

This locks the front panel.

1. Displaying Parameter Mode

Key operation	Display example	Explanation
DATA	Un_SPd.	Press the DATA key to display Monitor Mode.
(-)	Po_ 10.	Press 🕞 key to display Parameter Setting Mode.

2. Setting the parameter number

Key operation	Display example	Explanation
$\overset{\text{(s)}}{\circledast}$	Por 535.	 Use the (() (() () () () () () () () () () () (

3. Displaying parameter set values

Key operation	Display example	Explanation
DATA	<u> </u>	Press the DATA key to display the set value.

4. Changing the parameter set value

Key operation	Display example	Explanation
$\overset{\textup{(s)}}{\circledast}$	<u> </u>	 Use the (()) (()) (()) (()) (()) (()) (()) ((
DATA	<i>.</i>	 Press the path key to save the new set value. To cancel the change, instead of pressing path, press () to return to the display in procedure 2.

5. Returning to Parameter Setting Mode

Key operation	Display example	Explanation
DATA	Por 535.	Press the watak key to return to Parameter Setting Mode.

6. Saving changed set values

Key operation	Display example	Explanation
(-)	88-988	Press the (5) key to display Parameter Write Mode.
DATA	EEP	Press the Data key to enter Parameter Write Mode.

Operation

Key operation	Display example	Explanation
\bigcirc	<u> 228</u>	Press and hold the $\textcircled{>}$ key for 5 seconds or longer until $\boxed{5 \pm 8 - \pm}$ is displayed.
		The bar indicator will increase.
	SERrE	Writing will start. (This display will appear only momentarily.)
	F .n .5h.	This indicates a normal completion. In addition to this display, either $r \in 5 \in E$, or $[f \cap c \cap r]$, may be displayed. If $r \in 5 \in E$, is displayed, writing has been completed normally, but some of the changed parameters will be valid only after the power supply has been turned OFF and ON again. Turn OFF the drive power supply and then turn it ON again. $[f \cap c \cap c \cap r]$ will be displayed if there is a write alarm. Write the data again.

7. Returning to Parameter Write Mode

Key operation	Display example	Explanation
DATA	881988	Press the bata key to return to Parameter Write Mode.

8. Restart the power supply to the drive

Precautions for Correct Use

- The items that are limited depend on the mode.
- If the Front Panel Parameter Write Selection (Pn617) is set to 1, the parameter set value is automatically written to EEPROM when changed.
- Refer to the Front Key Protection Setting (Pn535) in "8-6 Extended Parameters" (P.8-47) for details on the front panel lock function.

Front Panel Lock Release

This releases the front panel lock.

1. Release the front panel lock

Key operation	Display example	Explanation
(Fnunt	Press the \bigotimes key to display the Front Panel Lock Mode from the alarm reset display in Auxiliary Function Mode.
DATA	unt	Press the DATA key to enter Front Panel Lock Mode.
	unt	Press and hold the $\textcircled{>}$ key for 5 seconds or longer until $\boxed{5 \pm R - \pm}$ is displayed.
		The bar indicator will increase.
	SERFE	The front panel lock will be released.
	FiniSh.	This indicates a normal completion. $\boxed{\underline{\mathcal{E}}_{\underline{r}}, \underline{r}_{\underline{o}}, \underline{r}_{\underline{o}}}$ will be displayed if the front panel lock is not released. Turn OFF the drive power supply and then execute again.

2. Returning to Auxiliary Function Mode display

Key operation	Display example	Explanation
DATA	Fn_Enc	Press the (ATA) key to return to Auxiliary Function Mode.

9-5 Trial Operation

When you have finished installation, wiring, and switch settings, and have confirmed that status is normal after turning ON the power supply, perform trial operation. The main purpose of trial operation is to confirm that the servo system is electrically correct.

If an error occurs during the trial operation, refer to "Chapter 11, Troubleshooting and Maintenance" to eliminate the cause. Then check for safety, and then retry the trial operation.

Preparation for Trial Operation

Inspections before Trial Operation

Check the following items.

Wiring

- Make sure that there is no error (especially the power supply input and motor output).
- Make sure that there are no short-circuits. (Check the ground for short circuits as well.)
- Make sure that there are no loose connections.

Power Supply Voltage

• Make sure that the voltage corresponds to the rated voltage.

Motor Installation

· Make sure that the Servomotor is securely installed.

Disconnection from Mechanical System

• If necessary, make sure that the motor has been disconnected from the mechanical system.

Brake Released

• Make sure that the brake has been released.

Trial Operation in Position Control Mode

- 1. Use the Connector CN1.
- 2. Turn ON the Servo Drive power.
- 3. Confirm that the parameters are set to the standard set values.
- 4. Set to the output from the host device that agrees using the Command Pulse Input Mode (Pn007).
- 5. Write the parameters to EEPROM and then turn OFF the power supply and turn it ON again.
- 6. Apply 12 to 24 VDC between the operation command input (RUN: CN1 pin 29) and +24VIN (CN1 pin 7). Servo ON status will be entered and the Servomotor will be activated.
- 7. Input a low-frequency pulse signal from the host device to start low-speed operation.

Check to see if the motor is rotating at the set speed and to see if the motor stops when the command (pulses) are stopped.

Trial Operation in Speed Control Mode

- 1. Use the Connector CN1.
- 2. Turn ON the Servo Drive power.
- 3. Confirm that the parameters are set to the standard set values.
- 4. Apply 12 to 24 VDC between the operation command input (RUN: CN1 pin 29) and +24VIN (CN1 pin 7). Servo ON status will be entered and the Servomotor will be activated.
- 5. Gradually vary the DC voltage between the speed command input (REF, CN1 pin 14) and AGND1 (CN1 pin 15) from 0 V in the positive and negative directions. Check to see if the Servomotor rotates.

Check to see if the motor is rotating at the set speed and to see if the motor stops when the command are stopped.

Use the following parameters to change the motor rotation speed or direction.

- Pn302: Speed Command Scale
- Pn303: Command Speed Rotation Direction Switching

Trial Operation in Torque Control Mode

- 1. Use the Connector CN1.
- 2. Turn ON the Servo Drive power.
- 3. Confirm that the parameters are set to the standard set values.
- 4. Set the Speed Limit Value Setting (Pn321) to a low value.
- 5. Apply 12 to 24 VDC between the operation command input (RUN: CN1 pin 29) and +24VIN (CN1 pin 7). Servo ON status will be entered and the Servomotor will be activated.
- 6. Apply a positive or negative DC voltage between the torque command input TREF1 (CN1 pin 14) and AGND1 (CN1 pin 15). Check to see if the motor rotates according to the direction (forward/reverse) set in Pn307.

Use the following parameters to change the amount of the torque, direction of the torque, or speed limit value for the command voltage.

- Pn321: Speed Limit Value Setting (default set value: 0 r/min)
- Pn319: Torque Command Scale
- Pn320: Torque Output Direction Switching

Trial Operation in Fully-closed Control Mode

- 1. Use the Connector CN1.
- 2. Turn ON the Servo Drive power.
- 3. Turn ON the power supply to the Servo Drive.
- 4. Confirm that the parameters are set to the standard set values.
- 5. Set the outputs from the host device to agree with the Command Pulse Mode (Pn005).
- 6. Write the parameters to EEPROM and then turn OFF the power supply and turn it ON again.
- 7. Apply 12 to 24 VDC between the operation command input (RUN: CN1 pin 29) and +24VIN (CN1 pin 7). Servo ON status will be entered and the Servomotor will be activated.
- 8. Input a low-frequency pulse signal from the host device to start low-speed operation.

Check to see if the motor is rotating at the set speed and to see if the motor stops when the command (pulses) are stopped.

10

Adjustment Functions

This chapter explains the functions, setting methods, and items to note regarding various gain adjustments.

10-1 Gain Adjustment	10-1
Purpose of the Gain Adjustment	
Gain Adjustment Methods	
Gain Adjustment Procedure	
10-2 Realtime Autotuning	10-3
Setting Realtime Autotuning	
Setting Machine Rigidity	
10-3 Manual Tuning	10-10
Basic Settings	

10-1 Gain Adjustment


OMNUC G5-series Servo Drives provide a realtime autotuning function.

With this function, gain adjustments can be made easily even by those using a servo system for the first time. If you cannot obtain the desired responsiveness with autotuning, use manual tuning.

Purpose of the Gain Adjustment

The Servo Drive must operate the motor in response to commands from the host system with minimal time delay and maximum reliability. The gain is adjusted to bring the actual operation of the motor as close as possible to the operation specified by the commands, and to maximize the performance of the machine.

Example: Ball screw




Gain Adjustment Methods

Function			Description	Reference page
Automatic adjustment	Real	time autotuning	Realtime autotuning estimates the load inertia of the machine in realtime and automatically sets the optimal gain according to the estimated load inertia.	P.10-3
Manual	Man	ual tuning	Manual adjustment is performed if autotuning cannot be executed due to restrictions on the control mode or load conditions or if ensuring that the maximum responsiveness matches each load is required.	P.10-10
adjustment		Basic procedure	Position Control/Fully-closed Control Mode adjustment	P.10-11
			Speed Control Mode adjustment	P.10-12
			Torque Control Mode adjustment	P.10-17

Note 1.Take sufficient measures to ensure safety.

Note 2.If vibration occurs (unusual noise or vibration), immediately turn OFF the power supply or turn OFF the servo.



Gain Adjustment and Machine Rigidity

To improve machine rigidity:


- Install the machine on a secure base so that it does not have any play.
- Use couplings that have a high rigidity, and that are designed for servo systems.
- Use a wide timing belt. And use a tension within the range of allowable axial load for the motor or Decelerator output.
- Use gears with small backlash.

The specific vibration (resonance frequencies) of the mechanical system has a large impact on the gain adjustment of the servo. The servo system responsiveness cannot be set high for machines with a low resonance frequency (low machine rigidity).

Adjustment Functions

10-2 Realtime Autotuning

Realtime autotuning estimates the load inertia of the machine in realtime, and operates the machine by automatically setting the gain according to the estimated load inertia. At the same time, it can lower the resonance and vibration if the adaptive filter is enabled. Realtime autotuning is enabled for any control to adjust the speed loop PI control.



• Realtime autotuning may not function properly under the conditions described in the following table. In such cases, use manual tuning.

	Conditions under which realtime autotuning does not operate properly
Load inertia	 If the load inertia is too small or too large compared with the rotor inertia (less than 3 times, more than 20 times, or more than the applicable load inertia ratio). If the load inertia changes quickly. (in less than 10 s)
Load	 If the machine rigidity is extremely low. If there is backlash or play in the system.
Operation pattern	 If the speed continues at below 100 r/min. If the acceleration/deceleration is below 2,000 r/min in 1 s. If the acceleration/deceleration torque is too small compared with the unbalanced load and the viscous friction torque. If either a speed of 100 r/min or higher, or an acceleration/deceleration of 2,000 r/min/s does not last for at least 50 ms.

• With realtime autotuning, each parameter is fixed to the value in the machine rigidity table at the time the machine rigidity is set. By estimating the load inertia from the operation pattern, the operation coefficient for the speed loop gain and the integral time constant are altered. Doing this for each pattern can cause vibration, so the estimation value is set conservatively.

Setting Realtime Autotuning

1. When setting realtime autotuning, turn the servo OFF.

2. Set Realtime Autotuning Mode Selection (Pn002) depending on the load.

Normally, set the parameter to 1 or 2. When using a vertical axis, set the parameter to 3 or 4. A setting of 5 is used in combination with a software tool. Do not set the parameter to 5 for normal operation.

The gain switching function is enabled for set values 2 to 4. If Pn002 is set to 2 to 4, the Switching Mode in Position Control (Pn115) must be set to 10 (Combination of command pulse input and speed). The gain is switched according to this switching condition setting. Refer to page "Gain Switching Setting for Each Control Mode" (P.6-30) for details on setting the Switching Mode in Position Control (Pn115).

Set value	Realtime autotuning	Description
0	Disabled	Realtime autotuning is disabled.
1	Focus on stability (default setting)	No unbalanced load, friction compensation, or gain switching.
2	Focus on position control	Used when unbalanced load and friction are small. Gain switching is set.
3	Vertical axis	Used when an unbalanced load is present, such as a vertical axis.
4	Friction compensation and vertical axis	Used when a vertical axis or other unbalanced load is present and when friction is large.
5	Load characteristic estimation	Used only for estimating load characteristics.
6	Customization	Used to customize the Realtime Autotuning Mode.

Setting Machine Rigidity

1. Set the Realtime Autotuning Machine Rigidity Selection (Pn003) according to the table below.

Start from the lower machine rigidity number and check the operation.

Machine configuration and drive method	Realtime Autotuning Machine Rigidity Selection (Pn003)
Ball screw direct coupling	12 to 24
Ball screw and timing belt	8 to 20
Timing belt	4 to 16
Gears, rack and pinion drives	4 to 16
Other machines with low rigidity	1 to 8
Stacker cranes	Perform manual tuning.

2. Turn the servo ON and operate the machine with a normal pattern.

To increase responsiveness, increase the machine rigidity number, and check the response. If vibration occurs, enable the adaptive filter and operate. If already enabled, lower the machine rigidity number.

• The adaptive filter can be left enabled even when disabling realtime autotuning after completing adjustments. Even if the adaptive filter is disabled, the set values of notch filters 3 and 4 will be maintained.

Precautions for Correct Use

 Unusual noise or vibration may occur until the load inertia is estimated or the adaptive filter stabilizes after startup, immediately after the first servo ON, or when the Realtime Autotuning Machine Rigidity Selection (Pn003) is increased. This is not an error if it disappears right away. If the unusual noise or vibration, however, continues for 3 or more reciprocating operations, take the following measures in any order you can.

- Write the parameters used during normal operation to the EEPROM.
- Lower the Realtime Autotuning Machine Rigidity Selection (Pn003).
- · Manually set the notch filter.
- Once unusual noise or vibration occurs, Inertia Ratio (Pn004), Torque Command Value Offset (Pn607), Forward Direction Torque Offset (Pn608), and Reverse Direction Torque Offset (Pn609) may have changed to an extreme value. In this case, also take the measures described above.
- Out of the results of realtime autotuning, the Inertia Ratio (Pn004), Torque Command Value Offset (Pn607), Forward Direction Torque Offset (Pn608) and Reverse Direction Torque Offset (Pn609) are automatically saved to the EEPROM every 30 minutes. Realtime autotuning will use this saved data as the default setting when the power supply is turned OFF and turned ON again.
- The parameter will automatically be set based on the Realtime Autotuning Machine Rigidity Setting (Pn003) if realtime autotuning is enabled.

Parameter number	Parameter name	AT Machine Rigidity Setting (Pn003)								
number		0	1	2	3	4	5	6	7	
Pn004	Inertia Ratio	Estimated load inertia ratio								
Pn100	Position Loop Gain	20	25	30	40	45	55	75	95	
Pn101	Speed Loop Gain	15	20	25	30	35	45	60	75	
Pn102	Speed Loop Integral Time Constant	3700	2800	2200	1900	1600	1200	900	700	
Pn103	Speed Feedback Filter Time Constant	0	0	0	0	0	0	0	0	
Pn104	Torque Command Filter Time Constant 1 ^{*1}	1500	1100	900	800	600	500	400	300	
Pn105	Position Loop Gain 2	25	30	40	45	55	70	95	120	
Pn106	Speed Loop Gain 2	15	20	25	30	35	45	60	75	
Pn107	Speed Loop Integral Time Constant 2 ^{*2}	10000	10000	10000	10000	10000	10000	10000	10000	
Pn108	Speed Feedback Filter Time Constant 2	0	0	0	0	0	0	0	0	
Pn109	Torque Command Filter Time Constant 2 ^{*1}	1500	1100	900	800	600	500	400	300	
Pn110	Speed Feed-forward Amount	300	300	300	300	300	300	300	300	
Pn111	Speed Feed-forward Command Filter	50	50	50	50	50	50	50	50	
Pn112	Torque Feed-forward Amount	0	0	0	0	0	0	0	0	
Pn113	Torque Feed-forward Command Filter	0	0	0	0	0	0	0	0	
Pn114	Gain Switching Input Operating Mode Selection	1	1	1	1	1	1	1	1	
Pn115	Switching Mode in Position Control		-	g Enable g Disabl			•	•	•	
Pn116	Gain Switching Delay Time in Position Control	30	30	30	30	30	30	30	30	
Pn117	Gain Switching Level in Position Control	50	50	50	50	50	50	50	50	
Pn118	Gain Switching Hysteresis in Position Control	33	33	33	33	33	33	33	33	
Pn119	Position Gain Switching Time	33	33	33	33	33	33	33	33	
Pn120	Switching Mode in Speed Control	0	0	0	0	0	0	0	0	
Pn121	Gain Switching Delay Time in Speed Control	0	0	0	0	0	0	0	0	

Realtime Autotuning (RTAT) Parameter Table

Parameter number	Parameter name		AT	Machir	ne Rigio	lity Set	ting (Pr	n003)	
number		0	1	2	3	4	5	6	7
Pn122	Gain Switching Level in Speed Control	0	0	0	0	0	0	0	0
Pn123	Gain Switching Hysteresis in Speed Control	0	0	0	0	0	0	0	0
Pn124	Switching Mode in Torque Control	0	0	0	0	0	0	0	0
Pn125	Gain Switching Delay Time in Torque Control	0	0	0	0	0	0	0	0
Pn126	Gain Switching Level in Torque Control	0	0	0	0	0	0	0	0
Pn127	Gain Switching Hysteresis in Torque Control	0	0	0	0	0	0	0	0
Pn605	Gain 3 Effective Time	0	0	0	0	0	0	0	0
Pn606	Gain 3 Ratio Setting	100	100	100	100	100	100	100	100
Pn607	Torque Command Value Offset	If Pn00 comma		r 4, this	is the e	stimate	d offset	for the	torque
Pn608	Forward Direction Torque Offset	If Pn00 comma		r 4, this	is the e	stimate	d offset	for the	torque
Pn609	Reverse Direction Torque Offset	If Pn00 comma		r 4, this	is the e	stimate	d offset	for the	torque
Pn610.0, Pn610.3	Function Expansion Setting	0	0	0	0	0	0	0	0
Pn611	Electric Current Response Setting	100	100	100	100	100	100	100	100
Pn613	Inertia Ratio 2	0	0	0	0	0	0	0	0
Pn623	Disturbance Torque Compensation Gain	0	0	0	0	0	0	0	0
Pn624	Disturbance Observer Filter Setting	0	0	0	0	0	0	0	0

*1. This is limited to a minimum value of 10 if a 17-bit absolute encoder is used.

*2 If realtime autotuning is performed in vertical axis mode or friction compensation and vertical axis mode, the value will be 9999 until load characteristic estimation (estimation of the inertia ratio, torque command value offset, and forward/reverse direction torque offset) is completed. The value will change to 10000 after the load characteristic estimation is completed.

Parameter number	Parameter name	AT Machine Rigidity Setting (Pn003)									
		8	9	10	11	12	13	14	15		
Pn004	Inertia Ratio	Estimated load inertia ratio									
Pn100	Position Loop Gain	115	140	175	320	390	480	630	720		
Pn101	Speed Loop Gain	90	110	140	180	220	270	350	400		
Pn102	Speed Loop Integral Time Constant	600	500	400	310	250	210	160	140		
Pn103	Speed Feedback Filter Time Constant	0	0	0	0	0	0	0	0		
Pn104	Torque Command Filter Time Constant 1 ^{*1}	300	200	200	126	103	84	65	57		
Pn105	Position Loop Gain 2	140	175	220	380	460	570	730	840		
Pn106	Speed Loop Gain 2	90	110	140	180	220	270	350	400		
Pn107	Speed Loop Integral Time Constant 2 ^{*2}	10000	10000	10000	10000	10000	10000	10000	10000		
Pn108	Speed Feedback Filter Time Constant 2	0	0	0	0	0	0	0	0		
Pn109	Torque Command Filter Time Constant 2 ^{*1}	300	200	200	126	103	84	65	57		
Pn110	Speed Feed-forward Amount	300	300	300	300	300	300	300	300		
Pn111	Speed Feed-forward Command Filter	50	50	50	50	50	50	50	50		
Pn112	Torque Feed-forward Amount	0	0	0	0	0	0	0	0		
Pn113	Torque Feed-forward Command Filter	0	0	0	0	0	0	0	0		
Pn114	Gain Switching Input Operating Mode Selection	1	1	1	1	1	1	1	1		

10-2 Realtime Autotuning

Parameter number	Parameter name	AT Machine Rigidity Setting (Pn003)									
number		8	9	10	11	12	13	14	15		
Pn115	Switching Mode in Position Control	Gain Switching Enable Mode: 10 Gain Switching Disable Mode: 0									
Pn116	Gain Switching Delay Time in Position Control	30	30	30	30	30	30	30	30		
Pn117	Gain Switching Level in Position Control	50	50	50	50	50	50	50	50		
Pn118	Gain Switching Hysteresis in Position Control	33	33	33	33	33	33	33	33		
Pn119	Position Gain Switching Time	33	33	33	33	33	33	33	33		
Pn120	Switching Mode in Speed Control	0	0	0	0	0	0	0	0		
Pn121	Gain Switching Delay Time in Speed Control	0	0	0	0	0	0	0	0		
Pn122	Gain Switching Level in Speed Control	0	0	0	0	0	0	0	0		
Pn123	Gain Switching Hysteresis in Speed Control	0	0	0	0	0	0	0	0		
Pn124	Switching Mode in Torque Control	0	0	0	0	0	0	0	0		
Pn125	Gain Switching Delay Time in Torque Control	0	0	0	0	0	0	0	0		
Pn126	Gain Switching Level in Torque Control	0	0	0	0	0	0	0	0		
Pn127	Gain Switching Hysteresis in Torque Control	0	0	0	0	0	0	0	0		
Pn605	Gain 3 Effective Time	0	0	0	0	0	0	0	0		
Pn606	Gain 3 Ratio Setting	100	100	100	100	100	100	100	100		
Pn607	Torque Command Value Offset	If Pn00 comma		r 4, this	is the e	stimate	d offset	for the	torque		
Pn608	Forward Direction Torque Offset	If Pn00 comma		r 4, this	is the e	stimate	d offset	for the	torque		
Pn609	IReverse Direction Lordie Offset	If Pn00 comma		r 4, this	is the e	stimate	d offset	for the	torque		
Pn610.0, Pn610.3	Function Expansion Setting	0	0	0	0	0	0	0	0		
Pn611	Electric Current Response Setting	100	100	100	100	100	100	100	100		
Pn613	Inertia Ratio 2	0	0	0	0	0	0	0	0		
Pn623	Disturbance Torque Compensation Gain	0	0	0	0	0	0	0	0		
Pn624	Disturbance Observer Filter Setting	0	0	0	0	0	0	0	0		

*1. This is limited to a minimum value of 10 if a 17-bit absolute encoder is used.

*2 If realtime autotuning is performed in vertical axis mode or friction compensation and vertical axis mode, the value will be 9999 until load characteristic estimation (estimation of the inertia ratio, torque command value offset, and forward/reverse direction torque offset) is completed. The value will change to 10000 after the load characteristic estimation is completed.

Parameter number	Parameter name	AT Machine Rigidity Setting (Pn003)							
		16	17	18	19	20	21	22	23
Pn004	Inertia Ratio	Estima	ted load	l inertia	ratio				
Pn100	Position Loop Gain	900	1080	1350	1620	2060	2510	3050	3770
Pn101	Speed Loop Gain	500	600	750	900	1150	1400	1700	2100
Pn102	Speed Loop Integral Time Constant	120	110	90	80	70	60	50	40
Pn103	Speed Feedback Filter Time Constant	0	0	0	0	0	0	0	0
Pn104	Torque Command Filter Time Constant 1 ^{*1}	45	38	30	25	20	16	13	11
Pn105	Position Loop Gain 2	1050	1260	1570	1880	2410	2930	3560	4400
Pn106	Speed Loop Gain 2	500	600	750	900	1150	1400	1700	2100
Pn107	Speed Loop Integral Time Constant 2 ^{*2}	10000	10000	10000	10000	10000	10000	10000	10000
Pn108	Speed Feedback Filter Time Constant 2	0	0	0	0	0	0	0	0

Parameter number	Parameter name	AT Machine Rigidity Setting (Pn003)									
number		16	17	18	19	20	21	22	23		
Pn109	Torque Command Filter Time Constant 2 ^{*1}	45	38	30	25	20	16	13	11		
Pn110	Speed Feed-forward Amount	300	300	300	300	300	300	300	300		
Pn111	Speed Feed-forward Command Filter	50	50	50	50	50	50	50	50		
Pn112	Torque Feed-forward Amount	0	0	0	0	0	0	0	0		
Pn113	Torque Feed-forward Command Filter	0	0	0	0	0	0	0	0		
Pn114	Gain Switching Input Operating Mode Selection	1	1	1	1	1	1	1	1		
Pn115	Switching Mode in Position Control		Switchin Switchin	•							
Pn116	Gain Switching Delay Time in Position Control	30	30	30	30	30	30	30	30		
Pn117	Gain Switching Level in Position Control	50	50	50	50	50	50	50	50		
Pn118	Gain Switching Hysteresis in Position Control	33	33	33	33	33	33	33	33		
Pn119	Position Gain Switching Time	33	33	33	33	33	33	33	33		
Pn120	Switching Mode in Speed Control	0	0	0	0	0	0	0	0		
Pn121	Gain Switching Delay Time in Speed Control	0	0	0	0	0	0	0	0		
Pn122	Gain Switching Level in Speed Control	0	0	0	0	0	0	0	0		
Pn123	Gain Switching Hysteresis in Speed Control	0	0	0	0	0	0	0	0		
Pn124	Switching Mode in Torque Control	0	0	0	0	0	0	0	0		
Pn125	Gain Switching Delay Time in Torque Control	0	0	0	0	0	0	0	0		
Pn126	Gain Switching Level in Torque Control	0	0	0	0	0	0	0	0		
Pn127	Gain Switching Hysteresis in Torque Control	0	0	0	0	0	0	0	0		
Pn605	Gain 3 Effective Time	0	0	0	0	0	0	0	0		
Pn606	Gain 3 Ratio Setting	100	100	100	100	100	100	100	100		
Pn607	Torque Command Value Offset	If Pn0 comm	02 = 3 c and.	or 4, this	is the e	estimate	d offset	for the	torque		
Pn608	Forward Direction Torque Offset	If Pn0 comm	02 = 3 c and.	or 4, this	is the e	estimate	d offset	for the	torque		
Pn609	Reverse Direction Torque Offset	If Pn0 comm	02 = 3 c and.	or 4, this	is the e	estimate	d offset	for the	torque		
Pn610.0, Pn610.3	Function Expansion Setting	0	0	0	0	0	0	0	0		
Pn611	Electric Current Response Setting	100	100	100	100	100	100	100	100		
Pn613	Inertia Ratio 2	0	0	0	0	0	0	0	0		
Pn623	Disturbance Torque Compensation Gain	0	0	0	0	0	0	0	0		
Pn624	Disturbance Observer Filter Setting	0	0	0	0	0	0	0	0		

*1. This is limited to a minimum value of 10 if a 17-bit absolute encoder is used.

*2 If realtime autotuning is performed in vertical axis mode or friction compensation and vertical axis mode, the value will be 9999 until load characteristic estimation (estimation of the inertia ratio, torque command value offset, and forward/reverse direction torque offset) is completed. The value will change to 10000 after the load characteristic estimation is completed.

Parameter number	Parameter name	AT Machine Rigidity Setting (Pn003)								
		24	25	26	27	28	29	30	31	
Pn004	Inertia Ratio	Estimated load inertia ratio								
Pn100	Position Loop Gain	4490	5000	5600	6100	6600	7200	8100	9000	
Pn101	Speed Loop Gain	2500	2800	3100	3400	3700	4000	4500	5000	
Pn102	Speed Loop Integral Time Constant	40	35	30	30	25	25	20	20	

Parameter Parameter name			AT Machine Rigidity Setting (Pn003)							
number		24	25	26	27	28	29	30	31	
Pn103	Speed Feedback Filter Time Constant	0	0	0	0	0	0	0	0	
Pn104	Torque Command Filter Time Constant 1 ^{*1}	9	8	7	7	6	6	5	5	
Pn105	Position Loop Gain 2	5240	5900	6500	7100	7700	8400	9400	1050	
Pn106	Speed Loop Gain 2	2500	2800	3100	3400	3700	4000	4500	5000	
Pn107	Speed Loop Integral Time Constant 2 ^{*2}	10000	10000	10000	10000	10000	10000	10000	1000	
Pn108	Speed Feedback Filter Time Constant 2	0	0	0	0	0	0	0	0	
Pn109	Torque Command Filter Time Constant 2 ^{*1}	9	8	7	7	6	6	5	5	
Pn110	Speed Feed-forward Amount	300	300	300	300	300	300	300	300	
Pn111	Speed Feed-forward Command Filter	50	50	50	50	50	50	50	50	
Pn112	Torque Feed-forward Amount	0	0	0	0	0	0	0	0	
Pn113	Torque Feed-forward Command Filter	0	0	0	0	0	0	0	0	
Pn114	Gain Switching Input Operating Mode Selection	1	1	1	1	1	1	1	1	
Pn115	Switching Mode in Position Control				e Mode: le Mode					
Pn116	Gain Switching Delay Time in Position Control	30	30	30	30	30	30	30	30	
Pn117	Gain Switching Level in Position Control	50	50	50	50	50	50	50	50	
Pn118	Gain Switching Hysteresis in Position Control	33	33	33	33	33	33	33	33	
Pn119	Position Gain Switching Time	33	33	33	33	33	33	33	33	
Pn120	Switching Mode in Speed Control	0	0	0	0	0	0	0	0	
Pn121	Gain Switching Delay Time in Speed Control	0	0	0	0	0	0	0	0	
Pn122	Gain Switching Level in Speed Control	0	0	0	0	0	0	0	0	
Pn123	Gain Switching Hysteresis in Speed Control	0	0	0	0	0	0	0	0	
Pn124	Switching Mode in Torque Control	0	0	0	0	0	0	0	0	
Pn125	Gain Switching Delay Time in Torque Control	0	0	0	0	0	0	0	0	
Pn126	Gain Switching Level in Torque Control	0	0	0	0	0	0	0	0	
Pn127	Gain Switching Hysteresis in Torque Control	0	0	0	0	0	0	0	0	
Pn605	Gain 3 Effective Time	0	0	0	0	0	0	0	0	
Pn606	Gain 3 Ratio Setting	100	100	100	100	100	100	100	100	
Pn607	Torque Command Value Offset	lf Pn00 comma		4, this	is the e	stimated	doffset	for the t	orque	
Pn608	Forward Direction Torque Offset	If Pn002 = 3 or 4, this is the estimated offset for the torque command.					orque			
Pn609	Reverse Direction Torque Offset	lf Pn00 comma		^r 4, this	is the e	stimated	d offset	for the t	orque	
Pn610.0, Pn610.3	Function Expansion Setting	0	0	0	0	0	0	0	0	
Pn611	Electric Current Response Setting	100	100	100	100	100	100	100	100	
Pn613	Inertia Ratio 2	0	0	0	0	0	0	0	0	
Pn623	Disturbance Torque Compensation Gain	0	0	0	0	0	0	0	0	
Pn624	Disturbance Observer Filter Setting	0	0	0	0	0	0	0	0	

*1. This is limited to a minimum value of 10 if a 17-bit absolute encoder is used.

*2 If realtime autotuning is performed in vertical axis mode or friction compensation and vertical axis mode, the value will be 9999 until load characteristic estimation (estimation of the inertia ratio, torque command value offset, and forward/reverse direction torque offset) is completed. The value will change to 10000 after the load characteristic estimation is completed.

 The parameters Pn103, Pn108, Pn110 to Pn127, Pn605, Pn606, Pn610, Pn611, Pn613, Pn623 and Pn624 are set to fixed values.

10-3 Manual Tuning

Basic Settings

As described before, the OMNUC G5-series Servo Drives have a realtime autotuning function. Readjustment, however, is required if realtime autotuning cannot adjust the gain properly for same reasons: there is a restriction by load conditions, or a necessity to ensue optimum responsiveness and stability for each load.

This section describes how to perform manual tuning for each control mode and function.

Before Manual Setting

More reliable adjustment can be performed quickly by using waveform monitoring with the data tracing function of the CX-Drive or by measuring the analog voltage waveform with the monitor function.


Analog Monitor Output


The actual motor speed, command speed, torque, and number of accumulated pulses can be measured in the analog voltage level using an oscilloscope or other device. The type of signal to output and the output voltage level are set with Analog Monitor 1 Selection (Pn416) and Analog Monitor 2 Selection (Pn418) settings. For details, refer to "12-2 Parameter List" (P.12-11).

The refresh period of the analog monitor is 1 ms.

CX-Drive Data Tracing Function

Commands to the motor and motor operation (speed, torque command, and position error) can be displayed on a computer as waveforms. Refer to the *CX-Drive Operation Manual* (Cat. No. W453).





Speed Control Mode Adjustment Adjustments in speed control for the OMNUC G5 Series are very similar to Position Control Mode adjustment. Use the following procedure to perform the adjustment. Never adjust or set parameters to extreme values, (Start adjustment.) because it will make the operation unstable. Failure to follow this guideline may result in injury. Set the realtime autotuning to disabled (Pn002 = 0) Gradually change the value to adjust the gain while checking the motor operation. Set each parameter according to the parameter settings for different applications. Operate based on the normal operation pattern and load. Are the speed responsiveness and other performances satisfied? Yes No (Adjustment completed.) Increase Speed Loop Gain (Pn101) to the extent that hunting does not occur upon servo lock. Decrease Speed Loop Integral Time Constant (Pn102) to the extent that hunting does not occur upon servo lock. Does hunting or vibration occur when the motor rotates? Yes No Decrease Speed Loop Gain (Pn101). Write to the EEPROM in the Parameter Write Mode. Increase Speed Loop Integral Time Constant (Pn102). (Adjustment completed.) If vibration persists after repeated adjustments or the positioning is slow: Increase Torque Command Filter Time Constant (Pn104). Set the damping frequency in the

10

Notch 1 Frequency Setting (Pn201), Notch 2 Frequency Setting (Pn204), Notch 3 Frequency Setting (Pn207) or Notch 4 Frequency Setting (Pn210).

Servo Manual Tuning Method

The following 4 parameters are the basic servo adjustment parameters. If desired operation characteristics are obtained by adjusting the following 4 parameters, the

adjustments of other parameters are not necessary.

Parameter number	Parameter name	Default setting	Parameter number 2
Pn100	Position Loop Gain	48.0 [1/s]	Pn105
Pn101	Speed Loop Gain	27.0 Hz	Pn106
Pn102	Speed Loop Integral Time Constant	21.0 ms	Pn107
Pn104	Torque Command Filter Time Constant	0.84 ms	Pn109

Adjustment of Each Parameter

The control loop for the servo consists of, from the outside, a position loop, speed loop and current loop.

The inner loop is affected by the outer loop, and the outer loop is affected by the inner loop. What determines the default setting includes the structure and the rigidity of the machine, and the inertia ratio.

Guide of each parameter for different applications is as follows.

Parameter Settings for Different Applications

Application name	Inertia	Rigidity	Position loop gain [1/s]	Speed loop gain [Hz]	Speed loop integral time constant	Torque command filter time constant [x 0.01 ms]
Ball screw horizontal	Large	Low	20	140	35	160
Ball screw horizontal	Medium	Medium	40	80	20	100
Ball screw horizontal	Small	High	80	60	15	80
Ball screw vertical	Large	Low	20	160	45	160
Ball screw vertical	Medium	Medium	40	80	30	120
Ball screw vertical	Small	High	60	60	20	100
Ball screw nut rotation horizontal	Large	Low	20	140	40	160
Ball screw nut rotation horizontal	Medium	Medium	40	100	30	120
Ball screw nut rotation vertical	Large	Low	20	160	45	160
Ball screw nut rotation vertical	Medium	Medium	40	120	25	120
Timing belt	Large	Low	20	160	60	160
Timing belt	Medium	Medium	30	120	40	120
Rack and pinion drives	Large	Low	20	160	60	160
Rack and pinion drives	Large	Medium	30	120	40	120
Rack and pinion drives	Medium	Medium	40	100	20	100
Index table	Large	Medium	40	120	25	120
Index table	Small	High	80	120	20	100
Robot arm cylinder	Large	Low	15	160	60	160
Robot arm cylinder	Medium	Medium	25	120	40	120
Other general-purpose	Medium	Medium	30	100	30	150

• Inertia Ratio (Pn004) is when fixed at 300%.

Inertia guide

-	
The inertia is small.	5 times the rotor inertia max.
The inertia is medium.	5 to 10 times the rotor inertia max.
The inertia is large.	10 to 20 times the rotor inertia max.

Pn100 and Pn105 Position Loop Gain

This loop controls the number of pulses from encoder to be the designated number of pulses. This is called an error counter, and when the pulse is equal to or lower than the specified value, positioning is completed and the signal is output.

The ratio of maximum speed used and error counter is called a position loop gain.

Position loop gain [1/s] = <u>Command maximum speed [pps]</u> Error counter accumulated pulse (P)


For the position loop gain, use the inverse of Speed Loop Integral Time Constant (Pn102) as a guide for setting. Setting Pn102 to 100 ms results in 10 [1/s].

There will be no overshooting under this condition. To quicken positioning, increase the value of position loop gain. If the value is too large, overshooting or vibration will occur. In such cases, set the value smaller.


If the speed loop or the current loop is vibrating, adjusting the position loop does not eliminate the vibration.

Response to the position loop gain adjustment is illustrated below.

• If the position loop gain is high, an overshooting occurs.



• If the position loop gain is low, positioning completion speed becomes slow.



Time t

Pn101 and Pn106 Speed Loop Gain


The speed loop gain determines the responsiveness of the servo.

This value becomes the response frequency if the Inertia Ratio (Pn004) is set correctly.

Increasing the value of the speed loop gain improves the responsiveness and quickens positioning, but vibration is more likely to occur. Adjustment must be made so vibration will not occur.


This is related to Speed Loop Integral Time Constant (Pn102), and by increasing the integral time constant, the speed loop gain value can be increased.

• If the speed loop gain is low, the speed response becomes slow and a large overshooting occurs. In such case, increase the speed loop gain.



• If the speed loop gain is high, vibrations are more likely to occur. Vibration or resonance may not disappear.

In such case, decrease the speed loop gain.




Time t

Pn102 and Pn107 Speed Loop Integral Time Constant


The speed loop integral time constant also determines the responsiveness of the servo.

• If the speed loop integral time constant is low, vibration or resonance occurs. In such case, increase the speed loop integral time constant.



• If the speed loop integral time constant is high, the response is delayed. The servo rigidity becomes weak.

In such case, decrease the speed loop integral time constant.



Pn104 and Pn109 Torque Command Filter Time Constant (Current Loop Input Adjustment)

The torque command filter applies a filter so the current command from the speed loop becomes smooth. The result is a smooth current flow which suppresses vibration. The default setting of the filter time constant is 84 (0.84 ms).

Increase the value to reduce vibration. Increasing the value slows the response.

As a guide, aim for about 1/25 of the Speed Loop Integral Time Constant (Pn102).


Also, the torque command filter reduces vibration due to the machine rigidity.

This is related to Speed Loop Gain (Pn101), and if Pn101 is too large, increasing the torque command filter time constant does not reduce vibration.

If there is machine resonance such as with the ball screw, vibration is reduced by using notch filters such as Pn201, Pn204, Pn207 and Pn210. Or, enable the adaptive filter.

Other Adjustments

If the torque loop is saturated because the acceleration time is short or the load torque is large, an overshooting occurs for the speed response. In such case, increase the acceleration time to prevent the torque from saturating.



Torque Control Mode Adjustment

This is a torque control based on the speed control loop where the speed limit is the speed limit value from Speed Limit (Pn304, Pn305, Pn306 or Pn307). This section describes the settings for these speed limit values.

Setting Speed Limit Values

- If Torque Command/Speed Limit Selection (Pn317) is 0, speed limit is the value set by Speed Limit Value Setting (Pn321) and Reverse Direction Speed Limit Value Setting (Pn322). If Torque Command/Speed Limit Selection (Pn317) is 1, the speed limit is the value obtained by converting the voltage applied to analog input 1 with Torque Command Scale (Pn319).
- When the motor speed approaches the speed limit value, the speed control switches to that using Speed Limit Value Setting (Pn321) and Reverse Direction Speed Limit Value Setting (Pn322) as commands.
- To have a stable operation while the speed is limited, the parameter should be set according to "Speed Control Mode Adjustment".
- The torque may not be produced as specified by the torque command because the input to the torque limit section is small, when the speed limit values in Speed Limit Value Setting (Pn321) and Reverse Direction Speed Limit Value Setting (Pn322) are too low, when the speed loop gain is too low, or when the speed loop integral time constant is 10,000 (disabled).

11

Troubleshooting and Maintenance

This chapter explains the items to check when problems occur, error diagnosis using the alarm LED display and measures, error diagnosis based on the operating condition and measures, and periodic maintenance.

11-1 Troubleshooting	11-1
Preliminary Checks When a Problem Occurs	
Precautions When a Problem Occurs	11-2
Replacing the Servomotor or Servo Drive	11-3
11-2 Warning List	11-4
11-3 Alarm List	11-5
11-4 Troubleshooting	11-10
Error Diagnosis Using the Alarm Displays	11-10
Troubleshooting Using the Operation Status	11-23
11-5 Periodic Maintenance	11-27
Servomotor Life Expectancy	
Servo Drive Life Expectancy	11-28
Replacing the Absolute Encoder Battery	11-29

Preliminary Checks When a Problem Occurs

This section explains the preliminary checks required to determine the cause of a problem if one occurs.

Checking the Power Supply Voltage

· Check the voltage at the power supply input terminals.

1	• Check the voltage at the power supply input terminals.						
	Main Circuit Power Supply Input Terminals (L1, L2, L3)						
	R88D-KT□L	(50 to 400 W)	: Single-phase 100 to 120 VAC (85 to 132 V) 50/60 Hz				
	R88D-KT⊡H	(100 W to 1.5 kW)	: Single-phase 200 to 240 VAC (170 to 264 V) 50/60 Hz				
		(750 W to 1.5 kW)	: 3-phase 200 to 240 VAC (170 to 264 V) 50/60 Hz				
		(2 to 15 kW)	: 3-phase 200 to 230 VAC (170 to 253 V) 50/60 Hz				
	R88D-KT□F	(750 W to 15 kW)	: 3-phase 380 to 480 VAC (323 to 528 V) 50/60 Hz				
	Control Circuit Po	wer Supply Input Te	rminals (L1C, L2C)				
	R88D-KT□L	(50 to 400 W)	: Single-phase 100 to 120 VAC (85 to 132 V) 50/60 Hz				
	R88D-KT⊡H	(100 W to 1.5 kW)	: Single-phase 200 to 240 VAC (170 to 264 V) 50/60 Hz				
		(2 to 15 kW)	: Single-phase 200 to 230 VAC (170 to 253 V) 50/60 Hz				
	R88D-KT□F	(750 W to 15 kW)	: 24 VDC (21.6 to 26.4 V)				

If the voltage is out of range, there is a risk of operation failure. Be sure that the power supply is within the specified range.

• Check the voltage of the sequence input power supply (+24 VIN terminal (CN1 pin 7)). It must be between 11 and 25 VDC.

If the voltage is out of range, there is a risk of operation failure. Be sure that the power supply is within the specified range.

Checking Whether an Alarm Has Occurred

- Make an analysis using the 7-segment LED display area in the front of the Servo Drive and using the Operation keys.
- When an alarm has occurred

 \dots Check the alarm display that is displayed ($\Box\Box$) and make an analysis based on the alarm that is indicated.

- When an alarm has not occurred
 - ... Make an analysis according to the error conditions.
- In either case, refer to "11-4 Troubleshooting" (P.11-10) for details.

íſ

Precautions When a Problem Occurs

When checking and verifying I/O after a problem has occurred, the Servo Drive may suddenly start to operate or suddenly stop, so always take the following precautions. You should assume that anything not described in this manual is not possible with this product.

Precautions

- Disconnect the wiring before checking for cable breakage. If you test conduction with the cable connected, test results may not be accurate due to conduction via bypassing circuit.
- If the encoder signal is lost, the motor may run away, or an alarm may occur. Be sure to disconnect the motor from the mechanical system before checking the encoder signal.
- When measuring the encoder output, perform the measurement based on the SENGND (CN1 pin 13).

When an oscilloscope is used for measurement, it will not be affected by noise if measurements are performed using the differential between CH1 and CH2.

• When performing tests, first check that there are no persons in the vicinity of the equipment, and that the equipment will not be damaged even if the motor runs away.

Before performing the tests, verify that you can immediately stop the machine using an emergency stop even if it runs away.

Replacing the Servomotor or Servo Drive

Use the following procedure to replace the Servomotor or Servo Drive.

Replacing the Servomotor

1. Replace the motor.

2. Perform origin adjustment (for position control).

- When the motor is replaced, the motor's origin position (phase Z) may deviate, so origin adjustment must be performed.
- Refer to the position controller's manual for details on performing origin adjustment.

3. Set up the absolute encoder.

• If a motor with an absolute encoder is used, the absolute value data in the absolute encoder is cleared when the motor is replaced, so setup is again required.

The multi-rotation data will be different from before it was replaced, so initialize the Motion Control Unit settings.

• For details, refer to "Absolute Encoder Setup"(P.9-4).

Replacing the Servo Drive

1. Copy the parameters.

Use a software tool such as the CX-Drive to read and save all parameter settings from the Servo Drive.

2. Replace the Servo Drive.

3. Reset the parameters.

Use a software tool such as the CX-Drive to set and transfer all parameter settings to the Servo Drive.

4. Set up the absolute encoder.

- If a motor with an absolute encoder is used, the absolute value data in the absolute encoder is cleared when the Servo Drive is replaced, so setup is again required.
- The multi-rotation data will be different from before it was replaced, so initialize the Motion Control Unit settings.
- For details, refer to "Absolute Encoder Setup"(P.9-4).

11-2 Warning List

This is a function to output a warning signal before the protective function operates to notify the overload and other statuses in advance. Set the warning output type to Warning Output Selection 1 (Pn440) and Waning Output Selection 2 (Pn441).

Precautions for Correct Use

• Each warning automatically returns to the status before it occurred once the system recovers from the error. However, for the time set in the Warning Latch Hold Time Selection (Pn627), the warning status will be held. To clear the warning during the latch hold time, do so by performing the same procedures as alarm clear.

Warning List

Warning number	Warning name	Latch ^{*1}	Warning condition	Warning Output Selection (Pn440, Pn441) ^{*2}	Warning Mask Setting (Pn638)
A0	Overload warning	\checkmark	The load ratio is 85% or more of the protection level.	1	bit 7
A1	Excessive regeneration warning	\checkmark	The regeneration load ratio is 85% or more of the protection level.	2	bit 5
A2	Battery warning	Always fixed with no time limit	Battery voltage is 3.2 V or less.	3	bit 0
A3	Fan warning	\checkmark	The fan stops for 1 second.	4	bit 6
A4	Encoder communications warning	\checkmark	Encoder communications errors occurred in series more than the specified value.	5	bit 4
A5	Encoder overheating warning		The encoder temperature exceeded the specified value.	6	bit 3
A6	Vibration detection warning	\checkmark	Vibration is detected.	7	bit 9
A7	Life expectancy warning	Always fixed with no time limit	The life expectancy of the capacitor or the fan is shorter than the specified value.	8	bit 2
A8	External encoder error warning	\checkmark	The external encoder detected a warning.	9	bit 8
A9	External encoder communications warning	\checkmark	The external encoder has more communications errors in series than the specified value.	10	bit 10

*1. The "√" fields can be set to 1 to 10 s in the Warning Latch Hold Time Selection (Pn627) or to the notime limit setting. However, the battery warning is fixed with no time limit.

*2. Select the type of warning to be output in warning output 1 (WARN1) and warning output 2 (WARN2) in the Warning Output Selection 1 (Pn440) and Warning Output Selection 2 (Pn441). If you set this to 0, all warning types will be output. Do not set it to a value other than above.

*3. Each warning detection can be masked using the Warning Mask Setting (Pn638). The corresponding bits are shown in the table.

The warning detection is masked when the bit = 1.

11-3 Alarm List

If the drive detects an error, the alarm output (ALM) will turn ON, the power drive circuit in the drive will turn OFF, and the alarm code will be displayed.

Precautions for Correct Use

- Refer to "Error Diagnosis Using the Alarm Displays" (P.11-10) for appropriate alarm measures.
- Reset the alarm using one of the following methods. Remove the cause of the alarm first.
 - · Input the alarm reset input (RESET) signal.
 - · Turn OFF the power supply, then turn it ON again.
 - · Reset the alarm from the CX-Drive.

However, some alarms can only be reset by turning the power supply OFF then ON again. Refer to the next item "Alarm List".

• If you reset an alarm while the operation command (RUN) is turned ON, the Servo Drive will start operation as soon as the alarm is released, which is dangerous. Be sure to turn OFF the RUN before clearing the alarm.

If the RUN is always ON, first check safety sufficiently before clearing the alarm.

- · When an alarm occurs, the servo drive latches the status of the servo drive just before the alarm occurrence. Those latched values can be read with the software tool for diagnostics. Refer to the CX-Drive Operation Manual (Cat. No. W453) for details.
- The stop mode in case of an alarm may vary depending on the "Immediate stop" attribute in each alarm.

Alarm List

Alarm number				Attribute		
		Error detection function Cause			Can be	Immediate
Main	Sub			History	cleared	stop *1
11	0	Control power supply undervoltage	The DC voltage of the control circuit is below the specified value.	-	\checkmark	-
12	0	Overvoltage	The DC voltage in the main circuit is abnormally high.	\checkmark	\checkmark	-
13	0	Main power supply undervoltage (Insufficient voltage between P and N)	The DC voltage of the main circuit is low.	_	\checkmark	_
15	1	Main power supply undervoltage (AC cut-off detection)	A location was detected where the main circuit AC power supply is cut off.	_	\checkmark	_
14	0	Overcurrent	Overcurrent flowed to the IGBT.	\checkmark	-	-
i -1	1	IPM error	Motor power line ground fault or short circuit.	\checkmark	-	-
15	0	Servo Drive overheat	The temperature of the Servo Drive radiator exceeded the specified value.		_	
16	0	Overload	Operation was performed with torque significantly exceeding the rating for several seconds to several tens of seconds.		\checkmark	-
18	0Regeneration overloadThe regenerative energy exceeds the processing capacity of the Regeneration Resistor.		\checkmark	-	\checkmark	
	1	Regeneration Tr error	An error was detected in a Servo Drive regeneration drive Tr.		_	_
21	0	Encoder communications disconnection error	The encoder wiring is disconnected.		_	_
21	1	Encoder communications error	An encoder communications error was detected.		-	-
23	0	Encoder communications data error	Communications cannot be performed between the encoder and the Servo Drive.	\checkmark	_	_
	0	Error counter overflow	The error counter accumulated pulse exceeds the set value for the Error Counter Overflow Level (Pn014).	\checkmark	\checkmark	
24	1	Excessive speed error	The difference between the internal position command speed and the actual speed (i.e., the speed error) exceeded the Excessive Speed Error Setting (Pn602).	V		
25	0	Excessive hybrid error	During fully-closed control, difference between position of load from external encoder and position of motor due to encoder was larger than the pulse number set by Excessive Hybrid Error Setting (Pn332).	V	_	V

Alarm number		- Error detection function	Detection details and probable	Attribute		
Main	Sub		cause	History	Can be cleared	
26	0	Overspeed	The motor rotation speed exceeded the value set on the Overspeed Level set (Pn513).	\checkmark	\checkmark	
20	1	Overspeed 2	The motor rotation speed exceeded the value set on the Overspeed Level set 2 (Pn615).	\checkmark	\checkmark	_
27	0	Command pulse frequency error	A command pulse frequency error was detected.	\checkmark	\checkmark	
21	2	Command pulse multiplier error	The command pulse divider or multiplier is not suitable.	\checkmark	\checkmark	
28	0	Pulse regeneration error	The pulse regeneration output frequency exceeded the limit.	\checkmark	\checkmark	\checkmark
29	0	Error counter overflow	Error counter value based on the encoder pulse reference exceeded 2 ²⁹ (536,870,912).		\checkmark	-
30 (st)	0	Safety input error	Safety input signal turned OFF.	-	\checkmark	_
	0	Interface input duplicate allocation error 1	A duplicate setting for the interface input signals was detected.	\checkmark	-	-
	1	Interface input duplicate allocation error 2		\checkmark	_	_
	2	Interface input function number error 1	An undefined number was detected in the interface input signal allocations.	\checkmark	-	-
	3	Interface input function number error 2		\checkmark	-	-
33	4	Interface output function number error 1	An undefined number was detected in the interface output signal allocations.	\checkmark	-	-
	5	Interface output function number error 2		\checkmark	-	-
	6	Counter reset allocation error	The counter reset function was allocated to something other than input signal SI7.	\checkmark	-	_
	7	Command pulse prohibition input allocation error	The command pulse prohibition input function was allocated to something other than input signal SI10.	\checkmark	-	_
34	0	Overrun limit error	The motor exceeded the allowable operating range set in the Overrun Limit Setting (Pn514) with respect to the position command input.			-
36	0 to 2	Parameter error	Data in the Parameter Save area was corrupted when the power supply was turned ON and data was read from the EEPROM.	-	-	-
37	0 to 2	Parameters destruction	The checksum for the data read from the EEPROM when the power supply was turned ON does not match.	-	-	-
38	0	Drive prohibition input error	The forward drive prohibition and reverse drive prohibition inputs are both turned OFF.	-	\checkmark	-

Alarm number		- Error detection function	Detection details and probable	Attribute		
Main	Sub	Error detection function	cause		Can be cleared	Immediate stop *1
	0	Excessive analog input 1	A current exceeding the Speed Command/Torque Command Input		\checkmark	\checkmark
39	1	Excessive analog input 2	Overflow Level Setting (Pn424, Pn427 or Pn430) was applied to the analog command input (pin 14).	\checkmark	\checkmark	\checkmark
	2	Excessive analog input 3		\checkmark	\checkmark	\checkmark
40	0	Absolute encoder system down error ABS	The voltage supplied to the absolute encoder is lower than the specified value.		\checkmark	-
41	0	Absolute encoder counter overflow error ABS	The multi-rotation counter of the absolute encoder exceeds the specified value.		_	-
42	0	Absolute encoder overspeed error ABS	The motor rotation speed exceeds the specified value when only the battery power supply of the absolute encoder is used.		\checkmark	_
43	0	Encoder initialization error	An encoder initialization error was detected.		_	_
44	0	Absolute encoder 1- rotation counter error ABS	A 1-turn counter error was detected.		-	_
45	0	Absolute encoder multi- rotation counter error ABS	A multi-rotation counter error or phase-AB signal error was detected.		-	_
47	0	Absolute encoder status error ABS	The rotation of the absolute encoder is higher than the specified value.	\checkmark	_	-
48	0	Encoder phase-Z error	A serial incremental encoder phase Z pulse irregularity was detected.		_	_
49	0	Encoder CS signal error	A logic error was detected in the CS signal for serial incremental encoder.		-	-
50	0	External encoder connection error	An error was detected in external encoder connection.	\checkmark	_	_
	1	External encoder communications data error	An error was detected in external encoder communications data.		_	_
	0	External encoder status error 0	An external encoder alarm code was detected.		-	_
	1	External encoder status error 1			-	_
51	2	External encoder status error 2			-	_
51	3	External encoder status error 3			-	_
	4	External encoder status error 4			_	_
	5	External encoder status error 5			-	_

11-3 Alarm List

	Alarm number Error detection function		Detection details and probable		Attribute		
Main	Sub		cause		Can be cleared		
	0	Phase-A connection error	An error was detected in the external encoder phase A connection.	\checkmark	-	_	
55	1	Phase-B connection error	An error was detected in the external encoder phase B connection.	\checkmark	-	_	
	2	Phase-Z connection error	An error was detected in the external encoder phase Z connection.	\checkmark	-	_	
87	0	Emergency stop input error	An emergency stop input signal (STOP) was input.	_	\checkmark	_	
95	0 to 4	Motor non-conformity	The combination of the Servomotor and Servo Drive is not appropriate.	_	_	_	
99	0	Other errors	 The control circuit malfunctioned due to excess noise or some other problem. 				
Other numb			• An alarm clear operation was performed when safety input 1 or safety input 2 was not in the normal status (i.e., when the input photocoupler was not ON).		-	_	

*1. An immediate stop means an alarm causing an immediate stop when the Pn510 "Stop Selection for Alarm Detection" is set to 4 to 7. For details, refer to "Stop Selection for Alarm Detection" (P.8-51).

If an error occurs in the machine, determine the error conditions from the alarm displays and operation status, identify the cause of the error, and take appropriate measures.

Error Diagnosis Using the Alarm Displays

Ala num	arm nber	Name	Cause	Measures		
Main	Sub					
11	0	Control power supply undervoltage	 The voltage between the positive and negative terminals in the control power supply converter dropped below the specified value. 100-V models: Approx. 70 VDC (approx. 50 VAC) 200-V models: Approx. 145 VDC (approx. 100 VAC) 400-V models: Approx. 15 VDC The power supply voltage is low. A momentary power interruption occurred. Insufficient power supply capacity: The power supply voltage dropped because there was inrush current when the main power supply was turned ON. The Servo Drive has failed (circuit failure). 	 Measure the voltage between the L1C and L2C lines on the connector and the terminal block. Increase the power supply voltage. Change the power supply. Increase the power supply capacity. Replace the Servo Drive. 		

Alarm number		Name	Cause	Measures
Main	Sub			
12	0	Overvoltage	 The power supply voltage exceeded the allowable input voltage range, causing the voltage between the positive and negative terminals in the converter to exceed the specified value. The power supply voltage is high. The voltage was suddenly increased by the phase advance capacitor or the uninterruptible power supply (UPS). 100-V models: Approx. 200 VDC (approx. 140 VAC) 200-V models: Approx. 400 VDC (approx. 280 VAC) 400-V models: Approx. 800 VDC (approx. 560 VAC) The regeneration resistor wiring is broken. The External Regeneration Resistor is inappropriate and cannot absorb all of the regenerative energy. The load inertia is too large, gravitational torque on the vertical axis is too large, or there is some other problem in absorbing the regenerative energy. The Servo Drive has failed (circuit failure). 	 Measure the voltage between the L1, L2, and L3 lines on the connector and the terminal block. Input the correct voltage. Remove the phase advance capacitor. Use a tester to measure the resistance of the external resistor between the B1 and B2 terminals on the Servo Drive. If the resistance is infinite, the wiring is broken. Replace the External Regeneration Resistor. Change the regeneration resistance and wattage to the specified values. (Calculate the regenerative energy and connect an External Regeneration Resistor with the required regeneration absorption capacity. Reduce the descent speed.) Replace the Servo Drive.

Alarm number		Name	Cause	Measures
Main	Sub			
13	0	Main power supply undervoltage (insufficient voltage between P and N)	If the Undervoltage Error Selection (Pn508) is set to 1, a momentary power interruption occurred between L1 and L3 for longer than the value specified for the Momentary Hold Time (Pn509). Or, the voltage between the positive and negative terminals in the control power supply converter dropped below the	 Measure the voltage between the L1, L2, and L3 lines on the connector and the terminal block. Increase the power supply voltage capacity. Change the power supply. Eliminate the cause of the failure of the electromagnetic contactor on the main circuit power supply,
	1	Main power supply undervoltage (AC cut- off detection)	 specified value while the Servo was ON. 100-V models: Approx. 80 VDC (approx. 55 VAC) 200-V models: Approx. 110 VDC (approx. 75 VAC) 400-V models: Approx. 180 VDC (approx. 125 VAC) The power supply voltage is low. A momentary power interruption occurred. Insufficient power supply capacity: The power supply voltage dropped because there was inrush current when the main power supply was turned ON. Phase loss: A Servo Drive with 3-phase input specification was operated with a single-phase power supply. The Servo Drive has failed (circuit failure). 	 and then turn ON the power again. Check the setting of the Momentary Hold Time (Pn509). Correctly set the phases of the power supply. Increase the power supply capacity. Refer to Servo Drive and Servomotor Combination Tables on page 2-11 for information on the power supply capacity. Connect the phases (L1, L2, L3) of the power supply correctly. Use L1 and L3 for single-phase 100 V and single-phase 200 V. Replace the Servo Drive.

Alarm number		Name	Cause	Measures
Main	Sub			
	0	Overcurrent	 The current flowing between P and N of the converter exceeded the specified value. The Servo Drive is faulty (faulty circuit, faulty IGBT part, etc.). The Servomotor cable is short-circuited between phases U, V, and W. The Servomotor cable is ground-faulted. Motor windings are burned out. The Servomotor wiring contact is faulty. The relay for the dynamic brake 	 Disconnect the Servomotor cable, and turn ON the servo. If the problem immediately recurs, replace the Servo Drive with a new one. Check to see if the Servomotor cable is short-circuited between phases U, V and W by checking for loose wire strands on the connector leads. Connect the Servomotor cable correctly. Check the insulation resistance between phases U, V, and W of the Servomotor cable and the
14	1	IPM error	 The relay for the dynamic brake has been welded due to frequent servo ON/OFF operations. The command pulse input timing is the same as or earlier than the servo ON timing. Check the balance between the servomotor. If resistance is unbalanced, replace the Servomotor. Check for missing connector in Servomotor connections U and W. If any loose or missing connector pins are found, see them firmly. Replace the Servo Drive. Do not turn ON the Servo for least ten minutes after using dynamic brake. Wait at least 100 ms after the 	 Check the balance between the resistance of each wire of the Servomotor. If resistance is unbalanced, replace the Servomotor. Check for missing connector pins in Servomotor connections U, V, and W. If any loose or missing connector pins are found, secure them firmly. Replace the Servo Drive. Do not turn ON the Servo for at least ten minutes after using the dynamic brake. Wait at least 100 ms after the Servo is turned ON, then input
15	0	Servo Drive overheat	 The temperature of the Servo Drive radiator or power elements exceeded the specified value. The ambient temperature of the Servo Drive exceeded the specified value. Overload 	 Improve the ambient temperature and the cooling conditions of the Servo Drive. Increase the capacities of the Servo Drive and the Servomotor. Set longer acceleration and deceleration times. Reduce the load.

Alarm number		Name	Cause	Measures
Main 16	Sub	Ib Noverload	 When the feedback value for torque command exceeds the overload level specified in the Overload Detection Level Setting (Pn512), overload protection is performed according to the overload characteristics. The load was heavy, the effective torque exceeded the rated torque, and operation continued too long. Vibration or hunting occurred due to faulty gain adjustment. The Servomotor vibrates or makes unusual noise. The Inertia Ratio (Pn004) setting is incorrect. The Servomotor wiring is incorrect or broken. The machine load suddenly became heavy, e.g., the machine hit an object. The machine was distorted. The electromagnetic brake remained ON. When multiple machines were wired, the wiring was incorrect and the Servomotor cable was connected to a Servomotor for 	 Use the analog output or CX-Drive and check to confirm that the torque (current) waveform oscillates and make sure that is does not oscillate excessively vertically. Check the overload warning display and the load rate through communications. Increase the capacities of the Servo Drive and the Servomotor. Set longer acceleration and deceleration times. Reduce the load. Readjust the gain. Connect the Servomotor cable as shown in the wiring diagram. Replace the cable. Remove the distortion from the machine. Reduce the load. Release the brake. Wire the Servomotor and the encoder correctly so that the wiring matches the axes.
			another axis. Refer to 3-2 Overload Characteristics (Electronic Thermal Function) for information on overload characteristics. The connected external regeneration resistance is lower than the minimum allowable value (for the minimum allowable value, refer to page 4-56) Connect a regeneration resistance with a suitable resistance value (for external regeneration resistance combinations and resistance values, refer to P.4-59)	

Alarm number		Name	Cause	Measures
Main	Sub			
18	0	Regeneration overload	 The regenerative energy exceeds the processing capacity of the Regeneration Resistor. The regenerative energy during deceleration caused by a large load inertia increased the voltage between P and N of the converter, and then insufficient energy absorption by the Regeneration Resistor further increased the voltage. The Servomotor rotation speed is too high to absorb the regenerative energy within the specified deceleration time. The operating limit of the external resistor is limited to a 10% duty. 	 Check the load rate of the Regeneration Resistor through CX- Drive. This Regeneration Resistor cannot be used for continuous regenerative braking. Check the operation pattern (speed monitor). Check the load rate of the Regeneration Resistor and check for the excessive regeneration warning display. Increase the capacities of the Servo Drive and the Servomotor, and lengthen the deceleration time. Use an External Regeneration Resistor. Check the operation pattern (speed monitor). Check the load rate of the Regeneration Resistor and check for the excessive regeneration warning display. Increase the capacities of the Servo Drive and the Servomotor, and lengthen the deceleration time. Reduce the Servomotor, and lengthen the deceleration time. Reduce the Servomotor rotation speed. Use an External Regeneration Resistor. Set the Regeneration Resistor Selection (Pn016) to 2.
			 Precautions for Correct Use Always install a thermal switch when setting the Regeneration Resistor Selection (Pn016) to 2. Otherwise the Regeneration Resistor will not be protected, may generate excessive heat, and may be burnt. 	
	1	Regeneration Tr error	The Servo Drive regeneration drive Tr is faulty.	Replace the Servo Drive.
21	0	Encoder communications disconnection error	A disconnection was detected because communications between the encoder and the Servo Drive were stopped more frequently than the specified value.	Wire the encoder correctly as shown in the wiring diagram. Correct the connector pin connections.
	1	Encoder communications error	There was a communications error in data from the encoder. There was a data error mainly due to noise. The encode cable is connected, but a communications data error occurred.	 Provide the required encoder power supply voltage of 5 VDC ±5% (4.75 to 5.25 V). Be careful especially when the encode cable is long. If the Servomotor cable and the encoder cable are bundled together, separate them. Connect the encoder cable correctly.

	Alarm number Name		Cause	Measures
Main	Sub			
23	0	Encoder communications data error	No communications error occurred with the data from the encoder, but there is an error in the contents of the data. There was a data error mainly due to noise. The encode cable is connected, but a communications data error occurred.	 Provide the required encoder power supply voltage of 5 VDC ±5% (4.75 to 5.25 V). Be careful especially when the encode cable is long. If the Servomotor cable and the encoder cable are bundled together, separate them. Connect the encoder cable correctly.
	0	Error counter overflow	 Position error pulses exceeded the setting of the Error Counter Overflow Level (Pn014). Motor operation does not follow the command. The value of the Error Counter Overflow Level (Pn014) is small. 	 Check to see if the Servomotor rotates according to the position command pulse. Check on the torque monitor to see if the output torque is saturated. Adjust the gain. Set the No. 1 Torque Limit (Pn013) or No. 2 Torque Limit (Pn522) is set to the maximum value. Connect the encoder cable correctly. Lengthen the acceleration and deceleration times. Reduce the load and the speed. Increase the set value for the Error Counter Overflow Level (Pn014).
24	1	Excessive speed error	The difference between the internal position command speed and the motor speed (i.e., the speed error) exceeded the Excessive Speed Error Setting (Pn602). Note: When the internal position command speed is forced to 0 for an immediate stop due to a command pulse prohibition input (IPG) or forward/reverse drive prohibition input, the speed deviation immediately increases. The speed deviation also increases at the start of the internal position command speed. Therefore, provide enough margin when making the settings.	 Increase the set value of the Excessive Speed Error Setting (Pn602). Lengthen the acceleration time of the internal position command speed. Alternatively, improve the tracking (following) performance by adjusting the gain. Disable the Excessive Speed Deviation Setting. (Pn602 = 0)

Ala num	arm nber	Name	Cause	Measures	
Main	Sub				
25	0	Excessive hybrid error	During fully-closed control, the difference between the position of load from the external encoder and the position of the motor due to the encoder was larger than the number of pulses set for the Internal/External Feedback Pulse Error Counter Overflow Level (Pn328).	 Check the motor and load connections. Check the external encoder and drive connection. When moving the load, check to see if the change in the Servomotor position (total encoder pulses) has the same sign as the change in the load position (total external encoder feedback pulses). Check to see if the External Feedback Pulse Dividing Numerator and Denominator (Pn324 and Pn325), and External Feedback Pulse Direction Switching (Pn326) are set correctly. 	
	0	Overspeed	The Servomotor rotation speed exceeded the value set for the Overspeed Detection Level Setting (Pn513).	 Do not give excessive speed commands. Check the input frequency, dividing ratio, and multiplication ratio of the command pulse. 	
26	1	Overspeed 2	The Servomotor rotation speed exceeded the value set for the Overspeed Detection Level Setting at Immediate Stop (Pn615).	 If overshooting occurred due to faulty gain adjustment, adjust the gain. Connect the encoder cable correctly. 	
	0	Command pulse frequency error	The command pulse input frequency exceeded 1.2 multiplied by the Command Pulse Input Maximum Setting (Pn532).	Check the command pulse input.	
27	2	Command pulse multiplier error	The command pulse frequency or electronic gear ratio parameters are not set correctly. The number of command pulses per 0.167 ms multiplied by the electronic gear ratio exceeded approximately 3 Gpps (or approx. 175 Kpps for software versions lower than V1.10). The command pulse input frequency varies greatly. Counting errors are resulting from noise on the command pulse input.	 Set the electronic gear ratio to the lower possible value between 1/1,000 and 1,000. Check the command pulse input. If possible, use a line driver interface. Set the Command Pulse Input Maximum Setting (Pn532) to less than 1,000 to enable a digital filter. 	
28	0	Pulse regeneration error	The pulse regeneration output frequency exceeded the limit.	 Check the set values of the Encoder Dividing Numerator (Pn011) and Encoder Dividing Denominator (Pn503). To disable detection, set the Pulse Regeneration Output Limit Setting (Pn533) to 0. 	

Alarm number		Name	Cause	Measures	
Main	Sub				
29	0	Error counter overflow	The position error for the encoder feedback pulse reference exceeded ±2 ²⁹ (536,870,912).	 Check that the motor rotates according to the position command. Check on the torque monitor that the output torque is not saturated. Adjust the gain. Set the No. 1 Torque Limit (Pn013) or No. 2 Torque Limit (Pn522) is set to the maximum value. Connect the encoder cable correctly. 	
30 (st)	0	Safety input error	At least one of the input photocouplers for safety inputs 1 and 2 turned OFF.	Check the input wiring of safety inputs 1 and 2.	
	0 duplicate allocation input		There is a duplicate setting in the input signal (IN1, IN2, IN3, IN4, and IN5) function allocations.		
33	1	Interface input duplicate allocation error 2	There is a duplicate setting in the input signal (IN6, IN7, IN8, IN9, and IN10) function allocations.		
	2	Interface input function number error 1	There is an undefined number specification in the input signal (IN1, IN2, IN3, IN4, and IN5) function allocations.		
	3	Interface input function number error 2	There is an undefined number specification in the input signal (IN6, IN7, IN8, IN9, and IN10) function allocations.	Allocate the functions to the connector pins correctly.	
	4	Interface output function number error 1	There is an undefined number specification in the output signal (SO1 and SO2) function allocations.		
	5	Interface output function number error 2	There is an undefined number specification in the output signal (SO4) function allocation.		
	6	Counter reset allocation error	The error counter reset input (ECRST) was allocated to something other than input signal SI7.		
	7	Command pulse prohibition input allocation error	The pulse prohibition input (IPG) was allocated to something other than input signal SI10.		
34	0	Overrun limit error	 The Servomotor exceeded the allowable operating range set in the Overrun Limit Setting (Pn514) with respect to the position command input range. The gain is not suitable. The set value of Pn514 is too small. 	 Check the gain (the balance between position loop gain and speed loop gain) and the inertia ratio. Increase the set value of Pn514. Alternatively, set Pn514 to 0 to disable the protection function. 	

Alarm number		Name	Cause	Measures
Main	Sub			
36	0	Parameter error	Data in the Parameter Save area was corrupted when the power supply was	 Reset all parameters. If this error occurs repeatedly, the Servo Drive may be faulty. In this
	2		turned ON and data was read from the EEPROM.	case, replace the Servo Drive. Return the Servo Drive to the dealer that it was purchased from.
	0	Parameters	EEPROM write verification data was corrupted when the power supply was	The Servo Drive is faulty. Replace the Servo Drive. Return the Servo Drive
37	1 2	destruction	turned ON and data was read from the EEPROM.	to the dealer that it was purchased from.
38	0	Drive prohibition input error	When the Drive Prohibition Input Selection (Pn504) was set to 0, both the Forward Drive Prohibition Input (POT) and the Reverse Drive Prohibition Input (NOT) turned ON. When Pn504 was set to 2, either the Forward Drive Prohibition input or the Reverse Drive Prohibition input turned ON.	Check for any problems with the switches, wires, and power supplies that are connected to the forward drive prohibition input or the reverse drive prohibition input. In particular, check to see if the external DC power supply (12 to 24 VDC) for sequence inputs turned ON too slowly.
	0	Excessive analog input 1	A voltage that exceeded the value set for the Excessive Analog Input 1 (Pn424) was applied to analog input 1.	 Set the Pn424 correctly. Check the connections to CN1. Set Pn424 to 0 to disable alarm detection.
39	1	Excessive analog input 2	A voltage that exceeded the value set for the Excessive Analog Input 2 (Pn427) was applied to analog input 2.	 Set the Pn427 correctly. Check the connections to CN1. Set Pn427 to 0 to disable alarm detection.
	2	Excessive analog input 3	A voltage that exceeded the value set for the Excessive Analog Input 3 (Pn430) was applied to analog input 3.	 Set the Pn430 correctly. Check the connections to CN1. Set Pn430 to 0 to disable alarm detection.
40	0	Absolute encoder system down error ABS	The voltage of the built-in capacitor dropped below the specified value because the power supply to the encoder or the battery power supply was down.	Connect the battery power supply, and then clear the absolute encoder. Unless the absolute encoder is cleared, the error cannot be reset.
41	0	Absolute encoder counter overflow error ABS	The multi-rotation counter of the encoder exceeded the specified value.	 Set the Operation Switch when Using Absolute Encoder (Pn015) to an appropriate value. Make sure that the traveling distance from the origin of the machine is no more than 32,767 revolutions.
42	0	Absolute encoder overspeed error ABS	The Servomotor rotation speed exceeded the specified value when only the battery power supply was used during a power interruption.	 Check the power supply voltage (5 VDC ± 5%) at the encoder. Check the connections to connector CN2. Unless the absolute encoder is cleared, the error cannot be reset.
43	0	Encoder initialization error	An encoder initialization error was detected.	Replace the Servomotor.

11

	ırm nber	Name	Cause	Measures	
Main	Sub				
44	0	Absolute encoder 1- rotation counter error ABS	The encoder detected a 1-rotation counter error.	Replace the Servomotor.	
45	0	Absolute encoder multi-rotation counter error ABS	The encoder detected a multi-rotation counter error.	Replace the Servomotor.	
47	0	Absolute encoder status error ABS	The rotation of the encoder was higher than the specified value when the power supply was turned ON.	Do not let the Servomotor move when the power supply is turned ON.	
48	0	Encoder phase-Z error	A missing serial incremental encoder phase-Z pulse was detected. The encoder is faulty.	Replace the Servomotor.	
49	0	Encoder CS signal error	A logic error was detected in the CS signal for serial incremental encoder. The encoder is faulty.	Replace the Servomotor.	
	0	External encoder connection error	A disconnection was detected because communications between the external encoder and the Servo Drive were interrupted more than the specified number of times.	Wire the external encoder correctly as shown in the connection diagram. Correct the connector pin connections.	
50	1	External encoder communications data error	There was a communications error in data from external encoder. There was a data error mainly due to noise. The external encoder connection cable is connected, but a communications data error occurred.	 Provide the required external encoder power supply voltage or 5 VDC ±5% (4.75 to 5.25 V). Be careful especially when the external encoder connection cable is long. If the Servomotor cable and the external encoder connection cable are bundled together, separate them. Wire the external encoder cable correctly. Refer to the external encoder connection diagram. 	
	0	External encoder status error 0	Bit 0 of the external encoder error code (ALMC) was set to 1. Check the external encoder specifications.		
	1	External encoder status error 1	Bit 1 of the external encoder error code (ALMC) was set to 1. Check the external encoder specifications.		
51	2	External encoder status error 2	Bit 2 of the external encoder error code (ALMC) was set to 1. Check the external encoder specifications.	Eliminate the cause of the error and then clear the external encoder error	
51	3	External encoder status error 3	Bit 3 of the external encoder error code (ALMC) was set to 1. Check the external encoder specifications.	from the front panel. Then, cycle the control power supply.	
	4	External encoder status error 4	Bit 4 of the external encoder error code (ALMC) was set to 1. Check the external encoder specifications.		
	5	External encoder status error 5	Bit 5 of the external encoder error code (ALMC) was set to 1. Check the external encoder specifications.		

Troubleshooting and Maintenance

Alarm number		Name	Cause	Measures
Main	Sub			
	0	Phase-A connection error	An error such as broken wiring was detected in the external encoder phase-A connection.	Check the external encoder phase-A connection.
55	1	Phase-B connection error	An error such as broken wiring was detected in the external encoder phase-B connection.	Check the external encoder phase-B connection.
	2	Phase-Z connection error	An error such as broken wiring was detected in the external encoder phase-Z connection.	Check the external encoder phase-Z connection.
87	0	Emergency stop input error	An emergency stop input (STOP) was input.	Check the emergency stop input (STOP) wiring.
95	0 to 4	Motor non-conformity	The Servomotor does not match the Servo Drive.	Replace the Servomotor with a Servomotor that matches the Servo Drive.
99	0		 An alarm was reset when safety input 1 or 2 was not normal (one of the input photocouplers is not ON). *1 The control circuit malfunctioned due to excess noise or some other problem. The self-diagnosis function of the Servo Drive was activated, and an error occurred in the Servo Drive. 	 Reset the alarm when safety inputs 1 and 2 are normal (both input photocouplers are ON). *2 Turn OFF the power once, and turn it ON again. If the alarm is displayed even after the power is turned ON again, the system may be faulty. Stop using the system, and replace the Servomotor and/or the Servo Drive. Return the Servo Drive to the dealer that it was purchased from and ask for investigation and repair.
Other numbers		Other errors	 The control circuit malfunctioned due to excess noise or some other problem. The self-diagnosis function of the Servo Drive was activated, and an error occurred in the Servo Drive. A voltage of ±11 V or higher was applied to analog input 2 or analog input 3. 	 Turn OFF the power once, and turn it ON again. If the alarm is displayed even after the power is turned ON again, the system may be faulty. Stop using the system, and replace the Servomotor and/or the Servo Drive. Return the Servo Drive to the dealer that it was purchased from and ask for investigation and repair. Adjust the voltage applied to analog input 2 or analog input 3 to a suitable value.


*1. This alarm may occur due to the timing between safety input 1/2 and alarm clear input. For details, refer to Alarm No. 99.0 on page 11-22.

*2. For the alarm reset input timing, refer to Operation Timings to a Safety Status on page 7-4.

Alarm No. 99.0

Alarm No. 99.0 may occur due to the timing between safety input 1/2 and alarm clear input. This alarm will occur if both of the following conditions are met:

- An alarm was cleared when at least one of the input photocouplers for safety inputs 1 and 2 was OFF (which means that a Safety Input Error (Alarm No. 30.0) had occurred).
- At least one of the input photocouplers for safety inputs 1 and 2 was turned from OFF to ON in a specific period during the alarm clear process (See below).



*1. Alarm No. 99.0 will occur if at least one of the input photocouplers for safety inputs 1 and 2 is turned from OFF to ON.

Precautions for Correct Use

Be sure to clear the alarm after turning ON the photocouplers for safety inputs 1 and 2 again.

Troubleshooting Using the Operation Status

Symptom	Probable cause	Items to check	Measures
The PWR LED indicator does not light when the power	The power supply cable is wired incorrectly.	Check to see if the power supply input is within the allowed power supply voltage range.	Supply the correct power supply voltage.
supply is turned ON.		Check to see if the power supply input is wired correctly.	Wire correctly.
The motor does not rotate even if commands are input from the controller.	The operation command (RUN) is OFF.	In Monitor Mode, check whether the RUN signal is ON or OFF.	 Turn ON the operation command (RUN). Wire correctly.
(Continued on next page)	The Forward or Reverse Drive Prohibition Input (POT or NOT) is OFF.	In Monitor Mode, check whether the POT signal and NOT signal are ON or OFF.	 Turn ON the POT and NOT signals. Disable them in the settings when the POT and NOT signals are not used.
	The control mode does not conform to the command.	Check the control mode Selection (Pn001).	Set the control mode according to the command.
	The error counter reset (ECRST) is ON.	In Monitor Mode, check whether the ECRST signal is ON or OFF.	 Turn OFF the ECRST signal. Wire correctly.
	Command Pulse Mode Selection (Pn007) is selection is incorrect.	Check the controller's command pulse type and the Servo Drive's command pulse type.	Set the Servo Drive's pulse type to match the controller's command pulse type.
	The zero speed designation (VZERO) is OFF.	In Monitor Mode, check whether the VZERO signal is ON or OFF.	 Turn ON the VZERO signal. Wire correctly.
	The internally set speeds are not set.	Check the set value of Pn304 to Pn311.	Set the desired speeds.
	The No. 1 Torque Limit (Pn013) or No. 2 Torque Limit (Pn522) is set to 0.	Check the set value of Pn013 and Pn522.	Return the set value to the default setting.
	The Servomotor power cable is wired incorrectly.	Check the wiring.	Wire correctly.
	The encoder cable is wired incorrectly.		
	The control I/O connector (CN1)	Check the command pulse's wiring.	Wire correctly.
	is wired incorrectly.	Check the command pulse type.	Set the Servo Drive's pulse type to match the controller's command pulse type.
		Check the command pulse's voltage.	Connect a resistor that matches the voltage.
	Power is not supplied.	Check whether the power supply is ON and check the PWR LED indicator.	Turn ON the power supply.
		Check the voltage across the power supply terminals.	Wire the power-ON circuit correctly.
	The speed command is disabled.	Check if the speed command method is correct.	 Set the external analog command correctly. Set the internal speed correctly.

Symptom	Probable cause	Items to check	Measures
The motor does not rotate even if	The torque command is disabled.	Check if the torque command input method is correct.	Set the torque command correctly.
commands are input from the controller. (Continued from previous page)	The CW input and CCW input are ON at the same time.	Check the command pulse's wiring.	 Input the pulse signal either to the CW input or CCW input. Always turn OFF the terminal that is not input to.
	The Servo Drive has broken down.	_	Replace the Servo Drive.
The Servomotor operates	The Servomotor power cable is wired incorrectly.	Check the wiring of the Servomotor power cable's phases U, V, and W.	Wire correctly.
nomentarily, but then t does not operate after that.	The encoder cable is wired incorrectly.	Check the encoder cable's wiring.	Wire correctly.
The Servomotor	The command pulse input is	Check the command pulse type.	Set the correct command pulse input.
rotates without a command.	incorrect.	Check the command pulse's voltage.	Connect a resistor that matches the voltage.
	The Servo Drive has broken down.	-	Replace the Servo Drive.
The Servomotor rotates n the reverse direction from the command.	The CW input and CCW input connections are reversed.	Check the controller's command pulse type and the Servo Drive's command pulse type.	Connect the CW pulse signal to the CW input and the CCW pulse signal to the CCW input.
Motor rotation is unstable.	The Servomotor power cable or encoder cable is wired incorrectly.	Check the wiring of the Servomotor power cable's phases U, V, and W and check the encoder cable's wiring.	Wire correctly.
	The coupling system between the motor shaft and the mechanical	Check the mechanical system's coupling section.	Review and adjust the machine
	system has eccentricity or loose screws, or the load torque is fluctuating due to engagement between pulleys or gears.	Try rotating the motor without a load. (Disconnect it from the mechanical system.)	•
	The load's moment of inertia exceeds the Servo Drive's allowable value.	Try rotating the motor without a load. (Disconnect it from the mechanical system.)	 Reduce the load. Replace the Servomotor and Servo Drive with higher capacity models.
	The pulse signal line's connections are loose.	Check the pulse signal line's wiring at the controller and Servo Drive.	Wire correctly.
		Check the controller's command pulse type and the Servo Drive's command pulse type.	Set the Servo Drive's pulse type to match the controller's command pulse type.
	The gain is wrong.	_	Perform manual tuning.
	The CN1 input signal is chattering.	Check the operation command (RUN), error counter reset (ECRST), zero speed designation (VZERO), internally set speed selection 1 (VSEL1) and internally set speed selection 2 (VSEL2).	Wire correctly so that there is no chattering.
The Servomotor is overheating.	The ambient temperature is too high.	Check that the ambient temperature around the motor is 40°C or less.	Lower the ambient temperature around the Servomotor to 40°C or less. (Use a fan or air conditioner.
	Ventilation is obstructed.	Check to see whether anything is blocking ventilation.	Improve ventilation.
	The Servomotor is overloaded. The Servomotor vibrates during rotation.	Try rotating the motor without a load. (Disconnect it from the mechanical system.)	 Reduce the load. Replace the Servomotor and Servo Drive with higher capacity models.

Troubleshooting and Maintenance

Symptom	Probable cause	Items to check	Measures
The Servomotor holding brake is ineffective.	Power is supplied to the holding brake.	Check whether power is supplied to the holding brake.	Configure a circuit that cuts power supply to the holding brake when the motor stops and the load is held by the holding brake.
The motor does not stop or is hard to stop even if the operation	The load inertia is too large.	Check the following: ·Is the load too large? ·Is the motor rotation speed too high?	Review the load conditions, and replace the Servomotor and Servo Drive with appropriate models.
command (RUN) is turned OFF while the motor is rotating.	The stop circuit failed.	_	Replace the Servo Drive.
The motor is producing unusual noises or the	There are problems with the machine's installation.	Check to see if the Servomotor's mounting screws are loose.	Retighten the mounting screws.
machine is vibrating. (Continued on next		Check whether the axes are misaligned in the coupling.	Align the coupling.
page)		Check whether the coupling is unbalanced.	Adjust the coupling's balance.
	There is a problem with the bearings.	Check for noise or vibration around the bearings.	Contact your OMRON dealer or sales office.
	The gain is wrong.	-	Perform manual tuning.
	The Speed Feedback Filter Time Constant (Pn103) is wrong.	Check the value set in Pn103.	Return the set to 0 (default set) or increase the set value.
	Noise is entering into the control I/O signal cable because the cable does not meet specifications.	Check to see if the cable is a twisted-pair cable or shielded twisted-pair cable with core wires that are at least 0.08 mm dia.	Use a control I/O signal cable that meets specifications.
	Noise is entering into the control I/O signal cable because the cable is longer than the specified length.	Check the length of the control I/O signal cable.	Shorten the control I/O signal cable to 3 m or less.
	Noise is entering into the cable because the encoder cable does not meet specifications.	Check to see if it is a shielded twisted-pair cable with core wires that are at least 0.12 mm dia.	Use an encoder cable that meets specifications.
	Noise is entering into the encoder cable because the cable is longer than the specified length.	Check the length of the encoder cable.	Shorten the encoder cable to less than 50 m.
	Noise is entering into the signal lines because the encoder cable is stuck or the sheath is damaged.	Check the encoder cable for damage.	Correct the encoder cable's pathway.
	Excessive noise on encoder cable.	Check to see if the encoder cable is bound together with or too close to high- current lines.	Install the encoder cable where it won't be subjected to surges.
	The FG's potential is fluctuating due to devices near the Servomotor, such as welding machines.	Check for ground problems (loss of ground or incomplete ground) at equipment such as welding machines near the Servomotor.	Ground the equipment properly and prevent current from flowing to the encoder FG.
	Errors are being caused by excessive vibration or shock on the encoder.	There are problems with mechanical vibration or Servomotor installation (such as the precision of the mounting surface, attachment, or axial offset).	Reduce the mechanical vibration or correct the Servomotor's installation.
The motor is producing unusual noises or the machine is vibrating. (Continued from previous page)	The machine and the motor are resonating.	Check to see if the machine is resonating.	 Readjust the torque command filter time constant. If there is resonance, set the Notch Filter 1 Frequency (Pn201), Notch Filter 1 Width (Pn202), and Notch Filter 1 Depth (Pn203).

Symptom	Probable cause	Items to check	Measures
Vibration is occurring at the same	Inductive noise is occurring.	Check to see if the drive control signal lines are too long.	Shorten the control signal lines.
frequency as the power supply.		Check to see if the control signal lines and power supply lines are not bound together.	 Separate control signal lines from power supply lines. Use a low-impedance power supply for control signals.
The position is misaligned. (Position	There is an error in the coupling of the mechanical system and the Servomotor.	Check to see if the coupling of the mechanical system and the Servomotor is misaligned.	Correct the coupling between the mechanical system and the Servomotor.
misalignment occurs without an alarm being output.)	larm	Check to see if the control signal lines and power supply lines are bound together.	Separate the control signal lines from the power lines or take other measures against noise.
		Check to see if it is a shielded twisted-pair cable with core wires that are at least 0.08 mm dia.	Use a control I/O signal cable that meets specifications.
		Check the length of the control I/O signal cables.	Do not allow the length of the control I/O signal cables to exceed 10 m for a line driver input and 3 m for an open-connector input.
	The gain is wrong.	-	Perform manual tuning.
	The load inertia is large.	Inspect the following. Is the load too large? Is the motor rotation speed too high? 	 Adjust the gain. Review the load conditions, and replace the Servomotor and Servo Drive with appropriate models.

11-5 Periodic Maintenance

▲ Caution



After replacing the Servo Drive, transfer to the new Servo Drive all data needed to resume operation, before restarting the operation. Equipment damage may result.



Never repair the Servo Drive by disassembling it. Electric shock or injury may result.

Servomotors and Servo Drives contain many components and will operate properly only when each of the individual components is operating properly.

Some of the electrical and mechanical components require maintenance depending on application conditions. Periodic inspection and replacement are necessary to ensure proper long-term operation of Servomotors and Servo Drives. (Quoted from *The Recommendation for Periodic Maintenance of a General-purpose Inverter* published by JEMA.)

The periodic maintenance cycle depends on the installation environment and application conditions of the Servomotors and Servo Drives.

Recommended maintenance times are listed below for Servomotors and Servo Drives. Use these for reference in periodic maintenance.

Servomotor Life Expectancy

• The lifetimes for the different motor parts are listed below.

	Bearings:	20,000 hours
Oli seal: 5,000 nours	Oil seal:	5,000 hours

Encoder: 30,000 hours

These values presume an ambient motor operating temperature of 40° C, within the allowable axial load, rated operation (rated torque and rated rotation speed), and proper installation as described in this manual.

The bearings, reducer, oil seal, and encoder can be replaced for repair work.

 The radial load during Servomotor operation on timing pulleys and other components contacting belts is two or more times the static load or more. Consult with the belt and pulley manufacturers and adjust designs and system settings so that the motor allowable axial load is not exceeded even during operation. If a motor is used under a shaft load exceeding the allowable limit, the motor shaft can break and the bearings can be damaged.

11

Servo Drive Life Expectancy

- The lifetimes for the different drive parts are listed below.
 Aluminum electrolytic capacitors: 28,000 hours

 (at an ambient drive operating temperature of 55°C, constant output of rated torque, constant output of rated rotation speed, and installation as described in this manual)
 Axial-flow fan: 10,000 to 30,000 hours (The limit depends on the operating conditions.)
 Inrush current prevention relay: Approx. 20,000 operations (The limit depends on the operation conditions.)
- When using the Servo Drive in continuous operation, use fans or air conditioners to maintain the ambient temperature below 40°C.
- We recommend that ambient temperature and the power supply ON time be reduced as much the possible to lengthen the service life of the Servo Drive.
- The limit of aluminum electrolytic capacitors is greatly affected by the ambient operating temperature. Generally, an increase of 10°C in the operating ambient temperature will reduce capacitor service life by 50%. Following equation shows an example for 25°C: .

Lifetime 25°C = Lifetime 55°C × 2
$$\frac{55-25}{10}$$
 = 224000 hour

- The aluminum electrolytic capacitors deteriorate even when the Servo Drive is stored with no power supplied. If the Servo Drive is not used for a long time, we recommend periodic inspection and a part replacement period of 5 years.
- If the Servomotor or Servo Drive is not to be used for a long time, or if they are to be used under conditions worse than those described above, a periodic inspection period of 5 years is recommended.
- Upon request, OMRON will examine the Servo Drive and Servomotor and determine if part replacement is required.

Replacing the Absolute Encoder Battery ABS

If an Absolute Encoder System Down Error (Alarm No. 40) occurs, replace the battery.

Battery Life

Examples of calculating the life of the absolute encoder battery are given below for robot operation.


A battery capacity of 2,000 mAh is used in the calculations.

The calculations only estimate the life of the battery. The actual life may vary.

Precautions for Correct Use

Only the current consumption is included in the following calculations. They do not consider deterioration of the battery due to fluid leakage or other factors. The battery life will be reduced depending on ambient conditions.

1. Example for Two Operations per Day



Consumed capacity in 1 year

(10 hr \times a + 0.0014 hr \times b + 2 hr \times c) \times 2 \times 313 days+ 24 hr \times c \times 52 days = 222.7 mAh Battery life = 2,000 mAh/222.7 mAh/year = 9.0 (8.9809) years

2. Example for One Operation per Day

An example of calculating the battery life is given below for when the second operation in the first example given above is not performed.

Consumed capacity in 1 year

(10 hr \times a + 0.0014 hr \times b + 14 hr \times c) \times 313 days+ 24 hr \times c \times 52 days = 461.7 mAh Battery life = 2,000 mAh/461.7 mAh/year = 4.3 (4.3314) years

Item	Specifications
Name	Absolute Encoder Backup Battery Unit
Model	R88A-BAT01G
Battery model	ER6V (Toshiba)
Battery voltage	3.6 V
Current capacity	2,000 mA·h

Replacement Battery Model and Specifications

Mounting the Backup Battery Unit

Mounting the Battery Unit for the First Time

Connect the Absolute Encoder Backup Battery Unit to the motor, then set up the absolute encoder. Refer to "Absolute Encoder Setup" (P.9-4).

After the Absolute Encoder Battery Unit is attached, it is recommended that the control power supply be turned ON and OFF once a day to refresh the battery.

If you neglect to refresh the battery, battery warning will occur due to voltage delays in the battery.

Replacing the Battery Unit

If a battery warning occurs, the Absolute Encoder Backup Battery Unit must be replaced.


Replace the Battery Unit with the control power supply of the Servo Drive turned ON. If the Battery Unit is replaced with the control power supply of the Servo Drive turned OFF, data held in the encoder will be lost.

The Battery Warning will occur after you replace the Absolute Encoder Backup Battery Unit. Use one of the following methods to clear it.


- Use the alarm reset input signal of CN1 control inputs.
- Use the front panel to perform the alarm clear (refer to page 9-25).
- Use the absolute encoder setting in the CX-Drive.
- Note: If the absolute encoder is cleared using the front panel or communications, all alarms and multi-rotation data will be lost and the absolute encoder must be set up again. Refer to "Absolute Encoder Setup"(P.9-4).

Battery Unit Mounting Method

1. Prepare the replacement Battery Unit (R88A-BAT01G).





2. Remove the Battery Unit box cover.



Raise the tabs and remove the cover.

3. Put the Battery Unit into the battery box.






Insert the Battery Unit.

Plug in the connector.

4. Close the cover to the battery box.



Close the battery box cover by making sure the connector wires are not pinched.





11


12

Appendix

This chapter provides connection examples using OMRON's PLC and Position Controller, as well as a list of parameters.

12-1 Connection Examples	12-1
12-2 Parameter List	12-11

12-1 Connection Examples




Connection Example 1: Connecting to SYSMAC CJ1W-NC133/233/433



- The wiring for the pins with * is the same as it is when a Servo Relay Unit Cable is used. Set Pn005 (Command Pulse Input Selection) to 0 (photocoupler input).
- The example shows a 3-phase, 200-VAC input to the drive for the main circuit power supply. Be sure to provide a power supply and wiring conforming to the power supply specifications for the drive in use.
- Incorrect signal wiring can cause damage to units and the drive.
- + Leave unused signal lines open and do not wire them.
- Use mode 2 for origin search.
- The diode recommended for surge absorption is the RU 2 (Sanken Electric Co., Ltd.) or the equivalent.
- Make the setting so that the servo can be turned ON/OFF with the RUN signal.


Connection Example 2: Connecting to SYSMAC CJ1W-NC113/213/413





- The wiring for the pins with * is the same as it is when a Servo Relay Unit Cable is used. Set Pn005 (Command Pulse Input Selection) to 0 (photocoupler input).
- The example shows a 3-phase, 200-VAC input to the drive for the main circuit power supply. Be sure to provide a power supply and wiring conforming to the power supply specifications for the drive in use.
- Incorrect signal wiring can cause damage to units and the drive.
- Leave unused signal lines open and do not wire them.
- Use mode 2 for origin search.
- The diode recommended for surge absorption is the RU 2 (Sanken Electric Co., Ltd.) or the equivalent.
- Make the setting so that the servo can be turned ON/OFF with the RUN signal.

Connection Example 3: Connecting to SYSMAC CS1W-NC133/233/433




Precautions for Correct Use

- The wiring for the pins with * is the same as it is when a Servo Relay Unit Cable is used. Set Pn005 (Command Pulse Input Selection) to 0 (photocoupler input).
- The example shows a 3-phase, 200-VAC input to the drive for the main circuit power supply. Be sure to provide a power supply and wiring conforming to the power supply specifications for the drive in use.
- Incorrect signal wiring can cause damage to units and the drive.
- Leave unused signal lines open and do not wire them.
- Use mode 2 for origin search.
- The diode recommended for surge absorption is the RU 2 (Sanken Electric Co., Ltd.) or the equivalent.
- Make the setting so that the servo can be turned ON/OFF with the RUN signal.

12


Connection Example 4: Connecting to SYSMAC CS1W-NC113/213/413 or C200HW-NC113/213/413






- The wiring for the pins with * is the same as it is when a Servo Relay Unit Cable is used. Set Pn005 (Command Pulse Input Selection) to 0 (photocoupler input).
- The example shows a 3-phase, 200-VAC input to the drive for the main circuit power supply. Be sure to provide a power supply and wiring conforming to the power supply specifications for the drive in use.
- Incorrect signal wiring can cause damage to units and the drive.
- Leave unused signal lines open and do not wire them.
- Use mode 2 for origin search.
- The diode recommended for surge absorption is the RU 2 (Sanken Electric Co., Ltd.) or the equivalent.
- Make the setting so that the servo can be turned ON/OFF with the RUN signal.

Connection Example 5: Connecting to a SYSMAC Motion Control Unit




- The example shows a 3-phase, 200-VAC input to the drive for the main circuit power supply. Be sure to provide a power supply and wiring conforming to the power supply specifications for the drive in use.
- Incorrect signal wiring can cause damage to units and the drive.
- Leave unused signal lines open and do not wire them.
- Connect terminals and wiring marked with an asterisk (*) when using an absolute encoder.
- This wiring diagram is an example of X-axis wiring only. For other axes, connections must be made in the same way with the drive.
- Always short unused NC input terminals at the Motion Control Unit I/O connectors.
- Make the setting so that the servo can be turned ON/OFF with the RUN signal.

Connection Example 6: Connecting to SYSMAC CP1H-Y



- Incorrect signal wiring can cause damage to units and the drive.
- Leave unused signal lines open and do not wire them.
- Do not share the power supply for brakes (24 VDC) with the 24-VDC power supply for controls.
- The diode recommended for surge absorption is the RU 2 (Sanken Electric Co., Ltd.) or the equivalent.

Connection Example 7: Connecting to SYSMAC CP1H-X DT-D/CP1L-DDT-D




Precautions for Correct Use

- Incorrect signal wiring can cause damage to units and the drive.
- Leave unused signal lines open and do not wire them.
- Do not share the power supply for brakes (24 VDC) with the 24-VDC power supply for controls.
- The diode recommended for surge absorption is the RU 2 (Sanken Electric Co., Ltd.) or the equivalent.


12

Connection Example 8: Connecting to SYSMAC CJ1M



- Incorrect signal wiring can cause damage to units and the drive.
- + Leave unused signal lines open and do not wire them.
- Use mode 2 for origin search.
- Use the power supply for command pulse (24 VDC) as a dedicated power supply.
- Do not share the power supply for brakes (24 VDC) with the 24-VDC power supply for controls.
- The diode recommended for surge absorption is the RU 2 (Sanken Electric Co., Ltd.) or the equivalent.

Connection Example 9: Connecting to a SYSMAC CS1W-HCP22-V1 Customizable Counter Unit




*1. The I/O signals for the HCP22 depend on the memory allocations in the Internal Memory area. Change the wiring according to the allocations.

Precautions for Correct Use

- Incorrect signal wiring can cause damage to units and the drive.
- Leave unused signal lines open and do not wire them.
- Use the power supply for command pulse (24 VDC) as a dedicated power supply.
- The diode recommended for surge absorption is the RU 2 (Sanken Electric Co., Ltd.) or the equivalent.
- Do not share the power supply for brakes (24 VDC) with the 24-VDC power supply for controls.

12

Connection Example 10: Connecting to a SYSMAC CS1W-HCA12/22-V1 Customizable Counter Unit



*1. The I/O signals for the HCA12/22 depend on the allocations in the Internal Memory area. Change the wiring according to the allocations.



- Incorrect signal wiring can cause damage to units and the drive.
- + Leave unused signal lines open and do not wire them.
- Use the power supply for command pulse (24 VDC) as a dedicated power supply.
- The diode recommended for surge absorption is the RU 2 (Sanken Electric Co., Ltd.) or the equivalent.
- Do not share the power supply for brakes (24 VDC) with the 24-VDC power supply for controls.

12-2 Parameter List

- Some parameters are enabled by turning the power supply OFF and then ON again. (Those parameters are indicated in the table.) After changing these parameters, turn OFF the power supply, confirm that the power supply indicator has gone OFF, and then turn ON the power supply again.
- Do not change the parameters marked "Reserved". Do not change the settings marked "Reserved".

Basic Setting Parameters

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
			the relation between the command ection and the motor rotation direction.				Yes
000	Rotation Direction	0	A forward direction command sets the direction to CW as viewed from the shaft end	1	_	0 or 1	
	Switching	1	A forward direction command sets the direction to CCW as viewed from the shaft end				
		Sel	ect the Servo Drive control mode.				
		0	Position control (pulse train command)				
		1	Speed control (analog command)				Yes
		2	Torque control (analog command)			0 to 6	
001	Control Mode Selection	3	No. 1: Position control No. 2: Speed control	0	_		
		4	No. 1: Position control No. 2: Torque control				
		5	No. 1: Speed control No. 2: Torque control				
		6	Fully-closed control				
		Set	the operation mode for realtime autotuning.				
		0	Disabled				
		1	Emphasizes stability				
		2	Emphasizes positioning				
002	Realtime Autotuning Mode Selection	3	If there is an unbalanced load like in a vertical axis.	1	_	0 to 6	_
		4	Used when friction is large.				
		5	Used when there is an unbalanced load, such as a vertical axis, and friction is large.				
		6	Used to customize the Realtime Autotuning Mode.				
003	Realtime Autotuning Machine Rigidity Setting		the machine rigidity for executing litime autotuning.	See Note 1	_	0 to 31	-
004	Inertia Ratio		the load inertia as a percentage of the tor rotor inertia.	250	%	0 to 10,000	_

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
	Command	Sele	ect the command pulse input.				
005	Pulse Input	0	Photocoupler input	0	-	0 or 1	Yes
	Selection	1	Input for line driver only				
	Command Pulse	Set	the command pulse count direction.				
006	Rotation Direction Switching	0	Forward direction	0	-	0 or 1	Yes
	Selection	1	Reverse direction				
		Set	the command pulse mode.				
	Command	0	90° differential-phase (A/B) inputs				
007	Pulse Mode	1	Forward pulse/reverse pulse	1	_	0 to 3	Yes
	Selection	2	90° differential-phase (A/B) inputs				
		3	Feed pulse and direction signal				
008	Electronic Gear Integer Setting		the number of command pulses per or rotation.	10000	Pulses	0 to 2 ²⁰	Yes
009	Electronic Gear Ratio Numerator 1	lf Pr	the electronic gear ratio. 1009 = 0, the encoder resolution is set as numerator.	0	_	0 to 2 ³⁰	_
010	Electronic Gear Ratio Denominator		Electronic gear ratio numerator 1 (Pn009) Electronic gear ratio denominator (Pn010)	10000	_	1 to 2 ³⁰	-
011	Encoder Dividing Numerator		the number of phase A and phase B put pulses, respectively per motor rotation.	2500	P/r	1 to 262,144	Yes
			ect the phase B logic for pulse eneration output and the output source.				Yes
	Encoder Output	0	Phase B logic: Not reversed Output source: Encoder		_		
012	Direction Switching Selection	1	Phase B logic: Reversed Output source: Encoder	0		0 to 3	
	Selection	2	Phase B logic: Not reversed Output source: External encoder				
		3	Phase B logic: Reversed Output source: External encoder				
013	No. 1 Torque Limit		ne No. 1 limit value for the output torque of the motor.	500	%	0 to 500	-
014	Error Counter Overflow Level	leve	the range of the error counter overflow I. Detection of error counter overflow I error is disabled if the set value is 0.	100000	Command units	0 to 2 ²⁷	-
		Sele	ect the absolute encoder usage method.				
	Operation	0	Used as an absolute encoder.	1			
015	Switch when	1	Used as an incremental encoder.	1	_	0 to 2	Yes
	Using Absolute Encoder	2	Used as an absolute encoder. (Multi-rotation counter overflows are ignored.)				Yes

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
	Regeneration Resistor Select the Regeneration Resistor used.Use the Built-in Resistor. Triggering of regeneration overload o protection (Alarm No. 18) depends on the Built-in Resistor (with approx. 1% duty).Use an External Resistor. The regeneration processing circuit operates and regeneration overload protection (Alarm No. 18) is triggered when the operating rate of the Regeneration Resistor.See Note 21Use an External Resistor. The regeneration processing circuit operates and regeneration overload protection (Alarm No. 18) is triggered when the operating rate of the Regeneration Resistor exceeds 10%.See Note 22Use an External Resistor. 						
016		0	Triggering of regeneration overload protection (Alarm No. 18) depends on the Built-in Resistor (with approx. 1%			0 to 3	Yes
		1	The regeneration processing circuit operates and regeneration overload protection (Alarm No. 18) is triggered when the operating rate of the		_		
		2	Regeneration overload protection				
		3	All regeneration power is processed				
			ect the type of load ratio calculation for External Regeneration Resistor.				
017	External	0	Regeneration load ratio is 100% when operating rate of the External Regeneration Resistor is 10%.			0 to 4	Yes
017	Regeneration Resistor Setting	1	Reserved	0	_	0 to 4	
		2	Reserved	1			
		3	Reserved]			
		4	Reserved				

•Note 1: The default setting is 11 for 200-V Servo Drives of 1 kW or higher and 400-V Servo Drives.

•Note 2: The default setting is 0 for 100-V Servo Drives of 400 W, 200-V Servo Drives of 750 W to 5 kW, and 400-V Servo Drives of 5 kW or lower.

Gain Parameters

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
100	Position Loop Gain	Set	the position loop gain 1.	See Note 1	0.1/s	0 to 30,000	_
101	Speed Loop Gain	Set	the speed loop gain 1.	See Note 2	0.1 Hz	1 to 32,767	-
102	Speed Loop Integral Time Constant	Set	the speed loop integral time constant 1.	See Note 3	0.1 ms	1 to 10,000	-
103	Speed Feedback Filter Time Constant		speed feedback filter 1 can be set to one values.	0	-	0 to 5	-
104	Torque Command Filter Time Constant	Set	the time constant for the torque filter 1.	See Note 4	0.01 ms	0 to 2,500	_
105	Position Loop Gain 2	Set	the position loop gain 2.	See Note 5	0.1/s	0 to 30,000	-
106	Speed Loop Gain 2	Set	the speed loop gain 2.	See Note 6	0.1 Hz	1 to 32,767	-
107	Speed Loop Integral Time Constant 2	Set	the speed loop integral time constant 2.	10000	0.1 ms	1 to 10,000	_
108	Speed Feedback Filter Time Constant 2		speed feedback filter 2 can be set to one values.	0	_	0 to 5	_
109	Torque Command Filter Time Constant 2	Set	the time constant for the torque filter 2.	See Note 7	0.01 ms	0 to 2,500	_
110	Speed Feed- forward Amount	Set	the speed feed-forward amount.	300	0.1%	0 to 1,000	-
111	Speed Feed- forward Command Filter		the speed feed-forward filter time stant.	50	0.01 ms	0 to 6,400	_
112	Torque Feed- forward Amount	Set	the torque feed-forward amount.	0	0.1%	0 to 1,000	_
113	Torque Feed- forward Command Filter		the torque feed-forward filter.	0	0.01 ms	0 to 6,400	_
114	Gain Switching Input Operating Mode Selection		cute optimum tuning using the gain ching function. Gain 1 (PI/P switching enabled) Gain 1 and gain 2 switching available	1	_	0 or 1	_

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
		pos	ect the gain switching condition for ition control. necessary that Pn114 be set to 1.				
		0	Always gain 1				
		1	Always gain 2				
		2	Switching using gain switching input (GSEL)				
	Switching Mode	3	Torque command change amount				
115	in Position	4	Always gain 1	0	-	0 to 10	_
	Control	5	Command speed				
		6	Amount of position error				
		7	Command pulses received				
		8	Positioning completion signal (INP) OFF				
		9	Actual motor speed				
		10	Combination of command pulse input and speed				
116	Gain Switching Delay Time in Position Control		the delay time for switching from gain 2 ain 1.	50	0.1 ms	0 to 10,000	_
117	Gain Switching Level in Position Control	Set	the gain switching level.	50	_	0 to 20,000	_
118	Gain Switching Hysteresis in Position Control	Set	the hysteresis for gain switching.	33	_	0 to 20,000	_
119	Position Gain Switching Time		the position gain switching time for gain tching.	33	0.1 ms	0 to 10,000	-
		con	elect the gain switching condition for speed ontrol. is necessary that Pn114 be set to 1.				
		0	Always gain 1				
	0	1	Always gain 2				
120	in Speed Control	2	Switching using gain switching input (GSEL)	0	-	0 to 5	-
		3	Torque command change amount				
		4	Speed command change amount				
		5	Command speed				
121	Gain Switching Delay Time in Speed Control		the delay time for switching from gain 2 ain 1.	0	0.1 ms	0 to 10,000	_
122	Gain Switching Level in Speed Control	Set	the gain switching level.	0	_	0 to 20,000	-
123	Gain Switching Hysteresis in Speed Control	Set	the hysteresis for gain switching.	0	_	0 to 20,000	_

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
		toro	ect the gain switching condition for jue control. necessary that Pn114 be set to 1.			0 to 3	
101	Switching Mode	0	Always gain 1				
124	in Torque Control	1	Always gain 2	10	_		-
		2	Switching using gain switching input (GSEL)				
		3	Torque command change amount				
125	Gain Switching Delay Time in Torque Control		the delay time for switching from gain 2 ain 1.	0	0.1 ms	0 to 10,000	-
126	Gain Switching Level in Torque Control	Set	the gain switching level.	0	_	0 to 20,000	_
127	Gain Switching Hysteresis in Torque Control	Set	the hysteresis for gain switching.	0	_	0 to 20,000	_

- •Note 1: The default setting is 320 for 200-V Servo Drives of 1 kW or higher, and 400-V Servo Drives.
- •Note 2: The default setting is 180 for 200-V Servo Drives of 1 kW or higher, and 400-V Servo Drives.
- •Note 3: The default setting is 310 for 200-V Servo Drives of 1 kW or higher, and 400-V Servo Drives.
- •Note 4: The default setting is 126 for 200-V Servo Drives of 1 kW or higher, and 400-V Servo Drives.
- •Note 5: The default setting is 380 for 200-V Servo Drives of 1 kW or higher, and 400-V Servo Drives.
- •Note 6: The default setting is 180 for 200-V Servo Drives of 1 kW or higher, and 400-V Servo Drives.
- •Note 7: The default setting is 126 for 200-V Servo Drives of 1 kW or higher, and 400-V Servo Drives.

Vibration Suppression Function Parameters

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
		Set	the operation of the adaptive filter.				
		0	Disabled				
		1	One enabled. Frequency limited after adaptation.	0		0 to 4	
200	Adaptive Filter Selection	2	Two enabled. Frequency limited after adaptation.		_		_
		3	One enabled. Adaptation performed at all times.	-			
		4	Two enabled. Adaptation performed with 1 filter at all times.				
201	Notch 1 Frequency Setting		the notch frequency of resonance pression notch filter 1.	5000	Hz	50 to 5,000	_
202	Notch 1 Width Setting		the notch width of the resonance pression notch filter 1.	2	_	0 to 20	_
203	Notch 1 Depth Setting		the notch depth of resonance pression notch filter 1.	0	_	0 to 99	-
204	Notch 2 Frequency Setting		the notch frequency of resonance pression notch filter 2.	5000	Hz	50 to 5,000	-
205	Notch 2 Width Setting		the notch width of the resonance pression notch filter 2.	2	_	0 to 20	-
206	Notch 2 Depth Setting		the notch depth of resonance pression notch filter 2.	0	_	0 to 99	-
207	Notch 3 Frequency Setting	sup This	the notch frequency of resonance pression notch filter 3. s is set automatically when an adaptive ch is enabled.	5000	Hz	50 to 5,000	-
208	Notch 3 Width Setting	sup This	the notch width of the resonance pression notch filter 3. s is set automatically when an adaptive ch is enabled.	2	_	0 to 20	-
209	Notch 3 Depth Setting	sup This	the notch depth of resonance pression notch filter 3. s is set automatically when an adaptive ch is enabled.	0	_	0 to 99	-
210	Notch 4 Frequency Setting	sup This	the notch frequency of resonance pression notch filter 4. s is set automatically when an adaptive ch is enabled.	5000	Hz	50 to 5,000	_
211	Notch 4 Width Setting	sup This	the notch width of the resonance pression notch filter 4. s is set automatically when an adaptive ch is enabled.	2	_	0 to 20	-

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
212	Notch 4 Depth Setting	suppre This is	e notch depth of resonance ession notch filter 4. s set automatically when an adaptive is enabled.	0	_	0 to 99	_
		Select	the damping filter switching method.				
		0 Er	nabled				
		1 Da W	/hen DF-SEL1 input open: amping filter 1 and 3 enabled /hen DF-SEL1 input shorted: amping filter 2 and 4 enabled				
213	Selection	2 2 2 2 3 2 2 3 3 3 3 3 3 3 3 3 3 3 3 3	Then DF-SEL1 open and DF-SEL2 open: amping filter 1 enabled hen DF-SEL1 shorted and DF-SEL2 open: amping filter 2 enabled Then DF-SEL1 open and DF-SEL2 norted: amping filter 3 enabled Then DF-SEL1 shorted and DF-SEL2 norted: amping filter 4 enabled	0	_	0 to 3	-
		3 Da Re	orward direction: amping filter 1 and 3 enabled everse direction: amping filter 2 and 4 enabled				
214	Damping Frequency 1		e damping frequency 1. The function is d if the set value is 10 (= 1 Hz) or greater.	0	0.1 Hz	0 to 2,000	-
215	Damping Filter 1 Setting	torque	adjust damping control function 1. If a saturation occurs, lower this setting; ease responsiveness, raise this g.	0	0.1 Hz	0 to 1,000	_
216	Damping Frequency 2		e damping frequency 2. The function is d if the set value is 10 (= 1 Hz) or greater.	0	0.1 Hz	0 to 2,000	-
217	Damping Filter 2 Setting	torque	adjust damping control function 2. If a saturation occurs, lower this setting; ease responsiveness, raise this g.	0	0.1 Hz	0 to 1,000	_
218	Damping Frequency 3		e damping frequency 3. The function is ed if the set value is 10 (= 1 Hz) or er.	0	0.1 Hz	0 to 2,000	_
219	Damping Filter 3 Setting	torque	adjust damping control function 3. If a saturation occurs, lower this setting; ease responsiveness, raise this g.	0	0.1 Hz	0 to 1,000	_
220	Damping Frequency 4		e damping frequency 4. The function is ed if the set value is 10 (= 1 Hz) or er.	0	0.1 Hz	0 to 2,000	_
221	Damping Filter 4 Setting	torque	adjust damping control function 4. If a saturation occurs, lower this setting; ease responsiveness, raise this g.	0	0.1 Hz	0 to 1,000	_

12-2 Parameter List

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
222	Position Command Filter Time Constant		the time constant of the first-order lag r for the position command.	0	0.1 ms	0 to 10,000	_
223	Smoothing Filter Time Constant		the time constant of the FIR filter for the tion command.	0	0.1 ms	0 to 10,000	_

Speed, Torque Control, and Fully-Closed Control Parameters

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
	Command Speed Selection	Sele	ct the speed command when using speed control.				
		0	Analog speed command				
		1	No. 1 Internally Set Speed to No. 4 Internally Set Speed (Pn304 to Pn307)	10			
300		2	No. 1 Internally Set Speed to No. 4 Internally Set Speed (Pn304 to Pn306), analog speed command		_	0 to 3	_
		3	No. 1 Internally Set Speed to No. 8 Internally Set Speed (Pn304 to Pn311)				
	Speed Command		ct the method for designating the direction for the d command	_	_	0 or 1	_
301	Direction	0	Specified with the sign	0			
	Selection	1	Specified with VSIGN				
302	Speed Command Scale		the input gain for the analog speed mand input.	500	(r/min)/ V	10 to 2,000	-
	Analog Speed	Set	the polarity for analog speed commands.				
303	Command Rotation	0	+Voltage: Forward direction -Voltage: Reverse direction	1	-	0 or 1	_
	Direction Switching	1	+Voltage: Reverse direction -Voltage: Forward direction				

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
304	No. 1 Internally Set Speed	Set valu	the No. 1 internal speed command ie.	0	r/min		_
305	No. 2 Internally Set Speed	Set valu	the No. 2 internal speed command ie.	0	r/min		_
306	No. 3 Internally Set Speed	Set valu	the No. 3 internal speed command ie.	0	r/min		-
307	No. 4 Internally Set Speed	Set valu	the No. 4 internal speed command ie.	0	r/min	-20,000	_
308	No. 5 Internally Set Speed	Set valu	the No. 5 internal speed command ie.	0	r/min	to 20,000	_
309	No. 6 Internally Set Speed	Set valu	the No. 6 internal speed command ie.	0	r/min		_
310	Set Speed	Set valu	the No. 7 internal speed command le.	0	r/min		_
311	No. 8 Internally Set Speed	Set valu	the No. 8 internal speed command le.	0	r/min		_
312	Soft Start Acceleration Time		et the acceleration processing acceleration 0 ms/ (1,000 r/ 1 min) 0				-
313	Soft Start Deceleration Time		the deceleration processing eleration time for speed commands.	0	ms/ (1,000 r/ min)	0 to 10,000	_
314	S-curve Acceleration/ Deceleration Time Setting	pro	the acceleration/deceleration cessing S-curve time for speed nmands.	0	ms	0 to 1,000	_
			ect the function of the zero speed ignation input (ZEROSPD).				
		0	Disabled				
		1	The speed command is 0.				
315	Zero Speed Designation Selection	2	If the speed command is 0 and the actual speed is less than the zero speed designation, the servo lock is applied.	0	_	0 to 3	_
		3	When the speed command is equal to or less than the Position Lock Level Setting (Pn316) minus 10 r/min, the servo lock is applied.				
316	Position Lock Level Setting	Set	the threshold for position lock moving.	30	r/min	10 to 20,000	-
		Sele	ct the torque command and speed limit value.				
	Torque	0	Torque command: Analog input 1 Speed limit: Pn321 set value				
317	Command/ Speed Limit Selection	1	Torque command: Analog input 2 Speed limit: Analog input 1	0	_	0 to 2	_
		2	Torque command: Analog input 1 Speed limit: Pn321 and Pn322 set values				

Appendix

OMNUC G5-SERIES AC SERVOMOTOR AND SERVO DRIVE USER'S MANUAL

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
	Torque		ect the method for selecting the direction the torque command.				
318	Command Direction	0	Specified with the sign	0	_	0 or 1	-
	Selection	1	Specified with VSIGN				
319	Torque Command Scale		the input gain for analog torque nmand input.	30	0.1 V/ 100%	10 to 100	_
	Analog Torque	Set	the analog torque command input polarity.				
320	Command Rotation Direction	0	Forward operation	0	-	0 or 1	-
	Switching	1	Reverse operation				
321	Speed Limit Value Setting	Set	the speed limit value.	0	r/min	0 to 20,000	-
322	Reverse Direction Speed Limit Value Setting		tch the speed limit value according to the ction.	0	r/min	0 to 20,000	_
	Type Selection	Sel	ect the external feedback pulse type.				
		0	90° phase difference output type	•	_	0 to 2	
323		1	Incremental encoder with serial communications	0			Yes
		2	Reserved (Do not use this setting.)				
324	External Feedback Pulse Dividing Numerator		et the external feedback pulse dividing umerator.		_	0 to 2 ²⁰	Yes
325	External Feedback Pulse Dividing Denominator		the external feedback pulse dividing ominator.	10000	_	1 to 2 ²⁰	Yes
	External Feedback Pulse		verse the external feedback pulse count ction by changing the setting.				
326	Direction	0	Count direction not reversed	0	-	0 or 1	Yes
	Switching	1	Count direction reversed				
327	External Feedback Pulse	unc fee	disconnection detection in the phase-Z onnected state when the external dback pulse of a 90° phase difference but type is used.	0	_	0 or 1	Yes
	Phase-Z Setting	0	Enabled				
		1	Disabled				
328	Internal/External Feedback Pulse Error Counter Overflow Level		the threshold for feedback pulse iation errors.	16000	Command units	1 to 2 ²⁷	Yes
329	Internal/External Feedback Pulse Error Counter Reset		ar to 0 the feedback pulse error value for h set rotation speed.	0	Rotations	0 to 100	Yes

Interface Monitor Setting Parameters

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
400	Input Signal Selection 1	Set	the input signal 1 function and logic.	855309 0	-	0 to 00FFFFFFh	Yes
401	Input Signal Selection 2	Set	the input signal 2 function and logic.	848729 7	_	0 to 00FFFFFFh	Yes
402	Input Signal Selection 3	Set	the input signal 3 function and logic.	953985 0	_	0 to 00FFFFFFh	Yes
403	Input Signal Selection 4	Set	the input signal 4 function and logic.	394758	_	0 to 00FFFFFFh	Yes
404	Input Signal Selection 5	Set	the input signal 5 function and logic.	4108	_	0 to 00FFFFFFh	Yes
405	Input Signal Selection 6	Set	the input signal 6 function and logic.	197379	_	0 to 00FFFFFFh	Yes
406	Input Signal Selection 7	Set	the input signal 7 function and logic.	3847	_	0 to 00FFFFFFh	Yes
407	Input Signal Selection 8	Set	the input signal 8 function and logic.	263172	_	0 to 00FFFFFFh	Yes
408	Input Signal Selection 9	Set	the input signal 9 function and logic.	328965	_	0 to 00FFFFFFh	Yes
409	Input Signal Selection 10	Set	the input signal 10 function and logic.	3720	_	0 to 00FFFFFFh	Yes
410	Output Signal Selection 1	Set	the output signal 1 function allocation.	197379	_	0 to 00FFFFFFh	Yes
411	Output Signal Selection 2	Set	the output signal 2 function allocation.	131586	_	0 to 00FFFFFFh	Yes
412	Not used	Do	not change the set value.	-	-	-	-
413	Output Signal Selection 4	Set	the output signal 4 function allocation.	328964	_	0 to 00FFFFFFh	Yes

Appendix

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
		Sel	ect the type for analog monitor 1.				
		0	Motor speed				
		1	Position command speed				
		2	Internal position command speed				
		3	Speed Control Command				
		4	Torque command				
		5	Position command error				
		6	Encoder Position Error				
		7	Fully-closed Error				
		8	Hybrid Error	-			
		9	P-N voltage				
416	Analog Monitor 1 Selection	10	Regeneration load ratio	0	_	0 to 21	_
	T Delection	11	Overload load ratio				
		12	Forward direction torque limit				
		13	Reverse direction torque limit				
		14	Speed limit value				
		15	Inertia Ratio				
		16	Analog input 1				
		17	Analog input 2				
		18	Analog input 3				
		19	Encoder temperature				
		20	Drive temperature				
		21	Encoder 1-rotation data				
417	Analog Monitor 1 Scale Setting	Set	the output gain for analog monitor 1.	0	_	0 to 214,748,364	_
418	Analog Monitor 2 Selection	The	ect the type for analog monitor 2. e set values for this parameter are the ne as Analog Monitor 1 Type (Pn416).	4	_	0 to 21	_
419	Analog Monitor 2 Scale Setting	Sel	ect the output gain for analog monitor 2.	0	-	0 to 214,748,364	-
		Sele	ect the analog monitor output voltage method.				
	Analog Monitor	0	Output range: -10 to 10 V Data output: Positive, negative				
421	Output Setting	1	Output range: 0 to 10 V Data output: Positive, negative	0	_	0 to 2	_
		2	Output range: 0 to 10 V Data output: Positive, negative				
422	Analog Input 1 Offset	Set	the analog input 1 offset.	0	0.359 mV	-5,578 to 5,578	_
423	Analog Input 1 Filter Time Constant	Set	the analog input 1 filter.	0	0.01 ms	0 to 6,400	_

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
424	Excessive Analog Input 1		the voltage after offset for the excess of analog input 1 input voltage.	0	0.1 V	0 to 100	_
425	Analog Input 2 Offset	Set	the analog input 2 offset.	0	5.86 mV	-342 to 342	-
426	Analog Input 2 Filter Time Constant	Set	the analog input 2 filter.	0	0.01 ms	0 to 6,400	_
427	Excessive Analog Input 2		the voltage after offset for the excess of analog input 2 input voltage.	0	0.1 V	0 to 100	-
428	Analog Input 3 Offset	Set	the analog input 3 offset.	0	5.86 mV	-342 to 342	_
429	Analog Input 3 Filter Time Constant	Set	the analog input 3 filter.	0	0.01 ms	0 to 6,400	_
430	Excessive Analog Input 3		the voltage after offset for the excess of analog input 3 input voltage.	0	0.1 V	0 to 100	_
431	Positioning Completion Range 1		the allowed number of pulses for the itioning completion range.	10	Command units	0 to 262,144	_
		Set the judgment conditions for positioning completion output.0Positioning completion output turns ON when the position error is within the Positioning Completion Range 1 (Pn431).					
	Positioning Completion Condition Selection	1	Positioning completion output turns ON when the position error is within the Positioning Completion Range 1 (Pn431) and there is no position command.	-		0 to 3	
432		2	Positioning completion output turns ON when the zero speed detection signal is ON, the position error is within the Positioning Completion Range 1 (Pn431), and there is no position command.		_		_
		3	Positioning completion output turns ON when the position error is within the Positioning Completion Range 1 (Pn431) and there is no position command. The ON status will then be held until the next position command is received.				
433	Positioning Completion Hold Time	Set	the positioning completion hold time.	0	1 ms	0 to 30,000	-
434	Zero Speed Detection	Set (ZS	the detection threshold for zero speed P).	50	r/min	10 to 20,000	-
435	Speed Conformity Detection Range	outp	the detection threshold for speed conformity but (VCMP) with the difference between the ed command and the actual speed.	50	r/min	10 to 20,000	_
436	Rotation Speed for Motor Rotation Detection		the detection threshold for the motor tion speed detection output (TGON).	1000	r/min	10 to 20,000	_
437	Brake Timing when Stopped		the operation time for the mechanical ke at stop.	0	1 ms	0 to 10,000	_
438	Brake Timing During Operation		the operation time for the mechanical we during operation.	0	1 ms	0 to 10,000	_
439	Brake Release Speed Setting		the speed threshold for mechanical ke output judgment during operation.	30	r/min	30 to 3,000	-

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
			ect the warning type to be output by rning Output 1.				
		0	An OR output of all alarm status				
		1	Overload warning				
		2	Excessive regeneration warning				
		3	Battery warning			0 to 10	
440	Warning Output Selection 1	4	Fan warning	0			
440		5	Encoder communications warning	0	_		_
		6	Encoder overheating warning				
		7	Vibration detection warning				
		8	Service life detection warning				
		9	External encoder error warning				
		10	External encoder communications error warning				
441	Warning Output Selection 2	Wa The	elect the warning type to be output by arning Output 2. e relationships among the set values for this parameter e the same as for Warning Output Selection 1 (Pn440).		-	0 to 10	_
442	Positioning Completion Range 2		the allowable number of pulses for the ond positioning completion range.	10	Command units	0 to 262,144	_

Expansion Parameters

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
500	Electronic Gear Ratio Numerator 2	lf Pi	the electronic gear ratio. n500, Pn501, Pn502 = 0, the encoder olution is set as the numerator.	0	-	0 to 2 ³⁰	-
501	Electronic Gear Ratio Numerator 3	reso	Electronic Gear Ratio Numerator 2 (Pn500) or	0	-	0 to 2 ³⁰	_
502	Electronic Gear Ratio Numerator 4		lectronic Gear Ratio Numerator 3 (Pn501) or lectronic Gear Ratio Numerator 4 (Pn502) lectronic Gear Ratio Denominator (Pn010)	0	_	0 to 2 ³⁰	_
503	Encoder Dividing Denominator		he denominator when the number of pulses per or rotation in pulse regeneration is not an integer.	0	-	0 to 262,144	Yes
504	Drive Prohibition		the operation to be performed upon forward/ erse direction drive prohibition input. Forward or reverse direction drive prohibition input enabled	1		0 to 2	Yes
504	Input Selection	1	Forward or reverse direction drive prohibition input disabled	- 1	-	0102	165
		2	Forward or reverse direction drive prohibition input enabled				

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
		Mak	te the setting upon drive prohibition input.				
	Stop Selection for Drive	0	The torque in the drive prohibit direction is disabled, and the dynamic brake is activated.				
505	Prohibition Input	1	The torque in the drive prohibit direction is disabled, and free-run deceleration is performed.	0	_	0 to 2	Yes
		2	The torque in the drive prohibit direction is disabled, and an emergency stop is performed.				
		Set t	he stop operation when the servo is turned OFF.				
		0	During deceleration: Dynamic brake After stopping: Dynamic brake Error counter: Clear				
		1	During deceleration: Free-run After stopping: Dynamic brake Error counter: Clear				
	Stop Selection with Servo OFF	2	During deceleration: Dynamic brake After stopping: Servo free Error counter: Clear	•			
		3	During deceleration: Free-run After stopping: Servo free Error counter: Clear				
506		4	During deceleration: Dynamic brake After stopping: Dynamic brake Error counter: Hold	0	_	0 to 9	_
		5	During deceleration: Free-run After stopping: Dynamic brake Error counter: Hold	-			
		6	During deceleration: Dynamic brake After stopping: Servo free Error counter: Hold				
		7	During deceleration: Free-run After stopping: Servo free Error counter: Hold				
		8	During deceleration: Emergency stop After stopping: Dynamic brake Error counter: Clear				
		9	During deceleration: Emergency stop After stopping: Servo free Error counter: Clear				
507	Stop Selection with Main Power Supply OFF	sup The	the stop operation when the main power ply is turned OFF. set values for this parameter are the same Stop Selection with Servo OFF (Pn506).	0	_	0 to 9	_
508	Undervoltage Alarm Selection		ect whether to trip the LV or turn OFF the /o if there is a main power supply alarm.	1	_	0 or 1	_
509	Momentary Hold Time	Set	the main power supply alarm detection time.	70	1 ms	70 to 2,000	Yes

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
		Set	the alarm sequence.				
		0	During deceleration: Dynamic brake After stopping: Dynamic brake				
		1	During deceleration: Free-run After stopping: Dynamic brake				
		2	During deceleration: Dynamic brake After stopping: Servo free	0			
		3	During deceleration: Free-run After stopping: Servo free				
510	Stop Selection for Alarm Detection	4	During Emergency stop alarm deceleration: Emergency stop During deceleration: Dynamic brake After stopping: Dynamic brake		_	0 to 7	_
		5	During Emergency stop alarm deceleration: Emergency stop During deceleration: Free-run After stopping: Dynamic brake				
		6	During Emergency stop alarm deceleration: Emergency stop During deceleration: Dynamic brake After stopping: Servo free				
		7	During Emergency stop alarm deceleration: Emergency stop During deceleration: Free-run After stopping: Servo free				
511	Immediate Stop Torque	Set	the torque limit for immediate stops.	0	%	0 to 500	_
512	Overload Detection Level Setting	Set	the overload detection level.	0	%	0 to 500*	_
513	Overspeed Detection Level Setting	Set	the overspeed error detection level.	0	r/min	0 to 20,000	_
514	Overrun Limit Setting		the motor over-travel distance for ition commands.	10	0.1 Rotations	0 to 1,000	_
		Sele	ect from one of 4 values for the IF read cycle.				
	Control Input	0	0.166 ms				
515	Signal Read	1	0.333 ms	0	-	0 to 3	Yes
	Setting	2	1 ms				
		3	1.666 ms				
	Alarm Reset	Set	the alarm clear input detection method.				
516	Condition	0	120 ms	0	-	0 or 1	Yes
	Setting	1	Follow the Control Input Signal Read Setting (Pn515).				
	•						

* For example, if you set 115 or higher, the resolution will be 115%.

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
			the clear condition for the error counter reset t signal.				
		0	Disabled				
	Error Counter	1	Clears the error counter with the level. (Shorted for 500 μ s or longer)				
517	Reset Condition Selection	2	Clears the error counter with the level. (Shorted for 1 ms or longer)	0	-	0 to 4	-
		3	Clears the error counter with the edge. (Change from open to shorted for 100 μ s or longer)				
		4	Clears the error counter with the edge. (Change from open to shorted 1 ms or longer)				
	Command Pulse		ble or disable the command pulse hibition input signals (INH).				
518	Prohibition	0	Enabled	1	-	0 or 1	-
	Input Setting	1	Disabled				
		Selec	t the signal read cycle for the command pulse prohibition input.				
	Command Pulse Prohibition Input Read Setting	0	0.166 ms		_	0 to 4	
F10		1	0.333 ms	0			Vee
519		2	1 ms				Yes
		3	1.666 ms				
		4	0.166 ms				
	Position Setting		ect the positioning completion range and or counter overflow level setting unit.	0		0 or 1	
520	Unit Selection	0	Command unit		_		Yes
		1	Encoder unit				
			the forward or reverse direction torque t selection method.				
		0	Use P-ATL and N-ATL as analog torque limit inputs.				
		1	Pn013 is the limit value for both forward and reverse directions.				
	Taurus Lineit	2	Forward operation: Set by Pn013, Reverse operation: Set by Pn522.	•			
521	Torque Limit Selection	3	When TL-SEL input is open: Use Pn013. When TL-SEL input is shorted: Use Pn522.	1	-	0 to 6	-
		4	Use P-ATL and N-ATL as analog torque limit inputs.				
		5	Use P-ATL and N-ATL as analog torque limit inputs.				
		6	When TL-SEL input is open: Forward direction, use Pn013; Reverse direction, use Pn522. When TL-SEL input is shorted: Forward direction, use Pn525; Reverse direction, use Pn526.				
522	No. 2 Torque Limit	Set	the No. 2 limit value for the motor output torque.	500	%	0 to 500	-
523	Torque Limit Switching Setting 1		the change rate (fluctuate) for when the ue limit is switched from No. 1 to No. 2.	0	ms/ 100%	0 to 4,000	-

12-2 Parameter List

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
524	Torque Limit Switching Setting 2		the change rate (fluctuate) for when the ue limit is switched from No. 2 to No. 1.	0	ms/ 100%	0 to 4,000	_
525	Forward External Torque Limit		the forward direction torque limit for TL-SEL t when Pn521 Torque Limit Selection is set to 6.	500	%	0 to 500	_
526	Reverse External Torque Limit		the reverse direction torque limit for TL-SEL t when Pn521 Torque Limit Selection is set to 6.	500	%	0 to 500	-
527	Analog Torque Limit Scale		the gain of conversion for analog torque t input.	30	0.1 V/ 100%	10 to 100	_
			ct the data to be displayed on the 7-segment LED Ily when the control power supply is turned ON.				
		0	Position command error		Command units		
		1	Motor speed		r/min		
		2	Position command speed		r/min		
		3	Speed Control Command		r/min	-	
		4	Torque command		%		
		5	Total encoder pulses		Pulses	-	
		6	Total command pulses		Pulses		
		8	Total External Encoder Feedback Pulses		Pulses		
		9	Control mode		_		
		10	I/O signal status		-		
		11	Analog input value		V		
		12	Alarm factor, history		-		
528	Default Display	13	Warning number	1	-	0 to 35	Yes
		14	Regeneration resistance load ratio		%		
		15	Overload load ratio		%		
		16	Inertia Ratio		%		
		17	Reason for no rotation		-		
		18	Display of the number of I/O signal changes		times		
		20	Absolute encoder data		-		
		21	Absolute external encoder position		-		
		22	Monitor for the number of encoder communications errors		times		
		23	Display of axis numbers for communication		-		
		24	Position error (encoder unit)		_		
		25	External encoder error (external encoder unit)		_		
		26	Hybrid error	Command units			
		27	P-N voltage		V	1	
		28	Soft version		_	1	

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
		29	Drive serial number		-		
		30	Motor serial number		_		
528	Default Display	31	Accumulative operation time	. 1	h	0 to 35	Yes
520	Delault Display	32	Automatic Motor Recognition Function		-	0 10 35	165
		33	Temperature Information		°C		
		35	Safety status monitor		-		
531	Axis Number	con	the axis number for USB munications. Normally, do not change set value.	1	_	0 to 127	Yes
532	Command Pulse Input Maximum Setting	Set	the maximum command pulse input.	4000	kpps	250 to 4,000	Yes
	Pulse	Set	the detection of pulse regeneration limit error.				
533	Regeneration Limit Output	0	Disabled	0	-	0 or 1	Yes
	Setting	1	Enabled				
	Front Key	Set the operation limit for the front panel.					
535	Protection	0	Operation not blocked	0	-	0 or 1	Yes
	Setting	1	Operation blocked				

Special Setting Parameters

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
600	Analog Torque Feed-forward Gain Setting	forw	the input gain for analog torque feed- vard. 9 will be disabled.	0	0.1 V/ 100%	0 to 100	_
602	Excessive Speed Error Setting	pos	Set the detection level between the internal position command speed and the actual speed (i.e., the speed error).		r/min	0 to 20000	_
604	Jog Speed		the command speed during JOG trial ration (speed control).	300	r/min	0 to 500	-
605	Gain 3 Effective Time		effective time of gain 3 of 3-step gain ching.	0	0.1 ms	0 to 10,000	_
606	Gain 3 Ratio Setting	Set	gain 3 as a multiple of gain 1.	100	%	50 to 1,000	_
607	Torque Command Value Offset	Set	offset torque to add to torque command.	0	%	-100 to 100	-
608	Forward Direction Torque Offset		Set the value to add to a torque command or forward direction operation.		%	-100 to 100	_
609	Reverse Direction Torque Offset		Set the value to add to a torque command for reverse direction operation.		%	-100 to 100	_
610	Function Expansion Setting		Set the function expansion. The setting contents vary depending on the function.		_	0 to 63	-
611	Electric Current Response Setting		Make fine adjustment to electric current response. The default setting is 100%.		%	50 to 100	-
613	Inertia Ratio 2	Set	Set the inertia ratio switching.		%	0 to 10,000	-
614	Alarm Detection Allowable Time Setting	an e	Set the allowable time until stopping when an emergency stop is actuated upon alarm detection.		ms	0 to 1,000	_
615	Overspeed Detection Level Setting at Immediate Stop	dete	During an emergency stop upon alarm detection, if the motor speed exceeds this set value, this is an overspeed 2 error.		r/min	0 to 20,000	-
	Absolute	Sele	ect the absolute encoder data transfer.				
616	Interface Function	0	Disabled	1	-	0 or 1	Yes
	Selection	1	Enabled				
		Select the EEPROM write specifications when a parameter is changed.					
617	Front Panel Parameter Write Selection	0	Writing not to be performed when a parameter is changed.	0	_	0 or 1	Yes
		1	Writing to be performed when a parameter is changed.				
618	Power Supply ON Initialization Time		initialization time after power supply ON ne standard 1.5 s plus some.	0	0.1 s	0 to 100	Yes
	1	I		I	I	1	L

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
619	Encoder Phase- Z Setting	pha This and (Pn mul ratic The pha Pha	ely adjust the ON width of encoder se-Z signal output. s is enabled when the phase-Z output phase-A output are not synchronized 011/Pn503 × Encoder resolution is not a tiple of 4) due to the encoder dividing o setting. set value of Pn619 and the ON width of se-Z output are related as follows: use-Z output width [s] = $30/(Pn619 \times or speed [r/min])$	0	Pulses	0 to 32,767	Yes
620	External Encoder Phase-Z Expansion Setting		Set the external encoder phase-Z output (μs	0 to 400	Yes
621	Serial Absolute External Encoder Phase- Z Setting		Set the phase-Z regeneration position when the serial absolute external encoder is used.		Pulses	0 to 2 ²⁸	Yes
622	90° Phase Difference Output Type External Encoder Phase- AB Regeneration Method Selection	outp outp 0	ect the regeneration method of pulse outs A and B when a 90° phase difference out type external encoder is used. Without signal regeneration With signal regeneration	0	_	0 or 1	Yes
623	Disturbance Torque Compensation Gain		Set the compensation gain for the disturbance torque.		%	-100 to 100	_
624	Disturbance Observer Filter Setting		Set the filter time constant for disturbance torque compensation.		0.01 ms	10 to 2,500	-
627	Warning Latch Hold Time Selection	0 1	ect the warning latch time. Latch time infinite Latch time of 1 to 10 s	5	S	0 to 10	Yes
628	Not used	Do	not change the setting.	_	_	-	-
	Realtime Autotuning Estimated Speed Selection		the load characteristics estimated speed on realtime autotuning is enabled. Finalize estimated results when load estimation becomes stable.				
631		1	Estimates every minute from the load characteristic changes.	0) –	0 to 3	_
		2	Estimates every second from the load characteristic changes.				
		3	Estimates the optimum speed from the load characteristic changes.				
632	Realtime Autotuning Customization Mode Setting		the Customization Mode detail for time autotuning.	0	_	-32,768 to 32,767	_

Pn number	Parameter name	Setting	Description	Default setting	Unit	Setting range	Power supply OFF to ON
633	Absolute Encoder Initial Pulse Regeneration Speed		the pulse regeneration speed when the al pulse is output.	1000	r/min	1,000 to 3,000	_
634	Hybrid Vibration Suppression Gain		the hybrid vibration suppression gain ng fully-closed control.	0	0.1/s	0 to 30,000	-
635	Hybrid Vibration Suppression Filter		the hybrid vibration suppression filter e constant during fully-closed control.	10	0.01 ms	0 to 6,400	-
637	Vibration Detection Threshold	If to	the vibration detection threshold. rque vibration that exceeds this setting is ected, the vibration detection warning will ur.	0	0.1%	0 to 1,000	_
638	Warning Mask Setting	the corr	a mask for warning detection. If you set corresponding bit to 1, the esponding warning detection will be ibled.	4	_	-32,768 to 32,767	Yes



Precautions for Correct Use

Parameters between Pn700 and Pn800 are not used. Do not change the settings.



Numerics

1,000-r/min Servomotors	2-10, 3-90
2,000-r/min Servomotors	2-8, 3-76
3,000-r/min Servomotors	2-6, 3-60

Α

Absolute encoder	3-96
Absolute encoder backup battery	
Absolute encoder battery cable	
Absolute Encoder Initial Pulse Regeneration	
Speed (Pn633)	8-66
Absolute encoder reset	
Absolute encoder setup	
Absolute Interface Function Selection (Pn616)	
Adaptive filter	
Adaptive Filter Selection (Pn200)	
Alarm clear	
Alarm clear attribute output (ALM-ATB)	3-50
Alarm Generation Allowable Time Setting	0.00
(Pn614)	8-61
Alarm list	
Alarm output (/ALM)	
Alarm Reset Condition Selection (Pn516)	
Alarm reset input (RESET)	
Allowable current	
Analog Input 1 Filter Time Constant (Pn423)	
Analog Input 1 Offset (Pn422)	
Analog Input 2 Filter Time Constant (Pn426)	
Analog Input 2 Offset (Pn425)	
Analog Input 2 Oliset (F1425) Analog Input 3 Filter Time Constant (Pn429)	
Analog Input 3 Offset (Pn428)	
Analog input automatic offset adjustment	
Analog Monitor 1 Scale Setting (Pn417)	
Analog Monitor 1 Selection (Pn416)	
Analog Monitor 1 Selection (F1410) Analog Monitor 2 Scale Setting (Pn419)	
Analog Monitor 2 Selection (Pn418)	
Analog monitor cable	
Analog monitor connector specifications (CN5)	
Analog Monitor Output Selection (Pn421)	0-40
Analog Speed Command Rotation Direction	0.07
Switching (Pn303) Analog Torque Command Rotation Direction	0-27
	0.04
Switching (Pn320)	0-34
Analog Torque Limit Scale (Pn527)	
Applicable standards	
Axis Number (Pn531)	0-00

В

Backup battery input (BAT)	
Brake cable connector	3-109
Brake cables (robot cables)	2-19
Brake cables (standard cables)	. 2-15, 2-17
Brake interlock	6-19
Brake interlock output (BKIR)	3-48
Brake Release Speed Setting (Pn439)	8-46
Brake Timing During Operation (Pn438)	8-45
Brake Timing when Stopped (Pn437)	8-45

С

Cable specifications	. 3-97
Changing the mode	
characteristics	3-2
Clamp core	. 4-45
Command Pulse Input Maximum Setting	
(Pn532)	. 8-59
Command Pulse Input Selection (Pn005)	8-3
Command Pulse Mode Selection (Pn007)	8-4
Command Pulse Prohibition Input Read Setting	
(Pn519)	. 8-55
Command Pulse Prohibition Input Setting	
(Pn518)	. 8-55
Command Pulse Rotation Direction Switching	
Selection (Pn006)	
Command Speed Selection (Pn300)	. 8-25
Communications connector specifications	
(CN3A)	. 3-55
Connection examples	. 12-1
Connector specifications	. 3-97
Connectors	
Connector-terminal block	
Connector-terminal block cables 2-23,	
Connector-terminal Block Conversion Unit	3-124
Contactor	. 4-49
Control cable specifications	. 3-97
Control cables	
Control circuit connector specifications (CND)	
Control I/O connector	
Control I/O connector specifications	
Control input circuits	
Control input signal	
Control Input Signal Read Setting (Pn515)	
Control Mode Selection (Pn001)	
Control Mode Switching (TVSEL)	
Control output circuits	
Control output sequence	. 3-46

D

	_
Damping control 6-	1
Damping Filter 3 Setting (Pn219) 8-23	3
Damping Filter 4 Setting (Pn221) 8-23	3
Damping Filter Selection (Pn213) 8-2	1
Damping filter switching 1 (DFSEL1) 3-3	9
Damping filter switching 2 (DFSEL2) 3-39	9
Damping Frequency 1 (Pn214) 8-22	2
Damping Frequency 2 (Pn216) 8-22	2
Damping Frequency 3 (Pn218) 8-23	3
Damping Frequency 4 (Pn220) 8-23	3
Default Display (Pn528) 8-5	7
Disturbance Observer Filter Setting (Pn624) 8-6	3
Disturbance Torque Compensation Gain	
(Pn623)	3
Drive Prohibition Input Selection (Pn504)	8
Drive Regeneration absorption capacity 4-5	6

Ε

EC directive 1-15
Electric Current Response Setting (Pn611)
Electronic gear function
Electronic Gear Integer Setting (Pn008) 8-5
Electronic Gear Ratio Denominator (Pn010)
Electronic Gear Ratio Numerator 1 (Pn009)
Electronic Gear Ratio Numerator 2 (Pn500) 8-47
Electronic Gear Ratio Numerator 3 (Pn501) 8-47
Electronic Gear Ratio Numerator 4 (Pn502) 8-47
Electronic gear switching 1 (GESEL1)
Electronic gear switching 2 (GESEL2)
Emergency stop input (STOP) 3-44
Encoder cable
Encoder cables (robot cables) 2-18, 3-97
Encoder Cables (Standard Cables) 2-13, 2-15
Encoder connector specifications (CN2) 3-51
Encoder connectors
Encoder Dividing Denominator (Pn503) 8-47
Encoder Dividing Numerator (Pn011) 8-6
Encoder Output Direction Switching Selection
(Pn012) 8-6
Encoder outputs (Phases A, B and Z) 3-47
Encoder specifications 3-96
Error Counter Overflow Level (Pn014) 8-7
Error Counter Reset Condition Selection
(Pn517)
Error counter reset input (ECRST) 3-38
Error diagnosis using the alarm displays 11-10
Error diagnosis using the operation status 11-23
Excessive Analog Input 1 (Pn424)
Excessive Analog Input 2 (Pn427)
Excessive Analog Input 3 (Pn430) 8-42
External dimensions
External encoder connector specifications
(CN4)
External Feedback Pulse Direction Switching
(Pn326)
0
(Pn325)
External Feedback Pulse Dividing Numerator
(Pn324)
(Pn327)
External Feedback Pulse Type Selection
(Pn323)
External Regeneration Resistor
External Regeneration Resistor
connector specifications (CNC)
External Regeneration Resistor dimensions 2-70
External Regeneration Resistor Setting (Pn017) 8-8
External Regeneration Resistor specifications 3-146

F

Forward Direction Torque Offset (Pn608) 8-	60
Forward drive prohibition input (POT) 3-	37
Forward External Torque Limit (Pn525) 8-	57
Forward torque limit input (PCL) 3-	37
Front Panel Parameter Write Selection (Pn617) 8-	62
Fully-closed Control Mode adjustment 10-	11
Function Expansion Setting (Pn610) 8-	60

Index

Gain 3 Effective Time (Pn605) Gain 3 Ratio Setting (Pn606)	8-60 8-60
Gain adjustment	10-1
Gain switching (GSEL)	3-39
Gain Switching 3 Function	6-46
Gain Switching Delay Time in Position Control	0 1 4
(Pn116)	8-14
Gain Switching Delay Time in Speed Control (Pn121)	8-17
Gain Switching Delay Time in Torque Control	
(Pn125)	8-19
Gain switching function	6-24
Gain Switching Hysteresis in Position Control (Pn118)	8-15
Gain Switching Hysteresis in Speed Control	8-18
(Pn123) Gain Switching Hysteresis in Torque Control	0-10
(Pn127)	8-19
Gain Switching Input Operating Mode Selection	0 10
(Pn114)	8-12
Gain Switching Level in Position Control (Pn117)	8-15
Gain Switching Level in Speed Control (Pn122)	8-17
Gain Switching Level in Torque Control	
(Pn126)	
General control cable 2-23, 3	
general specifications	
General-purpose input	3-31

Η

Harmonic current measures	4-52
Hybrid vibration suppression filter	8-66
Hybrid vibration suppression gain	8-66

I

Improving Control I/O Signal Noise Resistance Improving encoder cable noise resistance Incremental encoder	4-51 4-50 3-96 8-3
Inertia Ratio (Pn004)	o-o 8-61
Inertia Ratio 2 (Pn613)	3-44
Inertia ratio switching input (JSEL)	
Input Signal Selection 1 (Pn400)	8-37
Input Signal Selection 10 (Pn409)	8-37
Input Signal Selection 2 (Pn401)	8-37
Input Signal Selection 3 (Pn402)	8-37
Input Signal Selection 4 (Pn403)	8-37
Input Signal Selection 5 (Pn404)	8-37
Input Signal Selection 6 (Pn405)	8-37
Input Signal Selection 7 (Pn406)	8-37
Input Signal Selection 8 (Pn407)	8-37
Input Signal Selection 9 (Pn408)	8-37
Internal/External Feedback Pulse Error	
Counter Overflow Level (Pn328)	8-36
Internal/External Feedback Pulse Error Counter	0.00
Reset (Pn329)	8-36
Internally set speed control	5-19
Internally set speed selection 1, 2 and 3	o 40
(VSEL1, 2 and 3)	3-40

J

Jog operation	9-27
Jog Speed (Pn604)	8-60

Κ

Korean Radio Regulations (KC)	1-16
L	
Leakage Breaker	4-42

Μ

Main circuit connector specifications (CNA)

	2
Main circuit terminal block specifications 3-11, 3-1	5
Maintenance 11-2	
Manual tuning 10-1	0
Momentary Hold Time (Pn509) 8-5	0
Monitor Mode	-8
Motion Control Unit Cable 3-11	2
Motor characteristics	60
Motor connector specifications (CNB)	
	23
Motor connector specifications (CNC) 3-10, 3-1	4
Motor connector specifications (CND) 3-1	4
Motor general specifications 3-5	9
Motor power cable 3-10	0
Motor power cables (robot cables) 2-1	8
Motor power cables (standard cables) 2-14, 2-1	6
Mounting brackets (L-brackets for rack mounting)	
	24
Mounting dimensions 2-2	25

Ν

Notch 3 Width Setting (Ph208) 8-2 Notch 4 Depth Setting (Ph212) 8-21 Notch 4 Frequency Setting (Ph210) 8-21	No. 3 Internally Set Speed (Pn306)No. 4 Internally Set Speed (Pn307)No. 5 Internally Set Speed (Pn308)No. 6 Internally Set Speed (Pn309)No. 7 Internally Set Speed (Pn310)No. 8 Internally Set Speed (Pn311)No-fuse breaker (NFB)Noise filterNoise filters for brake power supplyNotch 1 Depth Setting (Pn203)Notch 1 Width Setting (Pn202)	. 4-40, . 4-37,	8-27 8-27 8-28 8-28 8-28 4-41 4-45 4-40 8-20 8-20 8-20
	Notch 2 Depth Setting (Pn206) Notch 2 Frequency Setting (Pn204)		8-20
Notch 4 Depth Setting (Pn212) 8-21	Notch 2 Depth Setting (Pn206) Notch 2 Frequency Setting (Pn204) Notch 2 Width Setting (Pn205) Notch 3 Depth Setting (Pn209)		8-20 8-20 8-21
	Notch 2 Depth Setting (Pn206) Notch 2 Frequency Setting (Pn204) Notch 2 Width Setting (Pn205) Notch 3 Depth Setting (Pn209) Notch 3 Frequency Setting (Pn207)		8-20 8-20 8-21 8-21
	Notch 2 Depth Setting (Pn206) Notch 2 Frequency Setting (Pn204) Notch 2 Width Setting (Pn205) Notch 3 Depth Setting (Pn209) Notch 3 Frequency Setting (Pn207) Notch 3 Width Setting (Pn208)		8-20 8-20 8-21 8-21 8-21

1	-	~	•	
	N	Л		

Notch 4 Width Setting (Pn211) 8-	21

0

Operation command (RUN)	,
Encoder (Pn015)	,
Operational procedure	
Output during speed limit (V-LIMIT) 3-50)
Output Signal Selection 1 (Pn410) 8-37	7
Output Signal Selection 2 (Pn411) 8-37	7
Output Signal Selection 3 (Pn412) 8-37	7
Output Signal Selection 4 (Pn413) 8-37	7
Overload Detection Level Setting (Pn512)	3
Overrun Limit Setting (Pn514) 8-53	3
Overspeed Detection Level Setting (Pn513) 8-53	3
Overspeed Detection Level Setting	
at Immediate Stop (Pn615) 8-62	2

Ρ

Parameter list	12-11
Parameter Setting Mode	
Parameter Write Mode	
Periodic maintenance	
Phase-Z output (open collector output)	3-45
Pin arrangement	
Position Command Filter Time Constant	-
(Pn222)	8-23
Position command pulse 3	-28. 3-29
Position command status output (P-CMD)	
Position control	
Position Control Mode adjustment	
Position Control Unit-Servo	
Relay Unit cable specifications	3-136
Position feedback output	
Position Gain Switching Time (Pn119)	
Position Lock Level Setting (Pn316)	8-31
Position Loop Gain (Pn100)	
Position Loop Gain 2 (Pn105)	
Position Setting Unit Selection (Pn520)	
Positioning Completion Condition Selection	
(Pn432)	8-43
Positioning Completion Hold Time (Pn433)	
Positioning completion output 1 (INP1)	3-48
Positioning completion output 2 (INP2)	3-48
Positioning Completion Range 1 (Pn431)	8-42
Positioning Completion Range 2 (Pn442)	8-46
Power cable connector	3-109
Power cables with brakes (robot cables)	3-103
Power cables without brakes (robot cables)	3-100
Power Supply ON Initialization Time (Pn618)	
Preparing for operation	9-2
Protective functions	
Pulse prohibition input (IPG)	3-40
Pulse Regeneration Output Limit Setting	
(Pn533)	8-59

R

Radio noise filter	4-45
Reactor	4-52
Reactor to reduce harmonic current	

Realtime autotuning Realtime Autotuning Customization Mode	10-3
Setting (Pn632)	8-64
Realtime Autotuning Estimated Speed	
Selection (Pn631)	8-64
Realtime Autotuning Machine Rigidity Setting	
(Pn003)	
Realtime Autotuning Mode Selection (Pn002)	. 8-2
Regeneration Resistor Selection (Pn016)	. 8-7
Regenerative energy absorption	4-53
Regenerative energy with an External	
Regeneration Resistor	
Replacement method 11-3, 1	1-29
Replacing the absolute encoder battery 1	1-29
Replacing the battery 1	1-29
Replacing the Servo Drive	11-3
Replacing the Servomotor	11-3
Reverse Direction Speed Limit Value Setting	
(Pn322)	8-34
Reverse Direction Torque Offset (Pn609)	8-60
Reverse drive prohibition input (NOT)	3-37
Reverse External Torque Limit (Pn526)	8-57
Reverse torque limit input (NCL)	3-37
Rotation Direction Switching (Pn000)	. 8-1
Rotation speed characteristics	
(1,000-r/min Servomotors)	3-94
Rotation speed characteristics	
(2,000-r/min Servomotors)	3-88
Rotation speed characteristics	
(3,000-r/min Servomotors)	3-72
Rotation Speed for Motor Rotation Detection	
(Pn436)	8-44

S

Safety connector specifications (CN8)	. 3-55
S-curve Acceleration/Deceleration Time	
Setting (Pn314)	. 8-29
Sensor input	
Sensor ON input (SEN)	. 3-36
Sequence output	. 3-45
Servo Drive and Servomotor combination list	. 2-11
Servo Drive functions	1-4
Servo Drive installation conditions	4-1
Servo Drive limit	11-28
Servo Drive models	2-5
Servo Drive part names	
Servo ready completed output (READY)	. 3-48
Servo Relay Unit 2-21,	3-127
Servo Relay Unit cables for Servo Drives	. 2-21
Servo Relay Unit cables for	
Position Control Units	. 2-22
Servomotor installation conditions 4-	3, 4-6
Servomotor limit	
Servomotor models	2-6
Setting the mode	9-7
Smoothing Filter Time Constant (Pn223)	8-24
Soft Start Acceleration Time (Pn312)	8-28
Soft Start Deceleration Time (Pn313)	. 8-29
Speed Command Direction Selection (Pn301)	
Speed command input (REF) 3-28	
Speed Command Scale (Pn302)	8-27
Speed command sign input (VSIGN)	
Speed command status output (V-CMD)	
· · · ·	

Speed Conformity Detection Width (Pn435)	8-44
Speed conformity output (TGON)	3-49
Speed conformity output signal (VCMP)	3-49
Speed control	5-7
Speed Control Mode Adjustment	0-12
Speed Feedback Filter Time Constant (Pn103)	8-11
Speed Feedback Filter Time Constant 2	
(Pn108)	
Speed Feed-forward Command Filter (Pn111)	
Speed Feed-forward Gain (Pn110)	
Speed limit input (VLIM) 3-28,	
Speed limit value	
Speed Limit Value Setting (Pn321)	8-34
Speed Loop Gain (Pn101)	8-10
Speed Loop Gain 2 (Pn106)	
Speed Loop Integral Time Constant (Pn102)	
Speed Loop Integral Time Constant 2 (Pn107)	8-11
Stop Selection for Alarm Generation (Pn510)	8-51
Stop Selection for Drive Prohibition Input	
(Pn505)	8-48
Stop Selection with Main Power Supply OFF	
(Pn507)	8-50
Stop Selection with Servo OFF (Pn506)	8-49
Surge absorber	4-44
Surge suppressor	4-49
Switching control	5-23
Switching Mode in Position Control (Pn115)	8-13
Switching Mode in Speed Control (Pn120)	8-16
Switching Mode in Torque Control (Pn124)	8-18
System block diagrams	
System configuration	1-2

Т

Terminal block specifications	
	4-23
Terminal Block Wire Sizes	4-27
Terminal block wiring	4-32
Torque Command Direction Selection (Pn318)	8-32
Torque Command Filter Time Constant	
(Pn104)	8-11
Torque Command Filter Time Constant 2	
(Pn109)	8-11
Torque command input (TREF1)	3-36
Torque command input 1 (TREF1)	3-28
Torque command input 2 (TREF2)	3-37
Torque Command Scale (Pn319)	8-34
Torque command sign input (TSIGN)	3-43
Torque Command Value Offset (Pn607)	8-60
Torque Command/Speed Limit Selection	
(Pn317)	8-31
Torque control	5-14
Torque Control Mode adjustment 1	0-17
Torque Feed-forward Amount (Pn112)	8-12
Torque Feed-forward Command Filter (Pn113)	8-12
Torque limit	6-32
Torque Limit Selection (Pn521)	8-56
Torque limit switching (TLSEL)	3-43
Torque Limit Switching Setting 1 (Pn523)	8-57
Torque Limit Switching Setting 2 (Pn524)	8-57
Torque limiting signal (TLIMT)	3-49
Trial operation	9-33
Troubleshooting 11-1, 1	1-10

U

UL and cUL standards	1-15
Undervoltage Alarm Selection (Pn508)	8-50
USB connector specifications (CN7)	3-55

V

Vibration detection	threshold	8-66

W

Warning Latch Hold Time Selection (Pn627)	
Warning mask setting	
Warning output 1 (WARN1)	
Warning output 2 (WARN2)	3-49
Warning Output Selection 1 (Pn440)	
Warning Output Selection 2 (Pn441)	8-46
Wire sizes	4-31
Wiring conforming to EMC directives	4-33

Ζ

Zero speed designation (VZERO)	3-41
Zero Speed Designation Selection (Pn315)	
Zero Speed Detection (Pn434)	8-43
Zero speed detection signal (ZSP)	3-49

OMRON Corporation Industrial Automation Company

Kyoto, JAPAN

Regional Headquarters

OMRON EUROPE B.V. Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands Tel: (31) 2356-81-300 Fax: (31) 2356-81-388

OMRON ASIA PACIFIC PTE. LTD. 438B Alexandra Road, #08-01/02 Alexandra Technopark, Singapore 119968 Tel: (65) 6835-3011 Fax: (65) 6835-2711 OMRON ELECTRONICS LLC 2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900 Fax: (1) 847-843-7787

Contact : www.ia.omron.com

OMRON (CHINA) CO., LTD. Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2220 Fax: (86) 21-5037-2200 Authorized Distributor:

©OMRON Corporation 2009-2022 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

Cat. No. I571-E1-07 0922