

Machine Automation Controller

NX-series

System Units

User's Manual

NX-PD1□□□

NX-PF0□□□

NX-PC0□□□

NX-TBX01

Additional NX Unit Power Supply Units
Additional I/O Power Supply Units
I/O Power Supply Connection Units
Shield Connection Units



NOTE

- All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.
- No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice.
- Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

Trademarks

- Sysmac and SYSMAC are trademarks or registered trademarks of OMRON Corporation in Japan and other countries for OMRON factory automation products.
- Microsoft, Windows, Excel, Visual Basic, and Microsoft Edge are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.
- Safety over EtherCAT® is a registered trademark and a patented technology licensed by Beckhoff Automation GmbH, Germany.
- ODVA, CIP, CompoNet, DeviceNet, and EtherNet/IP are trademarks of ODVA.
- The SD and SDHC logos are trademarks of SD-3C, LLC. 

Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

Copyrights

- Microsoft product screen shots used with permission from Microsoft.

Introduction

Thank you for purchasing an NX-series System Unit.

This manual contains information that is necessary to use the NX-series System Unit. Please read this manual and make sure you understand the functionality and performance of the NX-series System Unit before you attempt to use it in a control system.

Keep this manual in a safe place where it will be available for reference during operation.

Intended Audience

This manual is intended for the following personnel, who must also have knowledge of electrical systems (an electrical engineer or the equivalent).

- Personnel in charge of introducing FA systems.
- Personnel in charge of designing FA systems.
- Personnel in charge of installing and maintaining FA systems.
- Personnel in charge of managing FA systems and facilities.

For programming, this manual is intended for personnel who understand the programming language specifications in international standard IEC 61131-3 or Japanese standard JIS B 3503.

Applicable Products

This manual covers the following product.

- NX-series System Unit
NX-PD□□□□/PF□□□□/PC□□□□
NX-TBX□□


Relevant Manuals

To use the System Unit, you must refer to the manuals for all related products.

Read all of the manuals that are relevant to your system configuration and application before you use the NX-series System Unit.

	(A) NX Units		System configuration						(D) Support Software		All Units
			(B) CPU Units			(C) Slave Terminals		Communication Control Units			
	NX-series System Units User's Manual	User's manuals for other NX Units	NX-series NX102 CPU Unit Hardware User's Manual	NX-series NX1P2 CPU Unit Hardware User's Manual	NJ/NX-series CPU Unit Software User's Manual	NX-series EtherCAT Coupler Unit User's Manual	NX-series EtherNet/IP Coupler Unit User's Manual	NX-series Safety Control Unit / Communication Control Unit User's Manual	Sysmac Studio Version 1 Operation Manual	NX-IO Configurator Operation Manual	NX-series Data Reference Manual
Learning about NX Units											
Specifications	☐	☐									
Functionality	☐	☐									
Application procedures	☐	☐									
Power supply system	☐		☐	☐		☐	☐	☐			
Wiring I/O power supply terminals and power supply terminals	☐	☐									
Wiring ground terminals	☐		☐	☐		☐	☐	☐			
Learning about CPU Racks of NX-series CPU Units											
Specifications			☐	☐	☐						
System configuration			☐	☐	☐						
Power supply system			☐	☐							
Application procedures			☐	☐	☐						
Installation procedures			☐	☐							
Support Software connection procedures					☐						
Performance calculations					☐						☐
Learning about Slave Terminals											
Specifications						☐	☐				
System configuration						☐	☐				
Power supply system						☐	☐				
Application procedures						☐	☐				
Installation procedures						☐	☐				
Support Software connection procedures						☐	☐				
Performance calculations						☐	☐				☐
Learning about CPU Racks of NX-series Communication Control Units											
Specifications								☐			
System configuration								☐			
Power supply system								☐			
Application procedures								☐			


		(A) NX Units	System configuration						(D) Support Software	All Units		
			(B) CPU Units			(C) Slave Terminals		Commu- nication Control Units				
		NX-series System Units User's Manual	User's manuals for other NX Units	NX-series NX102 CPU Unit Hardware User's Manual	NX-series NX1P2 CPU Unit Hardware User's Manual	NJ/NX-series CPU Unit Software User's Manual	NX-series EtherCAT Coupler Unit User's Manual	NX-series EtherNet/IP Coupler Unit User's Manual	NX-series Safety Control Unit / Communication Control Unit User's Manual	Sysmac Studio Version 1 Operation Manual	NX-IO Configurator Operation Manual	NX-series Data Reference Manual
	Installation procedures								○			
	Support Software connection procedures								○			
	Performance calculations								○			○
Making settings										○	○	
Troubleshooting												
	Troubleshooting CPU Racks or Slave Terminals			○	○	○	○	○	○	○	○	
	Troubleshooting NX Units	○	○									
Performing NX Unit maintenance		○	○									
Referencing data lists for NX Unit power consumptions, weights, etc.												○



Manual Structure

Page Structure

The following page structure is used in this manual.



This illustration is provided only as a sample. It may not literally appear in this manual.

Special Information

Special information in this manual is classified as follows:



Precautions for Safe Use

Precautions on what to do and what not to do to ensure safe usage of the product.



Precautions for Correct Use

Precautions on what to do and what not to do to ensure proper operation and performance.



Additional Information

Additional information to read as required.

This information is provided to increase understanding or make operation easier.




Version Information

Information on differences in specifications and functionality for Controller with different unit versions and for different versions of the Sysmac Studio is given.

Precaution on Terminology

- In this manual, "download" refers to transferring data from the Support Software to a physical device and "upload" refers to transferring data from a physical device to the Support Software.
- In this manual, the directions in relation to the Units are given in the following figure, which shows upright installation.



- This user's manual refers to "NY-series IPC Machine Controller Industrial Panel PCs and Industrial Box PCs" as simply "Industrial PCs" or as "NY-series Industrial PCs".

- This user's manual refers to the "built-in EtherCAT port on an NJ/NX-series Controller" or "built-in EtherCAT port on an NY-series Industrial PC" as simply a "built-in EtherCAT port".
- This user's manual may omit manual names and manual numbers in places that refer to the user's manuals for CPU Units and Industrial PCs. The following table gives some examples.

Examples:

Manual name	Omitted contents	Common text
NJ/NX-series CPU Unit Software User's Manual	Software user's manual for the connected CPU Unit or Industrial PC	Software User's Manual
NY-series IPC Machine Controller Industrial Panel PC / Industrial Box PC Software User's Manual		
NJ/NX-series CPU Unit Built-in EtherCAT® Port User's Manual	User's manual for the built-in EtherCAT port on the connected CPU Unit or Industrial PC	Built-in EtherCAT port
NY-series IPC Machine Controller Industrial Panel PC / Industrial Box PC Built-in EtherCAT® Port User's Manual		

- This user's manual may omit manual names and manual numbers in places that refer to the user's manuals for Communications Coupler Units.
- This user's manual may omit manual names and manual numbers in places that refer to the user's manuals for Communication Control Units.
- If the manual names and manual numbers for CPU Units are omitted, refer to *Related Manuals* on page 33 to determine the appropriate manual based on the common text for the omitted contents. If the manual names and manual numbers for Communications Coupler Units are omitted, refer to *Related Manuals* on page 33 to identify the manual for your Unit. If the manual names and manual numbers for Communication Control Units are omitted, refer to *Related Manuals* on page 33 to identify the manual for your Unit.

Sections in this Manual

1	Features and System Configuration	1
2	Specifications	2
3	Part Names and Functions	3
4	Installation and Wiring	4
5	Troubleshooting	5
6	Inspection and Maintenance	6
A	Appendices	A
I	Index	I

CONTENTS

Introduction	1
Intended Audience	1
Applicable Products	1
Relevant Manuals	2
Manual Structure	5
Page Structure	5
Special Information	6
Precaution on Terminology	6
Sections in this Manual	9
Terms and Conditions Agreement	13
Warranty, Limitations of Liability	13
Application Considerations	14
Disclaimers	14
Statement of security responsibilities for assumed use cases and against threats	15
Safety Precautions	16
Definition of Precautionary Information	16
Symbols	16
Warnings	17
Cautions	19
Precautions for Safe Use	20
Precautions for Correct Use	25
Regulations and Standards	27
Conformance to EU Directives	27
Conformance to UL and CSA Standards	28
Conformance to Shipbuilding Standards	28
Conformance to KC Certification	28
Software Licenses and Copyrights	29
Unit Versions	30
Unit Versions	30
Unit Versions and Support Software Versions	32
Related Manuals	33
Terminology	36
Revision History	38

Section 1 Features and System Configuration

1-1 Features and Types of System Units	1-2
1-1-1 System Unit Features	1-2
1-1-2 System Unit Types	1-3
1-2 System Configuration	1-4
1-2-1 System Configuration in the Case of a CPU Unit	1-4

1-2-2	System Configuration of Slave Terminals	1-5
1-2-3	System Configuration in the Case of a Communication Control Unit.....	1-7
1-3	Model List	1-10
1-3-1	Model Notation	1-10
1-3-2	Additional NX Unit Power Supply Unit	1-11
1-3-3	Additional I/O Power Supply Unit	1-11
1-3-4	I/O Power Supply Connection Unit.....	1-11
1-3-5	Shield Connection Unit.....	1-11
1-4	Support Software	1-13

Section 2 Specifications

2-1	General Specifications	2-2
2-2	Individual Specifications.....	2-3

Section 3 Part Names and Functions

3-1	Names of Power Supply-related Unit Parts	3-2
3-1-1	Screwless Clamping Terminal Block Type	3-2
3-1-2	Indicators.....	3-6
3-2	Names of Shield Connection Unit Parts	3-9
3-2-1	Screwless Clamping Terminal Block Type	3-9
3-2-2	Indicators.....	3-12

Section 4 Installation and Wiring

4-1	Installing NX Units	4-2
4-1-1	Installing NX Units	4-2
4-1-2	Attaching Markers	4-5
4-1-3	Removing NX Units.....	4-6
4-1-4	Installation Orientation	4-7
4-2	Wiring the Power Supply to the CPU Unit	4-9
4-2-1	Power Supply Types	4-9
4-2-2	Supplying Each Power Supply and Wiring.....	4-9
4-2-3	Power Supply-related Units and Wiring Methods.....	4-12
4-3	Wiring the Power Supply to the Slave Terminal.....	4-15
4-3-1	Power Supply Types	4-15
4-3-2	Supplying Each Power Supply and Wiring.....	4-15
4-3-3	Power Supply-related Units and Wiring Methods.....	4-17
4-4	Wiring the Power Supply to the Communication Control Unit.....	4-20
4-4-1	Power Supply Types	4-20
4-4-2	Supplying Each Power Supply and Wiring.....	4-20
4-4-3	Power Supply-related Units and Wiring Methods.....	4-22
4-5	Wiring of Grounding	4-25
4-6	Wiring the Additional Power Supply Units	4-27
4-6-1	Wiring the Additional NX Unit Power Supply Unit	4-28
4-6-2	Wiring the Additional I/O Power Supply Unit.....	4-32
4-6-3	Protective Devices	4-38
4-7	Wiring the I/O Power Supply Connection Unit	4-40
4-8	Wiring the Shield Connection Unit.....	4-44
4-9	Wiring the Terminals.....	4-45
4-9-1	Wiring to the Screwless Clamping Terminal Blocks	4-45
4-9-2	Preventing Incorrect Attachment of Terminal Blocks.....	4-55

Section 5 Troubleshooting

5-1	How to Check for Errors.....	5-2
5-2	Checking for Errors with the Indicators	5-3
5-3	Checking for Errors and Troubleshooting on the Support Software.....	5-5
5-3-1	Checking for Errors from the Sysmac Studio	5-5
5-3-2	Checking for Errors from Support Software Other Than the Sysmac Studio	5-6
5-3-3	Event Codes and Corrections for Errors	5-6
5-3-4	Meaning of Error	5-7
5-4	Resetting Errors.....	5-11
5-5	Troubles Specific to Each Type of NX Units.....	5-12
5-5-1	Additional NX Unit Power Supply Unit	5-12
5-5-2	Additional I/O Power Supply Unit	5-12
5-6	Troubleshooting Flowchart.....	5-13

Section 6 Inspection and Maintenance

6-1	Cleaning and Inspection	6-2
6-1-1	Cleaning	6-2
6-1-2	Periodic Inspections	6-2
6-2	Maintenance Procedures	6-5

Appendices

A-1	Data Sheet	A-2
A-1-1	Model List.....	A-2
A-1-2	Additional NX Unit Power Supply Unit	A-3
A-1-3	Additional I/O Power Supply Unit	A-7
A-1-4	I/O Power Supply Connection Unit.....	A-12
A-1-5	Shield Connection Unit.....	A-19
A-2	Dimensions.....	A-23
A-2-1	Additional NX Unit Power Supply Unit, Additional I/O Power Supply Unit, I/O Power Supply Connection Unit, and Shield Connection Unit	A-23
A-3	List of NX Objects	A-25
A-3-1	Format of NX Object Descriptions.....	A-25
A-3-2	System Units	A-25
A-4	List of Screwless Clamping Terminal Block Models	A-27
A-4-1	Model Notation	A-27
A-4-2	List of Terminal Block Models.....	A-27
A-5	Version Information with CPU Units	A-29
A-5-1	Relationship between Unit Versions of Units	A-29
A-6	Version Information with Communications Coupler Units	A-31
A-6-1	Connection to an EtherCAT Coupler Unit.....	A-31
A-6-2	Connection to an EtherNet/IP Coupler Unit	A-32
A-7	Version Information with Communication Control Units	A-34
A-7-1	Relationship between Unit Versions of Units	A-34

Index

Terms and Conditions Agreement

Warranty, Limitations of Liability

Warranties

● Exclusive Warranty

Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

● Limitations

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

● Buyer Remedy

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See <https://www.omron.com/global/> or contact your Omron representative for published information.

Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY

WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Application Considerations

Suitability of Use

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Disclaimers

Performance Data

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

Change in Specifications

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may

be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

Statement of security responsibilities for assumed use cases and against threats

OMRON SHALL NOT BE RESPONSIBLE AND/OR LIABLE FOR ANY LOSS, DAMAGE, OR EXPENSES DIRECTLY OR INDIRECTLY RESULTING FROM THE INFECTION OF OMRON PRODUCTS, ANY SOFTWARE INSTALLED THEREON OR ANY COMPUTER EQUIPMENT, COMPUTER PROGRAMS, NETWORKS, DATABASES OR OTHER PROPRIETARY MATERIAL CONNECTED THERETO BY DISTRIBUTED DENIAL OF SERVICE ATTACK, COMPUTER VIRUSES, OTHER TECHNOLOGICALLY HARMFUL MATERIAL AND/OR UNAUTHORIZED ACCESS.

It shall be the users sole responsibility to determine and use adequate measures and checkpoints to satisfy the users particular requirements for (i) antivirus protection, (ii) data input and output, (iii) maintaining a means for reconstruction of lost data, (iv) preventing Omron Products and/or software installed thereon from being infected with computer viruses and (v) protecting Omron Products from unauthorized access.

Safety Precautions

Definition of Precautionary Information

The following notation is used in this manual to provide precautions required to ensure safe usage of the NX-series System Units.

The safety precautions that are provided are extremely important to safety. Always read and heed the information provided in all safety precautions.

The following notation is used.

 WARNING	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury. Additionally, there may be severe property damage.
 Caution	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, or property damage.

Symbols

	The circle and slash symbol indicates operations that you must not do. The specific operation is shown in the circle and explained in text. This example indicates prohibiting disassembly.
	The triangle symbol indicates precautions (including warnings). The specific operation is shown in the triangle and explained in text. This example indicates a precaution for electric shock.
	The triangle symbol indicates precautions (including warnings). The specific operation is shown in the triangle and explained in text. This example indicates a general precaution.
	The filled circle symbol indicates operations that you must do. The specific operation is shown in the circle and explained in text. This example shows a general precaution for something that you must do.

Warnings

WARNING

During Power Supply

Do not touch the terminal section while power is ON.
Electric shock may occur.



Do not attempt to take any Unit apart.
In particular, high-voltage parts are present in Units that supply power while power is supplied or immediately after power is turned OFF. Touching any of these parts may result in electric shock. There are sharp parts inside the Unit that may cause injury.



Fail-safe Measures

Provide safety measures in external circuits to ensure safety in the system if an abnormality occurs due to malfunction of the CPU Unit, Industrial PC, other Units, or slaves or due to other external factors affecting operation.
Not doing so may result in serious accidents due to incorrect operation.



Emergency stop circuits, interlock circuits, limit circuits, and similar safety measures must be provided in external control circuits.



The CPU Unit or Industrial PC will turn OFF all outputs from Output Units in the following cases. The remote I/O slaves will operate according to the settings in the slaves.

- If a power supply error occurs.
- If the power supply connection becomes faulty.
- If a CPU watchdog timer error or CPU reset occurs.
- If a Controller error in the major fault level occurs.
- While the CPU Unit is on standby until RUN mode is entered after the power is turned ON



External safety measures must be provided to ensure safe operation of the system in such cases.

The outputs may remain ON or OFF due to deposition or burning of the output relays or destruction of the output transistors. As a countermeasure for such problems, external safety measures must be provided to ensure safe operation of the system.



If external power supplies for slaves or other devices are overloaded or short-circuited, the voltage will drop, outputs will turn OFF, and the system may be unable to read inputs. Provide external safety measures in control with monitoring of external power supply voltage as required so that the system operates safely in such a case.



You must take fail-safe measures to ensure safety in the event of incorrect, missing, or abnormal signals caused by broken signal lines, momentary power interruptions, or other causes.



Not doing so may result in serious accidents due to incorrect operation.

Voltage and Current Inputs

Make sure that the voltages and currents that are input to the Units and slaves are within the specified ranges.

Inputting voltages or currents that are outside of the specified ranges may cause accidents or fire.



Transferring

Always confirm safety at the destination node before you transfer Unit configuration information, parameters, settings, or other data from tools such as the Sysmac Studio. The devices or machines may operate unexpectedly, regardless of the operating mode of the Controller.



Cautions


Caution

Wiring

When you connect a computer or other peripheral device to a Communications Coupler Unit that has a non-isolated DC power supply, either ground the 0-V side of the external power supply (i.e. Unit power supply) or do not ground it at all.

If the peripheral devices are grounded incorrectly, the external power supply (i.e. Unit power supply) may be short-circuited.

Never ground the 24-V side of the power supply, as shown in the following figure.



Be sure that all terminal screws and cable connector screws are tightened to the torque specified in the relevant manuals. The loose screws may result in fire or malfunction.



Online Editing

Execute online editing only after confirming that no adverse effects will be caused by deviations in the timing of I/O. If you perform online editing, the task execution time may exceed the task period, I/O may not be refreshed with external devices, input signals may not be read, and output timing may change.



Precautions for Safe Use

Transporting


- When transporting any Unit, use the special packing box for it.
Also, do not subject the Unit to excessive vibration or shock during transportation.
- Do not drop any Unit or subject it to abnormal vibration or shock.
Doing so may result in Unit malfunction or burning.

Mounting

- Mount terminal blocks and connectors only after checking the mounting location carefully.
- Be sure that the terminal blocks, expansion cables, and other items with locking devices are properly locked into place.


Installation

- Always turn OFF the power supply before installing the Unit. If the power supply is not OFF, the Unit may malfunction or may be damaged.
- Always turn OFF the Unit power supply and I/O power supply before you remove the NX Unit.
- Do not apply labels or tape to the Unit. When the Unit is installed or removed, adhesive or scraps may adhere to the pins in the NX bus connector, which may result in malfunctions.
- Do not touch the pins in the NX bus connector on the Unit. Dirt may adhere to the pins in the NX bus connector, which may result in malfunctions.




Example: NX Unit (12 mm width)

- Do not write on an NX Unit with ink within the restricted region that is shown in the following figure. Also do not get this area dirty. When the Unit is installed or removed, ink or dirt may adhere to the pins in the NX bus connector, which may result in malfunctions in the CPU Rack or the Slave Terminal.
Refer to the user's manual for the connected CPU Unit, Communications Coupler Unit, or Communication Control Unit for details on the restricted region on the CPU Unit, Communications Coupler Unit, or Communication Control Unit.




- For the installation orientations in the following figure, support the cables, e.g., with a duct, so that the End Plate on the bottom is not subjected to the weight of the cables. The weight of the cables may cause the bottom End Plate to slide downward so that the Slave Terminal is no longer secured to the DIN Track, which may result in malfunctions.




Wiring

- Double-check all switches and other settings and double-check all wiring to make sure that they are correct before turning ON the power supply.
- Use the correct wiring parts and tools when you wire the system.
- Do not pull on the cables or bend the cables beyond their natural limit. Also, do not place heavy objects on top of the cables or other wiring lines. Doing so may break the cable.
- When wiring or installing the Units, do not allow metal fragments to enter the Units.
- Do not press the flat-blade screwdriver straight into the release holes on a screwless clamping terminal block. Doing so may damage the terminal block.

NG




OK




- When you insert a flat-blade screwdriver into a release hole on a screwless clamping terminal block, press it down with a force of 30N or less. Applying excessive force may damage the terminal block.
- Do not incline or twist the flat-blade screwdriver while it is in a release hole on a screwless clamping terminal block. Doing so may damage the terminal block.

NG



NG



- If you use reed switches for the input contacts for AC Input Units, use switches with an allowable current of 1 A or greater. If the capacity of the reed switches is too low, inrush current may fuse the contacts.
- Use crimp terminals for wiring the M3 screw terminal blocks. Do not connect bare stranded wires directly to the M3 screw terminal blocks.

Power Supply Design

- Use all Units within the I/O power supply ranges that are given in the specifications.
- The I/O power supply current for the CPU Rack with an NX-series CPU Unit should be within the range specified for the CPU Unit model. For example, use the NX1P2 CPU Unit with a current of 4 A or less. Using the currents that are outside of the specifications may cause failure or corruption. Refer to the user's manual for the connected CPU Unit for the I/O power supply current for the CPU Unit model.
- Supply sufficient power according to the contents of this manual.
- Use the power supply voltage that is specified in this manual.
- Do not apply voltages that exceed the rated value to any Input Unit.
- Do not apply voltages or connect loads to the Output Units or slaves in excess of the maximum ratings.
- Inrush current occurs when the power supply is turned ON. When selecting fuses or breakers for external circuits, consider their fusing and detection characteristics as well as the above precautions and allow sufficient margin in shut-off performance.
- Install external breakers and take other safety measures against short-circuiting and overcurrents in external wiring.

Turning ON the Power Supply

- When you set the Operating Mode at Startup, confirm that no adverse effect will occur in the system.

Actual Operation

- Before you start operation, always register the NX Units that are connected to the Communications Coupler Unit in the host communications master as the Unit Configuration Information.
- Check the user program, data, and parameter settings for proper execution before you use them for actual operation.
- If you change the fail-soft operation setting, the output status when the error occurs may also change. Confirm safety before you change the fail-soft operation setting.

- If you use fail-soft operation, write programming to determine whether Unit I/O data is valid. Without such programming, the user program cannot distinguish between Units for which I/O refreshing is continued and Units for which I/O refreshing is stopped.

Turning OFF the Power Supply

- Do not disconnect the cable or turn OFF the power supply to the Controller or a Slave Terminal when downloading data or the user program from the Support Software.
- Always turn OFF the external power supply to the Units before attempting any of the following.
 - a) Mounting or removing an NX Unit, Communications Coupler Unit, CPU Unit, Industrial PC, or Communication Control Unit
 - b) Assembling Units
 - c) Setting DIP switches or rotary switches
 - d) Connecting or wiring cables
 - e) Attaching or removing terminal blocks or connectors

Units that supply power continue to supply power to the Units for up to several seconds after the power supply is turned OFF. The PWR indicator remains lit as long as power is supplied. Confirm that the PWR indicator is not lit before you perform any of the above.

Operation

- Confirm that the controlled system will not be adversely affected before you perform any of the following operations.
 - a) Changing the operating mode of the CPU Unit or Industrial PC (including changing the setting of the Operating Mode at Startup)
 - b) Changing the user program or settings
 - c) Changing set values or present values
 - d) Forced refreshing
- Always sufficiently check the safety at the connected devices before you change the settings of a slave or Unit.

General Communications

- Do not exceed the ranges that are given in the specifications for the communications distance and number of connected Units.
- Refer to the user's manual for the Communications Coupler Unit for precautions for the safe use of communications with the connected Communications Coupler Unit.

Unit Replacement

- When you replace a Unit, start operation only after you transfer the settings and variables that are required for operation to the new Unit.

Disposal

- Dispose of the product according to local ordinances as they apply.

Precautions for Correct Use

Storage, Mounting, and Wiring

- Follow the instructions in this manual to correctly perform installation and wiring.
- Do not operate or store the Units in the following locations. Doing so may result in malfunction, in operation stopping, or in burning.
 - Locations subject to direct sunlight
 - Locations subject to temperatures or humidity outside the range specified in the specifications
 - Locations subject to condensation as the result of severe changes in temperature
 - Locations subject to corrosive or flammable gases
 - Locations subject to dust (especially iron dust) or salts
 - Locations subject to exposure to water, oil, or chemicals
 - Locations subject to shock or vibration
- Take appropriate and sufficient countermeasures during installation in the following locations.
 - Locations subject to strong, high-frequency noise
 - Locations subject to static electricity or other forms of noise
 - Locations subject to strong electromagnetic fields
 - Locations subject to possible exposure to radioactivity
 - Locations close to power lines
- Before touching a Unit, be sure to first touch a grounded metallic object in order to discharge any static build-up.
- Use the rated power supply voltage for the Units that supply power. Take appropriate measures to ensure that the specified power with the rated voltage and frequency is supplied in places where the power supply is unstable.
- Install the Units away from sources of heat and ensure proper ventilation. Not doing so may result in malfunction, in operation stopping, or in burning.
- Do not allow foreign matter to enter the openings in the Unit. Doing so may result in Unit burning, electric shock, or failure.

Actual Operation

- If you change the event level of an error, the output status when the error occurs may also change. Confirm safety before you change an event level.

Turning OFF the Power Supply

- Do not turn OFF the power supply while data is being transferred.
- Do not turn OFF the power supply while parameters are being written to the CPU Unit, Communications Coupler Unit, Communication Control Unit, or NX Units.

General Communications

- Refer to the user's manual for the Communications Coupler Unit for precautions for the correct use of communications with the connected Communications Coupler Unit.
- Refer to the user's manual for the Communication Control Unit for precautions for the correct use of communications with the connected Communication Control Unit.

Regulations and Standards

Conformance to EU Directives

Applicable Directives

- EMC Directives
- Low Voltage Directive

Concepts

● EMC Directives

OMRON devices that comply with EU Directives also conform to the related EMC standards so that they can be more easily built into other devices or the overall machine. The actual products have been checked for conformity to EMC standards.*1

Whether the products conform to the standards in the system used by the customer, however, must be checked by the customer. EMC-related performance of the OMRON devices that comply with EU Directives will vary depending on the configuration, wiring, and other conditions of the equipment or control panel on which the OMRON devices are installed. The customer must, therefore, perform the final check to confirm that devices and the overall machine conform to EMC standards.

*1. Applicable EMC (Electromagnetic Compatibility) standards are as follows: EMS (Electromagnetic Susceptibility): EN 61131-2, EMI (Electromagnetic Interference): EN 61131-2 (Radiated emission: 10-m regulations).

● Low Voltage Directive

Always ensure that devices operating at voltages of 50 to 1,000 VAC and 75 to 1,500 VDC meet the required safety standards. The applicable directive is EN 61010-2-201.

● Conformance to EU Directives

The NX-series Units comply with EU Directives. To ensure that the machine or device in which the NX-series Units are used complies with EU Directives, the following precautions must be observed.

- The NX-series Units must be installed within a control panel.
- You must use SELV power supply for the DC power supplies that are connected as the Unit power supplies and I/O power supplies for the NX-series Units.

EMC standard compliance was confirmed for the recommended Power Supplies. Refer to the user's manual for the connected CPU Unit for the recommended power supplies for the CPU Rack with an NX-series CPU Unit. Refer to the user's manual for the connected Communications Coupler Unit for the recommended power supplies for the Slave Terminal. Refer to the user's manual for the connected Communication Control Unit for the recommended power supplies for the CPU Rack with an NX-series Communication Control Unit.

- NX-series Units that comply with EU Directives also conform to the Common Emission Standard (EN 61131-2). Radiated emission characteristics (10-m regulations) may vary depending on the configuration of the control panel used, other devices connected to the control panel, wiring, and other conditions.

You must therefore confirm that the overall machine or equipment in which the NX-series Units are used complies with EU Directives.

- You must use power supplies with an output hold time of 10 ms or longer for the DC power supplies that are connected as the Unit power supplies and I/O power supplies for the NX-series Units.
- This is a Class A product (for industrial environments). In a residential environment, it may cause radio interference. If radio interference occurs, the user may be required to take appropriate measures.

Conformance to UL and CSA Standards

Some NX-series products comply with UL and CSA standards.

If you use an NX-series product that complies with UL or CSA standards and the machinery or system in which you use the NX-series product must also comply with the standards, refer to the *Instruction Sheet* that is provided with the product. The *Instruction Sheet* provides the application conditions for complying with the standards.

Conformance to Shipbuilding Standards

Some NX-series products comply with shipbuilding standards.

If you use an NX-series product that complies with shipbuilding standards and the machinery or system in which you use the NX-series product must also comply with the standards, consult with your OMRON representative. Application conditions are defined according to the installation location. Application may not be possible for some installation locations.

For shipbuilding standard usage conditions, refer to *Conformance to Shipbuilding Standards* in the user's manual for the CPU Unit, Communications Coupler Unit, or Communication Control Unit that the NX Units are connected to.

Note that the usage conditions are provided in the relevant user's manuals for Units whose conformance to shipbuilding standards is confirmed.

Conformance to KC Certification

Observe the following precaution if you use NX-series Units in Korea.

A급 기기 (업무용 방송통신기자재)
이 기기는 업무용(A급) 전자파적합기기로서 판매자
또는 사용자는 이 점을 주의하시기 바라며, 가정외의
지역에서 사용하는 것을 목적으로 합니다.

Class A Device (Broadcasting Communications Device for Office Use)

This device obtained EMC registration for office use (Class A), and it is intended to be used in places other than homes.

Sellers and/or users need to take note of this.

Software Licenses and Copyrights

This product incorporates certain third party software. The license and copyright information associated with this software is available at http://www.fa.omron.co.jp/nj_info_e/.

Unit Versions

This section describes the notation that is used for unit versions, the confirmation method for unit versions, and the relationship between unit versions and Support Software versions.


Unit Versions


A “unit version” has been introduced to manage the Units in the NX Series according to differences in functionality accompanying Unit upgrades.

An example is provided below for Communications Coupler Units and NX Units. Refer to the user’s manual for each Unit for details on the version notation and the method for checking version information of the CPU Units, Industrial PCs, and Communication Control Units.

Notation of Unit Versions on Products

The unit version is given with the Unit specifications on the side of the Unit or in the notched area.





The following information is provided in the Unit specifications on the Unit.

Name	Function
Unit model number	Gives the model of the Unit.
Unit version	Gives the unit version of the Unit.
Lot number	Gives the lot number of the Unit. DDMY□: Lot number, □: Used by OMRON. “M” gives the month (1 to 9: January to September, X: October, Y: November, Z: December)

The following information is provided in the notched area on the Unit.

Name	Function
Lot number and unit version	Gives the lot number and unit version of the Unit. - DDMY□: Lot number, □: Used by OMRON. “M” gives the month (1 to 9: January to September, X: October, Y: November, Z: December) 1□: Unit version The decimal portion of the unit version is omitted. (It is provided in the Unit specifications.)

Confirming Unit Versions with the Support Software

If your NX Unit is connected to a CPU Unit, refer to the user's manual of the connected CPU Unit for the confirmation method for the unit version of the NX Unit.

If your NX Unit is connected to a Communications Coupler Unit, refer to the user's manual of the connected Communications Coupler Unit for the confirmation method for the unit version of the Communications Coupler Unit and NX Unit.

If your NX Unit is connected to a Communication Control Unit, refer to the user's manual of the connected Communication Control Unit for the confirmation method for the unit version of the NX Unit.

Unit Versions and Support Software Versions

The functions that are supported depend on the unit version of the Unit. The version of Support Software that supports the functions that were added for an upgrade is required to use those functions. Depending on the Unit to which the NX Unit is connected, refer to the following appendices for the functions that are supported by each unit version.

- *A-5 Version Information with CPU Units* on page A-29
- *A-6 Version Information with Communications Coupler Units* on page A-31
- *A-7 Version Information with Communication Control Units* on page A-34

Related Manuals

The following table shows related manuals. Use these manuals for reference.

Manual name	Cat. No.	Model numbers	Application	Description
NX-series System Units User's Manual	W523	NX-PD1□□□ NX-PF0□□□ NX-PC0□□□ NX-TBX01	Learning how to use NX-series System Units.	The hardware and functions of the NX-series System Units are described.
NX-series Data Reference Manual	W525	NX-□□□□□□	Referencing lists of the data that is required to configure systems with NX-series Units.	Lists of the power consumptions, weights, and other NX Unit data that is required to configure systems with NX-series Units are provided.
Sysmac Studio Version 1 Operation Manual	W504	SYSMAC -SE2□□□	Learning about the operating procedures and functions of the Sysmac Studio.	Describes the operating procedures of the Sysmac Studio.
NX-IO Configurator Operation Manual	W585	CXONE- AL□□D-V4	Learning about the operating procedures and functions of the NX-IO Configurator.	Describes the operating procedures of the NX-IO Configurator.
NJ/NX-series Troubleshooting Manual	W503	NX701-□□□□ NX502-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Learning about the errors that may be detected in an NJ/NX-series Controller.	Concepts on managing errors that may be detected in an NJ/NX-series Controller and information on individual errors are described.
NY-series Troubleshooting Manual	W564	NY532-□□□□ NY512-□□□□	Learning about the errors that may be detected in an NY-series Industrial PC.	Concepts on managing errors that may be detected in an NY-series Controller and information on individual errors are described.
NX-series NX502 CPU Unit Hardware User's Manual	W629	NX502-□□□□	Learning the basic specifications of the NX502 CPU Units, including introductory information, designing, installation, and maintenance. Mainly hardware information is provided.	An introduction to the entire NX502 system is provided along with the following information on the CPU Unit. • Features and system configuration • Introduction • Part names and functions • General specifications • Installation and wiring • Maintenance and inspection

Manual name	Cat. No.	Model numbers	Application	Description
NX-series NX102 CPU Unit Hardware User's Manual	W593	NX102-□□□□	Learning the basic specifications of the NX102 CPU Units, including introductory information, designing, installation, and maintenance. Mainly hardware information is provided.	An introduction to the entire NX102 system is provided along with the following information on the CPU Unit. • Features and system configuration • Introduction • Part names and functions • General specifications • Installation and wiring • Maintenance and inspection
NX-series NX1P2 CPU Unit Hardware User's Manual	W578	NX1P2-□□□□	Learning the basic specifications of the NX1P2 CPU Units, including introductory information, designing, installation, and maintenance. Mainly hardware information is provided.	An introduction to the entire NX1P2 system is provided along with the following information on the CPU Unit. • Features and system configuration • Introduction • Part names and functions • General specifications • Installation and wiring • Maintenance and inspection
NX-series EtherCAT® Coupler Unit User's Manual	W519	NX-ECC20□	Learning how to use an NX-series EtherCAT Coupler Unit and EtherCAT Slave Terminals.	The following items are described: the overall system and configuration methods of an EtherCAT Slave Terminal (which consists of an NX-series EtherCAT Coupler Unit and NX Units), and information on hardware, setup, and functions to set up, control, and monitor NX Units through EtherCAT.
NX-series EtherNet/IP™ Coupler Unit User's Manual	W536	NX-EIC202	Learning how to use an NX-series EtherNet/IP Coupler Unit and EtherNet/IP Slave Terminals.	The following items are described: the overall system and configuration methods of an EtherNet/IP Slave Terminal (which consists of an NX-series EtherNet/IP Coupler Unit and NX Units), and information on hardware, setup, and functions to set up, control, and monitor NX Units.
NJ/NX-series CPU Unit Built-in EtherCAT® Port User's Manual	W505	NX701-□□□□ NX502-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Using the built-in EtherCAT port on an NJ/NX-series CPU Unit.	Information on the built-in EtherCAT port is provided. This manual provides an introduction and provides information on the configuration, features, and setup.
NY-series IPC Machine Controller Industrial Panel PC / Industrial Box PC Built-in EtherCAT® Port User's Manual	W562	NY532-□□□□ NY512-□□□□	Using the built-in EtherCAT port in an NY-series Industrial PC.	Information on the built-in EtherCAT port is provided. This manual provides an introduction and provides information on the configuration, features, and setup.

Manual name	Cat. No.	Model numbers	Application	Description
NX-series Safety Control Unit / Communication Control Unit User's Manual	Z395	NX-SL5□□□ NX-SI□□□□ NX-SO□□□□ NX-CSG□□□	Learning how to use the NX-series Safety Control Units and Communication Control Units.	Describes the hardware, setup methods, and functions of the NX-series Safety Control Units and Communication Control Units.


Terminology

Term	Abbreviation	Description
CPU Rack	---	A Rack to which a CPU Unit or Communication Control Unit is mounted. For NX-series CPU Units to which NX Units can be connected, a CPU Rack has a CPU Unit with NX Units and an End Cover mounted to it. For NX-series Communication Control Units, a CPU Rack has a Communication Control Unit with NX Units and an End Cover mounted to it.
DC time	---	In a CPU Rack of a NX-series CPU Unit to which NX Units can be connected, time indicated by the clock shared between the CPU Unit and the NX Units. EtherCAT slaves that support distributed clock synchronization have a clock that is shared by all slaves in the network. The time that is based on this distributed clock is called the DC time. The same clock is shared by a CPU Unit, NX Units connected to the CPU Unit, and applicable EtherCAT slaves.
EtherCAT slave information	ESI	An XML file that contains setting information for an EtherCAT slave. Refer to <i>1-2-2 System Configuration of Slave Terminals</i> on page 1-5 for details.
I/O port	---	A logical interface that is used by the NJ/NX-series CPU Unit or NY-series Industrial PC to exchange data with an external device (slave or Unit).
I/O refreshing	---	Cyclic data exchange with external devices that is performed with predetermined memory addresses.
NX bus	---	The NX-series internal bus.
NX message communications	---	Message communications to access NX objects.
PDO communications	---	An acronym for process data communications.
SDO communications	---	One type of EtherCAT communications in which service data objects (SDOs) are used to transmit information whenever required. Refer to the user's manual for the built-in EtherCAT port on the connected CPU Unit or Industrial PC for details.
Sync0	---	A signal that gives the interrupt timing based on the distributed clock (DC) in EtherCAT communications. The slaves execute controls according to this interrupt timing. Refer to the <i>NX-series EtherCAT Coupler Unit User's Manual (Cat. No. W519)</i> for details.
index	---	Address of an object within an application process.
object	---	An abstract representation of a particular component within a device, which consists of data, parameters, and methods.
subindex	---	Sub-address of an object within the object dictionary.
Slave Terminal	---	A building-block remote I/O terminal, which consists of a Communication Coupler Unit connected with NX Units.
Safety Network Controller	---	A building-block Safety Controller, which consists of a Communication Control Unit connected with Safety Control Units.
task period	---	The interval at which the primary periodic task or a periodic task is executed. Refer to the software user's manual for the connected CPU Unit or Industrial PC for details.
Communications Coupler Units	---	The generic name of an interface unit for remote I/O communications on a network between NX Units and a host network master.

Term	Abbreviation	Description
Communication Control Unit	---	An interface unit for CIP Safety communications between a Safety CPU Unit and a CIP Safety on EtherNet/IP device on a network.
primary periodic task	---	The task with the highest priority. Refer to the software user's manual for the connected CPU Unit or Industrial PC for details.
process data	---	Collection of application objects designated to be transferred cyclically or acyclically for the purpose of measurement and control.
process data object	PDO	A structure that describes the mappings of parameters that have one or more process data entities.
process data communications	---	One type of EtherCAT communications in which process data objects (PDOs) are used to exchange information cyclically and in realtime. This is also called PDO communications.

Revision History

A manual revision code appears as a suffix to the catalog number on the front and back covers of the manual.



Revision code	Date	Revised content
01	April 2013	Original production
02	June 2013	Corrected mistakes.
03	September 2013	Added information on the NX-PF0730 and corrected mistakes.
04	April 2015	Made changes accompanying the addition of the NX-series CPU Unit and corrected mistakes.
05	October 2016	• Made changes accompanying the addition of NY-series IPC Machine Controller Industrial Panel PCs and Industrial Box PCs. • Made changes accompanying the addition of the NX-series NX1P2 CPU Unit. • Corrected mistakes.
06	June 2017	• Made changes accompanying the upgrade of the NX-ECC203 unit version to version 1.5. • Made changes accompanying the upgrade of the NX-EIC202 unit version to version 1.2. • Corrected mistakes.
07	April 2018	• Made changes accompanying the addition of the NX-series NX102 CPU Unit. • Corrected mistakes.
08	July 2018	• Made changes accompanying the addition of the NX-series Communication Control Unit. • Corrected mistakes.
09	October 2018	Made revisions accompanying the appearance change of the indicators.
10	April 2023	• Made changes accompanying the addition of the NX-series NX502 CPU Unit. • Corrected mistakes.
11	October 2025	Corrected mistakes.

Features and System Configuration

This section describes NX system configuration and System Unit types.

1-1	Features and Types of System Units.....	1-2
1-1-1	System Unit Features.....	1-2
1-1-2	System Unit Types	1-3
1-2	System Configuration	1-4
1-2-1	System Configuration in the Case of a CPU Unit.....	1-4
1-2-2	System Configuration of Slave Terminals.....	1-5
1-2-3	System Configuration in the Case of a Communication Control Unit.....	1-7
1-3	Model List.....	1-10
1-3-1	Model Notation	1-10
1-3-2	Additional NX Unit Power Supply Unit.....	1-11
1-3-3	Additional I/O Power Supply Unit	1-11
1-3-4	I/O Power Supply Connection Unit.....	1-11
1-3-5	Shield Connection Unit.....	1-11
1-4	Support Software	1-13

1-1 Features and Types of System Units

This section describes features and types of System Units.

1-1-1 System Unit Features

System Units are Units used to build the system for separating power supply systems or supplying power in the midstream in a CPU Rack or a Slave Terminal.

The NX-series System Units provide the following features.



Additional Information

CPU Rack

A CPU Rack is a rack to which a CPU Unit or Communication Control Unit is mounted. For NX-series CPU Units to which NX Units can be connected, a CPU Rack is configured to have a CPU Unit with NX Units and an End Cover mounted to it. For NX-series Communication Control Units, a CPU Rack has a Communication Control Unit with NX Units and an End Cover mounted to it.

Slave Terminal

Slave Terminal is a generic name for a building block-type remote I/O terminal that contains a group of NX Units connected to a Communications Coupler Unit.

Can Be Connected to More Than One Unit with the NX Bus


NX Unit NX-series System Units can be connected to the following Units, which each support an NX bus. *1

- NX-series CPU Unit
- NX-series Communications Coupler Unit
- NX-series Communication Control Unit


When these Units are used, you can unify the methods for installing, wiring, and setting up NX Units, and eventually reduce design costs.

Example:

NX-series NX1P2 CPU Unit



NX Units: NX-series Digital I/O Units or other Units



NX-series EtherCAT Coupler Unit

- *1. For whether NX Units can be connected to the CPU Unit or Communications Coupler Unit to be used, refer to the user's manual for the CPU Unit or Communications Coupler Unit to be used.

Simple I/O Wiring with a Screwless Clamping Terminal Block

The terminal block is a screwless clamping terminal block.

You can connect the wires simply by pushing the ferrules into the terminals. The amount of wiring work is reduced without requiring the use of screws.

1-1-2 System Unit Types

The types of System Units are as follows.

Type	Purpose
System Units	These Units are used as required to build a CPU Rack or a Slave Terminal.
Additional NX Unit Power Supply Unit	This Unit is used when the NX Unit power supply is insufficient.
Additional I/O Power Supply Unit	This Unit is used when the I/O power supply is insufficient or to separate the I/O power supply in the CPU Rack or Slave Terminal. This Unit must be used when the type of the I/O power supply for the NX Unit that is used in a CPU Rack of NX-series CPU Unit is the supply from NX bus.
I/O Power Supply Connection Unit	This Unit is used when the I/O power supply terminals are insufficient for connections to external I/O devices.
Shield Connection Unit	This Unit is used to ground more than one shield from external I/O connections to the same ground.

Refer to *1-3 Model List* on page 1-10 for details on System Unit models.

1-2 System Configuration

NX Unit NX-series System Units can be connected to the following Units.

- NX-series CPU Unit
- NX-series Communications Coupler Unit

The following explains the system configuration for each NX Unit connection destination.


1-2-1 System Configuration in the Case of a CPU Unit

The following figure shows a system configuration when a group of NX Units is connected to an NX-series NX1P2 CPU Unit. You can connect the EtherCAT Slave Terminal to the built-in EtherCAT port on the CPU Unit.

Refer to 1-2-2 *System Configuration of Slave Terminals* on page 1-5 for details on the system configuration of a Slave Terminal.

Refer to the user's manual for the connected CPU Unit for details on how to configure the system if the connected CPU Unit is not an NX1P2 CPU Unit.

(D) Support Software
Sysmac Studio



Letter	Item	Description
(A)	NX-series CPU Unit	The Unit that serves as the center of control for a Machine Automation Controller. It executes tasks, refreshes I/O for other Units and slaves, etc. NX Units can be connected to an NX1P2 CPU Unit.
(B)	NX Units *1	The NX Units perform I/O processing with connected external devices. The NX Units exchange data with the CPU Unit through I/O refreshing. A maximum of eight NX Units can be connected to an NX1P2 CPU Unit.
(C)	End Cover	The End Cover is attached to the end of the CPU Rack.
(D)	Support Software (Sysmac Studio)	A computer software application for setting, programming, debugging, and troubleshooting NJ/NX/NY-series Controllers. For an NX1P2 CPU Unit, this application performs setting operation by making a connection to a built-in EtherNet/IP port.

*1. For whether an NX Unit can be connected to the CPU Unit, refer to the version information in the user's manual for the NX Unit.


1-2-2 System Configuration of Slave Terminals

A building-block remote I/O slave provided with a group of NX Units connected to a Communications Coupler Unit is generically called a Slave Terminal.

The NX Units can be flexibly combined with a Communications Coupler Unit to achieve the optimum remote I/O slave for the application with less wiring, less work, and less space.

The following figure shows an example of the system configuration when an EtherCAT Coupler Unit is used as a Communications Coupler Unit.

Refer to the user's manual for the connected Communications Coupler Unit for details on how to configure the system when any other type of Communications Coupler Unit is used.



*1. The connection method for the Support Software depends on the model of the CPU Unit or Industrial PC.

Let-ter	Item	Description
(A)	EtherCAT master *1	The EtherCAT master manages the network, monitors the status of slaves, and exchanges I/O data with slaves.
(B)	EtherCAT Coupler Unit	The EtherCAT Coupler Unit serves as an interface for process data communications on the EtherCAT network between the NX Units and the EtherCAT master. The I/O data for the NX Units is accumulated in the EtherCAT Coupler Unit and then all of the data is exchanged with the EtherCAT master at the same time. The EtherCAT Coupler Unit can also perform message communications (SDO communications) with the EtherCAT master.
(C)	NX Units *2	The NX Units perform I/O processing with connected external devices. The NX Units perform process data communications with the EtherCAT master through the EtherCAT Coupler Unit.
(D)	End Cover	The End Cover is attached to the end of the Slave Terminal.
(E)	Support Software *3	The Support Software runs on a personal computer and it is used to configure the EtherCAT network and EtherCAT Slave Terminal, and to program, monitor, and troubleshoot the Controllers.


Letter	Item	Description
(F)	ESI (EtherCAT Slave Information) files	The ESI files contain information that is unique to the EtherCAT Slave Terminal in XML format. You can load an ESI file into the Support Software to easily allocate Slave Terminal process data and make other settings. The ESI files for OMRON EtherCAT slaves are installed in the Support Software. You can obtain the ESI files for the latest models through the Support Software's automatic update function.
(G)	Communications cable	Use a double-shielded cable with aluminum tape and braiding of Ethernet category 5 (100Base-TX) or higher, and use straight wiring.

- *1. An EtherCAT Slave Terminal cannot be connected to any of the OMRON CJ1W-NC□81/□82 Position Control Units even though they can operate as EtherCAT masters.
- *2. For whether an NX Unit can be connected to the Communications Coupler Unit, refer to the version information in the user's manual for the NX Unit.
- *3. The term Support Software indicates software that is provided by OMRON. If you connect to a master from another company, use the software tool corresponding to that master.

Refer to 1-4 *Support Software* on page 1-13 for information on Support Software.

1-2-3 System Configuration in the Case of a Communication Control Unit

The following figure shows a system configuration when a group of NX Units is connected to an NX-series Communication Control Unit. To configure a Safety Network Controller, mount the Safety CPU Unit, which is one of the NX Units, to the CPU Rack of the Communication Control Unit.



Letter	Item	Description
(A)	EtherNet/IP Unit	The EtherNet/IP Unit manages the EtherNet/IP network, monitors the status of slaves, and exchanges I/O data with the slaves. The types of EtherNet/IP Units are listed below. • CJ1W-EIP21 • Built-in EtherNet/IP port on a CPU Unit Refer to descriptions of the Support Software required to construct a network in the user's manual for your EtherNet/IP Unit for information on the Support Software to configure the EtherNet/IP Unit.
(B)	Communication Control Unit	The Communication Control Unit has built-in EtherNet/IP ports and relays CIP Safety communications between the Safety CPU Unit and CIP Safety on EtherNet/IP devices. It also performs tag data link communications with standard controllers.

Letter	Item	Description
(C)	NX Units ^{*1}	• Safety CPU Unit This Unit serves as the center of control for the Safety Network Controller. It executes safety programs and CIP Safety communications. • Safety I/O Unit This Unit performs safety input or output processing. • Other NX Units Digital I/O Units and other types of NX Units perform standard I/O processing.
(D)	End Cover	The End Cover is attached to the end of the CPU Rack.
(E)	CIP Safety on EtherNet/IP device	The CIP Safety on EtherNet/IP device performs CIP Safety communications with the Safety CPU Unit.
(F)	EDS (Electronic Data Sheet) files	The EDS files contain information that is unique to the Communication Control Unit. You can load EDS files into the Network Configurator or other EtherNet/IP network setup software to easily allocate data and view or change settings.
(G)	Network Configurator	The software tool to configure the EtherNet/IP network.
(H)	Support Software ^{*2}	The Support Software runs on a personal computer and it is used to configure the CPU Rack, and to perform programming, monitoring, and troubleshooting.
(I)	Communications cable	Use an STP (shielded twisted-pair) cable of category 5 or higher. You can use either a straight or cross cable.

^{*1}. For whether an NX Unit can be connected to the Communication Control Unit, refer to the version information in the user's manual for the NX Unit.


^{*2}. Refer to *1-4 Support Software* on page 1-13 for information on Support Software.

1-3 Model List


1-3-1 Model Notation

The System Unit models are assigned based on the following rules.
Model notation for the power supply-related Units (Additional NX Unit Power Supply Unit, Additional I/O Power Supply Unit and I/O Power Supply Connection Unit) differs from that of System Units other than power supply-related Units.

Power Supply-related Units



System Units Other Than Power Supply-related Units



1-3-2 Additional NX Unit Power Supply Unit

This section shows a list of Additional NX Unit Power Supply Units.

Refer to *A-1-2 Additional NX Unit Power Supply Unit* on page A-3 for details.

Screwless Clamping Terminal Block, 12 mm Width

Model	Rated power supply voltage	NX Unit power supply capacity	Reference
NX-PD1000	24 VDC	10 W max.	page A-5

1-3-3 Additional I/O Power Supply Unit

This section shows a list of Additional I/O Power Supply Units.

Refer to *A-1-3 Additional I/O Power Supply Unit* on page A-7 for details.

Screwless Clamping Terminal Block, 12 mm Width

Model	Rated power supply voltage	Maximum current of I/O power supply	Reference
NX-PF0630	5 to 24 VDC	4 A	page A-9
NX-PF0730	5 to 24 VDC	10 A ^{*1}	page A-11

- *1. When an Additional I/O Power Supply Unit is connected to the CPU Rack of a CPU Unit, the maximum I/O power supply current value may be smaller than that of the Additional I/O Power Supply Unit. For example, the maximum I/O power supply current for the CPU Rack of an NX1P2 CPU Unit is 4 A. For the maximum I/O power supply current of the CPU Rack, refer to *Maximum I/O Power Supply Current* under *Designing the I/O Power Supply from the NX Bus* in the hardware user's manual for the CPU Unit to which NX Units are connected.

1-3-4 I/O Power Supply Connection Unit

This section shows a list of I/O Power Supply Connection Units.

Refer to *A-1-4 I/O Power Supply Connection Unit* on page A-12 for details.

Screwless Clamping Terminal Block, 12 mm Width

Model	Number of I/O power supply terminals	Current capacity of I/O power supply terminal	Reference
NX-PC0020	IOV: 16 terminals	4 A/terminal max.	page A-14
NX-PC0010	IOG: 16 terminals		page A-16
NX-PC0030	IOV: 8 terminals IOG: 8 terminals		page A-18

1-3-5 Shield Connection Unit

This section shows a list of Shield Connection Units.

Refer to *A-1-5 Shield Connection Unit* on page A-19 for details.

Screwless Clamping Terminal Block, 12 mm Width

Model	Number of shield terminals	Reference
NX-TBX01	14 terminals (The following two terminals are functional ground terminals.)	page A-21

1-4 Support Software

The Support Software that is used depends on the system configuration.

- **Support Software for a System Configured with a CPU Unit**

If your system is configured by connecting an NX Unit to a CPU Unit, the Sysmac Studio is used as the Support Software.

- **Support Software for a System Configured with a Slave Terminal**

If your system is configured by connecting an NX Unit to a Communications Coupler Unit, refer to the user's manual for the Communications Coupler Unit for information on the Support Software.

- **Support Software for a System Configured with a Communication Control Unit**

If your system is configured by connecting an NX Unit to a Communication Control Unit, the Sysmac Studio is used as the Support Software.

Depending on the Unit to which the NX Unit is connected, refer to the following appendices for information on the Support Software versions.

- *A-5 Version Information with CPU Units* on page A-29
- *A-6 Version Information with Communications Coupler Units* on page A-31
- *A-7 Version Information with Communication Control Units* on page A-34

2

Specifications

This section describes the general specifications and individual specifications of System Units.

2-1	General Specifications	2-2
2-2	Individual Specifications	2-3

2-1 General Specifications

This table shows the general specifications of all System Units.

Item		Specification
Enclosure		Mounted in a panel
Grounding methods		Ground of 100 Ω or less
Operating environment	Ambient operating temperature	0 to 55°C
	Ambient operating humidity	10 to 95% RH (with no icing or condensation)
	Atmosphere	Must be free from corrosive gases.
	Ambient storage temperature	-25 to 70°C (with no icing or condensation)
	Altitude	2,000 m max.
	Pollution degree	Pollution degree 2 or less: Conforms to JIS B 3502 and IEC 61131-2.
	Noise immunity	Conforms to IEC 61000-4-4, 2 kV (power supply line)
	Overvoltage category	Category II: Conforms to JIS B 3502 and IEC 61131-2.
	EMC immunity level	Zone B
	Vibration resistance	Conforms to IEC 60068-2-6. 5 to 8.4 Hz with amplitude of 3.5 mm, 8.4 to 150 Hz, acceleration of 9.8 m/s ² 100 min each in X, Y, and Z directions (10 sweeps of 10 min each = 100 min total)
	Shock resistance	Conforms to IEC 60068-2-27, 147 m/s ² , 3 times each in X, Y, and Z directions
Insulation resistance		Refer to the individual specifications of NX Units.
Dielectric strength		Refer to the individual specifications of NX Units.
Applicable standards		cULus: Listed (UL508), ANSI/ISA 12.12.01, EU: EN 61131-2, C-Tick, KC (KC Registration), NK, and LR

Note 1. The specifications of insulation resistance and dielectric strength vary with NX Unit Models.

Note 2. Refer to the OMRON website (www.ia.omron.com) or ask your OMRON representative for the most recent applicable standards for each model.

2-2 Individual Specifications

Refer to *A-1 Data Sheet* on page A-2 for the specifications of individual System Units.

3

Part Names and Functions

3

This section describes the names and functions of the System Unit parts.


3-1	Names of Power Supply-related Unit Parts	3-2
3-1-1	Screwless Clamping Terminal Block Type.....	3-2
3-1-2	Indicators.....	3-6
3-2	Names of Shield Connection Unit Parts.....	3-9
3-2-1	Screwless Clamping Terminal Block Type.....	3-9
3-2-2	Indicators.....	3-12

3-1 Names of Power Supply-related Unit Parts

This section describes the names and functions of power supply-related Unit parts (Additional NX Unit Power Supply Unit, Additional I/O Power Supply Unit, and I/O Power Supply Connection Unit).

3-1-1 Screwless Clamping Terminal Block Type

NX Units (12 mm Width)




Letter	Name	Function
(A)	Marker attachment locations	The locations where markers are attached. The markers made by OMRON are installed for the factory setting. Commercially available markers can also be installed.
(B)	NX bus connector	This connector is used to connect each Unit.
(C)	Unit hookup guides	These guides are used to connect two Units.
(D)	DIN Track mounting hook	This hook is used to mount the NX Unit to a DIN Track.
(E)	Protrusions for removing the Unit	The protrusions to hold when removing the Unit.
(F)	Indicators	The indicators show the current operating status of the Unit.
(G)	Terminal block	The terminal block is used to connect external devices. The number of terminals depends on the type of Unit.
(H)	DIN Track contact plate	This plate is used to contact the ground terminal with a DIN Track. It is only on the Units that have ground terminals.
(I)	Unit specifications	The specifications of the Unit are given.

Refer to 4-1-2 *Attaching Markers* on page 4-5 for details on the marker attachment locations and 3-1-2 *Indicators* on page 3-6 for details on the indicators.


Terminal Blocks

There are two models of screwless clamping terminal blocks: NX-TB□□□2 and NX-TB□□□1. Each model has three types of terminal blocks: 8-terminal type, 12-terminal type, and 16-terminal type. Use the 8-terminal type and the 16-terminal type for the power supply-related Units.

● NX-TB□□□2



● NX-TB□□□1



Letter	Name	Function
(A)	Terminal number indications	Terminal numbers for which A and B indicate the column, and 1 to 8 indicate the line are displayed. The terminal number is a combination of column and line, i.e. A1 to A8 and B1 to B8. The terminal number indications are the same regardless of the number of terminals on the terminal block.
(B)	Release holes	Insert a flat-blade screwdriver into these holes to connect and remove the wires.
(C)	Terminal holes	The wires are inserted into these holes.
(D)	Ground terminal mark	This mark indicates the ground terminals. It is only on the NX-TBC□□2.

The NX-TB□□□2 and NX-TB□□□1 Terminal Blocks have different terminal current capacities.

The former has 10 A and the latter has 4 A.

To differentiate between the two models of terminal blocks, use the terminal number column indications. The terminal block with white letters on a dark background is the NX-TB□□□2.

You can mount either terminal block to the Units that the current capacity specification of the terminals is 4 A or less.

You can only mount the NX-TB□□□2 Terminal Block to the Units that the current capacity specification of the terminals is greater than 4 A.



Additional Information

- Each power supply-related Unit is compatible with only one of three types of terminal blocks. You cannot use a terminal block with a number of terminals that differs from the specifications for a particular Unit.
- The 8-terminal type does not have terminal holes and release holes for following terminal numbers.
A2, A4, A6, A8, B2, B4, B6, and B8

● Applicable Terminal Blocks for Each Unit Model

The following indicates the terminal blocks that are applicable to each Unit.

Unit model number	Terminal block			
	Model	Number of terminals	Ground terminal mark	Current capacity
NX-PD1000	NX-TBA081	8	Not provided	4 A
	NX-TBC082		Provided	10 A
NX-PF0630	NX-TBA081		Not provided	4 A
	NX-TBA082			10 A
NX-PF0730	NX-TBA082			
NX-PC0□□□	NX-TBA161	16		4 A
	NX-TBA162			10 A



Precautions for Correct Use

You can mount either NX-TB□□□1 or NX-TB□□□2 Terminal Blocks to the Units that the current capacity specification of the terminals is 4 A or less.

However, even if you mount the NX-TB□□□2 Terminal Block, the current specification does not change because the current capacity specification of the terminals on the Units is 4 A or less.



Additional Information


Refer to *A-4 List of Screwless Clamping Terminal Block Models* on page A-27 for information on the models of terminal blocks.

3-1-2 Indicators

The Additional NX Unit Power Supply Unit, Additional I/O Power Supply Unit, and I/O Power Supply Connection Unit have indicators that show the current operating status of the NX Unit.

The following indicator patterns are available depending on the Unit types.


The appearance of the indicators has been changed for models released in or before September 2018 with lot numbers that represent the date of or after September 20, 2018. In this manual, those models are shown with the indicators after the change. For details on the applicable models and the changes, refer to *Appearance Change of the Indicators* on page 3-8.







Letter	Name	Function
(A)	Model number indications	Gives the model number of the NX Unit, without the prefix. For example, <i>PD1000</i> in the case of NX-PD1000.
(B)	Indicators	The indicator shows the current operating status of the NX Unit.

The following section describes the specifications of each indicator.

TS Indicator





The following table lists the possible statuses for this indicator and what they mean.

Color	Status		Description
Green		Lit	The Unit is operating normally. The Unit is ready for I/O refreshing.
		Flashing (at 2-s intervals)	• Initializing • Restarting is in progress for the Unit. • Downloading
Red		Lit	A hardware failure, WDT error, or other fatal error that is common to all I/O Units occurred.
		Flashing (at 1-s intervals)	A communications error or other NX bus-related error that is common to all I/O Units occurred.
---		Not lit	• No Unit power supply • Restarting is in progress for the Unit. • Waiting for initialization to start

UNIT PWR Indicator


This is mounted only on an Additional NX Unit Power Supply Unit.




Color	Status		Description
Green		Lit	The Unit power is supplied.
		Not lit	The Unit power is not supplied.

I/O PWR Indicator

This is mounted only on the Additional I/O Power Supply Unit.



Color	Status	Description
Green		Lit The I/O power is supplied.
		Not lit The I/O power is not supplied.

Appearance Change of the Indicators

The appearance of the indicators has been changed for models released in or before September 2018 with lot numbers that represent the date of or after September 20, 2018. See below for details on the applicable models and the changes. Models that are not listed here have the appearance after the change.


- **Applicable Models**

NX-PD1000, NX-PF0630, NX-PF0730, NX-PC0020, NX-PC0010, NX-PC0030, NX-TBX01

- **Change Details**

The shape of the light emitting part of each indicator has been changed from a square to a pentagon.

Below is an example of the TS indicator.




3-2 Names of Shield Connection Unit Parts

This section describes the names and functions of the Shield Connection Unit parts.

3-2-1 Screwless Clamping Terminal Block Type

NX Units (12 mm Width)




Letter	Name	Function
(A)	Marker attachment locations	The locations where markers are attached. The markers made by OMRON are installed for the factory setting. Commercially available markers can also be installed.
(B)	NX bus connector	This connector is used to connect each Unit.
(C)	Unit hookup guides	These guides are used to connect two Units.
(D)	DIN Track mounting hook	This hook is used to mount the NX Unit to a DIN Track.
(E)	Protrusions for removing the Unit	The protrusions to hold when removing the Unit.
(F)	Indicators	The indicators show the current operating status of the Unit.
(G)	Terminal block	The terminal block is used to connect external devices. The number of terminals depends on the type of Unit.
(H)	DIN Track contact plate	This plate is used to contact the ground terminal with a DIN Track. It is only on the Units that have ground terminals.
(I)	Unit specifications	The specifications of the Unit are given.

Refer to *4-1-2 Attaching Markers* on page 4-5 for details on the marker attachment locations and *3-2-2 Indicators* on page 3-12 for details on the indicators.


Terminal Blocks

There are two models of screwless clamping terminal blocks: NX-TB□□□2 and NX-TB□□□1. Each model has three types of terminal blocks: 8-terminal type, 12-terminal type, and 16-terminal type. Use the 16-terminal type for the Shield Connection Unit.

● NX-TBC162



● NX-TBA161



Let-ter	Name	Function
(A)	Terminal number indi-cations	Terminal numbers for which A and B indicate the column, and 1 to 8 indicate the line are displayed. The terminal number is a combination of column and line, i.e. A1 to A8 and B1 to B8.
(B)	Release holes	Insert a flat-blade screwdriver into these holes to connect and remove the wires.
(C)	Terminal holes	The wires are inserted into these holes.
(D)	Ground terminal mark	This mark indicates the ground terminals. It is only on the NX-TBC□□2.

The NX-TB□□□2 and NX-TB□□□1 Terminal Blocks have different terminal current capacities. The former has 10 A and the latter has 4 A.

To differentiate between the two models of terminal blocks, use the terminal number column indica-tions. The terminal block with white letters on a dark background is the NX-TB□□□2.

You can mount either terminal block to the Shield Connection Unit.



Additional Information

The Shield Connection Unit is only compatible with the 16-terminal type. You cannot use a ter-minal block with a different number of terminals.

● Applicable Terminal Blocks for Each Unit Model

The following indicates the terminal blocks that are applicable to each Unit.

Unit model num-ber	Terminal block			
	Model	Number of termi-nals	Ground terminal mark	Current capacity
NX-TBX01	NX-TBA161	16	Not provided	4 A
	NX-TBC162		Provided	10 A




Additional Information

Refer to *A-4 List of Screwless Clamping Terminal Block Models* on page A-27 for information on the models of terminal blocks.

3-2-2 Indicators


A Shield Connection Unit has indicators that show the current operating status of the NX Unit. The appearance of the indicators has been changed for models released in or before September 2018 with lot numbers that represent the date of or after September 20, 2018. In this manual, those models are shown with the indicators after the change. For details on the applicable models and the changes, refer to *Appearance Change of the Indicators* on page 3-8.







Letter	Name	Function
(A)	Model number indications	Gives the model number of the NX Unit, without the prefix. For example, <i>TBX01</i> in the case of NX-TBX01.
(B)	TS indicator	The indicator shows the current operating status of the NX Unit.

The following section describes the specifications of the TS indicator.

TS Indicator



The following table lists the possible statuses for this indicator and what they mean.

Color	Status		Description
Green		Lit	The Unit is operating normally. The Unit is ready for I/O refreshing.
		Flashing (at 2-s intervals)	• Initializing • Restarting is in progress for the Unit. • Downloading
Red		Lit	A hardware failure, WDT error, or other fatal error that is common to all I/O Units occurred.
		Flashing (at 1-s intervals)	A communications error or other NX bus-related error that is common to all I/O Units occurred.
---		Not lit	• No Unit power supply • Restarting is in progress for the Unit. • Waiting for initialization to start

4

Installation and Wiring

This section describes how to install the NX Units, the types of power supplies used in the CPU Rack or Slave Terminal, their wiring methods, and how to wire the NX Units.

4

4-1	Installing NX Units.....	4-2
4-1-1	Installing NX Units	4-2
4-1-2	Attaching Markers	4-5
4-1-3	Removing NX Units	4-6
4-1-4	Installation Orientation.....	4-7
4-2	Wiring the Power Supply to the CPU Unit.....	4-9
4-2-1	Power Supply Types.....	4-9
4-2-2	Supplying Each Power Supply and Wiring	4-9
4-2-3	Power Supply-related Units and Wiring Methods.....	4-12
4-3	Wiring the Power Supply to the Slave Terminal	4-15
4-3-1	Power Supply Types.....	4-15
4-3-2	Supplying Each Power Supply and Wiring	4-15
4-3-3	Power Supply-related Units and Wiring Methods.....	4-17
4-4	Wiring the Power Supply to the Communication Control Unit	4-20
4-4-1	Power Supply Types.....	4-20
4-4-2	Supplying Each Power Supply and Wiring	4-20
4-4-3	Power Supply-related Units and Wiring Methods.....	4-22
4-5	Wiring of Grounding	4-25
4-6	Wiring the Additional Power Supply Units	4-27
4-6-1	Wiring the Additional NX Unit Power Supply Unit	4-28
4-6-2	Wiring the Additional I/O Power Supply Unit	4-32
4-6-3	Protective Devices.....	4-38
4-7	Wiring the I/O Power Supply Connection Unit	4-40
4-8	Wiring the Shield Connection Unit	4-44
4-9	Wiring the Terminals	4-45
4-9-1	Wiring to the Screwless Clamping Terminal Blocks	4-45
4-9-2	Preventing Incorrect Attachment of Terminal Blocks.....	4-55

4-1 Installing NX Units

This section describes how to install NX Units.

Refer to the user's manual for the CPU Unit, Communications Coupler Unit, or Communication Control Unit to which NX Units are connected for information on preparations of installation and installation in a control panel.

4-1-1 Installing NX Units

This section describes how to mount two NX Units to each other.


Always turn OFF the power supply before you mount NX Units.

Always mount NX Units one at a time. If you attempt to mount multiple NX Units that are already connected together, the connections between the NX Units may separate from each other and fall.




Precautions for Safe Use

- Always turn OFF the power supply before installing the Unit. If the power supply is not OFF, the Unit may malfunction or may be damaged.
- Do not apply labels or tape to the Unit. When the Unit is installed or removed, adhesive or scraps may adhere to the pins in the NX bus connector, which may result in malfunctions.
- Do not touch the pins in the NX bus connector on the Unit. Dirt may adhere to the pins in the NX bus connector, which may result in malfunctions.



Example: NX Unit (12 mm width)


- Do not write on an NX Unit with ink within the restricted region that is shown in the following figure. Also do not get this area dirty. When the Unit is installed or removed, ink or dirt may adhere to the pins in the NX bus connector, which may result in malfunctions in the CPU Rack or the Slave Terminal.
Refer to the user's manual for the connected CPU Unit, Communications Coupler Unit, or Communication Control Unit for details on the restricted region on the CPU Unit, Communications Coupler Unit, or Communication Control Unit.




Precautions for Correct Use

- When you install an NX Unit, do not touch or bump the pins in the NX bus connector.
- When you handle an NX Unit, be careful not to apply any stress to the pins in the NX bus connector. If the NX Unit is installed and the power supply is turned ON when the pins in the NX bus connector are deformed, contact failure may cause malfunctions.

- 1 From the front of the previously mounted NX Unit, engage the Unit hookup guides on a new Unit with the Unit hookup guides on the previously mounted NX Unit.



- 2** Slide the NX Unit in on the hookup guides.



- 3** Press the NX Unit with a certain amount of force against the DIN Track until you hear the DIN Track mounting hook lock into place.
When you mount the NX Unit, it is not necessary to unlock the DIN Track mounting hook on the NX Unit.
After you mount the NX Unit, make sure that it is locked to the DIN Track.



Additional Information

- It is not normally necessary to unlock the DIN Track mounting hook when you mount the NX Unit. If you mount an NX Unit on a DIN Track that is not one of the recommended DIN Tracks, the DIN Track mounting hook may not lock into place. If that happens, first unlock the DIN Track mounting hook, mount the NX Unit to the DIN Track, then lock the DIN Track mounting hook.
- Refer to the hardware user's manual for the CPU Unit to which NX Units can be connected for information on how to mount the CPU Unit and how to mount NX Units to the CPU Unit.
- Refer to the user's manual for the Communications Coupler Unit for information on how to mount the Communications Coupler Unit and how to mount the NX Unit to the Communications Coupler Unit.
- Refer to the user's manual for the Communication Control Unit for information on how to mount the Communication Control Unit, and how to mount NX Units to the Communication Control Unit.


4-1-2 Attaching Markers

You can attach markers to the NX Units to identify them.

The plastic markers made by OMRON are installed for the factory setting. The ID information can be written on them.

Commercially available markers can also be installed.

Replace the markers made by OMRON if you use commercially available markers now.




The marker attachment locations vary depending on the type of the external connection terminals on the NX Units.

Refer to the user's manual for the NX Units that you use for the external connection terminals.

External connection terminals on NX Units	Marker attachment location
Screwless clamping terminal block	NX Unit and terminal block
M3 screw terminal block	
MIL connector	NX Unit only
Fujitsu/OTAX connector	

Marker Installation Method

Insert the protrusions on the markers into the marker attachment locations.



Commercially Available Markers

Commercially available markers are made of plastic and can be printed on with a special printer. To use commercially available markers, purchase the following products.

Product name	Model number	
	Manufactured by Phoenix Contact	Manufactured by Weidmuller
Markers	UC1-TMF8	DEK 5/8
Special marker printer	UM EN BLUEMARK X1	PrintJet PRO

The markers made by OMRON cannot be printed on with commercially available special printers.

4-1-3 Removing NX Units


This section describes how to remove NX Units.




Precautions for Safe Use

Always turn OFF the Unit power supply and I/O power supply before you remove the NX Unit.

- 1 Use a flat-blade screwdriver or similar tool to pull up the DIN Track mounting hook on the NX Unit to remove.



- 2 Place your fingers on the protrusions on more than one NX Unit, including the NX Unit to remove, and pull the NX Units straight forward.



Precautions for Correct Use


- When you need to remove an NX Unit, always remove more than one NX Unit at a time, including the Unit you need to remove. It is sometimes very difficult to remove only one NX Unit by itself.
- Do not release the DIN Track mounting hooks on all of the NX Units at the same time. If you release the DIN Track mounting hooks on all of the Units at the same time, all of the Units will come off.

4-1-4 Installation Orientation

This section describes the installation orientation for each type of Unit that an NX Unit can be connected to.

Installation Orientation on the CPU Unit or Communication Control Unit

The NX Unit can be installed only in the upright orientation.




However, there are restrictions on the specifications depending on the NX Units to be used.

For detailed restrictions, refer to descriptions of installation orientations and restrictions for each model in the user's manuals for the NX Units and System Units that you will use.

Installation Orientation on Slave Terminals

The Slave Terminal can be installed in any of the following six orientations.

(A) is the upright installation orientation and (B) to (F) are installation orientations other than upright.




However, there are restrictions on the installation orientation and restrictions to the specifications that can result from the Communications Coupler Units and NX Units that are used.

For detailed restrictions, refer to descriptions of installation orientations and restrictions for each model in the user's manuals for the Communications Coupler Units, NX Units, and NX-series System Units that you will use.



Precautions for Safe Use

- For the installation orientations in the following figure, support the cables, e.g., with a duct, so that the End Plate on the bottom is not subjected to the weight of the cables. The weight of the cables may cause the bottom End Plate to slide downward so that the Slave Terminal is no longer secured to the DIN Track, which may result in malfunctions.



4-2 Wiring the Power Supply to the CPU Unit

This section describes the methods of power supplying and wiring with NX Unit in a CPU Rack when connecting NX Unit with NX-series CPU Unit.

4-2-1 Power Supply Types

There are the following two types of power supplies that supply power to the CPU Rack of the CPU Unit.

Some CPU Unit models have a circuit that requires power supply for other circuits besides NX Units. For example, NX1P2 CPU Units require I/O power supply to drive built-in I/O output circuits.

For details on power supply for circuits other than NX Units, refer to a description of the power supply system and types of power supplies in the hardware user's manual for the connected CPU Unit.

Power supply name	Description
Unit power supply	This is the power supply for generating the internal power supply required for the CPU Rack to operate. This power supply is connected to the Unit power supply terminals on the CPU Unit or Additional NX Unit Power Supply Unit. From the Unit power supply, the internal power supply circuit in the CPU Unit generates the power supply to the CPU Unit internal circuit and NX Unit power supply.*1 The internal power supply circuit in the Additional NX Unit Power Supply Unit generates the NX Unit power supply from the Unit power supply. The internal circuits of the NX Unit operates on the NX Unit power supply. The NX Unit power supply is supplied to the NX Units in the CPU Rack through the NX bus connectors.
I/O power supply	This power supply is used for driving the I/O circuits of the NX Units and for the connected external devices. There are the following two I/O power supply methods. Either supply method used depends on each model of NX Unit. • Supply from the NX bus • Supply from external source Refer to 4-2-2 <i>Supplying Each Power Supply and Wiring</i> on page 4-9 for the details on the power supply methods.


*1. For the NX1P2 CPU Unit, the Option Board power supply is also generated. The type of power supply generated by the internal power supply circuit in the CPU Unit depends on the CPU Unit model. For information on the power supply generated by the internal power supply circuit in the connected CPU Unit, refer to a description of the power supply system and types of power supplies in the hardware user's manual for the CPU Unit.

4-2-2 Supplying Each Power Supply and Wiring

The supply method for each power supply to the NX Units is as follows.

Power supply name	Description
NX Unit power supply	This power is supplied to the NX Units through the NX bus connectors by connecting a Unit power supply to the Unit power supply terminals on the CPU Unit or Additional NX Unit Power Supply Units.
I/O power supply	This power is supplied by one of the following two methods. • Supply from the NX bus This power is supplied through the NX bus connectors by connecting an I/O power supply to the I/O power supply terminals on the Additional I/O Power Supply Units. • Supply from external source This power is supplied to the Units from an external source. I/O power is supplied by connecting an I/O power supply to the I/O power supply terminals on the Units. For the supply method that you will use for an NX Unit model, refer to the data sheet in the user's manual for the NX Unit or <i>NX-series Data Reference Manual (Cat. No. W525)</i>. Refer to <i>A-1 Data Sheet</i> on page A-2 for the supply method for each System Unit model.

The following are wiring diagrams (examples) for each power supply.



Precautions for Correct Use

Always use separate power supplies for the Unit power supply and the I/O power supply. If you supply power from the same power supply, noise may cause malfunctions.



Additional Information

Refer to the hardware user's manual for the CPU Unit to which Units are connected for information on the designing of the power supply for the CPU Rack of the CPU Unit.



4-2-3 Power Supply-related Units and Wiring Methods



The CPU Unit supplies the NX Unit power to the NX Units in the CPU Rack.

There are the following types of NX-series power supply-related Units other than CPU Unit.

Refer to NX-series catalogs or OMRON websites, or ask your OMRON representative for information on the most recent lineup of NX Units.

Unit name	Function
Additional NX Unit Power Supply Unit	This NX Unit provides NX Unit power supply. This NX Unit is used when the total power consumption of the NX Units in the CPU Rack exceeds the NX Unit power supply capacity of the CPU Unit. The total power consumption from the NX Unit power supply is within the NX Unit power supply capacity. The total power consumption from the NX Unit power supply is within the NX Unit power supply capacity. Unit power supply terminals Additional I/O Power Supply Unit NX Unit NX Unit power supply Separated by Additional NX Unit Power Supply Unit Additional NX Unit Power Supply Unit Internal power supply circuit I/O power supply Internal power supply circuit NX Unit power supply Unit power supply The I/O power supply for the Additional NX Unit Power Supply Unit is connected to the NX Unit on the left through the NX bus connector.

Unit name	Function
Additional I/O Power Supply Unit	This NX Unit provides additional I/O power supply. This Unit is used when the I/O power supply for the NX Unit connected to the CPU Unit is supplied through the NX bus. Additionally use this NX Unit in the following cases. a. When the I/O power supply capacity is insufficient • When the total current consumption for the I/O power supply exceeds 4 A • When a voltage drop in the I/O power supply causes the voltage of the I/O power supply to go below the voltage specifications of the I/O circuits or connected external devices b. Separating the I/O power supply • When connected external devices have different I/O power supply voltages • When separating the power supply systems Case (a)  When the I/O power supply becomes the following states for the subsequent NX Units. • When it exceeds 4 A • When it goes below the voltage specifications of the connected external devices *1. The NX Unit to which I/O power is supplied from the NX bus Case (b)  • When different I/O power supply voltage are used. • When separating the power supply systems. *1. The NX Unit to which I/O power is supplied from the NX bus The NX Unit power supply of the Additional I/O Power Supply Unit is connected to the NX Unit on the left through the NX bus connector.

Unit name	Function
I/O Power Supply Connection Unit	This NX Unit is used when there are not enough I/O power supply terminals for the connected external devices that are connected to NX Units such as Digital I/O Units and Analog I/O Units.  I/O power supply is not separated in I/O Power Supply Connection Unit NX-series CPU Unit Additional I/O Power Supply Unit I/O Power Supply Connection Unit NX Unit Unit power supply Internal power supply circuit I/O power supply I/O power supply I/O power supply Not enough I/O power supply terminals Example of NPN type  I/O Power Supply Connection Unit (16 IOV terminals) I/O Power Supply Connection Unit (16 IOG terminals) DC Input Unit (NPN type) Two-wire sensor* (e.g., limit switch) Three-wire sensor with NPN output* (e.g., photoelectric sensor or proximity sensor) Brown (White) Blue (Black) Black (White) Brown (Red) Blue (Black) * Wire colors have been changed according to revisions in the JIS standards for photoelectric and proximity sensors. The colors in parentheses are the wire colors prior to the revisions.

4-3 Wiring the Power Supply to the Slave Terminal

This section describes how to supply power to the Slave Terminal and wiring.

4-3-1 Power Supply Types

There are the following two types of power supplies that supply power to the Slave Terminal.


Power supply name	Description
Unit power supply	This is the power supply for generating the NX Unit power supply required for the Slave Terminal to operate. This is connected to the Unit power supply terminal on the Communications Coupler Unit or on the Additional NX Unit Power Supply Unit. The internal power supply circuit in the Communications Coupler Unit or the Additional NX Unit Power Supply Unit generates the NX Unit power supply from the Unit power supply. The internal circuits of the Communications Coupler Unit and NX Units operate by the NX Unit power supply. The NX Unit power supply is supplied to the NX Units in the Slave Terminal through the NX bus connectors.
I/O power supply	This power supply is used for driving the I/O circuits of the NX Units and for the connected external devices. There are the following two I/O power supply methods. Either supply method used depends on each model of NX Unit. • Supply from the NX bus • Supply from external source Refer to 4-3-2 <i>Supplying Each Power Supply and Wiring</i> on page 4-15 for the details on the power supply methods.

4-3-2 Supplying Each Power Supply and Wiring

The supply method for each power supply to the NX Units is as follows.

Power supply name	Description
NX Unit power supply	This power is supplied to the NX Units through the NX bus connectors by connecting a Unit power supply to the Unit power supply terminals on the Communications Coupler Unit or Additional NX Unit Power Supply Units.
I/O power supply	This power is supplied by one of the following two methods. • Supply from the NX bus This power is supplied through the NX bus connectors by connecting an I/O power supply to the I/O power supply terminals on the Communications Coupler Unit or Additional I/O Power Supply Units. • Supply from external source This power is supplied to the Units from an external source. I/O power is supplied by connecting an I/O power supply to the I/O power supply terminals on the Units. For the supply method that you will use for an NX Unit model, refer to the data sheet in the user's manual for the NX Unit or <i>NX-series Data Reference Manual (Cat. No. W525)</i>. Refer to A-1 <i>Data Sheet</i> on page A-2 for the supply method for each System Unit model.

The following are wiring diagrams (examples) for each power supply.



Precautions for Correct Use

Always use separate power supplies for the Unit power supply and the I/O power supply. If you supply power from the same power supply, noise may cause malfunctions.



Additional Information

Refer to the user's manual for the Communications Coupler Unit on design for power supply to the Slave Terminal.



4-3-3 Power Supply-related Units and Wiring Methods



The Communications Coupler Unit supplies the NX Unit power and I/O power to the NX Units in the Slave Terminal.

There are the following types of NX-series power supply-related Units other than Communications Coupler Unit.

Refer to NX-series catalogs or OMRON websites, or ask your OMRON representative for information on the most recent lineup of NX Units.

Unit name	Function
Additional NX Unit Power Supply Unit	This NX Unit provides NX Unit power supply. This NX Unit is used when the total power consumption of the NX Units in the Slave Terminal exceeds the NX Unit power supply capacity of the Communications Coupler Unit. The total power consumption from the NX Unit power supply is within the NX Unit power supply capacity. The total power consumption from the NX Unit power supply is within the NX Unit power supply capacity. The I/O power supply for the Additional NX Unit Power Supply Unit is connected to the NX Unit on the left through the NX bus connector.

Unit name	Function
Additional I/O Power Supply Unit	This NX Unit provides additional I/O power supply. Use this NX Unit in the following cases. a. When the I/O power supply capacity is insufficient - When the total current consumption for the I/O power supply exceeds the maximum current of I/O power supply of the Communications Coupler Unit - When a voltage drop in the I/O power supply causes the voltage of the I/O power supply to go below the voltage specifications of the I/O circuits or connected external devices b. Separating the I/O power supply - When connected external devices have different I/O power supply voltages - When separating the power supply systems Case (a)  Separated by Additional I/O Power Supply Unit Communications Coupler Unit NX Unit Additional I/O Power Supply Unit Internal power supply circuit I/O power supply Unit power supply When the I/O power supply becomes the following states for the subsequent NX Units. - When it exceeds the maximum current of I/O power supply - When it goes below the voltage specifications of the connected external devices Case (b)  Separated by Additional I/O Power Supply Unit Communications Coupler Unit NX Unit Additional I/O Power Supply Unit Internal power supply circuit I/O power supply Unit power supply - When different I/O power supply voltage are used. - When separating the power supply systems. The NX Unit power supply of the Additional I/O Power Supply Unit is connected to the NX Unit on the left through the NX bus connector.

Unit name	Function
I/O Power Supply Connection Unit	This NX Unit is used when there are not enough I/O power supply terminals for the connected external devices that are connected to NX Units such as Digital I/O Units and Analog I/O Units.  Example of NPN type  * Wire colors have been changed according to revisions in the JIS standards for photoelectric and proximity sensors. The colors in parentheses are the wire colors prior to the revisions.

4-4 Wiring the Power Supply to the Communication Control Unit

This section describes the methods of power supplying and wiring with NX Unit in a CPU Rack when connecting NX Unit with NX-series Communication Control Unit.

4-4-1 Power Supply Types

There are the following two types of power supplies that supply power to the CPU Rack of the Communication Control Unit.

Power supply name	Description
Unit power supply	This is the power supply for generating the internal power supply required for the CPU Rack to operate. This power supply is connected to the Unit power supply terminals on the Communication Control Unit or Additional NX Unit Power Supply Unit. From the Unit power supply, the internal power supply circuit in the Communication Control Unit generates the power supply to the internal circuit of the Communication Control Unit and NX Unit power supply. The internal power supply circuit in the Additional NX Unit Power Supply Unit generates the NX Unit power supply from the Unit power supply. The internal circuits of the NX Unit operates on the NX Unit power supply. The NX Unit power supply is supplied to the NX Units in the CPU Rack through the NX bus connectors.
I/O power supply	This power supply is used for driving the I/O circuits of the NX Units and for the connected external devices. There are the following two I/O power supply methods. Either supply method used depends on each model of NX Unit. • Supply from the NX bus • Supply from external source Refer to 4-4-2 <i>Supplying Each Power Supply and Wiring</i> on page 4-20 for the details on the power supply methods.


4-4-2 Supplying Each Power Supply and Wiring

The supply method for each power supply to the NX Units is as follows.

Power supply name	Description
NX Unit power supply	This power is supplied to the NX Units through the NX bus connectors by connecting a Unit power supply to the Unit power supply terminals on the Communication Control Unit or Additional NX Unit Power Supply Units.

Power supply name	Description
I/O power supply	This power is supplied by one of the following two methods. - Supply from the NX bus This power is supplied through the NX bus connectors by connecting an I/O power supply to the I/O power supply terminals on the Communication Control Unit or Additional I/O Power Supply Unit. - Supply from external source This power is supplied to the Units from an external source. I/O power is supplied by connecting an I/O power supply to the I/O power supply terminals on the Units. For the supply method that you will use for an NX Unit model, refer to the data sheet in the user's manual for the NX Unit or <i>NX-series Data Reference Manual (Cat. No. W525)</i>. Refer to A-1 Data Sheet on page A-2 for the supply method for each System Unit model.

The following are wiring diagrams (examples) for each power supply.





Precautions for Correct Use

Always use separate power supplies for the Unit power supply and the I/O power supply. If you supply power from the same power supply, noise may cause malfunctions.



Additional Information


Refer to the hardware user's manual for the Communication Control Unit for the designing of the power supply to the CPU Rack of the Communication Control Unit.



4-4-3 Power Supply-related Units and Wiring Methods



The Communication Control Unit supplies the NX Unit power and I/O power to the NX Units in the CPU Rack.

There are the following types of NX-series power supply-related Units other than Communication Control Unit.

Refer to NX-series catalogs or OMRON websites, or ask your OMRON representative for information on the most recent lineup of NX Units.

Unit name	Function
Additional NX Unit Power Supply Unit	This NX Unit provides NX Unit power supply. This NX Unit is used when the total power consumption of the NX Units in the CPU Rack exceeds the NX Unit power supply capacity of the Communication Control Unit. The total power consumption from the NX Unit power supply is within the NX Unit power supply capacity. The total power consumption from the NX Unit power supply is within the NX Unit power supply capacity.  The I/O power supply for the Additional NX Unit Power Supply Unit is connected to the NX Unit on the left through the NX bus connector.

Unit name	Function
Additional I/O Power Supply Unit	This NX Unit provides additional I/O power supply. Use this NX Unit in the following cases. a. When the I/O power supply capacity is insufficient - When the total current consumption for the I/O power supply exceeds the maximum current of I/O power supply of the Communication Control Unit - When a voltage drop in the I/O power supply causes the voltage of the I/O power supply to go below the voltage specifications of the I/O circuits or connected external devices b. Separating the I/O power supply - When connected external devices have different I/O power supply voltages - When separating the power supply systems. Case (a)  Separated by Additional I/O Power Supply Unit Communication Control Unit NX Unit Additional I/O Power Supply Unit Internal power supply circuit I/O power supply Unit power supply When the I/O power supply becomes the following states for the subsequent NX Units. - When it exceeds the maximum current of I/O power supply - When it goes below the voltage specifications of the connected external devices Case (b)  Separated by Additional I/O Power Supply Unit Communication Control Unit NX Unit Additional I/O Power Supply Unit Internal power supply circuit I/O power supply Unit power supply - When different I/O power supply voltage is used. - When separating the power supply systems. The NX Unit power supply of the Additional I/O Power Supply Unit is connected to the NX Unit on the left through the NX bus connector.

Unit name	Function
I/O Power Supply Connection Unit	This NX Unit is used when there are not enough I/O power supply terminals for the connected external devices that are connected to NX Units such as Digital I/O Units and Analog I/O Units.  I/O power supply is not separated at the I/O Power Supply Connection Units. Communication Control Unit NX Unit Additional I/O Power Supply Unit I/O Power Supply Connection Unit Internal power supply circuit I/O power supply Unit power supply Not enough I/O power supply terminals Example of NPN type  I/O Power Supply Connection Unit (16 IOV terminals) A1 B1 IOV IOV IOV IOV IOV IOV IOV IOV IOV IOV IOV IOV IOV IOV A8 B8 I/O Power Supply Connection Unit (16 IOG terminals) A1 B1 IOG IOG IOG IOG IOG IOG IOG IOG IOG IOG IOG IOG IOG IOG A8 B8 DC Input Unit (NPN type) A1 B1 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 A8 B8 Two-wire sensor* (e.g. limit switch) Brown (White) Blue (Black) Three-wire sensor with NPN output* (photoelectric sensor or proximity sensor) Black (White) Brown (Red) Blue (Black) * Wire colors have been changed according to revisions in the JIS standards for photoelectric and proximity sensors. The colors in parentheses are the wire colors prior to the revisions.

4-5 Wiring of Grounding

This section describes how to ground the CPU Rack and the Slave Terminal.

Units with Functional Ground Terminals in CPU Rack of CPU Unit

Some of the Units in a CPU Rack of the NX-series CPU Unit have the following functional ground terminals.

- CPU Unit
- Additional NX Unit Power Supply Unit
- Shield Connection Unit



Additional Information

A Shield Connection Unit is used to connect the shield when connecting to external input devices. You can ground more than one shield to the same ground pole to reduce the amount of wiring work for grounding.

Refer to the hardware user's manual for the connected CPU Unit for the details on the ground terminals for the CPU Rack.

Units with Functional Ground Terminals in Slave Terminal

Some of the NX Units in a Slave Terminal have the following functional ground terminals.

- Communications Coupler Unit
- Additional NX Unit Power Supply Unit
- Shield Connection Unit



Additional Information

A Shield Connection Unit is used to connect the shield when connecting to external input devices. You can ground more than one shield to the same ground pole to reduce the amount of wiring work for grounding.

Refer to the user's manual for the connected Communications Coupler Unit for details on grounding the Slave Terminal.

Units with Functional Ground Terminals in CPU Rack of Communication Control Unit

Some of the Units in a CPU Rack of the NX-series Communication Control Unit have the following functional ground terminals.

- Communication Control Unit
- Additional NX Unit Power Supply Unit
- Shield Connection Unit



Additional Information

A Shield Connection Unit is used to connect the shield when connecting to external input devices. You can ground more than one shield to the same ground pole to reduce the amount of wiring work for grounding.

Refer to the user's manual for the connected Communication Control Unit for details on grounding the CPU Rack.

4-6 Wiring the Additional Power Supply Units

This section describes how to wire the terminals on the Additional Power Supply Units.

WARNING

Make sure that the voltages and currents that are input to the Units and slaves are within the specified ranges. Inputting voltages or currents that are outside of the specified ranges may cause accidents or fire.




CAUTION

When you connect a computer or other peripheral device to any of the following NX Units, ground the 0 V side of an external power supply (Unit power supply) or do not ground it at all.

- Communications Coupler Unit with non-isolated type internal power supply circuits
- Communications Coupler Unit that is connected to a non-isolated type Additional NX Unit Power Supply Unit

Depending on how the peripheral device is grounded, the external power supply (Unit power supply) may be shorted. Never ground the 24 V side of the power supply as shown in the figure below.

<Grounding that causes a 24-V power supply to short>



4-6-1 Wiring the Additional NX Unit Power Supply Unit

This section describes how to wire Additional NX Unit Power Supply Unit.

Wiring Terminals

- Unit power supply terminals
- Functional ground terminals


Wiring Examples

The Unit power supply is connected to the Unit power supply terminal (UV/UG).

You can use the unwired terminals of the Unit power supply terminals for through-wiring to the Unit power supply terminals on an Additional NX Unit Power Supply Unit, other CPU Units to which NX Units can be connected, other Communications Coupler Units or another Communication Control Unit. Make the current supplied from the unwired terminals meet the following conditions.

"Current supplied from unwired terminals" ≤ "Current capacity of power supply terminal" - "Current consumption of Additional NX Unit Power Supply Unit block"

Refer to *Required Power Supply Capacity* on page 4-29 for information on the block.



Ground the functional ground terminal to 100 Ω or less.

Power Supply Used

24 VDC power is supplied to the Unit power supply terminals. The power supply voltage range for the Unit power supplies is as follows.

Model	Power supply voltage range
NX-PD1000	20.4 to 28.8 VDC

Use an SELV power supply that meets the following conditions for the Unit power supply.

- Has overcurrent protection.
- Has double or reinforced insulation between the input and output.
- Has an output voltage that falls within the power supply voltage range for the Unit power supply.

We recommend the following power supply.

Recommended power supply in a CPU Rack: Model S8VK-S series (Omron)

Recommended power supply in a Slave Terminal: Model S8VK-S series or Model S8JX series (Omron)



Precautions for Correct Use

- Use the same Unit power supply to supply power to the entire CPU Rack. If you supply power from different power supplies, differences in electrical potential may cause unexpected currents in the NX Unit power supply, which may result in failure or malfunction.
- Use the same Unit power supply to supply power to the entire Slave Terminal. If you supply power from different power supplies, differences in electrical potential may cause unexpected currents in the NX Unit power supply, which may result in failure or malfunction.

Required Power Supply Capacity

The equation for the Unit power supply capacity in the CPU Rack and in the Slave Terminal is as follows.

● Equation in a CPU Rack of CPU Unit

<Equation>

The equation for the Unit power supply capacity in the CPU Rack of CPU Unit is as follows.

$$\text{Unit power supply capacity in the CPU Rack} = \text{Total power capacity from Unit power supply on each block}$$


The equation for the Unit power supply capacity on each block in the CPU Rack is as follows.

- Required Unit power supply capacity of each block in the CPU Unit= (A) + ((B)/(C))
- Unit power supply capacity of Additional NX Unit Power Supply Unit block = ((D) + (E))/(F)

(A): Unit power consumption of a CPU Unit
(B): Total power consumption from the NX Unit power supply that is required by the NX Units that are connected to the CPU Unit
(C): NX Unit power supply efficiency of the CPU Unit
(D): NX Unit power consumption of the additional NX Unit Power Supply Unit
(E): Total power consumption from the NX Unit power supply that is required by the NX Units that are connected to the Additional NX Unit Power Supply Unit
(F): NX Unit power supply efficiency of the Additional NX Unit Power Supply Unit

<Block>

The following shows the Unit that supplies NX Unit power and its supplying range. For example, the CPU Rack in the following diagram is configured with two blocks: the CPU Unit block and the Additional NX Unit Power Supply Unit block.



The total Unit power supply capacity for these two blocks is the power supply capacity that the CPU Rack requires.



Precautions for Correct Use

Select a Unit power supply with sufficient capacity by considering the inrush current when the power is turned ON. Sometimes, the Unit power supply may not be turned ON caused by inrush current when the power is turned ON.

● Equation in the Slave Terminal

<Equation>

The equation for the Unit power supply capacity in the Slave Terminal is as follows.

Unit power supply capacity in the Slave Terminal = Total power capacity from Unit power supply on each block

The equation for the Unit power supply capacity on each block in the Slave Terminal is as follows.

Required Unit power supply capacity of each block = $((A) + (B)) / (C)$


(A): NX Unit power consumption of the Unit that supplies NX Unit power

(B): Total power consumption from the NX Unit power supply that is required by the NX Units that are connected to the Unit that supplies NX Unit power

(C): NX Unit power supply efficiency of the Unit that supplies NX Unit power

<Block>

The following shows the Unit that supplies NX Unit power and its supplying range. For example, the Slave Terminal in the following diagram is configured with two blocks: the Communications Coupler Unit block and the Additional NX Unit Power Supply Unit block.



The total Unit power supply capacity for these two blocks is the power supply capacity that the Slave Terminal requires.



Precautions for Correct Use

Select a Unit power supply with sufficient capacity by considering the inrush current when the power is turned ON. Sometimes, the Unit power supply may not be turned ON caused by inrush current when the power is turned ON.

● Equation in a CPU Rack of Communication Control Unit

<Equation>

The equation for the Unit power supply capacity in the CPU Rack of Communication Control Unit is as follows.

Unit power supply capacity in the CPU Rack = Total power capacity from Unit power supply on each block

The equation for the Unit power supply capacity on each block in the CPU Rack is as follows.

- Required Unit power supply capacity of each block in the Communication Control Unit = $(A) + ((B)/(C))$
- Unit power supply capacity of Additional NX Unit Power Supply Unit block = $((D) + (E))/(F)$

(A): Unit power consumption of a Communication Control Unit

(B): Total power consumption from the NX Unit power supply that is required by the NX Units that are connected to the Communication Control Unit

(C): NX Unit power supply efficiency of the Communication Control Unit


(D): NX Unit power consumption of the additional NX Unit Power Supply Unit

(E): Total power consumption from the NX Unit power supply that is required by the NX Units that are connected to the Additional NX Unit Power Supply Unit

(F): NX Unit power supply efficiency of the Additional NX Unit Power Supply Unit

<Block>

The following shows the Unit that supplies NX Unit power and its supplying range. For example, the CPU Rack in the following diagram is configured with two blocks: the Communication Control Unit block and the Additional NX Unit Power Supply Unit block.



The total Unit power supply capacity for these two blocks is the power supply capacity that the CPU Rack requires.



Precautions for Correct Use

Select a Unit power supply with sufficient capacity by considering the inrush current when the power is turned ON. Sometimes, the Unit power supply may not be turned ON caused by inrush current when the power is turned ON.

4-6-2 Wiring the Additional I/O Power Supply Unit

This section describes how to wire Additional I/O Power Supply Unit.

For the terminal array for each model, refer to the terminal connection diagram for each model in *A-1 Data Sheet* on page A-2.


Wiring Terminals

- I/O power supply terminals


Wiring Examples

The external power supply is connected to the A1 and A3 terminals of the I/O power supply terminals. The other I/O power supply terminals can be used for power supply for connected external devices.

● NPN Type (NX-ID5342)



● PNP Type (NX-ID5442)



Additional Information

Wire colors have been changed according to revisions in the JIS standards for photoelectric and proximity sensors. The colors in parentheses are the wire colors prior to the revisions.

Power Supply Used and Required Power Supply Capacity

● Power Supply Used

5 to 24 VDC power is supplied to A1 and A3 terminals of the I/O power supply terminals.

Use an SELV power supply that meets the following conditions for the I/O power supply.

- Has overcurrent protection.
- Has double or reinforced insulation between the input and output.
- Has an output voltage of 5 to 24 VDC (4.5 to 28.8 VDC).^{*1}

^{*1}. Use an output voltage that is appropriate for the I/O circuits of the NX Units and the connected external devices.

We recommend the following power supply.

Recommended power supply in a CPU Rack: Model S8VK-S series (Omron)

Recommended power supply in a Slave Terminal: Model S8VK-S series or Model S8JX series (Omron)

● Required Power Supply Capacity

The power supply capacity required by the I/O power supply to be connected is equal to the NX Unit power supply total power consumption that uses the same I/O power supply. Refer to *Calculation Example for Power Supply Capacity of I/O Power Supply* on page 4-36 for details on calculating the required power supply capacity.

However, if the inrush current occurs when a connected external device turns ON or OFF, do not allow the effective value of the I/O power supply current including the inrush current to exceed the following rated values.

Connecting destination of Additional I/O Power Supply Unit	Rated item	Rating
NX1P2 CPU Unit	Maximum current of I/O power supply	4 A max. ^{*1}
	Current capacity of I/O power supply terminals	
• NX502 CPU Unit • NX102 CPU Unit • Communications Coupler Unit • Communication Control Unit	Maximum current of I/O power supply	Less than the rating of Additional I/O Power Supply Unit
	Current capacity of I/O power supply terminals	

^{*1}. When the Additional I/O Power Supply Unit is connected to the NX1P2 CPU Unit, use the I/O power supply current at 4 A or less, regardless of the Additional I/O Power Supply Unit specifications.

Refer to *A-1 Data Sheet* on page A-2 for details on the ratings for Additional I/O Power Supply Unit.



Precautions for Safe Use

The I/O power supply current for the CPU Rack with an NX-series CPU Unit should be within the range specified for the CPU Unit model. For example, use the NX1P2 CPU Unit with a current of 4 A or less. Using the currents that are outside of the specifications may cause failure or corruption. Refer to the user's manual for the connected CPU Unit for the I/O power supply current for the CPU Unit model.

Do not allow the inrush current to exceed the values in the table below.

Connecting destination of Additional I/O Power Supply Unit	Model of Additional I/O Power Supply Unit	Peak value	Pulse width
NX1P2 CPU Unit	NX-PF0730	20 A ^{*1}	1 s ^{*1}
	NX-PF0630		
- NX502 CPU Unit - NX102 CPU Unit - Communications Coupler Unit - Communication Control Unit	NX-PF0730	50 A	1 s
	NX-PF0630	20 A	1 s

*1. When the Additional I/O Power Supply Unit is connected to the NX1P2 CPU Unit, the value will be as described on this table, regardless of the specification of the Additional I/O Power Supply Unit.

For the ratings of the Communications Coupler Unit or Communication Control Unit that can supply I/O power, refer to a description of inrush current restrictions in the user's manual for the Communications Coupler Unit or Communication Control Unit.

Calculating the effective value of the I/O power supply current

The following gives the equation to calculate the effective value of the I/O power supply current, I_{rms} .

$$I_{rms} = \sqrt{I_p^2 \times D + I_a^2 \times (1-D)}$$

$$(D = \tau / T)$$

I_p : Peak inrush current (A)


I_{rms} : Effective value of the I/O power supply current (A)

I_a : Total current consumption from I/O power supply (A)

D : Inrush current duty

τ : Inrush current pulse width (s)

T : Inrush current period (s)



For details on the current consumption from I/O power supply of the NX Units to be used, refer to the user's manual for individual NX Units.

For details on calculating current consumption from I/O power supply, refer to the design of the I/O power supply from the NX bus described in the user's manual for the connected CPU Unit, Communications Coupler Unit, or Communication Control Unit.




Precautions for Correct Use

Select an I/O power supply with sufficient capacity by considering the inrush current when the power is turned ON. Sometimes, the I/O power supply may not be turned ON caused by inrush current when the power is turned ON.

● **Calculation Example for Power Supply Capacity of I/O Power Supply**

An example of calculating the required power supply capacity of the I/O power supply is given below.

a. Configuration and Conditions



Item		Condition
I/O power supply voltage		24 VDC
Inputs	Number of inputs used (that turn ON simultaneously)	4 points
	Current consumption of connected input devices	50 mA/point
Outputs	Number of outputs (that turn ON simultaneously)	4 points
	Load current of connected loads	125 mA/point
	Current consumption of connected output devices	50 mA/point

I/O power is supplied to the NX-ID3317 and NX-OD3121 from the NX bus.

b. Unit Specifications

Model	Current consumption from I/O power supply	Input current
NX-PF0730	10 mA	---
NX-ID3317	0 mA	6 mA/point
NX-OD3121	10 mA	---

c. Calculations

The current consumption from the I/O power supply for each Unit is calculated as follows.

NX-PF0730 Current Consumption	$= (\text{Current consumption from I/O power supply})$ $= 10 \text{ mA}$
-------------------------------	--

NX-ID3317 Current Consumption	$= (\text{Current consumption from I/O power supply}) + (\text{Input current} \times \text{Number of inputs used})$ $+ (\text{Total current consumption of connected input devices})$ $= 0 \text{ mA} + (6 \text{ mA} \times 4 \text{ points}) + (50 \text{ mA} \times 4 \text{ points})$ $= 224 \text{ mA}$
-------------------------------	--

NX-OD3121 Current Consumption	$= (\text{Current consumption from I/O power supply}) + (\text{Total load current of connected loads})$ $+ (\text{Total current consumption of connected output devices})$ $= 10 \text{ mA} + (125 \text{ mA} \times 4 \text{ points}) + (50 \text{ mA} \times 4 \text{ points})$ $= 710 \text{ mA}$
-------------------------------	--

The required power supply capacity for the I/O power supply is calculated as follows.

Power supply capacity of I/O power supply	$= (\text{Current consumed by NX-PF0730}) + (\text{Current consumed by NX-ID3317})$ $+ (\text{Current consumed by NX-OD3121})$ $= 10 \text{ mA} + 224 \text{ mA} + 710 \text{ mA}$ $= 944 \text{ mA}$
---	---

4-6-3 Protective Devices

This section describes the protective devices to protect against short circuits and overcurrents of external circuits.

Overcurrent means the current that flows when an excessive load is connected and one of the following ratings is exceeded.

Unit name of supplying Unit	Connecting destination of supplying Unit	Rated item	Rating
Additional NX Unit Power Supply Unit	• CPU Unit • Communications Coupler Unit • Communication Control Unit	NX Unit power supply capacity	Less than the rating of Additional NX Unit Power Supply Unit
		Current capacity of power supply terminals	
Additional I/O Power Supply Unit	NX1P2 CPU Unit	Maximum current of I/O power supply	4 A max.*1
		Current capacity of I/O power supply terminals	
	• NX502 CPU Unit • NX102 CPU Unit • Communications Coupler Unit • Communication Control Unit	Maximum current of I/O power supply	Less than the rating of Additional I/O Power Supply Unit
		Current capacity of I/O power supply terminals	

*1. When the Additional I/O Power Supply Unit is connected to the NX1P2 CPU Unit, use the I/O power supply current at 4 A or less, regardless of the Additional I/O Power Supply Unit specifications.

Refer to *A-1 Data Sheet* on page A-2 for details on the ratings for NX-series power supply-related Units.

For the rating of the CPU Unit, Communications Coupler Unit, or Communication Control Unit that can supply I/O power, refer to the following manuals depending on the connected Unit.

- CPU Unit Hardware User's Manual
- User's manual for the Communications Coupler Unit
- User's manual for the Communication Control Unit

Refer to the user's manual for the connected Communications Coupler Unit or Communication Control Unit for the ratings of the Communications Coupler Unit or Communication Control Unit that can supply I/O power.



Precautions for Safe Use

The I/O power supply current for the CPU Rack with an NX-series CPU Unit should be within the range specified for the CPU Unit model. For example, use the NX1P2 CPU Unit with a current of 4 A or less. Using the currents that are outside of the specifications may cause failure or corruption. Refer to the user's manual for the connected CPU Unit for the I/O power supply current for the CPU Unit model.

● Selecting Protective Devices

For selecting the protective devices, refer to the following manuals depending on the connected Unit.

- CPU Unit Hardware User's Manual
- User's manual for the Communications Coupler Unit
- User's manual for the Communication Control Unit

Refer to *Required Power Supply Capacity* on page 4-34 for information on the inrush current that occurs when external devices connected to an Additional I/O Power Supply Unit are turned ON or OFF, which is one of the items to consider when you select protective devices.

● Installation Locations for Protective Devices

For installation locations for protective devices, refer to the following manuals depending on the connected Unit.

- CPU Unit Hardware User's Manual
- User's manual for the Communications Coupler Unit
- User's manual for the Communication Control Unit

4-7 Wiring the I/O Power Supply Connection Unit

The I/O Power Supply Connection Unit is used as additional I/O power supply terminals when there are not enough I/O power supply terminals in which it is connected to the connected external devices. This section describes how to wire the I/O Power Supply Connection Unit.

Wiring Terminals

IOV or IOG terminal


Wiring Examples

A wiring example is shown below.
I/O power supply terminals can be used for power supply for connected external devices.
It is not possible to supply I/O power from the external power supply to this Unit.


● Wiring Example 1

When the I/O Power Supply Connection Unit (NX-PC0030) is connected to a Digital Input Unit (16 inputs)

NPN type (NX-ID5342)



PNP type (NX-ID5442)



Note Connecting three-wire sensors to all 16 inputs requires two NX-PC0030 Units.




Additional Information


Wire colors have been changed according to revisions in the JIS standards for photoelectric and proximity sensors. The colors in parentheses are the wire colors prior to the revisions.

● Wiring Example 2

When the I/O Power Supply Connection Unit (NX-PC0020 or NX-PC0010) is connected to a Digital Output Unit (16 outputs)

NPN type (NX-OD5121)







● **Wiring Example 3**

When the I/O Power Supply Connection Unit (NX-PC0020 or NX-PC0010) is connected to an Analog Input Unit (8 inputs, single-ended inputs)

For voltage 8 inputs (NX-AD4603)



For current 8 inputs (NX-AD4203)



4-8 Wiring the Shield Connection Unit

The Shield Connection Unit is used when there are not enough terminals to connect the shield for the connection of external devices.


This section describes how to wire the Shield Connection Unit.

Wiring Terminals

- SHLD terminal
- Functional ground terminals

Wiring Examples

The following shows a wiring example in which the shield wire is used to connect an Incremental Encoder Input Unit (NX-EC0122) and a rotary encoder to the Shield Connection Unit.



Connect the shield of cable to the SHLD terminal.

And ground the functional ground terminal to 100 Ω or less.

Refer to the hardware user's manual for the connected CPU Unit for details on grounding the CPU Rack of CPU Unit.

Refer to the user's manual for the connected Communications Coupler Unit for details on grounding the Slave Terminal.

Refer to the user's manual for the connected Communication Control Unit for details on grounding the CPU Rack of the Communication Control Unit.

4-9 Wiring the Terminals

This section describes how to wire the terminals on the System Units.



WARNING

Make sure that the voltages and currents that are input to the Units and slaves are within the specified ranges. Inputting voltages or currents that are outside of the specified ranges may cause accidents or fire.



4-9-1 Wiring to the Screwless Clamping Terminal Blocks

This section describes how to connect wires to the screwless clamping terminal blocks, the installation and removing methods, and functions for preventing incorrect attachment.

You can connect ferrules that are attached to the twisted wires to the screwless clamping terminal block. You can also connect the twisted wires or the solid wires to the screwless clamping terminal block. If you connect the ferrules, all you need to do to connect the wires is to insert the ferrules into the terminal holes.

Wiring Terminals

The terminals to be wired are as follows.

- Unit power supply terminals
- I/O power supply terminals
- SHLD terminal
- Functional ground terminals


Applicable Wires

You can connect twisted wires, solid wires, or ferrules attached to twisted wires to the screwless clamping terminal block. The applicable wire dimensions and preparation methods are given below.

● Dimensions of Wires Connected to the Terminal Block

The dimensions of wires that you can connect into the terminal holes of the screwless clamping terminal block are as in the figure below.

Process the applicable wires that are specified in the following description to apply the dimensions.



● Using Ferrules

If you use ferrules, attach the twisted wires to them.

Observe the application instructions for your ferrules for the wire stripping length when attaching ferrules.


Always use plated one-pin ferrules. Do not use unplated ferrules or two-pin ferrules.

The applicable ferrules, wires, and crimping tools are given in the following table.

Terminal type	Manufacturer	Ferrule model	Applicable wire (mm ² (AWG))	Crimping tool
All terminals except ground terminals	Phoenix Contact	AI0,34-8	0.34 (#22)	Phoenix Contact (Applicable wire sizes are given in parentheses.) CRIMPFOX 6 (0.25 to 6 mm ² , AWG24 to 10)
		AI0,5-8	0.5 (#20)	
		AI0,5-10		
		AI0,75-8	0.75 (#18)	
		AI0,75-10		
		AI1,0-8	1.0 (#18)	
		AI1,0-10		
		AI1,5-8	1.5 (#16)	
		AI1,5-10		
Ground terminals		AI2,5-10	2.0*1	
All terminals except ground terminals	Weidmuller	H0.14/12	0.14 (#26)	Weidmuller (Applicable wire sizes are given in parentheses.) PZ6 Roto (0.14 to 6 mm ² , AWG26 to 10)
		H0.25/12	0.25 (#24)	
		H0.34/12	0.34 (#22)	
		H0.5/14	0.5 (#20)	
		H0.5/16		
		H0.75/14	0.75 (#18)	
		H0.75/16		
		H1.0/14	1.0 (#18)	
		H1.0/16		
		H1.5/14	1.5 (#16)	
		H1.5/16		

*1. For the ferrule type AI2,5-10, use wires with a diameter of 2.0 to 2.1 mm². Wires with a diameter exceeding 2.1 mm² cannot be used with the screwless clamping terminal block.

When you use any ferrules other than those in the above table, crimp them to the twisted wires so that the following processed dimensions are achieved.



● Using Twisted Wires/Solid Wires

If you use twisted wires or solid wires, use the following table to determine the correct wire specifications.

Terminals		Wire type				Wire size	Conductor length (stripping length)
		Twisted wires		Solid wires			
Classification	Current capacity	Plated	Unplated	Plated	Unplated		
All terminals except ground terminals	2 A max.	Possible	Possible	Possible	Possible	0.08 to 1.5 mm ² (AWG28 to 16)	8 to 10 mm
	Greater than 2 A and 4 A or less		Not possible	Possible* ¹	Not possible		
	Greater than 4 A	Possible* ¹		Not possible			
Ground terminals	---	Possible	Possible	Possible* ²	Possible* ²	2.0 mm ²	9 to 10 mm

*1. Secure wires to the screwless clamping terminal block. Refer to *Securing Wires* on page 4-51 for how to secure wires.

*2. With the NX-TB□□□1 Terminal Block, use twisted wires to connect the ground terminal. Do not use a solid wire.




Conductor length (stripping length)



Precautions for Correct Use


- Use cables with suitable wire sizes for the carrying current. There are also restrictions on the current due to the ambient temperature. Refer to the manuals for the cables and use the cables correctly for the operating environment.
- For twisted wires, strip the sheath and twist the conductor portion. Do not unravel or bend the conductor portion of twisted wires or solid wires.

NG



Unravel wires

NG



Bend wires




Additional Information

If more than 2 A will flow on the wires, use plated wires or use ferrules.

Connecting and Removing Wires

This section describes how to connect and remove wires.


● Terminal Block Parts and Names



● Required Tools

Use a flat-blade screwdriver to connect and remove wires.

Use the following flat-blade screwdriver.




Recommended screwdriver

Model	Manufacturer
SZF 0-0,4X2,5	Phoenix Contact

● Connecting Ferrules

Insert the ferrule straight into the terminal hole.

You do not need to insert a flat-blade screwdriver into the release hole.




After you make a connection, make sure that the ferrule is securely connected to the terminal block.


● Connecting Twisted Wires or Solid Wires

Use the following procedure to connect the twisted wires or solid wires to the terminal block.


- 1 Press a flat-blade screwdriver diagonally into the release hole.
The optimal angle for insertion is between 10° to 15° . If the screwdriver is inserted correctly, you should feel resistance from the spring inside the release hole.



- 2 Leave the flat-blade screwdriver pressed into the release hole and insert the twisted wire or the solid wire into the terminal hole.
Insert the stripped portion of the wire all the way into the terminal hole to prevent shorting.



3 Remove the flat-blade screwdriver from the release hole.




After you make a connection, lightly pull the twisted wire or the solid wire to make sure that the wire is securely connected to the terminal block.




Precautions for Safe Use

- Do not press the flat-blade screwdriver straight into the release holes on a screwless clamping terminal block. Doing so may damage the terminal block.

NG




OK




- When you insert a flat-blade screwdriver into a release hole on a screwless clamping terminal block, press it down with a force of 30N or less. Applying excessive force may damage the terminal block.
- Do not incline or twist the flat-blade screwdriver while it is in a release hole on a screwless clamping terminal block. Doing so may damage the terminal block.

NG



NG



- Make sure that all wiring is correct.
- Do not bend the cable forcibly. Doing so may break the cables.

● Securing Wires

It is necessary to secure wires to the screwless clamping terminal block depending on the wire types that are used or the current flows on the wires.


The following table gives the necessity for securing wires.

Terminals		Wire type				
Classifica- tion	Current ca- pacity	Ferrule	Twisted wires		Solid wires	
			Plated	Unplated	Plated	Unplated
All terminals except ground termi- nals	2 A max.	No	No	No	No	No
	Greater than 2 A and 4 A or less			Not possible	Yes	Not possible
	Greater than 4 A		Yes	Not possible	Not possible	Not possible
Ground termi- nals	---	No	No	No	No	No


Use the following procedure to secure the wires.

1 Prepare a cable tie.


A cable tie can be used with a width of 4 mm or less and a thickness of 1.5 mm or less. Select a cable tie correctly for the operating environment.




2 Pass a cable tie through the hole for securing wires on the bottom of the screwless clamping terminal block.



- 3** Bundle the wires with a cable tie and secure them to the screwless clamping terminal block.



Secure wires within the range of 30 mm from the screwless clamping terminal block.




● Removing Wires


Use the following procedure to remove the wires from the terminal block.
The removal method is the same for ferrules, twisted wires, and solid wires.

If wires are secured firmly to the terminal block, release them first.


- 1** Press the flat-blade screwdriver diagonally into the release hole.
The optimal angle for insertion is between 10° to 15°. If the screwdriver is inserted correctly, you should feel resistance from the spring inside the release hole.



- 2** Insert the flat-blade screwdriver into the release hole and remove the wire from the terminal hole.



- 3** Remove the flat-blade screwdriver from the release hole.







Precautions for Safe Use

- Do not press the flat-blade screwdriver straight into the release holes on a screwless clamping terminal block. Doing so may damage the terminal block.

NG




OK




- When you insert a flat-blade screwdriver into a release hole on a screwless clamping terminal block, press it down with a force of 30N or less. Applying excessive force may damage the terminal block.
- Do not incline or twist the flat-blade screwdriver while it is in a release hole on a screwless clamping terminal block. Doing so may damage the terminal block.

NG




NG



- Make sure that all wiring is correct.
- Do not bend the cable forcibly. Doing so may break the cables.

Removing a Terminal Block


- Press the lock lever on the terminal block and pull out the top of the terminal block to remove it.



Attaching a Terminal Block

- 1 Mount the terminal block hook that is applicable to each Unit model on the guide at the bottom of the NX Unit, lift up the terminal block, and press in on the top of the terminal block until you hear it engage.

The terminal block will click into place on the Unit. After you mount the terminal block, make sure that it is locked to the Unit.




Refer to *Applicable Terminal Blocks for Each Unit Model* on page 3-4 for the applicable terminal blocks.

4-9-2 Preventing Incorrect Attachment of Terminal Blocks

In order to prevent unintentionally installing the wrong terminal block, you can limit the combination of a Unit and a terminal block.


Insert three Coding Pins (NX-AUX02) into three of the six incorrect attachment prevention holes on the Unit and on the terminal block. Insert these pins into positions so that they do not interfere with each other when the Unit and terminal block are connected to each other.

You can use these pins to create a combination in which the wrong terminal block cannot be attached because the pin patterns do not match.



Types of Coding Pins

There are two types of Coding Pins, both with their own unique shape: one for terminal blocks and one for Units.
Three pins come with each runner.




Use the following Coding Pins.

Name	Model	Specification
Coding Pin	NX-AUX02	For 10 Units (Terminal block: 30 pins, Unit: 30 pins)

Insertion Locations and Patterns of Coding Pins

Insert three Coding Pins each on the terminal block and on the Unit at the positions designated by the numbers 1 through 6 in the figure below.
As shown in the following table, there are 20 unique pin patterns that you can use.



○: Pin inserted

Pattern	Pin locations for terminal block						Pin locations for Unit					
	1	2	3	4	5	6	1	2	3	4	5	6
No.1	○	○	○							○	○	○
No.2	○	○		○					○		○	○
No.3	○	○			○				○	○		○
No.4	○	○				○			○	○	○	
No.5	○		○	○				○			○	○
No.6	○		○		○			○		○		○
No.7	○		○			○		○		○	○	
No.8	○			○	○			○	○			○
No.9	○			○		○		○	○		○	
No.10	○				○	○		○	○	○		
No.11		○	○	○			○				○	○
No.12		○	○		○		○			○		○
No.13		○	○			○	○			○	○	
No.14		○		○	○		○		○			○
No.15		○		○		○	○		○		○	
No.16		○			○	○	○		○	○		
No.17			○	○	○		○	○				○
No.18			○	○		○	○	○			○	
No.19			○		○	○	○	○		○		
No.20				○	○	○	○	○	○			

Two sets of NX-AUX02 Pins are required to make the maximum of 20 pin patterns. (One set for 10 Units.)




Precautions for Correct Use

- The holes not designated by the numbers 1 through 6 in the above figure are used by OMRON. If you insert any Coding Pins into the holes reserved for use by OMRON, you will not be able to mount the terminal block to the Unit.
- Do not use Coding Pins that have been attached and removed.


Inserting the Coding Pins

- 1 Hold the pins by the runner and insert a pin into one of the incorrect attachment prevention holes on the terminal block or on the Unit.

Terminal block






Unit



- 2 Rotate the runner to break off the Coding Pin.

Terminal block





5

Troubleshooting

This section describes the error information and corrections for errors that can occur when the System Units are used.

5-1	How to Check for Errors	5-2
5-2	Checking for Errors with the Indicators	5-3
5-3	Checking for Errors and Troubleshooting on the Support Software	5-5
5-3-1	Checking for Errors from the Sysmac Studio	5-5
5-3-2	Checking for Errors from Support Software Other Than the Sysmac Studio	5-6
5-3-3	Event Codes and Corrections for Errors	5-6
5-3-4	Meaning of Error	5-7
5-4	Resetting Errors	5-11
5-5	Troubles Specific to Each Type of NX Units	5-12
5-5-1	Additional NX Unit Power Supply Unit	5-12
5-5-2	Additional I/O Power Supply Unit	5-12
5-6	Troubleshooting Flowchart	5-13

5-1 How to Check for Errors

Use one of the following error checking methods.

- Checking the indicators
- Troubleshooting with the Support Software

Refer to the troubleshooting manual for the CPU Unit, or the user's manual for the Communications Coupler Unit or Communication Control Unit that the NX Units are connected to for details on troubleshooting with the Support Software.

5-2 Checking for Errors with the Indicators

You can use the indicators on the System Units to check the status of System Units and level of errors.

This section describes the meanings of errors that the indicator shows and the troubleshooting procedures for them.

In this section, the status of the indicator is indicated with the following abbreviations.

Abbreviation	Indicator status
Lit	Lit
Not Lit	Not lit
FS ()	Flashing. The numeric value in parentheses is the flashing interval.
---	Undefined

Troubleshooting the Primary Errors

● All Units

TS indicator		Cause	Correction
Green	Red		
Lit	Not Lit	---	--- (This is the normal status.)
FS (2 s)	Not Lit	- Initializing - Downloading	--- (Normal. Wait until the processing is completed.)
Lit	Lit	This status is not present.	
Not Lit	Not Lit	The Unit power supply is not supplied.	Check the following items and supply the Unit power supply correctly. [Check Items for Power Supply] - Make sure that the power supply cable is wired correctly. - Make sure that the power supply cable is not disconnected. - Make sure that the power supply voltage is within the specified range. - Make sure that the power supply has enough capacity. - Make sure that power supply has not failed.
		- Waiting for initialization start - Restarting	--- (Normal. Wait until the processing is completed.)
		If you cannot resolve the problem after you check the above items and cycle the Unit power supply, the Unit may have a hardware failure. If this happens, replace the Unit.	
Not Lit	Lit	Hardware failure	If this error occurs after you cycle the Unit power supply, replace the Unit.
Not Lit	Lit	Non-volatile Memory Hardware Error	Refer to Event <i>Non-volatile Memory Hardware Error</i> on page 5-9.
Not Lit	FS (1 s)	This status is not present.	

● Additional NX Unit Power Supply Unit

UNIT PWR indicator	Cause	Correction
Green		
Lit	The Unit power supply is supplied.	--- (This is the normal status.)
Not Lit	The Unit power supply is not supplied.	Check the following items and supply the Unit power supply correctly. [Check Items for Power Supply] • Make sure that the power supply cable is wired correctly. • Make sure that the power supply cable is not disconnected. • Make sure that the power supply voltage is within the specified range. • Make sure that the power supply has enough capacity. • Make sure that power supply has not failed.

● Additional I/O Power Supply Unit

I/O PWR indicator	Cause	Correction
Green		
Lit	The I/O power is supplied.	--- (This is the normal status.)
Not Lit	The I/O power is not supplied.	Check the following items and supply the I/O power supply correctly. [Check Items for Power Supply] • Make sure that the power supply cable is wired correctly. • Make sure that the power supply cable is not disconnected. • Make sure that the power supply voltage is within the specified range. • Make sure that the power supply has enough capacity. • Make sure that power supply has not failed.

5-3 Checking for Errors and Troubleshooting on the Support Software

Error management on the NX Series is based on the methods used for the NJ/NX/NY-series Controllers.

This allows you to use the Support Software to check the meanings of errors and troubleshooting procedures.

The confirmation method depends on the Support Software that is used.

5-3-1 Checking for Errors from the Sysmac Studio

When an error occurs, you can place the Sysmac Studio online to the Controller or the Communications Coupler Unit to check current Controller errors and the log of past Controller errors.

Refer to the user's manual for the connected CPU Unit, Communications Coupler Unit, or Communication Control Unit for details on how to check errors.

Current Errors

Open the Sysmac Studio's Controller Error Tab Page to check the current error's level, source, source details, event name, event codes, details, attached information 1 to 4, and correction.

Errors in the observation level are not displayed.



Additional Information

Number of Current Errors

The following table gives the number of errors that are reported simultaneously as current errors in each Unit.

Unit	Number of simultaneous errors
System Units	When these Units are connected to the CPU Unit, since current errors are managed in the CPU Unit, the number of current errors is limited by the number of errors for the CPU Units. For Slave Terminals, since current errors are managed in the Communications Coupler Unit, the number of current errors is limited by the number of errors for the Communications Coupler Unit. When these Units are connected to the Communication Control Unit, since current errors are managed in the Communication Control Unit, the number of current errors is limited by the number of errors for the Communication Control Units.

If the number of errors exceeds the maximum number of reportable current errors, errors are reported with a priority given to the oldest and highest-level errors. Errors that exceed the limit on simultaneous error notifications are not reported.

Errors that are not reported are still reflected in the error status.

Log of Past Errors

Open the Sysmac Studio's Controller Event Log Tab Page to check the times, levels, sources, source details, event names, event codes, details, attached information 1 to 4, and corrections for previous errors.



Additional Information

Number of Logs of Past Errors

Event logs in the System Units are stored in the CPU Unit, Communications Coupler Unit, or Communication Control Unit to which they are connected.

Refer to the software user's manual for the connected CPU Unit, or the user's manual for the Communications Coupler Unit or Communication Control Unit for details on the amount of event logs that are stored in the Unit.

Refer to the troubleshooting manual for the connected CPU Unit or Industrial PC and the *Sysmac Studio Version 1 Operation Manual (Cat. No. W504)* for information on the items you can check and for how to check for errors.

Refer to 5-3-3 *Event Codes and Corrections for Errors* on page 5-6 for details on event codes.

5-3-2 Checking for Errors from Support Software Other Than the Sysmac Studio

You can check the error descriptions and logs with Support Software other than the Sysmac Studio. For the error checking methods, refer to the user's manual for the connected Communications Coupler Unit and the operation manual for the Support Software.

Refer to 5-3-3 *Event Codes and Corrections for Errors* on page 5-6 for details on event codes.

The number of current errors and the number of error log errors that occurred in the past in the System Units are the same as for the Sysmac Studio.

5-3-3 Event Codes and Corrections for Errors

The errors (i.e., events) that can occur in the System Units are given below.

If your NX Unit is connected to a Communication Control Unit, replace CPU Unit with Communication Control Unit in the descriptions provided for "For the NX bus of CPU Units" in the table below.

The following abbreviations are used in the event level column.

Abbreviation	Name
Maj	Major fault level
Prt	Partial fault level
Min	Minor fault level
Obs	Observation
Info	Information

Refer to the troubleshooting manual for the connected CPU Unit or Industrial PC for all NJ/NX/NY-series event codes.

Event code	Event name	Meaning	Assumed cause	Level					Reference
				Maj	Part	Min	Obs	Info	
00200000 hex	Non-volatile Memory Hardware Error	An error occurred in non-volatile memory.	• Non-volatile memory failure			○			page 5-9
90400000 hex	Event Log Cleared	The event log was cleared.	• The event log was cleared by the user.					○	page 5-10

5-3-4 Meaning of Error

This section describes the information that is given for individual errors.

If your NX Unit is connected to a Communication Control Unit, replace CPU Unit with Communication Control Unit in the descriptions provided for “For the NX bus of CPU Units” in the tables below.

How to Read Error Descriptions

The items that are used to describe individual errors (events) are described in the following copy of an error table.

Event name	Gives the name of the error.			Event code	Gives the code of the error.	
Meaning	Gives a short description of the error.					
Source	Gives the source of the error.		Source details	Gives details on the source of the error.	Detection timing	Tells when the error is detected.
Error attributes	Level	Tells the level of influence on control. *1		Log category	Tells which log the error is saved in. *2	
	Recovery	Gives the recovery method. *3				
Effects	User program	Tells what will happen to execution of the user program. *4	Operation	Provides special information on the operation that results from the error.		
Indicators	Gives the status of the built-in EtherNet/IP port and built-in EtherCAT port indicators. Indicator status is given only for errors in the EtherCAT Master Function Module and the EtherNet/IP Function Module.					
System-defined variables	Variable	Data type			Name	
	Lists the variable names, data types, and meanings for system-defined variables that provide direct error notification, that are directly affected by the error, or that contain settings that cause the error.					
Cause and correction	Assumed cause	Correction			Prevention	
	Lists the possible causes, corrections, and preventive measures for the error.					
Attached information	This is the attached information that is displayed by the Support Software or an HMI. *5, *6					
Precautions/Remarks	Provides precautions, restrictions, and supplemental information. If the user can set the event level, the event levels that can be set, the recovery method, operational information, and other information are also provided.					

- *1. One of the following:
 - Major fault: Major fault level
 - Partial fault: Partial fault level
 - Minor fault: Minor fault level
 - Observation
 - Information
- *2. One of the following:
 - System: System event log
 - Access: Access event log
- *3. One of the following:
 - Automatic recovery: Normal status is restored automatically when the cause of the error is removed.
 - Error reset: Normal status is restored when the error is reset after the cause of the error is removed.
 - Cycle the power supply: Normal status is restored when the power supply to the Controller is turned OFF and then back ON after the cause of the error is removed.
 - Controller reset: Normal status is restored when the Controller is reset after the cause of the error is removed.
 - Depends on cause: The recovery method depends on the cause of the error.
- *4. One of the following:
 - Continues: Execution of the user program will continue.
 - Stops: Execution of the user program stops.
 - Starts: Execution of the user program starts.
- *5. "System information" indicates internal system information that is used by OMRON.
- *6. Refer to the appendices of the troubleshooting manual for the connected CPU Unit or Industrial PC for the applicable range of the HMI Troubleshooter.

Error Descriptions

This section describes errors that may occur in a System Unit.

Event name	Non-volatile Memory Hardware Error			Event code	00200000 hex	
Meaning	An error occurred in non-volatile memory.					
Source	Depends on where the Support Software is connected and the system configuration.		Source details	NX Unit	Detection timing	When power is turned ON to the NX Unit
Error attributes	Level	Minor fault		Log category	System	
	Recovery	For the NX bus of CPU Units Cycle the power supply to the Unit or restart the NX bus. For Communications Coupler Units Cycle the power supply to the Unit or restart the Slave Terminal. If the errors are detected in the Controller, reset all of the errors in the Controller.				
Effects	User program	Continues.	Operation	I/O refreshing for the NX Unit stops. Messages cannot be sent to the NX Unit.		
System-defined variables	Variable		Data type		Name	
	None		---		---	
Cause and correction	Assumed cause		Correction		Prevention	
	Non-volatile memory failure.		For the NX bus of CPU Units Cycle the power supply to the Unit or restart the NX bus. If the error persists even after you make the above correction, replace the relevant NX Unit. For Communications Coupler Units Cycle the power supply to the Unit or restart the Slave Terminal. If the error persists even after you make the above correction, replace the relevant NX Unit.		None	
Attached information	None					
Precautions/Remarks	None					

Event name	Event Log Cleared			Event code	90400000 hex	
Meaning	The event log was cleared.					
Source	Depends on where the Support Software is connected and the system configuration.		Source details	NX Unit	Detection timing	When commanded from user
Error attributes	Level	Information		Log category	Access	
	Recovery	---				
Effects	User program	Continues.	Operation	Not affected.		
System-defined variables	Variable		Data type		Name	
	None		---		---	
Cause and correction	Assumed cause		Correction		Prevention	
	The event log was cleared by the user.		---		---	
Attached information	Attached information 1: Events that were cleared 1: The system event log was cleared. 2: The access event log was cleared.					
Precautions/Remarks	None					

5-4 Resetting Errors

Refer to the troubleshooting manual for the connected CPU Unit, or the user's manual for the Communications Coupler Unit or Communication Control Unit for information on how to reset errors.

5-5 Troubles Specific to Each Type of NX Units

5-5-1 Additional NX Unit Power Supply Unit

Problem	Assumed cause	Correction
The UNIT PWR indicator is not lit.	The Unit power is not supplied.	Check that the Unit power is supplied.
	The Unit power supply voltage is outside the specified range.	Set the Unit power supply voltage within the specified range.
	Wiring with the Unit power supply is incorrect.	Check the wiring with the Unit power supply.
	Wiring with the Unit power supply is disconnected.	Check the wiring with the Unit power supply.
	The terminal block is loose.	Check the installation of the terminal block.
	The Unit power supply is defective.	Replace the Unit power supply.
	The NX Unit power consumption exceeds the power supply capacity of the Additional NX Unit Power Supply Unit.	Add an Additional NX Unit Power Supply Unit.
Even though the UNIT PWR indicator is lit, the indicators of NX Units on the right are not lit.	Either this NX Unit or the NX Unit on the right is not installed correctly.	Check the NX Units are installed correctly.

5-5-2 Additional I/O Power Supply Unit

Problem	Assumed cause	Correction
The I/O PWR indicator is not lit.	The I/O power is not supplied.	Check that the I/O power is supplied.
	The I/O power supply voltage is outside the specified range.	Set the I/O power supply voltage within the specified range.
	Wiring with the connected device is incorrect.	Check the wiring with the connected device.
	A connected device is disconnected.	Check the wiring with the connected device.
	The terminal block is loose.	Check the installation of the terminal block.
	A connected device is defective.	Replace the connected device.
Even though the external power supply is turned ON, the I/O PWR indicator is not lit.	The I/O power supply voltage is outside the specified range.	Set the I/O power supply voltage within the specified range.
	Wiring with the connected device is incorrect.	Check the wiring with the connected device.
	Wiring to the terminal block is loose.	Check the wiring to the terminal block.
	A connected device is disconnected.	Check the wiring with the connected device.
	The terminal block is loose.	Check the installation of the terminal block.
	A connected device is defective.	Replace the connected device.
Even though the I/O PWR indicator is lit, the indicators of NX Units on the right are not lit.	Either this NX Unit or the NX Unit on the right is not installed correctly.	Check the NX Units are installed correctly.

5-6 Troubleshooting Flowchart

Refer to the troubleshooting manual for the connected CPU Unit, or the user's manual for the Communications Coupler Unit or Communication Control Unit for the standard flow for troubleshooting errors.

6

Inspection and Maintenance

This section describes how to clean, inspect, and maintain the system.

6-1	Cleaning and Inspection.....	6-2
6-1-1	Cleaning	6-2
6-1-2	Periodic Inspections	6-2
6-2	Maintenance Procedures.....	6-5

6-1 Cleaning and Inspection

This section describes daily maintenance and the cleaning and inspection methods.
Inspect the System Units daily or periodically in order to keep it in optimal operating condition.

6-1-1 Cleaning

Clean the System Units regularly as described below in order to keep it in optimal operating condition.

- Wipe the equipment over with a soft, dry cloth when performing daily cleaning.
- If dirt remains even after wiping with a soft, dry cloth, wipe with a cloth that has been wet with a sufficiently diluted detergent (2%) and wrung dry.
- A smudge may remain on the NX Unit from gum, vinyl, or tape that was left on for a long time. Remove the smudge when cleaning.



Precautions for Correct Use

- Never use volatile solvents, such as paint thinner, benzene, or chemical wipes.
- Do not touch the NX bus connectors.

6-1-2 Periodic Inspections

Although the major components in NX Units have an extremely long life time, they can deteriorate under improper environmental conditions. Periodic inspections are thus required.

Inspection is recommended at least once every six months to a year, but more frequent inspections will be necessary in adverse environments.

Take immediate steps to correct the situation if any of the conditions in the following table are not met.

Periodic Inspection Items

No.	Inspection item	Inspection details	Criteria	Correction
1	External power supply	Is the power supply voltage measured at the terminal block within standards?	Within the power supply voltage range	Use a voltage tester to check the power supply at the terminals. Take necessary steps to bring the power supply within the power supply voltage range.
2	I/O power supply	Is the power supply voltage measured at the I/O terminal block within standards?	Voltages must be within I/O specifications of each NX Unit.	Use a voltage tester to check the power voltage at the terminals. Take necessary steps to bring the I/O power supply within NX Unit standards.

No.	Inspection item	Inspection details	Criteria	Correction
3	Ambient environment	Is the ambient operating temperature within standards?	0 to 55°C	Use a thermometer to check the temperature and ensure that the ambient operating temperature remains within the allowed range of 0 to 55°C.
		Is the ambient operating humidity within standards?	Relative humidity must be 10% to 95% with no condensation.	Use a hygrometer to check the humidity and ensure that the ambient operating humidity remains between 10% and 95%. Make sure that condensation does not occur due to rapid changes in temperature.
		Is it subject to direct sunlight?	Not in direct sunlight	Protect the Controller if necessary.
		Is there an accumulation of dirt, dust, salt, metal powder, etc.?	No accumulation	Clean and protect the Controller if necessary.
		Is there water, oil, or chemical sprays hitting the Controller?	No spray	Clean and protect the Controller if necessary.
		Are there corrosive or flammable gases in the area of the Controller?	No gases	Check by smell or use a sensor.
		Is the Unit subject to shock or vibration?	Vibration resistance and shock resistance must be within specifications.	Install cushioning or other vibration and shock absorbing equipment if necessary.
		Are there noise sources near the Controller?	No significant noise sources	Either separate the Controller and noise source or protect the Controller.
4	Installation and wiring	Are the DIN Track mounting hooks for each NX Unit securely locked?	No looseness	Securely lock the DIN Track mounting hooks.
		Are the cable connectors fully inserted and locked?	No looseness	Correct any improperly installed connectors.
		Are there any loose screws on the End Plates (PFP-M)?	No looseness	Tighten loose screws with a Phillips-head screwdriver.
		Are the NX Units connected to each other along the hookup guides and until they touch the DIN track?	You must connect and fix the NX Units to the DIN track.	Connect the NX Units to each other along the hookup guides and insert them until they touch the DIN track.
		Are there any damaged external wiring cables?	No visible damage	Check visually and replace cables if necessary.

Tools Required for Inspections

● Required Tools

- Phillips screwdriver
- Flat-blade screwdriver

- Voltage tester or digital voltmeter
- Industrial alcohol and pure cotton cloth

● **Tools Required Occasionally**

- Oscilloscope
- Thermometer and hygrometer

6-2 Maintenance Procedures

When you replace a System Unit, follow the procedure in the user's manual for the connected CPU Unit, Communications Coupler Unit, or Communication Control Unit.



Appendices

This section describes the data sheets of the System Units and their dimensions.

A-1	Data Sheet.....	A-2
A-1-1	Model List.....	A-2
A-1-2	Additional NX Unit Power Supply Unit.....	A-3
A-1-3	Additional I/O Power Supply Unit.....	A-7
A-1-4	I/O Power Supply Connection Unit.....	A-12
A-1-5	Shield Connection Unit.....	A-19
A-2	Dimensions.....	A-23
A-2-1	Additional NX Unit Power Supply Unit, Additional I/O Power Supply Unit, I/O Power Supply Connection Unit, and Shield Connection Unit.....	A-23
A-3	List of NX Objects	A-25
A-3-1	Format of NX Object Descriptions.....	A-25
A-3-2	System Units	A-25
A-4	List of Screwless Clamping Terminal Block Models.....	A-27
A-4-1	Model Notation	A-27
A-4-2	List of Terminal Block Models.....	A-27
A-5	Version Information with CPU Units.....	A-29
A-5-1	Relationship between Unit Versions of Units.....	A-29
A-6	Version Information with Communications Coupler Units.....	A-31
A-6-1	Connection to an EtherCAT Coupler Unit.....	A-31
A-6-2	Connection to an EtherNet/IP Coupler Unit.....	A-32
A-7	Version Information with Communication Control Units	A-34
A-7-1	Relationship between Unit Versions of Units.....	A-34

A-1 Data Sheet

The specifications of individual System Units are shown below.

A-1-1 Model List

Additional NX Unit Power Supply Unit

Model	Rated power supply voltage	NX Unit power supply capacity	Reference
NX-PD1000	24 VDC	10 W max.	page A-5

Additional I/O Power Supply Unit

Model	Rated power supply voltage	Maximum current of I/O power supply	Reference
NX-PF0630	5 to 24 VDC	4 A	page A-9
NX-PF0730	5 to 24 VDC	10 A*1	page A-11

*1. When an Additional I/O Power Supply Unit is connected to the CPU Rack of a CPU Unit, the maximum I/O power supply current value may be smaller than that of the Additional I/O Power Supply Unit. For example, the maximum I/O power supply current for the CPU Rack of an NX1P2 CPU Unit is 4 A. For the maximum I/O power supply current of the CPU Rack, refer to *Maximum I/O Power Supply Current* under *Designing the I/O Power Supply from the NX Bus* in the hardware user's manual for the CPU Unit to which NX Units are connected.

I/O Power Supply Connection Unit

Model	Number of I/O power supply terminals	Current capacity of I/O power supply terminal	Reference
NX-PC0020	IOV: 16 terminals	4 A/terminal max.	page A-14
NX-PC0010	IOG: 16 terminals		page A-16
NX-PC0030	IOV: 8 terminals IOG: 8 terminals		page A-18

Shield Connection Unit

Model	Number of shield terminals	Reference
NX-TBX01	14 terminals (The following two terminals are functional ground terminals.)	page A-21

A-1-2 Additional NX Unit Power Supply Unit

Description of Items on the Data Sheet of the Additional NX Unit Power Supply Unit




The meanings of the items on the data sheet of the Additional NX Unit Power Supply Unit are explained in the table below.

Item	Description
Unit name	The name of the Unit.
Model	The model of the Unit.
External connection terminals	The type of terminal block and connector that is used for connecting the Unit. The number of terminals on the terminal block is also described when a screwless clamping terminal block is used.
Power supply voltage	The rated voltage and voltage range that are supplied to the Unit.
NX Unit power supply capacity	The amount of power that the Unit can supply to the NX Units. The NX Unit power consumption of the Unit is not included.
NX Unit power supply efficiency	The efficiency of the power supply circuit.
Current capacity of power supply terminal	The current capacity of the Unit power supply terminal (UV/UG). When you supply the Unit power to the connected external devices, do not allow the total of the current consumed by its own block and the current supplied to external to exceed this value.
Dimensions	The dimensions of the Unit. They are described as W × H × D. The unit is "mm".
Isolation method	The isolation method between the NX Unit power supply and Unit power supply terminals of the Unit.
Insulation resistance	The insulation resistance between the external connection terminals and internal circuit of the Unit.
Dielectric strength	The dielectric strength between the external connection terminals and internal circuit of the Unit.
NX Unit power consumption	The power consumption of the NX Unit power supply of the Unit. The power consumption of the Unit connected to each of the following Units is separately given. If some of the following Units can not be connected to the Unit, relevant information is omitted. • CPU Unit • Communications Coupler Unit • Communication Control Unit
Current consumption from I/O power supply	The current consumption from I/O power supply of the Unit.
Weight	The weight of the Unit.
Circuit layout	The circuit layout of the Unit.
Installation orientation and restrictions	The installation orientation of the Unit. The installation orientation of the Unit connected to each of the following Units is separately given, along with details of the specifications restricted due to the installation orientation, if any. If some of the following Units can not be connected to the Unit, relevant information is omitted. • CPU Unit • Communications Coupler Unit • Communication Control Unit

Item	Description
Terminal connection diagram	A diagram of the connection between the Unit and connected external devices. When an I/O Power Supply Connection Unit or a Shield Connection Unit is required to be connected to the connected external devices, the description for such is included.

Additional NX Unit Power Supply Unit (Screwless Clamping Terminal Block, 12 mm Width)

Unit name	Additional NX Unit Power Supply Unit
Model	NX-PD1000
External connection terminals	Screwless clamping terminal block (8 terminals)
Power supply voltage	24 VDC (20.4 to 28.8 VDC)
NX Unit power supply capacity	10 W max. (Refer to page A-6 for details.)
NX Unit power supply efficiency	70%
Current capacity of power supply terminal	4 A max. (including the current of through-wiring)
Dimensions	12 (W) × 100 (H) × 71 (D)
Isolation method	No-isolation
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)
Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
NX Unit power consumption	- Connected to a CPU Unit or Communication Control Unit 0.85 W max. - Connected to a Communications Coupler Unit 0.45 W max.
Current consumption from I/O power supply	No consumption
Weight	65 g max.
Circuit layout	The circuit layout diagram illustrates the internal wiring of the NX Unit Power Supply Unit. It shows the connection between the terminal block, the NX bus connectors (left and right), and the DIN Track contact plate (Unit back surface). The terminal block includes terminals for UV, UG, and functional ground. The internal circuit features a 'No-isolation power supply circuit' and 'Internal circuits'. The NX bus connector (left) has terminals for NX Unit power supply +, NX Unit power supply -, I/O power supply +, and I/O power supply -. The NX bus connector (right) has terminals for NX Unit power supply +, NX Unit power supply -, I/O power supply +, and I/O power supply -. The DIN Track contact plate (Unit back surface) is also shown. A 'UNIT PWR Indicator' is connected to the NX Unit power supply + terminal.

Installation orientation and restrictions	Installation orientation: • Connected to a CPU Unit or Communication Control Unit Possible in upright installation. • Connected to a Communications Coupler Unit Possible in 6 orientations. Restrictions: As shown in the following. • For upright installation Output power (W) For 10 W output, 40°C  For 8.5 W output, 55°C Ambient operating temperature (°C) • For any installation other than upright Output power (W) For 10 W output, 40°C  For 6.0 W output, 55°C Ambient operating temperature (°C)
Terminal connection diagram	Additional NX Unit Power Supply Unit NX-PD1000  24 VDC Unit power supply Ground of 100 Ω or less Through-wiring for unwired terminals^{*1}

^{*1}. You can use the unwired terminals of the Unit power supply terminals (UV/UG) for through-wiring to the Unit power supply terminals on an Additional NX Unit Power Supply Unit, other CPU Units to which NX Units can be connected, other Communications Coupler Units or another Communication Control Unit.

*2. The NC terminals are not connected to the internal circuits.

A-1-3 Additional I/O Power Supply Unit

Description of Items on the Data Sheet of the Additional I/O Power Supply Unit


The meanings of the items on the data sheet of the Additional I/O Power Supply Unit are explained in the table below.

Item	Description
Unit name	The name of the Unit.
Model	The model of the Unit.
External connection terminals	The type of terminal block and connector that is used for connecting the Unit. The number of terminals on the terminal block is also described when a screwless clamping terminal block is used.
Power supply voltage	The rated voltage and voltage range of the I/O power supply that is supplied to the Unit.
Maximum current of I/O power supply	The maximum value of the current that can be supplied to the Units from the I/O power supply to be connected to the Unit through the NX bus connectors.
Current capacity of I/O power supply terminal	The current capacity of I/O power supply terminals of the Unit.
Dimensions	The dimensions of the Unit. They are described as W × H × D. The unit is "mm".
Isolation method	The isolation method between the I/O power supply terminal and internal I/O power supply of the Unit.
Insulation resistance	The insulation resistance between the external connection terminals and internal circuit of the Unit.
Dielectric strength	The dielectric strength between the external connection terminals and internal circuit of the Unit.
NX Unit power consumption	The power consumption of the NX Unit power supply of the Unit. The power consumption of the Unit connected to each of the following Units is separately given. If some of the following Units can not be connected to the Unit, relevant information is omitted. • CPU Unit • Communications Coupler Unit • Communication Control Unit
Current consumption from I/O power supply	The current consumption from I/O power supply of the Unit.
Weight	The weight of the Unit.
Circuit layout	The circuit layout of the Unit.
Installation orientation and restrictions	The installation orientation of the Unit. The installation orientation of the Unit connected to each of the following Units is separately given, along with details of the specifications restricted due to the installation orientation, if any. If some of the following Units can not be connected to the Unit, relevant information is omitted. • CPU Unit • Communications Coupler Unit • Communication Control Unit
Terminal connection diagram	A diagram of the connection between the Unit and connected external devices. When an I/O Power Supply Connection Unit or a Shield Connection Unit is required to be connected to the connected external devices, the description for such is included.

Item	Description
Overload/low voltage detection	The function of the Unit to detect an overload and low voltage in the I/O power supply.
Protective function	The protective function that the Unit has.

Additional I/O Power Supply Units (Screwless Clamping Terminal Block, 12 mm Width)

Unit name	Additional I/O Power Supply Unit
Model	NX-PF0630
External connection terminals	Screwless clamping terminal block (8 terminals)
Power supply voltage	5 to 24 VDC (4.5 to 28.8 VDC)* ¹
Maximum current of I/O power supply	4 A
Current capacity of I/O power supply terminal	4 A max.
Dimensions	12 (W) × 100 (H) × 71 (D)
Isolation method	No-isolation
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)
Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
NX Unit power consumption	- Connected to a CPU Unit or Communication Control Unit 0.85 W max. - Connected to a Communications Coupler Unit 0.45 W max.
Current consumption from I/O power supply	10 mA max.
Weight	65 g max.
Circuit layout	
Installation orientation and restrictions	Installation orientation: - Connected to a CPU Unit or Communication Control Unit Possible in upright installation. - Connected to a Communications Coupler Unit Possible in 6 orientations. Restrictions: No restrictions

Terminal connection diagram	
Overload/low voltage detection	Not supported.
Protective function	Not supported.

*1. Use a voltage that is appropriate for the I/O circuits of the NX Units and the connected external devices.

Unit name	Additional I/O Power Supply Unit
Model	NX-PF0730
External connection terminals	Screwless clamping terminal block (8 terminals)
Power supply voltage	5 to 24 VDC (4.5 to 28.8 VDC)* ¹
Maximum current of I/O power supply	10 A* ²
Current capacity of I/O power supply terminal	• A1 and A3: 10 A max.*² • A5, A7, B1, B3, B5 and B7: 4 A max.
Dimensions	12 (W) × 100 (H) × 71 (D)
Isolation method	No-isolation
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)
Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
NX Unit power consumption	• Connected to a CPU Unit or Communication Control Unit 0.85 W max. • Connected to a Communications Coupler Unit 0.45 W max.
Current consumption from I/O power supply	10 mA max.
Weight	65 g max.
Circuit layout	
Installation orientation and restrictions	Installation orientation: • Connected to a CPU Unit or Communication Control Unit Possible in upright installation. • Connected to a Communications Coupler Unit Possible in 6 orientations. Restrictions: No restrictions

Terminal connection diagram	
Overload/low voltage detection	Not supported.
Protective function	Not supported.

- *1. Use a voltage that is appropriate for the I/O circuits of the NX Units and the connected external devices.
- *2. When an Additional I/O Power Supply Unit is connected to the CPU Rack of a CPU Unit, the maximum I/O power supply current value may be smaller than that of the Additional I/O Power Supply Unit. For example, the maximum I/O power supply current for the CPU Rack of an NX1P2 CPU Unit is 4 A. For the maximum I/O power supply current of the CPU Rack, refer to *Maximum I/O Power Supply Current* under *Designing the I/O Power Supply from the NX Bus* in the hardware user's manual for the CPU Unit to which NX Units are connected.

A-1-4 I/O Power Supply Connection Unit

Description of Items on the Data Sheet of the I/O Power Supply Connection Unit

The meanings of the items on the data sheet of the I/O Power Supply Connection Unit are explained in the table below.


Item	Description
Unit name	The name of the Unit.
Model	The model of the Unit.
External connection terminals	The type of terminal block and connector that is used for connecting the Unit. The number of terminals on the terminal block is also described when a screwless clamping terminal block is used.
Number of I/O power supply terminals	The type (IOV/IOG) and number of I/O power supply terminals of the Unit.
Current capacity of I/O power supply terminal	The current capacity of I/O power supply terminals of the Unit.
Dimensions	The dimensions of the Unit. They are described as W × H × D. The unit is "mm".
Isolation method	The isolation method between the I/O power supply terminal and internal I/O power supply of the Unit.
Insulation resistance	The insulation resistance between the external connection terminals and internal circuit of the Unit.
Dielectric strength	The dielectric strength between the external connection terminals and internal circuit of the Unit.

Item	Description
NX Unit power consumption	The power consumption of the NX Unit power supply of the Unit. The power consumption of the Unit connected to each of the following Units is separately given. If some of the following Units can not be connected to the Unit, relevant information is omitted. • CPU Unit • Communications Coupler Unit • Communication Control Unit
Current consumption from I/O power supply	The current consumption from I/O power supply of the Unit.
Weight	The weight of the Unit.
Circuit layout	The circuit layout of the Unit.
Installation orientation and restrictions	The installation orientation of the Unit. The installation orientation of the Unit connected to each of the following Units is separately given, along with details of the specifications restricted due to the installation orientation, if any. If some of the following Units can not be connected to the Unit, relevant information is omitted. • CPU Unit • Communications Coupler Unit • Communication Control Unit
Terminal connection diagram	A diagram of the connection between the Unit and connected external devices. When an I/O Power Supply Connection Unit or a Shield Connection Unit is required to be connected to the connected external devices, the description for such is included.

I/O Power Supply Connection Unit (Screwless Clamping Terminal Block, 12 mm Width)


● IOV Terminal Type

Unit name	I/O Power Supply Connection Unit
Model	NX-PC0020
External connection terminals	Screwless clamping terminal block (16 terminals)
Number of I/O power supply terminals	IOV: 16 terminals
Current capacity of I/O power supply terminal	4 A/terminal max.
Dimensions	12 (W) × 100 (H) × 71 (D)
Isolation method	No-isolation
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)
Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
NX Unit power consumption	- Connected to a CPU Unit or Communication Control Unit 0.85 W max. - Connected to a Communications Coupler Unit 0.45 W max.
Current consumption from I/O power supply	No consumption
Weight	65 g max.
Circuit layout	Terminal block IOV IOV ⋮ IOV NX bus connector (left) NX Unit power supply + NX Unit power supply - I/O power supply + I/O power supply - Internal circuits NX Unit power supply + NX Unit power supply - I/O power supply + I/O power supply - NX bus connector (right)
Installation orientation and restrictions	Installation orientation: - Connected to a CPU Unit or Communication Control Unit Possible in upright installation. - Connected to a Communications Coupler Unit Possible in 6 orientations. Restrictions: No restrictions




● IOG Terminal Type

Unit name	I/O Power Supply Connection Unit
Model	NX-PC0010
External connection terminals	Screwless clamping terminal block (16 terminals)
Number of I/O power supply terminals	IOG: 16 terminals
Current capacity of I/O power supply terminal	4 A/terminal max.
Dimensions	12 (W) × 100 (H) × 71 (D)
Isolation method	No-isolation
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)
Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
NX Unit power consumption	- Connected to a CPU Unit or Communication Control Unit 0.85 W max. - Connected to a Communications Coupler Unit 0.45 W max.
Current consumption from I/O power supply	No consumption
Weight	65 g max.
Circuit layout	Terminal block NX bus connector (left) NX Unit power supply + NX Unit power supply - I/O power supply + I/O power supply - Internal circuits NX Unit power supply + NX Unit power supply - I/O power supply + I/O power supply - NX bus connector (right)
Installation orientation and restrictions	Installation orientation: - Connected to a CPU Unit or Communication Control Unit Possible in upright installation. - Connected to a Communications Coupler Unit Possible in 6 orientations. Restrictions: No restrictions



● IOV/IOG Terminal Type

Unit name	I/O Power Supply Connection Unit
Model	NX-PC0030
External connection terminals	Screwless clamping terminal block (16 terminals)
Number of I/O power supply terminals	IOV: 8 terminals IOG: 8 terminals
Current capacity of I/O power supply terminal	4 A/terminal max.
Dimensions	12 (W) × 100 (H) × 71 (D)
Isolation method	No-isolation
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)
Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
NX Unit power consumption	- Connected to a CPU Unit or Communication Control Unit 0.85 W max. - Connected to a Communications Coupler Unit 0.45 W max.
Current consumption from I/O power supply	No consumption
Weight	65 g max.
Circuit layout	Terminal block NX bus connector (left) NX Unit power supply + NX Unit power supply - I/O power supply + I/O power supply - Internal circuits NX Unit power supply + NX Unit power supply - I/O power supply + I/O power supply - NX bus connector (right)
Installation orientation and restrictions	Installation orientation: - Connected to a CPU Unit or Communication Control Unit Possible in upright installation. - Connected to a Communications Coupler Unit Possible in 6 orientations. Restrictions: No restrictions



A-1-5 Shield Connection Unit

Description of Items on the Data Sheet of the Shield Connection Unit

The meanings of the items on the data sheet of the Shield Connection Unit are explained in the table below.


Item	Description
Unit name	The name of the Unit.
Model	The model of the Unit.
External connection terminals	The type of terminal block and connector that is used for connecting the Unit. The number of terminals on the terminal block is also described when a screwless clamping terminal block is used.
Number of shield terminals	The number of terminals of the SHLD terminal of the Unit.
Dimensions	The dimensions of the Unit. They are described as W × H × D. The unit is "mm".
Isolation method	The isolation method between the SHLD terminal, functional ground terminal, and internal circuit of the Unit.
Insulation resistance	The insulation resistance between the external connection terminals and internal circuit of the Unit.
Dielectric strength	The dielectric strength between the external connection terminals and internal circuit of the Unit.
NX Unit power consumption	The power consumption of the NX Unit power supply of the Unit. The power consumption of the Unit connected to each of the following Units is separately given. If some of the following Units can not be connected to the Unit, relevant information is omitted. • CPU Unit • Communications Coupler Unit • Communication Control Unit
Current consumption from I/O power supply	The current consumption from I/O power supply of the Unit.
Weight	The weight of the Unit.
Circuit layout	The circuit layout of the Unit.

Item	Description
Installation orientation and restrictions	The installation orientation of the Unit. The installation orientation of the Unit connected to each of the following Units is separately given, along with details of the specifications restricted due to the installation orientation, if any. If some of the following Units can not be connected to the Unit, relevant information is omitted. • CPU Unit • Communications Coupler Unit • Communication Control Unit
Terminal connection diagram	A diagram of the connection between the Unit and connected external devices. When an I/O Power Supply Connection Unit or a Shield Connection Unit is required to be connected to the connected external devices, the description for such is included.

Shield Connection Unit (Screwless Clamping Terminal Block, 12 mm Width)

Unit name	Shield Connection Unit
Model	NX-TBX01
External connection terminals	Screwless clamping terminal block (16 terminals)
Number of shield terminals	14 terminals (The following two terminals are functional ground terminals.)
Dimensions	12 (W) × 100 (H) × 71 (D)
Isolation method	Isolation between the SHLD functional ground terminal, and internal circuit: No-isolation
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)
Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
NX Unit power consumption	- Connected to a CPU Unit or Communication Control Unit 0.85 W max. - Connected to a Communications Coupler Unit 0.45 W max.
Current consumption from I/O power supply	No consumption
Weight	65 g max.
Circuit layout	
Installation orientation and restrictions	Installation orientation: - Connected to a CPU Unit or Communication Control Unit Possible in upright installation. - Connected to a Communications Coupler Unit Possible in 6 orientations. Restrictions: No restrictions


Terminal connection diagram



A-2 Dimensions

A-2-1 Additional NX Unit Power Supply Unit, Additional I/O Power Supply Unit, I/O Power Supply Connection Unit, and Shield Connection Unit


12 mm Width



(Unit: mm)

*1. The dimension is 1.35 mm for Units with lot numbers through December 2014.

Installation Height



(Unit: mm)

A-3 List of NX Objects

This section describes the NX objects of the System Units.

The method to access NX objects through instructions or other messages depends on where the NX Unit is connected.

If the NX Unit is connected to a CPU Unit, access is possible with the Read NX Unit Object instruction and the Write NX Unit Object instruction.

When the NX Unit is connected to a Communications Coupler Unit, the method depends on the connected communications master and Communications Coupler Unit.

Refer to the user's manual for the connected Communications Coupler Unit for method to use messages to access NX objects on Slave Terminals.

Refer to the *NX-series Communication Control Unit Built-in Function User's Manual (Cat. No. Z396)* for the method to use messages to access NX objects of NX Units connected to a Communication Control Unit.

A-3-1 Format of NX Object Descriptions

In this manual, NX objects are described with the following format.

Index (hex)	Subindex (hex)	Object name	Default value	Data range	Unit	Data type	Accesses	I/O allocation	Data attribute
-------------	----------------	-------------	---------------	------------	------	-----------	----------	----------------	----------------

Index (hex)	:	This is the index of the NX object that is expressed as a four-digit hexadecimal number.							
Subindex (hex)	:	This is the subindex of the NX object that is expressed as a two-digit hexadecimal number.							
Object name	:	This is the name of the object. For a subindex, this is the name of the subindex.							
Default value	:	This is the value that is set by default.							
Data range	:	For a read-only (RO) NX object, this is the range of the data you can read. For a read-write (RW) NX object, this is the setting range of the data.							
Unit	:	The unit is the physical units.							
Data type	:	This is the data type of the object.							
Access	:	This data tells if the object is read-only or read/write. RO: Read only RW: Read/write							
I/O allocation	:	This tells whether I/O allocation is allowed.							
Data attribute	:	This is the timing when changes to writable NX objects are enabled. Y: Enabled by restarting N: Enabled at all times ---: Write-prohibited							

A-3-2 System Units

Unit Information Objects

These objects are related to product information.

Index (hex)	Subindex (hex)	Object name	Default value	Data range	Unit	Data type	Access	I/O allocation	Data attribute
1000	---	NX Bus Identity	---	---	---	---	---	---	---
	00	Number of Entries	7	7	---	USINT	RO	Not possible	---
	02	Model	*1	---	---	ARRAY[0..1] OF BYTE	RO	Not possible	---
	03	Device Type	*2	---	---	UDINT	RO	Not possible	---
	04	Product Code	*3	---	---	UDINT	RO	Not possible	---
	05	Vendor Code	00000001 hex*4	---	---	UDINT	RO	Not possible	---
	06	Unit Version	*5	---	---	UDINT	RO	Not possible	---
	07	Serial Number	*6	00000000 to FFFFFFFF hex	---	UDINT	RO	Not possible	---
1001	---	Production Info	---	---	---	---	---	---	---
	00	Number of Entries	2	2	---	USINT	RO	Not possible	---
	01	Lot Number	*7	00000000 to FFFFFFFF hex	---	UDINT	RO	Not possible	---
	02	Hardware Version	*8	---	---	ARRAY[0..19] OF BYTE	RO	Not possible	---

*1. The product models are assigned in ascending order from the lowest number of array elements. Any remainder elements are filled with spaces.

*2. The device types are assigned for each product Unit type.
Bits 0 to 31: Device type

*3. The product codes are assigned for each product model.
Bits 0 to 31: Product code

*4. OMRON vendor code

*5. Bits 24 to 31: Integer part of the Unit version
Bits 16 to 23: Fractional part of the Unit version
Bits 0 to 15: Reserved
(Example) For Ver. 1.0, 0100□□□□ hex

*6. A unique serial number is assigned for each product unit.
Bits 0 to 31: Serial number

*7. The year, month, and day of production are assigned to the "lot number".
Bits 24 to 31: Date of production
Bits 16 to 23: Month of production
Bits 8 to 15: Year of production
Bits 0 to 7: Reserved


*8. The hardware version is assigned in ascending order from the earliest number of array elements. Any remainder elements are filled with spaces.

A-4 List of Screwless Clamping Terminal Block Models

This section explains how to read the screwless clamping terminal block model numbers and shows the model number table.

A-4-1 Model Notation

The screwless clamping terminal block models are assigned based on the following rules.



A-4-2 List of Terminal Block Models

The following table shows a list of screwless clamping terminal blocks.

Terminal block model	Number of terminals	Ground terminal mark	Terminal current capacity
NX-TBA081	8	Not provided	4 A
NX-TBA121	12		
NX-TBA161	16		
NX-TBB121	12		
NX-TBB161	16		
NX-TBA082	8		10 A
NX-TBA122	12		
NX-TBA162	16		
NX-TBB082	8		
NX-TBB122	12		
NX-TBB162	16		
NX-TBC082	8	Provided	
NX-TBC162	16		

Note When you purchase a terminal block, purchase an NX-TB□□□2.

A-5 Version Information with CPU Units

This section provides version-related information when connecting Units to a CPU Unit. This section describes the relationships between the unit versions of each Unit and the CPU Unit, and Sysmac Studio version, and the specification changes for each unit version of each Unit.

A-5-1 Relationship between Unit Versions of Units

The relationship between the unit versions of each Unit and the CPU Unit, and Sysmac Studio version are shown below.

Interpreting the Version Combination Table

The items that are used in the version combination table are given below.

Refer to the user's manual for the CPU Unit for the models of CPU Unit to which NX Units can be connected.

NX Unit		Corresponding unit versions/versions	
Model	Unit version	CPU Unit	Sysmac Studio
Model numbers of NX Units.	Unit versions of NX Units.	Unit versions of the CPU Unit that are compatible with the NX Units.	Sysmac Studio versions that are compatible with the NX Units and CPU Unit.

Version Combination Tables

- With the combinations of the unit versions/versions shown below, you can use the functions that are supported by the unit version of the Unit model. Use the unit versions/versions (or the later/higher unit versions/versions) that correspond to the NX Unit models and the unit versions. You cannot use the specifications that were added or changed for the relevant NX Unit models and the unit versions unless you use the corresponding unit versions/versions.
- Depending on the type and model of the Unit to which the NX Unit is connected, some Units do not have the corresponding versions given in the table. If a Unit does not have the specified version, support is provided by the oldest available version after the specified version. Refer to the user's manuals for the specific Units for the relation between models and versions.
- If you use the corresponding unit versions/versions given in the following table or later/higher versions, refer to the version information in the user's manual for the CPU Unit.

NX Unit		Corresponding unit versions/versions	
Model	Unit version	CPU Unit	Sysmac Studio
NX-PD1000	Ver.1.0	Ver.1.13	Ver.1.17
NX-PF0630			
NX-PF0730			
NX-PC0020			
NX-PC0010			
NX-PC0030			
NX-TBX01			

A-6 Version Information with Communications Coupler Units

This section provides version-related information when connecting Units to a Communications Coupler Unit. Version information is provided separately for each Communications Coupler Unit that an NX Unit is connected to.

A-6-1 Connection to an EtherCAT Coupler Unit

This section describes the relationship between the unit versions of each Unit, EtherCAT Coupler Unit, CPU Unit and Industrial PC, versions of the Sysmac Studio, and the specification changes for each unit version.

Relationship between Unit Versions of Units

The items that are used in the version combination table are given below.

NX Unit		Corresponding unit versions/versions		
Model	Unit version	EtherCAT Coupler Unit	CPU Unit or Industrial PC	Sysmac Studio
Model numbers of NX Units.	Unit versions of NX Units.	Unit versions of EtherCAT Coupler Units that are compatible with the NX Units.	Unit versions of NJ/NX-series CPU Units or NY-series Industrial PCs that are compatible with the EtherCAT Coupler Units.	Sysmac Studio versions that are compatible with the NX Units, EtherCAT Coupler Units, CPU Units, and Industrial PCs.

The version combination table is given below.

- With the combinations of the unit versions/versions shown below, you can use the functions that are supported by the unit version of the Unit model. Use the unit versions/versions (or the later/higher unit versions/versions) that correspond to the NX Unit models and the unit versions. You cannot use the specifications that were added or changed for the relevant NX Unit models and the unit versions unless you use the corresponding unit versions/versions.
- Depending on the type and model of the Unit to which the NX Unit is connected, some Units do not have the corresponding versions given in the table. If a Unit does not have the specified version, support is provided by the oldest available version after the specified version. Refer to the user's manuals for the specific Units for the relation between models and versions.
- You cannot connect the relevant NX Unit to the target Communications Coupler Unit if "---" is shown in the corresponding unit versions/versions column.
- If you use the corresponding unit versions/versions given in the following table or later/higher versions, refer to the version information in the user's manual for the Communications Coupler Unit, CPU Unit, and Industrial PC.

NX Unit		Corresponding unit versions/versions		
Model	Unit version	EtherCAT Coupler Unit	CPU Unit or Industrial PC	Sysmac Studio
NX-PD1000	Ver.1.0	Ver.1.0	Ver.1.05	Ver.1.06
NX-PF0630				
NX-PF0730				Ver.1.08
NX-PC0020				Ver.1.06
NX-PC0010				
NX-PC0030				
NX-TBX01				

A-6-2 Connection to an EtherNet/IP Coupler Unit

This section describes the relationship between the unit versions of each Unit, EtherNet/IP Coupler Unit, CPU Unit and Industrial PC, versions of the Sysmac Studio and NX-IO Configurator, and the specification changes for each unit version.

Relationship between Unit Versions of Units

The items that are used in the version combination table are given below.

NX Unit		Corresponding unit versions/versions					
Model	Unit version	Application with an NJ/NX/NY-series Controller			Application with a CS/CJ/CP-series PLC		
		EtherNet/IP Coupler Unit	CPU Unit or Industrial PC	Sysmac Studio	EtherNet/IP Coupler Unit	Sysmac Studio	NX-IO Configurator
Model number of NX Unit.	Unit version of the NX Unit.	Unit version of EtherNet/IP Coupler Unit that is compatible with the NX Unit.	Unit version of NJ/NX-series CPU Unit or NY-series Industrial PC that is compatible with the EtherNet/IP Coupler Unit.	Sysmac Studio version that is compatible with the NX Unit, EtherNet/IP Coupler Unit, CPU Unit, and Industrial PC.	Unit version of EtherNet/IP Coupler Unit that is compatible with the NX Unit.	Sysmac Studio version that is compatible with the NX Unit, EtherNet/IP Coupler Unit, and CPU Unit.	NX-IO Configurator version that is compatible with the NX Unit, EtherNet/IP Coupler Unit, and CPU Unit.

The version combination table is given below.

- With the combinations of the unit versions/versions shown below, you can use the functions that are supported by the unit version of the Unit model. Use the unit versions/versions (or the later/higher unit versions/versions) that correspond to the NX Unit models and the unit versions. You cannot use the specifications that were added or changed for the relevant NX Unit models and the unit versions unless you use the corresponding unit versions/versions.
- Depending on the type and model of the Unit to which the NX Unit is connected, some Units do not have the corresponding versions given in the table. If a Unit does not have the specified version, support is provided by the oldest available version after the specified version. Refer to the user's manuals for the specific Units for the relation between models and versions.

- You cannot connect the relevant NX Unit to the target Communications Coupler Unit if "---" is shown in the corresponding unit versions/columns.
- If you use the corresponding unit versions/columns given in the following table or later/higher versions, refer to the version information in the user's manual for the Communications Coupler Unit, CPU Unit, and Industrial PC.

NX Unit		Corresponding unit versions/columns					
Model	Unit version	Application with an NJ/NX/NY-series Controller *1			Application with a CS/CJ/CP-series PLC *2		
		EtherNet/IP Coupler Unit	CPU Unit or Industrial PC	Sysmac Studio	EtherNet/IP Coupler Unit	Sysmac Studio	NX-IO Configurator *3
NX-PD1000	Ver.1.0	Ver.1.2	Ver.1.14	Ver.1.19	Ver.1.0	Ver.1.10	Ver.1.00
NX-PF0630							
NX-PF0730							
NX-PC0020							
NX-PC0010							
NX-PC0030							
NX-TBX01							

*1. Refer to version information in the user's manual of the EtherNet/IP Coupler Unit for the unit versions of EtherNet/IP Units corresponding to EtherNet/IP Coupler Units.

*2. Refer to version information in the user's manual of the EtherNet/IP Coupler Unit for the unit versions of CPU Units and EtherNet/IP Units corresponding to EtherNet/IP Coupler Units.

*3. For connection to an EtherNet/IP Coupler Unit with unit version 1.0, connection is supported only for a connection to the peripheral USB port on the EtherNet/IP Coupler Unit. You cannot connect by any other path. If you need to connect by another path, use an EtherNet/IP Coupler Unit with unit version 1.2 or later.

A-7 Version Information with Communication Control Units

This section provides version-related information when connecting Units to a Communication Control Unit.

This section describes the relationship between the unit versions of each Unit and the Communication Control Unit, and Sysmac Studio version, and the specification changes for each unit version of each Unit.

A-7-1 Relationship between Unit Versions of Units

The relationship between the unit versions of each Unit and the Communication Control Unit, and Sysmac Studio version are shown below.

Interpreting the Version Combination Tables

The items that are used in the version combination tables are given below.

NX Unit		Corresponding unit versions/versions	
Model	Unit version	Communication Control Unit	Sysmac Studio
Model numbers of NX Units.	Unit versions of NX Units.	Unit versions of the Communication Control Unit that are compatible with the NX Units.	Sysmac Studio versions that are compatible with the NX Units and Communication Control Unit.

Version Combination Tables

- With the combinations of the unit versions/versions shown below, you can use the functions that are supported by the unit version of the Unit model. Use the unit versions/versions (or the later/higher unit versions/versions) that correspond to the NX Unit models and the unit versions. You cannot use the specifications that were added or changed for the relevant NX Unit models and the unit versions unless you use the corresponding unit versions/versions.
- Depending on the type and model of the Unit to which the NX Unit is connected, some Units do not have the corresponding versions given in the table. If a Unit does not have the specified version, support is provided by the oldest available version after the specified version. Refer to the user's manuals for the specific Units for the relation between models and versions.
- You cannot connect the relevant NX Unit to the Communication Control Unit if "---" is shown in the corresponding unit versions/versions column.
- If you use the corresponding unit versions/versions given in the following table or later/higher versions, refer to the version information in the user's manual for the Communication Control Unit.

NX Unit		Corresponding unit versions/versions	
Model	Unit version	Communication Control Unit	Sysmac Studio
NX-PD1000	Ver.1.0	Ver.1.00	Ver.1.24
NX-PF0630			
NX-PF0730			
NX-PC0020			
NX-PC0010			
NX-PC0030			
NX-TBX01			



Index

Index

A		Log of Error.....5-6
Access.....	A-25	
Additional I/O Power Supply Unit.....	4-13, 4-18, 4-23	
Additional NX Unit Power Supply Unit.....	4-12, 4-17, 4-22	
angle for insertion.....	4-49, 4-52	
Applicable Wire.....	4-45	
B		
built-in EtherCAT port.....	7	
C		
Coding Pin.....	4-56	
Communication Control Unit.....	1-7	
Communications Coupler Unit.....	1-5	
CPU Rack.....	1-2, 1-5	
crimping tool.....	4-46	
Current Error.....	5-5	
D		
Data attribute.....	A-25	
Data range.....	A-25	
Data type.....	A-25	
Default value.....	A-25	
DIN Track contact plate.....	3-2, 3-9	
DIN Track mounting hook.....	3-2, 3-9	
E		
effective value of current.....	4-34	
F		
Ferrule.....	4-46	
Functional ground terminal.....	4-28, 4-44	
G		
ground of 100 Ω or less.....	4-28, 4-44	
Ground terminal.....	4-46, 4-47	
I		
I/O allocation.....	A-25	
I/O power supply.....	4-9, 4-15, 4-20	
I/O Power Supply Connection Unit.....	4-14, 4-19, 4-24	
I/O power supply terminal.....	4-10, 4-15, 4-21, 4-32	
incorrect attachment prevention hole.....	4-58	
Index.....	A-25	
Indicator.....	3-2, 3-9	
Industrial PC.....	6	
L		
M		
Marker.....	4-5	
Marker attachment location.....	3-2, 3-9	
maximum current of I/O power supply.....	4-18, 4-23, 4-34	
Model number indication.....	3-6, 3-12	
N		
NX bus connector.....	3-2, 3-9	
NX Object.....	A-25	
NX Unit power supply.....	4-9, 4-15, 4-20	
NX Unit power supply capacity.....	4-12, 4-17, 4-22	
O		
Object name.....	A-25	
P		
Periodic Inspection Item.....	6-2	
Power supply used.....	4-28, 4-33	
Preventing Incorrect Attachment.....	4-55	
Protective Devices.....	4-38	
Protrusions for removing the Unit.....	3-2, 3-9	
R		
Release hole.....	3-4, 3-11	
Required power supply capacity.....	4-33, 4-34	
S		
Securing Wires.....	4-51	
shield.....	4-25, 4-26, 4-44	
Shield Connection Unit.....	4-25, 4-26	
SHLD terminal.....	4-44	
Slave Terminal.....	1-2, 1-5, 4-15	
Solid Wire.....	4-47	
Subindex.....	A-25	
Supply from external source.....	4-10, 4-15, 4-21	
Supply from the NX bus.....	4-10, 4-15, 4-21	
T		
Terminal block.....	3-2, 3-3, 3-9, 3-10	
Terminal hole.....	3-4, 3-11	
Terminal number indication.....	3-4, 3-11	
Twisted Wire.....	4-47	
U		
Unit.....	A-25	
Unit hookup guide.....	3-2, 3-9	
Unit Information Object.....	A-25	

Unit power supply.....4-9, 4-15, 4-20
Unit power supply terminal.....4-10, 4-15, 4-20, 4-28
Unit specifications..... 3-2, 3-9
Unwired terminals.....4-28

W

Wiring Terminals..... 4-28, 4-32, 4-40, 4-44, 4-45

OMRON Corporation Industrial Automation Company

Kyoto, JAPAN

Contact : www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp
The Netherlands
Tel: (31) 2356-81-300 Fax: (31) 2356-81-388

OMRON ASIA PACIFIC PTE. LTD.

438B Alexandra Road, #08-01/02 Alexandra
Technopark, Singapore 119968
Tel: (65) 6835-3011 Fax: (65) 6835-3011

OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200
Hoffman Estates, IL 60169 U.S.A.
Tel: (1) 847-843-7900 Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD.

Room 2211, Bank of China Tower,
200 Yin Cheng Zhong Road,
PuDong New Area, Shanghai, 200120, China
Tel: (86) 21-6023-0333 Fax: (86) 21-5037-2388

Authorized Distributor:

©OMRON Corporation 2013-2025 All Rights Reserved.
In the interest of product improvement,
specifications are subject to change without notice.

Cat. No. W523-E1-11 1025