# OMRON

# Model K8AB-AS

Measuring & Monitoring Relay

# English Instructions Manual

Thank you for purchasing an OMRON pridyct. In this Instructions Manual, you will find information about this product's features, capabilities, and operating instructions. Please observe the following when using this product. This product is designed for use by qualified electrical engi

- neer Read and understand this Instructions Manual thoroughly, and make proper use of this product.
- Keep this Instructions Manual for future reference

# **OMRON** Corporation

## **Precautions for Safe Use**

9419058-9 B

Make sure to follow the instructions below to ensure safety.

- 1. Do not use or keep this product in the following environments. · Outdoors, or places subject to direct sunlight or
- Outdoors, or places subject to direct sunlight or wearing weather. Places where dust, iron powder, or corrosive gases(in particular, sulfuric or ammonia gas) exist. Places subject to static electricity or inductive noise. Places where water or oil come in contact with the product
- Make sure to install this product in the correct direction.
   There is a remote risk of electric shock. Do not touch
- terminals while electricity is being supplied.
- Make sure to thoroughly understand all instructions in the Instructions Manual before handling this product.
   Make sure to confirm terminal makings and polarity for correct wiring.
- Ensure that terminal screws have been tightened firmly.
- Recommended torque : 0.49 N  $\cdot$  m Assured torque : 0.59 N  $\cdot$  m Operating ambient temperature and humidity for this product must be within the indicated rating when using
- this product. 8. There is a remote risk of explosion. Do not use this roduct where flammable or explosive gas exists
- Make sure that no weight rests on the product after installation.
- 10. To enable an operator to turn off this product easily, install switches or circuit breakers that conform to
- relevant requirements of IEC60947-1 and IEC60947-3, and label them appropriately.
  11. For DC input, use a SELV power-supply capable of overcurrent protection. Specifically, a SELV power-supply has a double or reinforced insulation for input and output, and output voltage of 30Vr.m.s with 42.4V at peak or DC60V maximum. Recommended power-supply : Model S8VS-06024
- Omron product) 12. Do not turn a setting volume beyond the scope of

## **Precautions for Correct Use**

#### For Proper Use

movement.

- Do not use the product in the following locations.
   Places subject to radiant heat from heat generating devices.
- Places subject to vibrations or physical shocks (2) Make sure to use setting values appropriate for the controlled object. Failure to do so can cause
- unintended operation, and may result in accident or corruption of the product.
  (3) Do not use thinner or similar solvent for cleaning. Use commercial alcohol.
  (4) When the product dispersion of the product of the product of the product.
- (4) When discarding, properly dispose of the product as industrial waste. (5)~ Only use this product within a board whose structure
- About Installation
- When wiring, use only recommended crimp terminals. (2) Do not block areas around the product for proper assign to block areas around interproduct for proper dissipation of heat. (If you do not secure space for heat dissipation, life cycle of the product will be compromised.)
   To avoid electrical shocks, make sure that power is
- not supplied to the product while wiring.
- (4) To avoid electrical shocks, make sure that power is not supplied to the product when performing DIP

switch settings. loise Conutermeasures

- (1) Do not install the product near devices generating
- Do not install the product near devices generating strong high frequency waves or surges.
   When using a noise filter, check the voltage and current and install it as close to the product as possible.
   In order to prevent inductive noise, wire the lines connected to the product separately from power lines carrying high voltages or currents. Do not wire in parallel with or on the same cable as power lines. Other measures for reducing noise include running lines along separate ducts and using shield lines.
   To avoid faulty operations, malfunctions, or failure, observe the following operating instructions.
   When turning on the power, make sure to realize
- (1) When turning on the power, make sure to realize
- (1) when turning on the power, make sure to realize rated voltage within 1 second from the time of first supply of electricity.
   (2) Make sure to use power supply for operations, inputs, and transformer with the appropriate capacity and rated burden.
   (2) Make sure cod handling of this product may only.
- (3) Maintenance and handling of this product may only
- (4) Distortion ratio of input wave forms must be 30% or less. Use of this product with circuits that have large distortion in wave forms may result in unwanted constraints. operations
- (5) Using this product for thyrister controls or inverters wil result in errors.
- (6) When setting the volume, adjust the control from the minimum side to the maximum side.

# Applicable Standards on Category II Applicati EN60255-5/-6 EN60664-1 (EMI) EN61326+A1 Industrial applications Terminal interference wave voltage CISPR11 Group1, ClassA : CISPR16-1/-2 Electromagnetic interference wave CISPR11 Group1, ClassA : CISPR16-1/-2 (EMS) EN61326+A1 Industrial application ЕМС

	discharge	EN61000-4-2 : 4kV(Contact) 8kV(In air)
	Radiating radio- frequency electr -omagnetic field	EN61000-4-3 : 10V/m 1kHz Sine Wave Amplitude Modulation (80MHz to 1GHz)
	Burst	EN61000-4-4 : 2kV(Power Line) 1kV(I/O Signal line)
	Surge	EN61000-4-5 : 1kV with line (Power Line) 2kV with ground (Power Line)
	Conducted RF	EN61000-4-6 : 3V(0.15 to 80MHz)
	Power frequency magnetic field immunity	EN61000-4-8 : 30A/m
	Voltage dip/Short interruptions	EN61000-4-11 : 0.5 Cycle, 0.180* each polarity 100% (Rated Voltage)

#### This product is an electric controller for outputting an alarm upon detection of current.


Overview


[1-phase Over or Under current Relay]

Specifications						
●Rating						
Power Supply Voltage	DC24V,AC100/115V, AC200/230V,AC24V					
Permissible Voltage Variability Range	85 to 110% of rated power-supply voltage					
Power Consumption	DC24V : 1W maximum AC100/115V : 4VA maximum AC200/230V : 5VA maximum AC24V : 4VA maximum					
Dielectric Resistance	20MΩ minimum (at 500V) Between electric circuit and case					
Dielectric Withstanding Voltage		/ for 1 minute een electric circuit and case				
Noise Immunity	$\pm$ 1,500V on power-supply terminals in normal or common mode(Square wave with 1 ns at rearing Pulse duration 1 $\mu$ s/100ns)					
Vibration Resistance	$\begin{array}{l} \mbox{Vibrations}: 10 \mbox{ to } 55\mbox{Hz}, \\ \mbox{Acceleration}: 50\mbox{m/s}^2 \ , \\ \mbox{X},\mbox{Y},\mbox{Z} \ Directions: 5 \ min \ $$\times$ 10 \ scanning } \end{array}$					
Shock Resistance	150m/s <sup>2</sup> (however, 100m/s <sup>2</sup> at relay contact point 3 times each in 3 axis and 6 directions					
	-AS1	AC/DC 2-20/10-100/50-500mA				
Input Range	-AS2	AC/DC 0.1-1/0.5-5/0.8-8A				
	-AS3	10-100/20-200A (using a exclusive CT K8AC-CT200L)				
Input Impedance	5Ω maximum					
	-AS1	120% of maximum input within range (continuous)/150%, 1s				
	-AS2					
Overload Capacity	-AS3	Primary side of CT. 240A, contimuous 400A, 30s 1200A, 1s				
	-AS3	400A, 30s				

#### Output Rating

elay utput	Rated Load	Resistance Load : AC250V 6A, DC30V 6A			
	Maximum Contact Point Voltage	AC250V, DC30V			
	Maximum Contact Point Current	AC6A, DC6A			
	Maximum Opening and Closing Capacity	1500VA, 180W			
	Minimum Applicable Load (P Level)	DC5V, 10mA *Reference value			
	Mechanical Life	10 million times minimum			
	Electrical Life (Ambient temperature condition : +20°C)	Make 50 thousand time, Break 30 thousand times			






Installation Procedure : Attaching to the DIN rail or attaching with front screws \*Measurements for attachment with front screws 102

> 2-M 4 screw or 2- ¢ 4.5 opening \*When attaching wih front screws, draw out hooks on the bottom of the product to the left and right sides.


## Installation Procedure

Pull down the hook, and then fasten the upper tab onto the rail, fitting in the unit until the hook locks into place.



Uninstallation Procedure

 Using a flathead screwdriver or a similar tool. pull out the hook downward and lift the unit from the bottom.



## Fixing Bracket

Attach the type K8AB to the DIN rail. DIN Rail Type PFP-100N (1,000mm) Type PFP-50N (500mm)


### Recommended Crimp Terminal


Recommended Crimp Terminal	Recommended Cable Diameter
AI 1,5-8BK (Phoenix Contact product)	AWG#16
AI 1-8RD (Phoenix Contact product)	AWG#18
AI 0,75-8GY (Phoenix Contact product)	AWG#18

## Exclusive CT


K8AC-CT200L (Omron product)

#### List of DIP Switch settings






## Terminal Connections



Name	Terminal Name	Description		
	11, 12, 13	Current input terminals		
	С	Common for voltage input terminals		
Terminals	A1, A2	Operative power supply		
rerminais	11	Common for terminals		
	12	b-contact output		
	14	a-contact output		
	SV	Operate value setting (10 to 100%)		
Values Orthings	HYS.	Hysteresis setting (5 to 50%)		
Volume Settings	Т	Operate time setting (0.1 to 30s)		
	LOCK	Startup lock time setting (0 to 30s)		
	PWR	Power indication		
LED Indications	RY	Relay output status Light-on 11-14 conduction		
	ALM	Alarm operation status Light-on = Alarm output status		

## Wiring Diagram

1-phase power supply



### Suitability for use

OMRON shall not be responsible conformity with any stan -dards, codes, or regulations that apply to the combination of the products in the customer's application or use of the product.

. Take all necessary steps to determine the suitability of the product for the systems, machines, and equipment with which it will be used. Know and observe all prohibitions of use applicable to this

product

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT IS PROPER LY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM. See also Product catalog for Warranty and Limitation of Liability.

#### **Contact Information**

OMRON ELECTRONICS LLC Phone : 1-847-843-7900 Fax : 1-847-843-7787 OMRON CANADA INC. Phone : 1-416-286-6465 Fax : 1-416-286-6648 Phone : 1-514-636-6676 (French Language) Fax : 1-514-036-2959 EUROPEAN H.Q. : OMRON EUROPE B.V. Phone : 31-23-56-81-300 Fax : 31-23-56-81-388 OMRON ELECTRONICS PTV. LTD Phone : 61-2-9878-6377 Fax : 61-2-9878-6981 OMRON ASIA-PACIFIC PTE LTD Phone : 65-6-835-3011 Fax : 65-6-835-2711